

# CASIO PCR-T540 COMPLETE MANUAL



## Table of Contents

[CASIO Authorized Service Centers](#)

[Introduction](#)

[Location](#)

[Power Supply](#)

[Table of Contents](#)

[Power Cords and Plugs](#)

[Power supply voltage](#)

[Installation location](#)

[When moving the product](#)

LCD

Adjustment of display

Drawer

Disposing of batteries

Others

Take Advance Notice of the Following

When the cash drawer does not open

To use the cash register's basic function

Getting started

Name of Parts

Loading memory protection batteries

Warning

Installing paper roll

To install receipt paper

To set the language, date, time, tax rates and Bluetooth pairing

Setting paper roll as journal records

To install journal paper

Getting to know your cash register

Mode switch

To adjust the main display

To set the customer display

After finalization

Display

During a registration

Main display

Keyboard

How to read the printouts

Journal Sample

Receipt Sample

After closing the store

Before opening your store

How to use your cash register

While the store is open

Checking the time and date

Preparing bills and coins for change

Registering items in departments

Sample Operation

Single item sale

Single item sales with change calculation

Multiple items registration using multiplication key

Repeat registration

Department shift

Split sales of packaged items

Department number entry

Basic setups and registrations

Program menus

To program basic settings

Programming departments

Registering departments' preset data

Using preset prices

Using preset tax statuses

Programming PLUs

PLU repeat registration

Registering PLUs' preset data

Single item sales using PLU

PLU registration with multiplication key

Split sales of packaged PLU item

Open PLU

Discount

## Other registrations

Reduction

Charge sale

Check sale

Registering various payment methods

Credit sale

Mixed payments

Tax shift

Registering returned goods

Registering returned goods in the REG mode

Registering returned goods in the RF mode

Registering money paid out from the drawer

Registering money received on account

Registrations without transactions

Correcting erroneously entered item not registered

Corrections

Correcting items immediately after the registration

Voiding an item which has been already registered

Cancelling all items in a transaction

## Daily sales reports

Print out of daily sales report

Advanced programmings and registrations

## Advanced registrations

Enabling clerk assignment

Registrations with clerk assignment

Single item cash sales

Sample operation 1: Simple single item sale

Sample operation 2: Single item sale with multiplication

Sample operation 3: Single item sale with another item

## Character settings

Using character keyboard

Character keyboard

Using ten key pad

Multi typing keyboard

Setting characters

Setting symbol characters

Sales report symbols

Other symbols

Advanced programmings

Programming detail settings

Machine number

Tax system

Receipt printing selections

Calculation and operation methods

Fixed total print control

Programming functions of departments and PLUs in a lump

Programming department functions in a lump

Department and PLU lump set code

Programming PLU functions in a lump

Programming functions of departments and PLUs individually

Programming functions of PLUs individually

Programming functions of transaction keys

Programming further clerk functions

Printing programmed data

To print programmed unit price or percentage (other than PLU)

To print programmed characters (except PLUs)

To print general programming (except PLUs)

Printout

To print preset unit price of PLU

To print preset characters of PLU

To print PLU programmings

## Printing various sales reports

PLU sales report

Item group sales report

Hourly sales report

Monthly sales report

Flash report

About “Declared money” and “Cash in drawer”

Electronic journal

About electronic journal

To print individual department and PLUs

Periodic sales report

Bluetooth setting

Setting Bluetooth pairing

Using an SD card

Cautions when using optional SD memory card

To format an SD card

POP setting

To store program data in an SD card

Restoring backup data

POP setting

Handling of the cash drawer

To lock and unlock the cash drawer

To pull out the cash drawer (S drawer)

To pull out the cash drawer (M drawer)

To remove coin divider (certain models)

Before you consider it as a problem

Error code table

About HELP guidance

When “EJ FULL” sign appears on the display

In case of power failure

[In case the register is locked up](#)

[About the low battery indicator](#)

[About open source code](#)

[Specifications](#)

[Other Manuals](#)[Lib Projects](#)

Complete Manual


**PCR-T540**

**PCR-T560**

**SR-S500**

**SR-S820**

Electronic Cash Register



(S size drawer)



## Introduction

Thank you very much for purchasing this CASIO electronic cash register. START-UP is QUICK and EASY!

For the basic settings of your cash register, please see “Quick Start Guide”.

### IMPORTANT

For programming assistance please visit  
[http://casio4business.com/sa\\_index.html](http://casio4business.com/sa_index.html)

### CASIO Authorized Service Centers

If your CASIO product needs repair, or you wish to purchase replacement parts, please visit <http://casio-4business.com>.

### Original Carton/Package

If for any reason, this product is to be returned to the store where purchased, it must be packed in the original carton/package.

### Location

Locate the Cash register on a flat, stable surface, away from heaters or areas exposed to direct sunlight, humidity or dust.

### Power Supply

Your cash register is designed to operate on standard household current (120 V, 50/60 Hz). Do not overload the outlet by plugging in too many appliances.

The mains plug on this equipment must be used to disconnect mains power. Please ensure that the socket outlet is installed near the equipment and shall be easily accessible.

### Trademark



SD and SDHC Logos are trademarks of SD-3C, LLC.



The Bluetooth wordmark and logo are registered trademarks of Bluetooth SIG, Inc. and are used by permission granted to Casio Computer as a certified logo user.

### Interference with the Operation of Other Equipment (Using Wireless Data Communication)



- Keep your Cash Register well away from anyone wearing a pacemaker. Radio waves emitted by the Cash Register can affect the operation of a pacemaker.

|                                                                                               |             |
|-----------------------------------------------------------------------------------------------|-------------|
| <b>Safety Precautions .....</b>                                                               | <b>E-4</b>  |
| <b>Precautions for Use.....</b>                                                               | <b>E-8</b>  |
| <b>Regulatory Information.....</b>                                                            | <b>E-10</b> |
| <b>To use the cash register's basic function .....</b>                                        | <b>E-12</b> |
| Getting started.....                                                                          | E-13        |
| Getting to know your cash register .....                                                      | E-20        |
| How to read the printouts .....                                                               | E-25        |
| How to use your cash register .....                                                           | E-26        |
| Before opening your store.....                                                                | E-27        |
| Registering items in departments .....                                                        | E-28        |
| Basic setups and registrations .....                                                          | E-32        |
| Other registrations .....                                                                     | E-41        |
| Daily sales reports.....                                                                      | E-53        |
| <b>Advanced programmings and registrations .....</b>                                          | <b>E-56</b> |
| Advanced registrations.....                                                                   | E-58        |
| Character settings .....                                                                      | E-62        |
| Advanced programmings .....                                                                   | E-70        |
| Programming functions of departments and PLUs in a lump .....                                 | E-81        |
| Programming functions of departments and PLUs individually .....                              | E-84        |
| Printing programmed data.....                                                                 | E-92        |
| Printing various sales reports.....                                                           | E-97        |
| Bluetooth setting .....                                                                       | E-105       |
| Setting Bluetooth pairing.....                                                                | E-105       |
| Using an SD card .....                                                                        | E-107       |
| Restoring backup data (automatically backed up setting data) from built in flash memory ..... | E-110       |
| POP setting .....                                                                             | E-110       |
| Handling of the cash drawer .....                                                             | E-111       |
| Before you consider it as a problem .....                                                     | E-113       |
| Specifications .....                                                                          | E-119       |

# Safety Precautions

- Please read this “Safety Precautions” thoroughly and use the product accordingly.
- Please pay due attention to the following symbols to help you use the product safely and properly and to avoid any personal injury or damage to the product.

|                                                                                                  |                                                                                                                                           |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
|  <b>Danger</b>  | If this symbol is ignored and the product consequently misused, it can result in serious personal injury and/or death.                    |
|  <b>Warning</b> | This symbol indicates the contents that may cause death or serious injury to a person when the product is misused ignoring this symbol.   |
|  <b>Caution</b> | This symbol indicates the contents that may cause injury to a person or property damage when the product is misused ignoring this symbol. |

- The “pictorial indications” in this manual have the following meanings.

|                                                                                   |                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | △ This symbol means “to be careful = caution”. The example at left is “caution for electrical shock”.                                                                                                  |
|  | ⊘ This symbol means “must not do = prohibited”. The example at left is “prohibited to disassemble”.                                                                                                    |
|  | ● This symbol means “something must be done = instruction”. The example at left is “disconnect the power plug from the outlet”. The “instructions difficult to express in picture” are indicated by !. |

## **Danger**

**If liquid that leaked from a battery gets in your eye, on your skin or clothes, deal with it immediately as follows.**



1. Immediately rinse it off with lots of water.
  2. Immediately get medical treatment.
- Failing to act may result in a rash or loss of sight.

## **Warning**

### **Power Cords and Plugs**



- Do not twist, pull, heat, modify, or place anything heavy on the power cord. This may damage the power cord and result in fire or electrical shock.
- Refrain from routing cords under this product. If the power cord is damaged, it may cause a fire or an electrical shock.
- Contact the dealer or the CASIO service representative when the power cord is damaged (wire is exposed or disconnected). Using the power cord in such condition may result in fire or electrical shock.
- Securely insert the power plug all the way.
- Do not touch the power plug with wet hands. This may result in electrical shock.

# Safety Precautions

## Warning

### Power supply voltage



- Do not use with any voltage other than the indicated power supply voltage. This may result in fire or electrical shock.
- Do not overload the outlet with wires. This may result in fire or electrical shock.

### Do not disassemble or modify



- Do not disassemble or modify the product. There are high voltage parts and sharp parts inside. Touching them may result in injury or electric shock, or cause a malfunction or fire.

### Do not let any foreign object or water get inside



- Do not insert or drop metal object or flammable object inside from the opening.
- Do not spill any liquid such as water from a flower vase, coffee, juice, etc., inside this product.
- Disconnect the power plug from the outlet and contact the dealer where the product was purchased or the CASIO service representative when a foreign object or water got inside the product. Using the power cord in such condition may result in fire or electrical shock.

### Do not use the product in abnormal condition



- It may result in fire or electrical shock when the product is used in abnormal condition such as overheating, it is smoking, have strange odor, etc. Immediately disconnect the power plug from the outlet and contact the dealer where the product was purchased or the CASIO service representative.

## Caution

### Installation location



- Do not place in unstable locations such as on an unsteady table or an inclined location. It could fall and cause injury.
- Do not place in a location with high humidity or dust. This may result in fire or electrical shock.
- Do not place in a location exposed to oil smoke or humidity such as close to cooking table or humidifier. This may result in fire or electrical shock.
- Do not place in a location close to heating devices such as a stove or a heater, or location directly exposed to hot air. This may result in fire.
- The main plug on this equipment must be used to disconnect mains power.
- Select the outlet where the power cord of this product is easily reached, and plug/unplug of the power plug can easily be performed.

### Do not place anything on top



- Do not place flower vase or flower pot, cup or container with liquid, or metal object.
- Do not place anything that is hot such as cigarette.
- Do not place anything heavy.
- Do not place your hands and lean on the product.

# Safety Precautions

## Caution

### When moving the product



- Always disconnect the power plug from the outlet before moving.
- Always hold onto the plug when unplugging the power plug.
- Pulling on the power cord may damage the cord, resulting to fire or electrical shock.

### LCD



- Do not press hard on the LCD or apply strong impact. This may crack the glass on the LCD, resulting to injury.
- Never touch the liquid from inside when the LCD is cracked. This may result in irritation to the skin.
- Immediately rinse the mouth and contact the physician when the liquid inside the LCD gets inside the mouth.
- Rinse for minimum of 15 minutes with clean running water and contact the physician when the liquid inside the LCD gets in the eye or on the skin.

### Adjustment of display



- Do not put your hands at the back of the display while it is moving to adjust its angle. Doing so may result in an injury.
- Do not put your fingers between the sub display and the product when you put it back. Doing so may result in an injury.

### Drawer



- Take caution with the face of a child or pregnant person when opening a drawer.
- Do not lean on the drawer when the drawer is opened. It could fall and cause injury.



### When changing the roll paper



- Beware of your hair or scarf not to get caught in a gear or the platen arm while you are changing the roll paper.
- Do not touch the head of the printer. Doing so may result in an injury or burn.
- Do not oils to adhere to the paper roll or paper holder. Doing so may cause printing errors.

### Cleaning



- Unplug the power plug from the outlet for safety when cleaning.
- Clean the blades and surrounding of the blades of the power plug with a dry cloth at least once a year. Dust accumulation may result in fire. Do not use detergent to clean the power plug.

### When not using for a long period



- Unplug the power plug from the outlet for safety when not using this product for a long period such as consecutive holidays.

# Safety Precautions

## **Caution**

### **Only use the specified batteries.**



- Do not disassemble, modify or short-circuit them.
- Do not put them in fire or water or heat them.
- Do not mix new and old batteries or different types of batteries.
- Orient the terminals +- correctly.
- Remove the batteries if the system will not be used for a long time.
- After batteries are spent, dispose of them as per local regulations.
- Do not try to recharge dry cell batteries.

### **Disposing of batteries:**



- Make sure that you dispose of used batteries in accordance with the rules and regulations in your local area.

# Precautions for Use

Read the following items thoroughly and use this product properly. CASIO bears no responsibility whatsoever for malfunction or damage caused by handling not following below contents. Please note that it will also result in charged repair, and actual cost required for repair will be charged, even if it is within the warranty period.

## ■ Installation Location

Do not place in a hot or dusty location, or in any location exposed to oily smoke or water. Never store or leave in following locations. This could erase the memory and cause a malfunction or result in deformation of the case.

- Temperature of 0°C or lower
- Inside vehicles in summer
- Close to air conditioner
- Under direct sunlight
- Temperature of 40°C or higher

Avoid using this product in following locations.

- Outdoor
- Close to equipment that will become hot such as range, electrical heater, etc.
- Location exposed to water or steam
- Location with severe change in environment such as temperature, humidity, etc.
- Location where corrosive gas or saline matter is generated
- Location where dirt or dust is generated
- Location with vibration
- Location prone to static electricity

## ■ Others

- Prepare separate AC power supply from the power line for motor, ice maker, microwave oven, etc., which may generate noise.
- Do not touch the power switch with wet hands. This may result in electrical shock.
- Wipe thoroughly with dry cloth, etc., when there is any water droplet on the device.
- Do not use any volatile chemical such as thinner, benzine, cosmetics, etc., for cleaning. Wipe with dry soft cloth when this product gets dirty. The display section may be scratched when scuffed strongly with a cloth.
- When the capacity of the internal memory protection battery is insufficient and there is no power supply available due to a power outage, malfunction or other reason, the memory content might be erased.

# Precautions for Use

## ■ Take Advance Notice of the Following

- The content of this manual may be changed without prior notice due to improvement or specification change of the product.
- Please note that CASIO bears no responsibility for damage, loss of profit, or any claim from third party due to loss or change of data caused by usage, malfunction, or repair of this product.
- The copyright for this manual and all rights related to the software described in this manual are the property of CASIO Computer Co., Ltd. The unauthorized reproduction of this manual in whole or part is prohibited without the written permission of CASIO.
- The content of this manual was created with all possible care, but please contact us if there is any unclear point, mistake, omission, etc., in this manual.
- The screen or illustration used in this manual may be different from the actual product. The keys and icons are described in simplified manner.

### • Weld Line


The line on the exterior of the product is called “weld line”, which is created at the time of plastic forming, and it is not a crack or a scratch. This will not interrupt the usage.

## ■ When the cash drawer does not open!


In case of power failure or the machine is in malfunction, the cash drawer does not open automatically. Even in these cases, you can open the cash drawer by pulling drawer release lever (see the figure on the right).

**Important:** The drawer will not open, if it is locked with a drawer lock key.

S size drawer



M size drawer





## **GUIDELINES LAID DOWN BY FCC RULES FOR USE OF THE UNIT IN THE U.S.A. (Not applicable to other areas)**

**WARNING:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Proper connectors must be used for connection to host computer and/or peripherals in order to meet FCC emission limits.

#### **Caution Exposure to radio frequency radiation**

To comply with FCC/IC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter except in accordance with the FCC multi-transmitter product procedures or as described in the filing.

#### **Précaution Exposition aux champs de radiofréquences**

Pour respecter les normes relatives aux radiofréquences FCC/IC, ce dispositif ne doit pas être situé ou utilisé à proximité d'une autre antenne ou d'un autre émetteur si ce n'est selon les procédures mentionnées pour le multi-transmetteur FCC/IC ou décrites dans la documentation.

Model Number: PCR-T540-BK, PCR-T540L-BK, PCR-T560L-SR, SR-S500SC-BK, SR-S820-BK

Trade Name: CASIO

Responsible party: Systems Product Division Casio America, Inc.

Address: 570 Mt. Pleasant Avenue, Dover, New Jersey 07801, USA

Telephone number: 973-361-5400

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# Regulatory Information

PCR-T540-BK, PCR-T540L-BK, PCR-T560L-SR, SR-S500SC-BK, SR-S820-BK

This model is available in the USA and Canada only.

## **This device complies with Industry Canada's applicable licence-exempt RSSs.**

Operation is subject to the following two conditions:

- (1) These devices may not cause interference, and
- (2) These devices must accept any interference, including interference that may cause undesired operation of the device.

## **Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.**

L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum ( or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

## LIMITED WARRANTY : ELECTRONIC CASH REGISTERS

This product, except the battery, is warranted by CASIO to the original purchaser to be free from defects in material and workmanship under normal use for a period, from the date of purchase, of one year for parts and 90 days for labor. For one year, upon proof of purchase, the product will be repaired or replaced (with the same or a similar model) at CASIO's option, at a CASIO Authorized Service Center without charge for parts. Labor will be provided without charge for 90 days. The terminal resident software and programmable software, if any, included with this product or any programmable software which may be licensed by CASIO or one of its authorized dealers, is warranted by CASIO to the original licensee for a period of ninety (90) days from the date of license to conform substantially to published specifications and documentation provided it is used with the CASIO hardware and software for which it is designed.

For a period of ninety (90) days, upon proof of license, CASIO will, at its option, replace defective terminal resident software or programmable software, correct significant program errors, or refund the license fee for such software. Significant program errors will be significant deviations from written documentation or specifications. These are your sole remedies for any breach of warranty. In no event will CASIO's liability exceed the license fee, if any, for such software. This warranty will not apply if the product has been misused, abused, or altered.

Without limiting the foregoing, battery leakage, bending of the unit, a broken display tube, and any cracks or breaks in the display will be presumed to have resulted from misuse or abuse. To obtain warranty service you must take or ship the product, freight prepaid, with a copy of the sales receipt or other proof of purchase and the date of purchase, to a CASIO Authorized Service Center. Due to the possibility of damage or loss, it is recommended when shipping the product to a CASIO Authorized Service Center that you package the product securely and ship it insured. CASIO HEREBY EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE. NO RESPONSIBILITY IS ASSUMED FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION DAMAGES RESULTING FROM MATHEMATICAL INACCURACY OF THE PRODUCT OR LOSS OF STORED DATA. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

# To use the cash register's basic function


|                                                                       |             |
|-----------------------------------------------------------------------|-------------|
| <b>Getting started.....</b>                                           | <b>E-13</b> |
| Name of Parts .....                                                   | E-13        |
| Loading memory protection batteries.....                              | E-14        |
| Installing paper roll .....                                           | E-15        |
| To set the language, date, time, tax rates and Bluetooth pairing..... | E-16        |
| Setting paper roll as journal records.....                            | E-18        |
| <b>Getting to know your cash register .....</b>                       | <b>E-20</b> |
| To adjust the main display .....                                      | E-21        |
| To set the customer display .....                                     | E-21        |
| Display .....                                                         | E-22        |
| Keyboard .....                                                        | E-23        |
| <b>How to read the printouts .....</b>                                | <b>E-25</b> |
| <b>How to use your cash register .....</b>                            | <b>E-26</b> |
| <b>Before opening your store.....</b>                                 | <b>E-27</b> |
| Checking the time and date.....                                       | E-27        |
| Preparing bills and coins for change .....                            | E-27        |
| <b>Registering items in departments .....</b>                         | <b>E-28</b> |
| <b>Basic setups and registrations .....</b>                           | <b>E-32</b> |
| To program basic settings.....                                        | E-32        |
| Programming departments .....                                         | E-35        |
| Registering departments' preset data.....                             | E-36        |
| Programming PLUs .....                                                | E-37        |
| Registering PLUs' preset data.....                                    | E-38        |
| <b>Other registrations .....</b>                                      | <b>E-41</b> |
| Discount .....                                                        | E-41        |
| Reduction .....                                                       | E-42        |
| Registering various payment methods .....                             | E-43        |
| Tax shift .....                                                       | E-45        |
| Registering returned goods .....                                      | E-46        |
| Registrations without transactions .....                              | E-48        |
| Corrections .....                                                     | E-49        |
| <b>Daily sales reports .....</b>                                      | <b>E-53</b> |
| Print out of daily sales report.....                                  | E-54        |

# To use the cash register's basic function

## Getting started

This chapter shows how to setup the cash register and get it ready to operate.

### Name of Parts



- 1 Drawer
- 2 SD card slot cover
- 3 Printer cover
- 4 Printer
- 5 Customer display


- 6 Main display
- 7 Mode switch
- 8 COM port connector cover
- 9 Drawer lock

# To use the cash register's basic function


## Loading memory protection batteries

**Important:** These batteries protect information stored in your cash register's memory when there is a power failure or when you unplug the cash register. Be sure to install these batteries first.


**1** Remove the printer cover.



**2** Remove the battery compartment cover.



**3** Note the (+) and (–) markings in the battery compartment. Load a set of two new “AA” type alkaline batteries so that their plus (+) and minus (–) ends are facing as indicated by the markings.



**4** Replace the battery compartment cover and the printer cover.

### **Warning**

---

- No battery is included in the accessories.
- Never try to recharge the batteries.
- Do not expose batteries to direct heat, let them become shorted or try to take them apart.
- Keep batteries out of the reach of small children. If your child should swallow a battery, consult a physician immediately.
- There is a risk of explosion if the batteries are replaced with improper type.
- Dispose of used batteries according to the instructions.

# To use the cash register's basic function

## Installing paper roll

You can use the paper roll as receipts or journals (for business records). By default, your cash register is set as receipt printing. Please see pages E-18 and E-19 if you wish to use the paper roll for journals. The setting methods of the paper roll differ by the usage. Please follow the instructions below in accordance with your usage of the paper roll.





### **Caution (in handling the thermal paper)**

---

- Never touch the printer head and the platen.
- Unpack the thermal paper just before your use.
- Avoid heat and direct sunlight.
- Avoid dusty and humid places for storage.
- Do not scratch the paper.
- Do not keep the printed paper under the following circumstances:
  - High humidity and temperature/direct sunlight/contact with glue, thinner or a rubber eraser.

### ■ To install receipt paper

- 1** Remove the printer cover.
- 2** Open the platen arm by lifting it up.
- 3** Ensuring the paper is being fed from the bottom of the roll, lower the roll into the space behind the printer.
- 4** Put the leading end of the paper over the printer.
- 5** Close the platen arm slowly until it locks securely. Please push the position marked [PUSH HERE].
- 6** Replace the printer cover, passing the leading end of the paper through the cutter slot. Tear off the excess paper.




# To use the cash register's basic function

## To set the language, date, time, tax rates and Bluetooth pairing

- 1** Plug in the power socket into a wall outlet.

Be sure to check the rating plate on the side of the cash register to make sure that its voltage matches that of the power supply in your area.



- 2** As soon as the power socket is plugged in, the display shows the language selection display. Choose your language by using  or  keys then press  key.

|                         |        |
|-------------------------|--------|
| PLEASE SELECT LANGUAGE. |        |
| <CA/AMT TEND>           | :ENTER |
| English                 |        |
| Español                 |        |

**NOTE**

- Actual display shows characters in white on blue background.
- Selectable languages and countries depend on the cash register model.

- 3** Display changes to date and time setting display. Moving the input area (reversed area) by  or  keys, input date, month, year and time from ten key pad. Input the time by 24 - hour system. For example, 1356 for 1:56 pm. After then press  key.

|                           |         |
|---------------------------|---------|
| PLEASE INPUT DATE & TIME. |         |
| <CA/AMT TEND>             | :ENTER  |
| <SUBTOTAL>                | :RETURN |
| DATE                      | [DD]    |
| MONTH                     | [MM]    |
| YEAR                      | 20[YY]  |
| TIME(24-hour)             | [HHMM]  |

For the Canadian model, select your state on the state selection screen. The display then asks whether or not to use the Canadian rounding system. Set the necessary settings by following the instructions on the screen.

|                          |         |
|--------------------------|---------|
| PLEASE SELECT TAX TABLE. |         |
| <CA/AMT TEND>            | :ENTER  |
| <SUBTOTAL>               | :RETURN |
| NON SELECT               | ▲       |
| ALBERTA                  |         |
| BRITISH COLUMBIA         |         |
| MANITOBA                 |         |
| NEW BRUNSWICK            | ▼       |

- 4** Display then changes to tax table selection display. Using ten key pad, input tax rates. You can set four kinds of tax rates.

|                        |         |
|------------------------|---------|
| PLEASE INPUT TAX RATE. |         |
| <CA/AMT TEND>          | :ENTER  |
| <SUBTOTAL>             | :RETURN |
| Rate                   |         |
| Tax1                   | [ 3]    |
| Tax2                   | [ 5.25] |
| Tax3                   | [ 8.5]  |
| Tax4                   | [ 15]   |

- 5** Press  key. Replace the printer cover.

## To use the cash register's basic function

- 6** Using a smartphone application, you can perform cash register settings by pairing with a smartphone via Bluetooth connection.

If you wish to use the smartphone application, select [YES] and pair with a smartphone. If you do not wish to pair with a smartphone via Bluetooth connection, select [NO]. You can pair with a smartphone and use the application later on in PGM mode.

The followings are the procedures when you select [YES].

- 7** Activate Bluetooth on your smartphone. On the smartphone, find and select the device code of the cash register shown on the display. In this example, 12345678901234.

Note that the device code differs depending on each cash register. Make sure to select the same code shown on the cash register display.

- 8** After you select the device code on the smartphone, the cash register then shows a pass key on the display. Enter the pass key (in this example, 123456) on the smartphone. Pass key differs depending on each cash register.

- 9** Now your cash register and your smartphone are paired by Bluetooth connection.

Do you want to connect  
mobile via Bluetooth?  
<CA/AMT TEND> :ENTER

[YES]  
[NO]

Activate Bluetooth on  
mobile and select below  
device on the mobile.  
<SUBTOTAL> :CANCEL

12345678901234

Enter pass key on your  
mobile.  
<SUBTOTAL> :CANCEL

123456

**You can perform detail settings or data exchange using Bluetooth connection.  
Please refer to the website <http://web.casio.com/ecr/app/>.**






# To use the cash register's basic function


## Setting paper roll as journal records

By default, the printer of your cash register issues receipts. If you wish to use the printouts for sales journals, please follow the procedures described below.

- 1 Turn the Mode switch to PGM position and select [Paper Roll Setting] then press  key.  
[Paper Roll Setting] is not shown on the first screen.  
Keep pressing  key until it appears on the screen.








- 2 On the Paper Roll Setting screen, select "Journal" and press  key.  
Now your cash register is set to print sales journals.



# To use the cash register's basic function

## ■ To install journal paper

- 1** Repeat steps 1 through 5 of "To install receipt paper".
- 2** Remove the paper guide of the take-up reel.
- 3** Slide the leading end of the paper into the groove on the spindle of the take-up reel and wind it onto the reel two or three turns.
- 4** Replace the paper guide of the take-up reel.
- 5** Place the take-up reel into place behind the printer, above the roll paper.




# To use the cash register's basic function

## Getting to know your cash register

### Mode switch

Use the mode keys to change the position of the mode switch and select the mode you want to use.



#### PGM (Programming)

This position is for setting your cash register to suit the needs of your store.

#### RF (Refund)

Use this position to correct registered items.

#### OFF

The cash register turns off in this position.

#### REG (Register)

This position is for normal transactions.

#### X (Read)

This is the position used for issuing daily sales totals report without clearing the data.

#### Z (Reset)


This position is for issuing reports of daily totals with clearing the accumulated totals.

#### X2/Z2 (Periodic sale read/reset)

Used to obtain periodic sales reports without resetting total data.

### Mode keys

There are two types of mode keys: the program key (marked "PGM") and the operator key (marked "OP"). The program key can be used to set the mode switch to any position, while the operator key can select the REG and OFF position.



|         | PGM | RF | OFF | REG | X | Z | X2/Z2 |
|---------|-----|----|-----|-----|---|---|-------|
| OP key  | -   | -  | ○   | ○   | - | - | -     |
| PGM key | ○   | ○  | ○   | ○   | ○ | ○ | ○     |

### Drawer

The drawer opens automatically whenever you finalize a registration and whenever you issue a read or reset report. The drawer will not open if it is locked with the drawer key.

### Drawer key

Use this key to lock and unlock the drawer.


### Magnetic plate

Use this plate for tacking the notes received from customer.

# To use the cash register's basic function


## To adjust the main display

- 1 Put in fingers in the ditch of the main display and tilt it to the angle you can see clearly.




## To set the customer display

- 1 Lift the customer display until it stops.



- 2 Rotate the display so that customers can see it.



# To use the cash register's basic function

## Display

**NOTE** Actual display shows characters in white on blue background.

### ■ Main display

During a registration

|          |         |        |        |   |
|----------|---------|--------|--------|---|
| C01      | REG     | 000004 | 1      |   |
| 1        | PLU001  | \$1.00 | 2      |   |
| 3        | DEPT001 | \$6.00 |        |   |
| SUBTOTAL |         |        | \$7.00 | 3 |
| 4        | QT      | 6.00   | 4      |   |

After finalization

|     |         |         |   |
|-----|---------|---------|---|
| C01 | REG     | 000004  |   |
| 1   | PLU001  | \$1.00  |   |
| 3   | DEPT001 | \$6.00  |   |
|     | TL      | \$7.00  | 5 |
|     | CASH    | \$10.00 | 6 |
|     | CG      | \$3.00  | 7 |
| CG  |         | \$3.00  | 8 |
| 4   | QT      | 10.00   | 9 |


- 1 Mode/Clerk Number or name/Consecutive No.
- 2 Registered item Quantity/Category/Price
- 3 Subtotal amount
- 4 Total quantity/Price of the last item
- 5 Total amount
- 6 Paid by/Tendered amount
- 7 Change
- 8 Change
- 9 Total quantity/Tendered amount

### ■ Customer display



# To use the cash register's basic function

## Keyboard



- 1 Hold this key down to feed paper from the printer.
- 2 Use this key to issue a post-finalization receipt.
- 3 Use this key to temporarily release a limitation on the number of digits for a unit price.
- 4 Non-add key: Use this key to print reference number (to identify a personal check, credit card, etc.) during a transaction. Use this function after a numeral entry. No sale key: Use this key to open the drawer without any registration.
- 5 Use this key to input refunded amounts or to void preceding inputs.
- 6 Use this key to correct a registration error or to cancel a transaction.
- 7 Use this key to switch issuing receipts on and off.
- 8 Use this key to register unit prices for a PLU (subdepartment).
- 9 Use this key to input PLU (subdepartment) numbers.
- 10 Use this key to input a quantity for a multiplication and registration of split sales of packaged items. Between transactions, pressing this key displays the current time and date.
- 11 Use this key to clear an entry that has not yet been registered.
- 12 Use this key to input reduction values.
- 13 Use this key to register discounts.
- 14 Use this key to input a clerk number.
- 15 Use this key without a numeric entry to change the taxable 1 status of the following item.
- 16 Use this key without a numeric entry to change the taxable 2 status of the following item.

## To use the cash register's basic function

- 17  Department no. Use this key to input department numbers. Department shift: Use this key to shift the department number from 1 through 25 to 26 through 50.
- 18     Use these keys to input numbers.
- 19  Use this key to sign clerk off the register.
- 20  Use this key to move the cursor on the display up.
- 21  Use this key to move the cursor on the display down.
- 22  Use this key following a numeric entry to register money received for non-sale transactions.
- 23  Use this key following a numeric entry to register money paid out from the drawer.
- 24  Use this key to set the tax status and tax table.
- 25  Use this key to look up the procedures to set date/time, tax table etc.
- 26  to  Use these keys to register items to departments.  
 to : NON TAX  to : TAXABLE
- 27  Use this key to register a credit sale.
- 28  Not used for regular registrations.
- 29  Use this key to register a check tendering.
- 30  Use this key to register a charge sale.
- 31  Use this key to display and print the current subtotal (including tax) amount.
- 32  Use this key to register a cash sale.

# To use the cash register's basic function

## How to read the printouts

- The journal/receipts are records of all transactions and operations.
- The contents printed on receipts and journal are almost identical.
- You can choose the journal skip function.

If the journal skip function is selected, the cash register will print the total amount of each transaction, and the details of premium, discount and reduction operations only, without printing department and PLU item registrations on the journal.

- The following items can be skipped on receipts and journal.
  - Taxable status
  - Taxable amount
  - Item counter

### Receipt Sample

```
*****
* THANK YOU *
**  CALL AGAIN  **
*****
1
* COMMERCIAL MESSAGE *
* COMMERCIAL MESSAGE *
* COMMERCIAL MESSAGE *
* COMMERCIAL MESSAGE *
2
REG 20-06-2018 11:58
C01 0001 000123
3
4
1 DEPT001 T1 $1.00
1 DEPT002 T1 $2.00
5 DEPT003 $5.00
5
7 No
6
TA1 $3.00
TX1 $0.15
TL $8.15
CASH $10.00
CG $1.85
7
*** BOTTOM MESSAGE ***
*** BOTTOM MESSAGE ***
*** BOTTOM MESSAGE ***
*** BOTTOM MESSAGE ***
```

### Journal Sample (with items)

```
REG 20-06-2018 11:58
C01 0001 000123
1 DEPT001 T1 $1.00
1 DEPT002 T1 $2.00
5 DEPT003 $5.00
7 No
TA1 $3.00
TX1 $0.15
TL $8.15
CASH $10.00
CG $1.85
REG 20-06-2018 11:59
C01 0001 000124
1 DEPT001 T1 $1.00
1 DEPT012 T1 $1.00
5 DEPT003 $6.00
7 No
TA1 $2.00
TX1 $0.10
TL $8.10
CASH $10.00
CG $1.90
REG 20-06-2018 11:59
C01 0001 000124
```

### Journal Sample (by half height character)

```
REG 20-06-2018 11:58
C01 0001 000123
1 DEPT001 T1 $1.00
1 DEPT002 T1 $2.00
5 DEPT003 $5.00
7 No
TA1 $3.00
TX1 $0.15
TL $8.15
CASH $10.00
CG $1.85
REG 20-06-2018 11:59
C01 0001 000124
1 DEPT001 T1 $1.00
1 DEPT012 T1 $1.00
5 DEPT003 $6.00
7 No
TA1 $2.00
TX1 $0.10
TL $8.10
CASH $10.00
CG $1.90
REG 20-06-2018 11:59
C01 0001 000124
```

- |                                     |                                |
|-------------------------------------|--------------------------------|
| 1 Logo message* <sup>1</sup>        | 5 Q'ty/Item                    |
| 2 Commercial message* <sup>1</sup>  | 6 Item counter                 |
| 3 Mode/Date/Time                    | 7 Bottom message* <sup>1</sup> |
| 4 Clerk/Machine No./Consecutive No. |                                |

In the operation examples in this manual, the printout samples are what would be printed if the roll paper is being used for receipts.

\* 1 To set for printing those messages, please see page E-79 "Set code 21".



# To use the cash register's basic function

## How to use your cash register

The following describes the general procedure you should use in order to get the most out of your cash register.

### Before opening your store

---



- Plugged in? (page E-16)
- Enough paper roll? (pages E-15 and E-19)
- Date and time are correct? (pages E-27 and E-33)
- Enough small change in the drawer? (page E-27)



### While the store is open

---



- Registrations (page E-28)
- Issuing latest total sales report if needed. (page E-53)



### After closing the store

---




- Issuing day's total sales report. (page E-53)
- Withdraw the money from the drawer.  
After you withdraw all the money from the drawer, we recommend that you leave the drawer open when you leave your store. (page E-27)
- Turn the Mode switch to OFF. (page E-20)

# To use the cash register's basic function

## Before opening your store

### Checking the time and date


You can check the time or date on the display whenever there is no registration being made.



| Step                                                   | Operation | Display |
|--------------------------------------------------------|-----------|---------|
| 1 Press  key to show the date and time on the display. |           |         |
| 2 Press  key to clear the date/time display.           |           |         |

### Preparing bills and coins for change

To prepare coins and bills for change, you can open the drawer by pressing key. This operation must be performed when registrations are not being made.



**NOTE** Opening the drawer by key does not perform any calculation in the register. If you wish to obtain a report that tells you the total amount in drawer, use key instead of key. See page E-48.

| Step                                     | Operation | Printout |
|------------------------------------------|-----------|----------|
| 1 Press . The cash drawer opens.         |           |          |
| 2 Prepare coins and bills in the drawer. |           |          |

# To use the cash register's basic function

## Registering items in departments

The following examples show how you can use the department keys in various types of registrations.

Departments are used for categorizing items for example, department 01 for vegetables, department 02 for fruits, and department 03 for canned foods etc.



### Single item sale

#### Sample Operation

|         |            |        |                                                                                             |
|---------|------------|--------|---------------------------------------------------------------------------------------------|
| Item    | Unit Price | \$1.00 | One \$1.00 Dept. 01 item is sold and the customer paid the same amount as the total amount. |
|         | Quantity   | 1      |                                                                                             |
|         | Dept.      | 01     |                                                                                             |
| Payment | Cash       | \$1.00 |                                                                                             |

| Step                                  | Operation              | Printout                                                                                                                        |
|---------------------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| 1 Enter the unit price.               | <b>1 00</b>            | <div> 1 DEPT001                      \$1.00<br/> TL                      \$ 1 . 00<br/> CASH                      \$1.00 </div> |
| 2 Press corresponding department key. | <b>1</b>               |                                                                                                                                 |
| 3 Press <b>CA / AMT / TEND</b> key.   | <b>CA / AMT / TEND</b> |                                                                                                                                 |

#### Further operations:

- For simpler operation of single item sales, see page E-60 "Single item cash sales".

### Single item sales with change calculation

#### Sample Operation

|         |            |         |                                                                    |
|---------|------------|---------|--------------------------------------------------------------------|
| Item    | Unit Price | \$12.34 | One item is sold and the customer paid more than the total amount. |
|         | Quantity   | 1       |                                                                    |
|         | Dept.      | 01      |                                                                    |
| Payment | Cash       | \$20.00 |                                                                    |

| Step                                                                                                        | Operation                            | Printout                                                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------|--------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Enter the unit price.                                                                                     | <b>1 2 3 4</b>                       | <div> 1 DEPT001                      \$12.34<br/> TL                      \$ 12 . 34<br/> CASH                      \$20.00<br/> CG                      \$7.66 </div> |
| 2 Press corresponding department key.                                                                       | <b>1</b>                             |                                                                                                                                                                        |
| 3 Press <b>SUB TOTAL</b> key.                                                                               | <b>SUB TOTAL</b>                     |                                                                                                                                                                        |
| 4 Enter the tendered amount then press <b>CA / AMT / TEND</b> key. The display shows the change to be paid. | <b>2 0 00</b> <b>CA / AMT / TEND</b> |                                                                                                                                                                        |

# To use the cash register's basic function

## ■ Repeat registration

### Sample Operation

|         |            |         |                                      |
|---------|------------|---------|--------------------------------------|
| Item    | Unit Price | \$1.50  | Same priced multiple items are sold. |
|         | Quantity   | 3       |                                      |
|         | Dept.      | 1       |                                      |
| Payment | Cash       | \$10.00 |                                      |

| Step                                                                                                               | Operation                            | Printout                                                                                                                         |
|--------------------------------------------------------------------------------------------------------------------|--------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the unit price.                                                                                     | <b>1 5 0</b>                         | <div> 1 DEPT001 \$1.50<br/> 1 DEPT001 \$1.50<br/> 1 DEPT001 \$1.50<br/> TL <b>\$4.50</b><br/> CASH \$10.00<br/> CG \$5.50 </div> |
| <b>2</b> Press corresponding department key repeatedly for the purchased quantity.                                 | <b>1 1 1</b>                         |                                                                                                                                  |
| <b>3</b> Press <b>SUB TOTAL</b> key.                                                                               | <b>SUB TOTAL</b>                     |                                                                                                                                  |
| <b>4</b> Enter the tendered amount then press <b>CA / AMT / TEND</b> key. The display shows the change to be paid. | <b>1 0 00</b> <b>CA / AMT / TEND</b> |                                                                                                                                  |

## ■ Multiple items registration using multiplication key

### Sample Operation

|         |            |         |                                                                                         |
|---------|------------|---------|-----------------------------------------------------------------------------------------|
| Item    | Unit Price | \$1.00  | Twelve pieces of \$1.00 item are sold and the customer paid more than the total amount. |
|         | Quantity   | 12      |                                                                                         |
|         | Dept.      | 1       |                                                                                         |
| Payment | Cash       | \$20.00 |                                                                                         |

| Step                                                                                                               | Operation                            | Printout                                                                                |
|--------------------------------------------------------------------------------------------------------------------|--------------------------------------|-----------------------------------------------------------------------------------------|
| <b>1</b> Enter the quantity then press <b>X / FOR DATE TIME</b> key.                                               | <b>1 2</b> <b>X / FOR DATE TIME</b>  | <div> 12 DEPT001 \$12.00<br/> TL <b>\$12.00</b><br/> CASH \$20.00<br/> CG \$8.00 </div> |
| <b>2</b> Enter the unit price and press corresponding department key.                                              | <b>1 00</b> <b>1</b>                 |                                                                                         |
| <b>3</b> Press <b>SUB TOTAL</b> key.                                                                               | <b>SUB TOTAL</b>                     |                                                                                         |
| <b>4</b> Enter the tendered amount then press <b>CA / AMT / TEND</b> key. The display shows the change to be paid. | <b>2 0 00</b> <b>CA / AMT / TEND</b> |                                                                                         |

# To use the cash register's basic function

## ■ Split sales of packaged items

### Sample Operation

|         |            |               |                                                                         |
|---------|------------|---------------|-------------------------------------------------------------------------|
| Item    | Unit Price | 4 for \$10.00 | Three pieces of an item that price is \$10.00 for four pieces are sold. |
|         | Quantity   | 3             |                                                                         |
|         | Dept.      | 1             |                                                                         |
| Payment | Cash       | \$10.00       |                                                                         |

| Step                                                                                                                                                            | Operation                                                                                                                                                                                                                                                                                                                                                                                                                 | Printout                                                                                                                                                          |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter purchased quantity then press  key.                             |                                                                                                                                                                                                                                                         | <div> 3 DEPT001                      \$7.50<br/> TL                      \$7.50<br/> CASH                      \$10.00<br/> CG                      \$2.50 </div> |
| <b>2</b> Enter the quantity of one set and press  key.                         |                                                                                                                                                                                                                                                         |                                                                                                                                                                   |
| <b>3</b> Enter the package price and press corresponding department and  keys. |      |                                                                                                                                                                   |
| <b>4</b> Enter the tendered amount and press  key.                             |                                                                                       |                                                                                                                                                                   |

## ■ Department shift

By using  , Dept. 01 through 25 are assigned to Dept. 26 through 50.

### Sample Operation

|         |            |        |                                                                                                                               |
|---------|------------|--------|-------------------------------------------------------------------------------------------------------------------------------|
| Item    | Unit Price | \$1.00 | Department 26 is assigned by using  key. |
|         | Quantity   | 1      |                                                                                                                               |
|         | Dept.      | 26     |                                                                                                                               |
| Payment | Cash       | \$1.00 |                                                                                                                               |

| Step                                                                                                                                                                                                                             | Operation                                                                                                                                                                                                                                                                                                                                       | Printout                                                                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Press  key.<br>“SHIFT/No” will be shown at the bottom of the display.                                                                |                                                                                                                                                                                                                                                              | <div> 1 DEPT026                      \$1.00<br/> TL                      \$1.00<br/> CASH                      \$1.00 </div> |
| <b>2</b> Enter the unit price and press corresponding department key. Then press  key.<br>The item is registered in Dept. 26 in this example. |     |                                                                                                                              |
| <b>3</b> Press  key to finalize the transaction.                                                                                              |                                                                                                                                                                                                                                                              |                                                                                                                              |

# To use the cash register's basic function

## ■ Department number entry

Without using Department key, you can register departments manually.

### Sample Operation

|         |            |         |                                                               |
|---------|------------|---------|---------------------------------------------------------------|
| Item    | Unit Price | \$13.00 | Registering an item in Dept. 31 without using Department key. |
|         | Quantity   | 1       |                                                               |
|         | Dept.      | 31      |                                                               |
| Payment | Cash       | \$13.00 |                                                               |

| Step                                                                                                                                                                                                                                                                                    | Operation                                                                                                                                                                                                                                                                                                                                                                                                                 | Printout                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| <b>1</b> Enter Dept. number using ten key pad then press  key.                                                                                                                                         |                                                                                                                                                                        | <div>1 DEPT031 \$13.00<br/>TL \$13.00<br/>CASH \$13.00</div> |
| <b>2</b> Enter the unit price and press  key. Then press  key.<br>The item is registered in Dept. 31 in this example. |      |                                                              |
| <b>3</b> Press  key to finalize the transaction.                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                          |                                                              |

# To use the cash register's basic function

## Basic setups and registrations

### To program basic settings


You can program basic settings in the PGM mode of the Mode switch.



#### Step

#### Display

- 1 By turning the Mode switch to PGM position, the display indicates the programming top menu.
- 2 Use or keys to choose the item you wish to set then press key.  
Repeat the above step until the display shows an entry display.
- 3 Input values you wish to set and press key.



The following table shows the setting items of the basic programming.

#### ■ Program menus

| Top menu       | Sub menu                 |                           | What is to be set                                                                                                  |
|----------------|--------------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------|
| [DEPT Setting] | DEPT name [DEPT001 ]     |                           | Sets name, unit price, taxable status, item group and high amount limitation in each department.<br>See page E-35. |
|                | Unit Price [ 0.00 ]      |                           |                                                                                                                    |
|                | Taxable Status [NON TAX] |                           |                                                                                                                    |
|                | Group Link [00]          |                           |                                                                                                                    |
|                | High AMT Limit [0.00]    |                           |                                                                                                                    |
|                | POP No. [ ]              |                           |                                                                                                                    |
|                | Advanced                 | Single Item [NO]          |                                                                                                                    |
|                |                          | 0 Unit Price [NO]         |                                                                                                                    |
| [PLU Setting]  |                          | Negative Price [NO]       | Sets name, unit price, taxable status, item group, department link and open PLU in each PLU.<br>See page E-37.     |
|                | PLU name [PLU0001 ]      |                           |                                                                                                                    |
|                | Unit Price [ 0.00 ]      |                           |                                                                                                                    |
|                | Taxable Status [NON TAX] |                           |                                                                                                                    |
|                | Group Link [00]          |                           |                                                                                                                    |
|                | DEPT Link [000]          |                           |                                                                                                                    |
|                | Open PLU [NO]            |                           |                                                                                                                    |
|                | Advanced                 | Single Item [NO]          |                                                                                                                    |
|                |                          | 0 Unit Price [NO]         |                                                                                                                    |
|                |                          | Negative Price [NO]       |                                                                                                                    |
|                |                          | Min Stock [0]             |                                                                                                                    |
|                |                          | OBR Code [00000000000000] |                                                                                                                    |

# To use the cash register's basic function

| Top menu             | Sub menu                       |              | What is to be set                                                                                                                 |
|----------------------|--------------------------------|--------------|-----------------------------------------------------------------------------------------------------------------------------------|
| [Key Setting]        | %-                             |              | Sets name, taxable status, and whether to use taxable status or not in each function key.                                         |
|                      | -                              |              |                                                                                                                                   |
|                      |                                |              |                                                                                                                                   |
| [Date Setting]       | TIME (24 HOUR) [19:56]         |              | Sets date and time.                                                                                                               |
|                      | MONTH [12]                     |              |                                                                                                                                   |
|                      | DATE [26]                      |              |                                                                                                                                   |
|                      | YEAR 20[18]                    |              |                                                                                                                                   |
| [Clerk Setting]      | Secret No [0001]               |              |                                                                                                                                   |
|                      | Operation [YES]                |              |                                                                                                                                   |
| [Message Setting]    | 01 Logo 1                      | YOUR RECEIPT | Please refer to pages E-25 and E-79.                                                                                              |
|                      | 02 Logo 2                      | THANK YOU    |                                                                                                                                   |
|                      | 03 Logo 3                      | CALL AGAIN   |                                                                                                                                   |
|                      | 04 Logo 4                      |              |                                                                                                                                   |
|                      | 05 Commercial 1                |              |                                                                                                                                   |
|                      | 06 Commercial 2                |              |                                                                                                                                   |
|                      | 07 Commercial 3                |              |                                                                                                                                   |
|                      | 08 Commercial 4                |              |                                                                                                                                   |
|                      | 09 Bottom 1                    |              |                                                                                                                                   |
|                      | 10 Bottom 2                    |              |                                                                                                                                   |
|                      | 11 Bottom 3                    |              |                                                                                                                                   |
|                      | 12 Bottom 4                    |              |                                                                                                                                   |
| [POP Setting]        | Read POP Data                  |              | Please refer to page E-110.                                                                                                       |
|                      | POP Operation Setting          |              |                                                                                                                                   |
|                      | Print POP image                |              |                                                                                                                                   |
| [Tax Setting]        | RATE                           |              | Depending on the model and selected language (country), number of tax (Tax 1 - Tax 3, Tax 1 - Tax 4, Tax 1 - Tax 10 etc.) differ. |
|                      | ROUND                          |              |                                                                                                                                   |
|                      | CAL TYPE                       |              |                                                                                                                                   |
| [General Setting]    | Enable clerk [NO]              |              | Sets general controls of the register such as clerk assignment, printing journal in half size etc.                                |
|                      | Journal 1/2 Print [YES]        |              |                                                                                                                                   |
|                      | Consecutive No. Reset [YES]    |              |                                                                                                                                   |
|                      | EJ clear (After Daily Z) [YES] |              |                                                                                                                                   |
|                      | EJ/Sales→SD (After XZ) [NO]    |              |                                                                                                                                   |
|                      | Prohibit Reg(Stock < 0 ) [NO]  |              |                                                                                                                                   |
|                      | Min Stock Alert [NO]           |              |                                                                                                                                   |
| [Paper Roll Setting] | Receipt                        |              |                                                                                                                                   |
|                      | Journal                        |              |                                                                                                                                   |
| [Water Mark Setting] | YES                            |              |                                                                                                                                   |
|                      | NO                             |              |                                                                                                                                   |



## To use the cash register's basic function

| Top menu         | Sub menu        |  | What is to be set                                                                                                      |
|------------------|-----------------|--|------------------------------------------------------------------------------------------------------------------------|
| [SD card]        | Backup → SD     |  | Exchanges sales data, program data, and receipt's message data between the register and an SD card.<br>See page E-107. |
|                  | Restore← SD     |  |                                                                                                                        |
|                  | Program→ SD     |  |                                                                                                                        |
|                  | Program← SD     |  |                                                                                                                        |
|                  | SD Format       |  |                                                                                                                        |
|                  | Backup → Flash  |  |                                                                                                                        |
|                  | AutoProgram→ SD |  |                                                                                                                        |
|                  | AutoProgram← SD |  |                                                                                                                        |
| [Bluetooth]      | System Setting  |  | See page E-105.                                                                                                        |
|                  | Functions       |  | If you wish to perform further settings using a smartphone, please refer to page E-105.                                |
| [System Setting] |                 |  | Used to set characters, functions of keys, or calculation methods etc.                                                 |


# To use the cash register's basic function

## Programming departments

This section explains how you can set unit prices, taxable statuses, and item groups. You can program each department linking to a certain group. For example, department 01 is for packed milk, department 02 is for cheese and both belong to group 03 (dairy goods).

### Sample Operation

|          |                |         |                                                                                |
|----------|----------------|---------|--------------------------------------------------------------------------------|
| Dept. 01 | Unit Price     | \$2.50  | Programming Dept. 01 as unit price \$2.50, non taxable, belonging to Group 02. |
|          | Taxable status | Non tax |                                                                                |
|          | Group          | 02      |                                                                                |



### Step

**1** Turn the Mode switch to PGM position. The display shows the top screen of programming.

### Display

```

C01   PGM
[DEPT Setting]
[PLU Setting]
[Key Setting]
[Date Setting]
[Clerk Setting]
[Message Setting]
[POP Setting]
[Tax Setting]
Select & <CA/AMT TEND>
    
```

**2** Using  or  keys, select [DEPT Setting] then press  key. The display shows [DEPT Setting] screen.

```

DEPT Setting
Input DEPT No.
DEPT No.      [      ]
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
    
```

**3** Enter the department number (01 in this example) then press  key. The display shows department selection screen. You can change the department by using  or  keys.

```

DEPT Setting
0001. DEPT001
0002. DEPT002
0003. DEPT003
0004. DEPT004
0005. DEPT005
0006. DEPT006
0007. DEPT007
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
    
```

**4** Press  key. The display shows program input screen. Input unit price and group link you wish to program. The top column is for setting characters to the dept. You can leave the column empty. If you wish to set characters now, please see page E-62.

```

DEPT Setting
0001. [ DEPT0001 ]
Unit Price [      0.00 ]
Taxable Status [ NON TAX ]
Group Link [ 00 ]
High AMT Limit [      0.00 ]
POP No. [ 0 ]
Advanced →go
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
    
```

**5** Select [Taxable Status] and press  key. The display shows taxable status selection screen. Choose the taxable status and press  key.

```


DEPT Setting
Taxable Status
[ NON TAX ]
[ T/S1 ]
[ T/S2 ]
[ T/S3 ]
[ T/S4 ]
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
    
```

**NOTE** The display returns to the previous screen by pressing  key.

# To use the cash register's basic function

## Registering departments' preset data

The following examples explain the operations using preset department data programmed in the previous section.



### ■ Using preset prices

#### Sample Operation

|         |            |        |                                          |
|---------|------------|--------|------------------------------------------|
| Item    | Unit Price | \$2.50 | Unit price \$2.50 is preset in Dept. 02. |
|         | Quantity   | 1      |                                          |
|         | Dept.      | 02     |                                          |
| Payment | Cash       | \$2.50 |                                          |

| Step                                                  | Operation | Printout                                                                        |
|-------------------------------------------------------|-----------|---------------------------------------------------------------------------------|
| <b>1</b> Just press the corresponding Department key. |           | <div>1 DEPT002      \$2.50<br/>TL      <b>\$2.50</b><br/>CASH      \$2.50</div> |
| <b>2</b> Press  key to finalize the transaction.      |           |                                                                                 |

### ■ Using preset tax statuses

#### Sample Operation


|         |            |         |                                                                                                                         |
|---------|------------|---------|-------------------------------------------------------------------------------------------------------------------------|
| Item 1  | Unit Price | \$2.00  |                                                                                                                         |
|         | Quantity   | 5       |                                                                                                                         |
|         | Dept.      | 03      |                                                                                                                         |
|         | Taxable    | 1       |                                                                                                                         |
| Item 2  | Unit Price | \$2.00  | • Dept. 03 presets: Unit price \$2.00, Tax status 1 (4%).<br>• Dept. 04 presets: Unit price \$2.00, Tax status 2 (10%). |
|         | Quantity   | 1       |                                                                                                                         |
|         | Dept.      | 04      |                                                                                                                         |
|         | Taxable    | 2       |                                                                                                                         |
| Payment | Cash       | \$20.00 |                                                                                                                         |

| Step                                                                         | Operation | Printout                                                                                                                                                                                                   |
|------------------------------------------------------------------------------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Register five pieces of Dept. 03 item using the multiplication key. |           | <div>5 DEPT003    T1    \$10.00<br/>1 DEPT004    T2    \$2.00<br/>TA1    \$10.00<br/>TX1    \$0.40<br/>TA2    \$2.00<br/>TX2    \$0.20<br/>TL    <b>\$12.60</b><br/>CASH    \$20.00<br/>CG    \$7.40</div> |
| <b>2</b> Press Dept. 04 key to register one \$2.00 item.                     |           |                                                                                                                                                                                                            |
| <b>3</b> Press  key to indicate the total amount including tax.              |           |                                                                                                                                                                                                            |
| <b>4</b> Enter the tendered amount and press  key.                           |           |                                                                                                                                                                                                            |

# To use the cash register's basic function

## Programming PLUs

Like departments, you can program unit price, taxable status, and linking item group in a PLU (Price Look Up). Using PLUs allow you to register items quickly and accurately. You can use up to 3,000 PLUs.



### Sample Operation

|          |                |         |                                                                                |
|----------|----------------|---------|--------------------------------------------------------------------------------|
| PLU 0014 | Unit Price     | \$2.50  | Programming PLU 0014 as unit price \$2.50, non taxable, belonging to Group 03. |
|          | Taxable status | Non tax |                                                                                |
|          | Group          | 03      |                                                                                |

### Step

**1** Turn the Mode switch to PGM position. The display shows the top screen of programming.

```
C01    PGM
[DEPT Setting]
[PLU Setting]
[Key Setting]
[Date Setting]
[Clerk Setting]
[Message Setting]
[POP Setting]
[Tax Setting]
Select & <CA/AMT TEND>
```

**2** Using or keys, select [PLU Setting] then press key. The display shows [PLU Setting] screen.

```
PLU Setting
Input PLU No.
      PLU No.  [      ]
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

**3** Enter the PLU number (0014 in this example) then press key. The display shows [PLU Setting] screen. You can change the PLU number by using or keys.

```
PLU Setting
0014. PLU0014
0014. PLU0015
0016. PLU0016
0017. PLU0017
0018. PLU0018
0019. PLU0019
0020. PLU0020
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

**4** Press key. The display shows program input screen. Input unit price and group link you wish to program. The top column is for setting characters to the PLU. You can leave the column empty. If you wish to set characters now, please see page E-62.

```
PLU Setting
0014. [ PLU0014 ]
Unit Price  [      0.00 ]
Taxable Status [ NON TAX ]
Group Link   [ 00 ]
DEPT Link    [ 000 ]
Open PLU     [ NO ]
Advanced     →go
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

**5** Select [Taxable Status] and press key. The display shows taxable status selection screen. Choose the taxable status and press key.


```
PLU Setting
Taxable Status
      [ NON TAX ]
      [ T/S1 ]
      [ T/S2 ]
      [ T/S3 ]
      [ T/S4 ]
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

**NOTE** The display returns to the previous screen by pressing key.

# To use the cash register's basic function

## Registering PLUs' preset data

The following examples explain the operations using preset PLU data programmed in the previous section.



### ■ Single item sales using PLU

#### Sample Operation

|         |            |        |                                                                |
|---------|------------|--------|----------------------------------------------------------------|
| Item    | Unit Price | \$2.50 | One piece of PLU number 14 (preset unit price \$2.50) is sold. |
|         | Quantity   | 1      |                                                                |
|         | PLU No.    | 14     |                                                                |
| Payment | Cash       | \$3.00 |                                                                |

| Step                                                                                                                                                                                                                                                                                  | Operation                                                                                                                                                                                                                                                                                                                                  | Printout                                                                                                                               |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the PLU number and press  key. One piece of PLU number 14 item has been registered. Then press  key. |   <br> | <div>1 PLU0014            \$2.50<br/>TL                    \$2.50<br/>CASH                \$3.00<br/>CG                   \$0.50</div> |
| <b>2</b> Enter tendered amount and press  key.                                                                                                                                                       |                                                                                         |                                                                                                                                        |

### ■ PLU repeat registration

#### Sample Operation

|         |            |         |                                                                   |
|---------|------------|---------|-------------------------------------------------------------------|
| Item    | Unit Price | \$2.50  | Three pieces of PLU number 14 (preset unit price \$2.50) is sold. |
|         | Quantity   | 3       |                                                                   |
|         | PLU No.    | 14      |                                                                   |
| Payment | Cash       | \$10.00 |                                                                   |

| Step                                                                                                                                                                                                                                                                                                | Operation                                                                                                                                                                                                                                                                                                                                          | Printout                                                                                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the PLU number.                                                                                                                                                                                                                                                                      |                                                                                                                                                                              | <div>1 PLU0014            \$2.50<br/>1 PLU0014            \$2.50<br/>1 PLU0014            \$2.50<br/>TL                    \$7.50<br/>CASH                \$10.00<br/>CG                   \$2.50</div> |
| <b>2</b> Press  key repeatedly for the number of sold quantity. Three pieces of PLU 14 have been registered. Then press  key. |   <br> |                                                                                                                                                                                                         |
| <b>3</b> Enter the tendered amount and press  key.                                                                                                                                                               |        |                                                                                                                                                                                                         |
|                                                                                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                         |

# To use the cash register's basic function

## ■ PLU registration with multiplication key

### Sample Operation

|         |            |         |                                                                      |
|---------|------------|---------|----------------------------------------------------------------------|
| Item    | Unit Price | \$2.00  | Ten pieces of PLU number 7 item (preset unit price \$2.00) are sold. |
|         | Quantity   | 10      |                                                                      |
|         | PLU No.    | 7       |                                                                      |
| Payment | Cash       | \$20.00 |                                                                      |

| Step                                                                                                                                                                                                                                | Operation                                                                                                                                                                       | Printout                                                                                                                         |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the quantity sold then press  key.<br>Up to 9999.999 can be entered for multiplication calculations.                                | <b>1 0</b>                                                                                     | <div>           10 PLU0007 \$20.00<br/>           TL \$20.00<br/>           CASH \$20.00<br/>           CG \$0.00         </div> |
| <b>2</b> Enter the PLU number and press  key.<br>Then press  key. | <b>7</b> <br> |                                                                                                                                  |
| <b>3</b> Enter tendered amount and press  key.                                                                                                     | <b>2 0 00</b>                                                                                  |                                                                                                                                  |

## ■ Split sales of packaged PLU item

### Sample Operation

|         |            |            |                                                                         |
|---------|------------|------------|-------------------------------------------------------------------------|
| Item    | Unit Price | 5 for \$20 | Selling three pieces of an item that is priced \$20.00 for five pieces. |
|         | Quantity   | 3          |                                                                         |
|         | PLU No.    | 28         |                                                                         |
| Payment | Cash       | \$15.00    |                                                                         |

| Step                                                                                                                                                                                                                                                | Operation                                                                                                                                                                             | Printout                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the quantity being purchased and press  key for multiplication calculation. You can enter up to 9999.999 for multiplication calculations.         | <b>3</b>                                                                                           | <div>           3 PLU0028 \$12.00<br/>           TL \$12.00<br/>           CASH \$15.00<br/>           CG \$3.00         </div> |
| <b>2</b> Enter the packaged quantity and press  key. You can enter up to 9999.999 for packaged quantity.                                                         | <b>5</b>                                                                                           |                                                                                                                                 |
| <b>3</b> Enter the PLU number of the item and press  key.<br>Then press  key. | <b>2 8</b> <br> |                                                                                                                                 |
| <b>4</b> Enter the tendered amount and press  key.                                                                                                               | <b>1 5 00</b>                                                                                      |                                                                                                                                 |

# To use the cash register's basic function

## ■ Open PLU

Although unit price is preset in a PLU, you can enter price manually if the PLU is programmed as "Open PLU". To program open PLU, see page E-32.

### Sample Operation

|         |            |         |                                                                                                   |
|---------|------------|---------|---------------------------------------------------------------------------------------------------|
| Item 1  | Unit Price | \$32.80 | PLU numbers 30 and 31 are programmed as open PLU so that the unit prices can be entered manually. |
|         | Quantity   | 1       |                                                                                                   |
|         | PLU No.    | 30      |                                                                                                   |
| Item 2  | Unit Price | \$13.00 |                                                                                                   |
|         | Quantity   | 2       |                                                                                                   |
|         | PLU No.    | 31      |                                                                                                   |
| Payment | Cash       | \$60.00 |                                                                                                   |


| Step                                                                                                                                                                                                                                                      | Operation                                                                                                                                                                                                                                                                                                                                                                                                                 | Printout                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the PLU number of the first item then press  key.                                                                                                         |                                                                                                                                                                        | <div> 1 PLU0030 \$32.80<br/> 1 PLU0031 \$13.00<br/> 1 PLU0031 \$13.00<br/> TL \$58.80<br/> CASH \$60.00<br/> CG \$1.20 </div> |
| <b>2</b> Enter the unit price and press  key.                                                                                                                            |      |                                                                                                                               |
| <b>3</b> Enter the PLU number of the second item then press  key.                                                                                                        |                                                                                                                                                                        |                                                                                                                               |
| <b>4</b> Enter the unit price.                                                                                                                                                                                                                            |                                                                                                                                                                     |                                                                                                                               |
| <b>5</b> Press  key repeatedly for the number of purchased quantity and press  key. |                                                                                                                                                                  |                                                                                                                               |
| <b>6</b> Enter the tendered amount and press  key.                                                                                                                     |                                                                               |                                                                                                                               |

# To use the cash register's basic function

## Other registrations

### Discount

The following example shows how you can use the  key for discount registrations.



### ■ Discounts on items and subtotals

#### Sample Operation

|                   |          |                                                                                                   |                                                                                                                                                                                                                  |
|-------------------|----------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item 1            | Dept. 01 | \$5.00                                                                                            | Five percent (preset in  key) discount on PLU number 16 (preset unit price \$10.00) and discount 3.5% on the subtotal amount. |
|                   | Quantity | 1                                                                                                 |                                                                                                                                                                                                                  |
|                   | Taxable  | 1 (preset)                                                                                        |                                                                                                                                                                                                                  |
| Item 2            | PLU 16   | \$10.00 (preset)                                                                                  |                                                                                                                                                                                                                  |
|                   | Quantity | 1                                                                                                 |                                                                                                                                                                                                                  |
|                   | Taxable  | 2 (preset)                                                                                        |                                                                                                                                                                                                                  |
| Discount          | Rate     | 5% (preset in  ) |                                                                                                                                                                                                                  |
| Subtotal discount | Rate     | 3.5%                                                                                              |                                                                                                                                                                                                                  |
|                   | Taxable  | Non taxable (preset)                                                                              |                                                                                                                                                                                                                  |
| Payment           | Cash     | \$15.00                                                                                           |                                                                                                                                                                                                                  |

| Step                                                                                                                                                                                                             | Operation                                                                                                                                                                                                                                                                                                                                       | Printout                                                                                                                                                                                                                                                                        |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Enter the unit price and corresponding department key.                                                                                                                                                         |                                                                                        | <pre> 1 DEPT001   T1   \$5.00 1 PLU0016   T2   \$10.00 5% %-          T2   -0.50 SUBTOTAL    \$14.50 3.5% %-          -0.51 TA1          \$5.00 TX1          \$0.20 TA2          \$9.50 TX2          \$0.48 TL           \$14.67 CASH        \$15.00 CG           \$0.33 </pre> |
| 2 Enter the PLU number then press  key. The preset unit price (\$10.00) is registered.                                        |                                                                                        |                                                                                                                                                                                                                                                                                 |
| 3 Press  key. The discount amount with the preset rate (5%) is subtracted from the last item registered (PLU 16).             |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                 |
| 4 Press  key for giving discount on the subtotal amount.                                                                      |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                 |
| 5 Enter the discount rate manually and press  key. Discount amount with inputted rate is subtracted from the subtotal amount. |     |                                                                                                                                                                                                                                                                                 |
| 6 Press  key to show the total amount including tax and discounts.                                                            |                                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                 |
| 7 Enter the tendered amount and press  key.                                                                                   |     |                                                                                                                                                                                                                                                                                 |

Printout differs depending on preset tax statuses.

#### NOTE


- When you perform a discount operation on the last item registered, the tax of discount amount is calculated in accordance with the tax status programmed to the item.
- When you perform a discount operation on a subtotal amount, the tax of discount amount from subtotal is calculated in accordance with the tax status programmed in the  key.
- To program discount rate in  key, please see page E-33.



# To use the cash register's basic function

## Reduction

Using the reduction feature, you can subtract a certain amount from an item's unit price or from a subtotal amount.



### Sample Operation

|          |           |                      |                                                                                                                                                                                                                              |
|----------|-----------|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item 1   | Dept. 01  | \$5.00               | <ul style="list-style-type: none"> <li>Reducing \$0.25 (manual input) from item 1 unit price.</li> <li>Reducing \$0.50 (preset amount) from item 2.</li> <li>Reducing \$0.75 (manual input) from subtotal amount.</li> </ul> |
|          | Quantity  | 1                    |                                                                                                                                                                                                                              |
|          | Taxable   | 1 (preset)           |                                                                                                                                                                                                                              |
|          | Reduction | \$0.25               |                                                                                                                                                                                                                              |
| Item 2   | PLU 45    | \$6.00 (preset)      |                                                                                                                                                                                                                              |
|          | Quantity  | 1                    |                                                                                                                                                                                                                              |
|          | Taxable   | 1 (preset)           |                                                                                                                                                                                                                              |
|          | Reduction | \$0.50 (preset)      |                                                                                                                                                                                                                              |
| Subtotal | Reduction | \$0.75               |                                                                                                                                                                                                                              |
|          | Taxable   | Non taxable (preset) |                                                                                                                                                                                                                              |
| Payment  | Cash      | \$10.00              |                                                                                                                                                                                                                              |

| Step                                                                                                                                                        | Operation                        | Printout                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Register item 1 by inputting the unit price and department key.                                                                                           | <b>5 0 0</b> <b>1</b>            | <pre> 1 DEPT001   T1   \$5.00 -           T1   -0.25 1 PLU0045   T1   \$6.00 -           T1   -0.50 -           T1   -0.75 TA1          \$10.25 TX1          \$0.41 TL           \$9.91 CASH         \$10.00 CG           \$0.09                     </pre> |
| 2 Enter reduction amount manually and press <b>-</b> key. \$0.25 is subtracted from the unit price.                                                         | <b>2 5</b> <b>-</b>              |                                                                                                                                                                                                                                                             |
| 3 Register item 2 by inputting the PLU number and <b>PLU/S.DEPT</b> key.                                                                                    | <b>4 5</b> <b>PLU/S.DEPT</b>     |                                                                                                                                                                                                                                                             |
| 4 Press <b>-</b> key. Pressing <b>-</b> key without numeral entry subtracts the preset reduction amount (\$0.50 in this example) from the PLU's unit price. | <b>-</b>                         |                                                                                                                                                                                                                                                             |
| 5 Press <b>SUB TOTAL</b> key for reducing amount from the subtotal.                                                                                         | <b>SUB TOTAL</b>                 |                                                                                                                                                                                                                                                             |
| 6 Enter reduction amount manually then press <b>-</b> key. The inputted amount is subtracted from the subtotal amount.                                      | <b>7 5</b> <b>-</b>              |                                                                                                                                                                                                                                                             |
| 7 Enter the tendered amount then press <b>CA/AMT/TEND</b> key.                                                                                              | <b>1 0 00</b> <b>CA/AMT/TEND</b> |                                                                                                                                                                                                                                                             |

Printout differs depending on preset tax statuses.


### NOTE

- You can input up to seven digits reduction amount manually.
- To program preset reduction amount, please see page E-33.

# To use the cash register's basic function

## Registering various payment methods

Other than cash payments, you can register transactions made by checks, charges, credits, or even mixed tendering.



### ■ Check sale

#### Sample Operation

|                        |            |         |                                                                                |
|------------------------|------------|---------|--------------------------------------------------------------------------------|
| Item                   | Unit Price | \$11.00 | A \$11.00 item is sold and customer paid by \$20.00 check (check number 1234). |
|                        | Quantity   | 1       |                                                                                |
| Reference no. of check |            | 1234    |                                                                                |
| Payment                | Check      | \$20.00 |                                                                                |

| Step                                                                                                                        | Operation                                              | Printout                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|------------------------------------------------------------------------------------------------|
| <b>1</b> Register the item purchased.                                                                                       | <b>1</b> <b>1</b> <b>00</b> <b>1</b>                   | <div>1 DEPT001 \$11.00<br/># 1234<br/>TL <b>\$ 11.00</b><br/>CHECK \$20.00<br/>CG \$9.00</div> |
| <b>2</b> If you wish to record reference number such as a check number, enter the number then press <b>#</b> <b>NS</b> key. | <b>1</b> <b>2</b> <b>3</b> <b>4</b> <b>#</b> <b>NS</b> |                                                                                                |
| <b>3</b> Enter the paid amount then press <b>CHK</b> key.                                                                   | <b>2</b> <b>0</b> <b>00</b> <b>CHK</b>                 |                                                                                                |

### ■ Charge sale

#### Sample Operation

|         |          |         |                                                |
|---------|----------|---------|------------------------------------------------|
| Item    | Dept. 04 | \$15.00 | A purchased item is transacted by charge sale. |
|         | Quantity | 1       |                                                |
| Payment | Charge   | \$15.00 |                                                |

| Step                                                                 | Operation                                             | Printout                                                               |
|----------------------------------------------------------------------|-------------------------------------------------------|------------------------------------------------------------------------|
| <b>1</b> Register the item purchased and press <b>SUB TOTAL</b> key. | <b>1</b> <b>5</b> <b>00</b> <b>4</b> <b>SUB TOTAL</b> | <div>1 DEPT004 \$15.00<br/>TL <b>\$ 15.00</b><br/>CHARGE \$15.00</div> |
| <b>2</b> Press <b>CH</b> key to finalize the charge transaction.     | <b>CH</b>                                             |                                                                        |

# To use the cash register's basic function

## ■ Credit sale

### Sample Operation

|         |          |         |                                            |
|---------|----------|---------|--------------------------------------------|
| Item    | Dept. 03 | \$10.00 | A purchased item is paid by a credit card. |
|         | Quantity | 1       |                                            |
| Payment | Credit   | \$10.00 |                                            |

| Step                                                                                                                                  | Operation                                                                                                                                                                                                                                                                                                                                                                                                                 | Printout                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| <b>1</b> Register the item purchased and press  key. |      | <div> 1 DEPT003 \$10.00<br/> TL <b>\$10.00</b><br/> CREDIT \$10.00 </div> |
| <b>2</b> Press  key to finalize the transaction.     |                                                                                                                                                                                                                                                                                                                                          |                                                                           |

## ■ Mixed payments (cash and check)

### Sample Operation

|         |          |         |                                                                       |
|---------|----------|---------|-----------------------------------------------------------------------|
| Item    | Dept. 04 | \$55.00 | Customer paid \$30.00 by check and the rest in cash for \$55.00 item. |
|         | Quantity | 1       |                                                                       |
| Payment | Check    | \$30.00 |                                                                       |
|         | Cash     | \$25.00 |                                                                       |


| Step                                                                                                                                          | Operation                                                                                                                                                                                                                                                                                                                                                                                                                           | Printout                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <b>1</b> Register the item purchased and press  key.       |      | <div> 1 DEPT004 \$55.00<br/> TL <b>\$55.00</b><br/> CHECK \$30.00<br/> CASH \$25.00<br/> CG \$0.00 </div> |
| <b>2</b> Enter the amount paid by a check then press  key. |                                                                                         |                                                                                                           |
| <b>3</b> Enter the paid cash amount then press  key.       |                                                                                         |                                                                                                           |

# To use the cash register's basic function

## Tax shift

By using **T/S1** or **T/S2** keys, you can change the taxable status.

The **T/S1** key switches on and off of programmed taxable status 1 and **T/S2** key changes the taxable status 2. The following table explains how tax statuses change by **T/S1** or **T/S2** key.



|              |             |                    |              |             |                    |
|--------------|-------------|--------------------|--------------|-------------|--------------------|
| Non tax      | <b>T/S1</b> | ➡ Tax status 1     | Non tax      | <b>T/S2</b> | ➡ Tax status 2     |
| Tax status 1 | <b>T/S1</b> | ➡ Non-tax          | Tax status 1 | <b>T/S2</b> | ➡ Tax status 1 & 2 |
| Tax status 2 | <b>T/S1</b> | ➡ Tax status 1 & 2 | Tax status 2 | <b>T/S2</b> | ➡ Non-tax          |

## Sample Operation

|         |          |                                  |                                                                                                                                                                                                                                                                                                                                                         |
|---------|----------|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item 1  | Dept. 01 | \$2.00                           | <ul style="list-style-type: none"> <li>Item 1 is shifted from non-taxable to tax status 1 by <b>T/S1</b> key.</li> <li>Item 2 is shifted from tax status 1 to tax status 1 &amp; 2 by <b>T/S2</b> key.</li> <li>Item 3 is shifted from tax status 2 to non-taxable by <b>T/S2</b> key.</li> <li>Preset tax rates : Tax 1 = 4%<br/>Tax 2 = 5%</li> </ul> |
|         | Quantity | 1                                |                                                                                                                                                                                                                                                                                                                                                         |
|         | Taxable  | Non tax (preset) to tax status 1 |                                                                                                                                                                                                                                                                                                                                                         |
| Item 2  | Dept. 02 | \$6.00                           |                                                                                                                                                                                                                                                                                                                                                         |
|         | Quantity | 1                                |                                                                                                                                                                                                                                                                                                                                                         |
|         | Taxable  | Tax status 1 (preset) to 1 & 2   |                                                                                                                                                                                                                                                                                                                                                         |
| Item 3  | Dept. 03 | \$7.00                           |                                                                                                                                                                                                                                                                                                                                                         |
|         | Quantity | 1                                |                                                                                                                                                                                                                                                                                                                                                         |
|         | Taxable  | Tax status 2 (preset) to non-tax |                                                                                                                                                                                                                                                                                                                                                         |
| Payment | Cash     | \$30.00                          |                                                                                                                                                                                                                                                                                                                                                         |

| Step                                                                                                                            | Operation                            | Printout                                                                                                                                                                                                                                                                                                     |
|---------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Press <b>T/S1</b> then register item 1. The tax status of the item 1 is changed from non-taxable to tax status 1.      | <b>T/S1</b> <b>2 00 1</b>            | <pre> 1 DEPT001    T 1    \$2.00 1 DEPT002    T 12   \$6.00 1 DEPT003                \$7.00 TA1                \$8.00 TX1                \$0.32 TA2                \$6.00 TX2                \$0.30 TL              \$15.62 CASH                \$20.00 CG                 \$4.38                     </pre> |
| <b>2</b> Press <b>T/S2</b> then register item 2. The tax status of the item 2 is changed from tax status 1 to tax status 1 & 2. | <b>T/S2</b> <b>6 00 2</b>            |                                                                                                                                                                                                                                                                                                              |
| <b>3</b> Press <b>T/S2</b> then register item 3. The tax status of the item 3 is changed from tax status 2 to non-taxable.      | <b>T/S2</b> <b>7 00 3</b>            |                                                                                                                                                                                                                                                                                                              |
| <b>4</b> Press <b>SUB TOTAL</b> key to indicate the total amount including tax.                                                 | <b>SUB TOTAL</b>                     |                                                                                                                                                                                                                                                                                                              |
| <b>5</b> Enter tendered amount and press <b>CA / AMT / TEND</b> to finalize the transaction.                                    | <b>2 0 00</b> <b>CA / AMT / TEND</b> |                                                                                                                                                                                                                                                                                                              |

### NOTE


- To change the tax status of the next item to be registered, be sure to press **T/S1**, **T/S2**.
- If the last item registered is programmed as non-taxable, a discount (**%-** key) operation on this item is always non-taxable. In this case, you cannot manually change the tax status to taxable 1 or 2 by pressing **T/S1**, **T/S2** keys.

# To use the cash register's basic function

## Registering returned goods

### ■ Registering returned goods in the REG mode

The following example shows how to operate for registering goods returned by customer in the REG mode.



### Sample Operation


|                 |          |                 |                                                          |
|-----------------|----------|-----------------|----------------------------------------------------------|
| Item 1          | Dept. 01 | \$2.35          | Customer returned items 1 and 3 during the registration. |
|                 | Quantity | 1               |                                                          |
| Item 2          | Dept. 02 | \$2.00          |                                                          |
|                 | Quantity | 1               |                                                          |
| Item 3          | PLU 001  | \$1.20 (preset) |                                                          |
|                 | Quantity | 1               |                                                          |
| Refunded Item 1 | Dept. 01 | \$2.35          |                                                          |
|                 | Quantity | 1               |                                                          |
| Refunded Item 3 | PLU 0001 | \$1.20 (preset) |                                                          |
|                 | Quantity | 1               |                                                          |
| Payment         | Cash     | \$2.00          |                                                          |

| Step                                                                                    | Operation                                              | Printout                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Register purchased item 1.                                                            | <b>2</b> <b>3</b> <b>5</b> <b>1</b>                    | <pre> 1 DEPT001      \$2.35 1 DEPT002      \$2.00 1 PLU0001      \$1.20 RF              ..... 1 DEPT001      -2.35 RF              ..... 1 PLU0001      -1.20 TL              \$2.00 CASH           \$2.00 </pre> |
| 2 Register purchased item 2.                                                            | <b>2</b> <b>00</b> <b>2</b>                            |                                                                                                                                                                                                                   |
| 3 Register purchased item 3.                                                            | <b>1</b> <b>PLU/ S.DEPT</b>                            |                                                                                                                                                                                                                   |
| 4 Press <b>RF</b> key prior to registering returned item 1.                             | <b>RF</b>                                              |                                                                                                                                                                                                                   |
| 5 Register returned item 1.                                                             | <b>2</b> <b>3</b> <b>5</b> <b>1</b>                    |                                                                                                                                                                                                                   |
| 6 Press <b>RF</b> key and register returned item 3.<br>Then press <b>SUB TOTAL</b> key. | <b>RF</b> <b>1</b> <b>PLU/ S.DEPT</b> <b>SUB TOTAL</b> |                                                                                                                                                                                                                   |
| 7 Press <b>CA / AMT / TEND</b> key as the customer paid exact amount.                   | <b>CA / AMT / TEND</b>                                 |                                                                                                                                                                                                                   |

# To use the cash register's basic function


## ■ Registering returned goods in the RF mode

When a customer returns goods after the transaction has been completed, use RF mode for the refund operation.



### Sample Operation

|                 |            |                 |                                                                                                                           |
|-----------------|------------|-----------------|---------------------------------------------------------------------------------------------------------------------------|
| Refunded Item 1 | Dept. 03   | \$4.00          | A customer returned two items. Item 1 was sold with \$0.15 reduction and item 2 was sold with pre-programmed 5% discount. |
|                 | Quantity   | 1               |                                                                                                                           |
|                 | Reduced    | \$0.15          |                                                                                                                           |
| Refunded Item 2 | PLU 002    | \$1.20 (preset) |                                                                                                                           |
|                 | Quantity   | 1               |                                                                                                                           |
|                 | Discounted | 5% (preset)     |                                                                                                                           |
| Payment         | Cash       | \$4.99          |                                                                                                                           |

| Step                                                                                                                                                                         | Operation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Printout                                                                             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| 1 Turn the Mode switch to RF position.                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                      |
| 2 Register the returned items by the same operations as normal registration and press  key. | <br><br><br><br><br> |  |
| 3 Press  key and pay the total amount back to the customer.                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                      |


### Important

- After the refund operation, please do not forget to return the Mode switch to REG position otherwise the following registrations are stored as minus transactions.

# To use the cash register's basic function

## Registrations without transactions

The followings are the operations other than normal sales transactions. Please do not perform these operations during a sales transaction.



### ■ Registering money received on account

Use this operation when you put money in the drawer without any sales transactions such case as preparing change.

#### Sample Operation

|                 |         |                                                                     |
|-----------------|---------|---------------------------------------------------------------------|
| Received amount | \$70.00 | Prepared \$70.00 in the drawer for change before opening the store. |
|-----------------|---------|---------------------------------------------------------------------|

| Step                                                               | Operation                                             | Printout                         |
|--------------------------------------------------------------------|-------------------------------------------------------|----------------------------------|
| 1 Enter the amount put in the drawer then press <div>RA</div> key. | <div>7</div> <div>0</div> <div>00</div> <div>RA</div> | <div>RA</div> <div>\$70.00</div> |

### ■ Registering money paid out from the drawer

Use this operation when you withdraw money from the drawer without any sales transactions such case as paying for a cash-on-delivery item.

#### Sample Operation

|                 |        |                                |
|-----------------|--------|--------------------------------|
| Paid out amount | \$1.50 | Paying \$1.50 from the drawer. |
|-----------------|--------|--------------------------------|

| Step                                                                         | Operation                                                    | Printout                                  |
|------------------------------------------------------------------------------|--------------------------------------------------------------|-------------------------------------------|
| 1 Enter the amount withdrawn from the drawer then press <span>PO</span> key. | <span>1</span> <span>5</span> <span>0</span> <span>PO</span> | <div><div>P0</div><div>\$1.50</div></div> |

### ■ Opening the drawer without putting money in or out

Use this operation to open the drawer without putting money in or out. The number of  key operations will be printed on X or Z reports.

If you enter numbers prior to  key, the number will be printed on the receipt or journal.


| Step                                                                                                                    | Operation                                                                           | Printout                                            |      |       |
|-------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-----------------------------------------------------|------|-------|
| 1 Just press  key. The drawer opens. |  | <table><tr><td>#/NS</td><td>.....</td></tr></table> | #/NS | ..... |
| #/NS                                                                                                                    | .....                                                                               |                                                     |      |       |

# To use the cash register's basic function

## Corrections

There are three ways to correct erroneous operations that are;

- Correcting erroneous item not registered
- Correcting erroneous item already registered
- Cancelling all the items registered in a transaction



### ■ Correcting erroneously entered item not registered

| Step                                                                                                                              | Operation                                                                                                  | Printout                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Correcting wrong unit price \$2.00 to \$1.00.                                                                            | <div>2 00</div> <div>C</div> <div>1 00 1</div>                                                             | <div> 1 DEPT001 \$1.00<br/> 11 DEPT002 \$22.00<br/> 1 PLU0003 \$1.30<br/> 1 PLU0015 \$10.00<br/> TL <b>\$34.30</b><br/> CASH \$15.00<br/> CHECK \$19.30 </div> |
| <b>2</b> Correcting wrong quantity 12 to 11.                                                                                      | <div>1 2 X / FOR DATE TIME</div> <div>C</div> <div>1 1 X / FOR DATE TIME</div> <div>2 00 2</div>           |                                                                                                                                                                |
| <b>3</b> Correcting wrong PLU number 002 to 003.                                                                                  | <div>2</div> <div>C</div> <div>3 PLU/ S.DEPT</div>                                                         |                                                                                                                                                                |
| <b>4</b> Correcting open PLU unit price \$6.00 to \$10.00. You must re-enter the PLU number prior to entering correct unit price. | <div>1 5 PLU/ S.DEPT</div> <div>6 00</div> <div>C</div> <div>1 5 PLU/ S.DEPT</div> <div>1 0 00 PRICE</div> |                                                                                                                                                                |
| <b>5</b> Correcting wrong partially tendered cash amount \$10.00 to \$15.00.                                                      | <div>1 0 00</div> <div>C</div> <div>1 5 00 CA / AMT / TEND</div>                                           |                                                                                                                                                                |
| <b>6</b> The remaining amount is paid by check.                                                                                   | <div>CH</div>                                                                                              |                                                                                                                                                                |



# To use the cash register's basic function

## ■ Correcting items immediately after the registration

| Step                                                                                                                                                      | Operation                                                                                                                                                                          | Printout                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>1</b> Registering an item.                                                                                                                             | <b>1</b> <b>00</b> <b>1</b>                                                                                                                                                        |                                                                                                              |
| <b>2</b> By mistake, Dept. key has been pressed twice so cancelling the preceding registration by <b>ERR CORR CANCEL</b> key.                             | <b>2</b> <b>00</b> <b>2</b> <b>2</b><br><b>ERR CORR CANCEL</b>                                                                                                                     | 1 DEPT001 \$1.00<br>1 DEPT002 \$2.00<br>1 DEPT002 \$2.00<br>CORR -2.00                                       |
| <b>3</b> Cancelling wrong PLU registration (PLU No. 2) and re-registering correct PLU (PLU No. 5).                                                        | <b>2</b> <b>PLU/ S.DEPT</b> <b>ERR CORR CANCEL</b><br><b>5</b> <b>PLU/ S.DEPT</b>                                                                                                  | 1 PLU0002 \$2.00<br>CORR -2.00<br>1 PLU0005 \$1.50<br>1 PLU0015 \$6.00                                       |
| <b>4</b> Cancelling a registration of an open PLU's (PLU No. 15) wrong unit price \$6.00 and re-registering the item with the correct unit price \$10.00. | <b>1</b> <b>5</b> <b>PLU/ S.DEPT</b><br><b>6</b> <b>00</b> <b>PRICE</b> <b>ERR CORR CANCEL</b><br><b>1</b> <b>5</b> <b>PLU/ S.DEPT</b><br><b>1</b> <b>0</b> <b>00</b> <b>PRICE</b> | CORR -6.00<br>1 PLU0015 \$10.00<br>8 DEPT004 \$32.00<br>CORR -32.00<br>6 DEPT004 \$24.00<br>SUBTOTAL \$38.50 |
| <b>5</b> Cancelling a registration of an item with wrong quantity (8 pieces) and re-registering the item with the correct quantity (6 pieces).            | <b>8</b> <b>X / FOR / DATE TIME</b><br><b>4</b> <b>00</b> <b>4</b> <b>ERR CORR CANCEL</b><br><b>6</b> <b>X / FOR / DATE TIME</b><br><b>4</b> <b>00</b> <b>4</b>                    | 50%<br>%- -19.25<br>CORR \$19.25<br>SUBTOTAL \$38.50<br>5%<br>%- -1.93                                       |
| <b>6</b> Cancelling wrong subtotal discount calculation (with rate of 50%) and re-calculating the discount amount with the correct rate (5%).             | <b>SUB TOTAL</b><br><b>5</b> <b>0</b> <b>%-</b><br><b>ERR CORR CANCEL</b> <b>SUB TOTAL</b><br><b>5</b> <b>%-</b>                                                                   | RF .....<br>1 DEPT002 -2.00<br>CORR \$2.00<br>RF .....<br>1 DEPT002 -2.20<br>TL <b>\$34.37</b>               |
| <b>7</b> Cancelling wrong refund amount (\$2.00) and re-registering correct amount (\$2.20).                                                              | <b>RF</b> <b>2</b> <b>00</b> <b>2</b><br><b>ERR CORR CANCEL</b><br><b>RF</b> <b>2</b> <b>2</b> <b>0</b> <b>2</b>                                                                   | CASH \$20.00<br>CORR -20.00<br>CASH \$15.00<br>CHECK \$19.37                                                 |
| <b>8</b> Getting the subtotal amount.                                                                                                                     | <b>SUB TOTAL</b>                                                                                                                                                                   |                                                                                                              |
| <b>9</b> Cancelling partially tendered cash amount (\$20.00) and re-registering correct amount (\$15.00).                                                 | <b>2</b> <b>0</b> <b>00</b> <b>CA / AMT / TEND</b><br><b>ERR CORR CANCEL</b><br><b>1</b> <b>5</b> <b>00</b> <b>CA / AMT / TEND</b>                                                 |                                                                                                              |
| <b>10</b> The customer paid the balance due by check.                                                                                                     | <b>CHK</b>                                                                                                                                                                         |                                                                                                              |

Corrected items are not printed on receipt if programmed as "Buffered receipt printing".  
See page E-72 "Set code 05".

# To use the cash register's basic function

## ■ Voiding an item which has been already registered

### Step

**1** During a registration.

**2** Using  or  keys, select the item you have mis-registered.

**3** Press  key. The selected item is voided.

### Display

| C01      | REG     | 000011  |
|----------|---------|---------|
| 3        | DEPT001 | \$6.00  |
| 1        | PLU002  | \$2.00  |
| 3        | DEPT002 | \$9.00  |
| 2        | PLU003  | \$4.00  |
| 1        | DEPT003 | \$2.00  |
| SUBTOTAL |         | \$24.00 |
| QT       | 11      | 0.00    |

| REVIEW / VOID                                   |                |
|-------------------------------------------------|----------------|
| 1                                               | PLU001 \$1.00  |
| 3                                               | DEPT001 \$6.00 |
| 1                                               | PLU002 \$2.00  |
| 3                                               | DEPT002 \$9.00 |
| 2                                               | PLU003 \$4.00  |
| 1                                               | DEPT003 \$2.00 |
| Select & <CA/AMT TEND> or<br>CANCEL:<SUB TOTAL> |                |
| 0.00                                            |                |

| C01      | REG     | 000011  |
|----------|---------|---------|
| 2        | PLU003  | \$4.00  |
| 1        | DEPT003 | \$2.00  |
| 1        | DEPT003 | \$2.00  |
| SUBTOTAL |         | \$22.00 |
| QT       | 10      | 0.00    |

# To use the cash register's basic function

## ■ Cancelling all items in a transaction

### Step

**1** Press  key after items have been registered then press  key.

**2** Select [YES] on the pop up display.

**3** Press  key. The registered items are cancelled.

### Display

| C01      | REG     | 000011  |
|----------|---------|---------|
| 3        | DEPT001 | \$6.00  |
| 1        | PLU002  | \$2.00  |
| 3        | DEPT002 | \$9.00  |
| 2        | PLU003  | \$4.00  |
| 1        | DEPT003 | \$2.00  |
| SUBTOTAL |         | \$24.00 |
| QT       | 11      | 0.00    |


| C01              | 000011         |
|------------------|----------------|
| CANCEL OPEARTION |                |
| Please select    |                |
| Yes              | :<CA/AMT TEND> |
| No               | :<C>           |
| ST               |                |
| \$24.00          |                |
| QT               | 11 0.00        |

| C01      | REG     | 000011 |
|----------|---------|--------|
| 1        | PLU002  | \$2.00 |
| 3        | DEPT002 | \$9.00 |
| 2        | PLU003  | \$4.00 |
| 1        | DEPT003 | \$2.00 |
| CANCEL   |         | .....  |
| SUBTOTAL |         | \$0.00 |
| CANCEL   |         | 0.00   |

# To use the cash register's basic function

## Daily sales reports

At the end of the business day, you can print categorized and summarized results of the day. Reset report (Z) clears all the sales data whereas the data remains in memory by Read report (X).



**NOTE** Please do not perform the Reset report (Z) printing while your store is open. It clears all the sales data.

### Step

- 1 Turn the Mode switch to X or Z position. The display shows top display of sales reports.

### Display

|                          |   |        |
|--------------------------|---|--------|
| C01                      | Z | 000011 |
| [DAILY Z ]               |   |        |
| [PLU ]                   |   |        |
| [GROUP ]                 |   |        |
| [HOURLY ]                |   |        |
| [MONTHLY ]               |   |        |
| [OPEN CHK ]              |   |        |
| [EJ ]                    |   |        |
| Select and <CA/AMT TEND> |   |        |
|                          |   | 0.00   |

- 2 Select [DAILY Z] (DAILY X when you set the Mode switch to X) and press  key. The printer prints a sales report.

### Further operations:

- For individual reports, please see page E-97.

# To use the cash register's basic function

## Print out of daily sales report

|         |            |            |    |
|---------|------------|------------|----|
| Z       | 20-06-2018 | 17:00      | 1  |
|         | 0001       | 000231     | 2  |
| Z       | DAILY Z    |            | 3  |
| Z       | DEPT       | 0001       | 4  |
|         |            | 0001015    | 5  |
| DEPT001 |            | 203.25     | 6  |
|         |            | \$1,108.54 |    |
| DEPT002 |            | 183        |    |
|         |            | \$1,362.26 |    |
|         |            | 5          |    |
|         |            | \$47.00    |    |
| TL      |            | 421.25     | 7  |
|         |            | \$2,872.28 |    |
| Z       | FIX        | 0001       | 8  |
|         |            | 0001011    | 9  |
| GROSS   |            | 981.25     |    |
|         |            | \$6,574.40 | 10 |
| NET     | No         | 111        |    |
|         |            | \$7,057.14 | 11 |
| CAID    |            | \$1,919.04 | 12 |
| CHID    |            | \$139.04   | 13 |
| CKID    |            | \$859.85   | 14 |
| CRID(1) |            | \$709.85   | 15 |
| CRID(2) |            | \$0.00     | 16 |
| CRID(3) |            | \$0.00     | 17 |
| CRID(4) |            | \$0.00     | 18 |
| RF      | No         | 3          | 19 |
|         |            | \$10.22    |    |
| CUST    | CT         | 111        | 20 |
| AVRG    |            | \$63.57    | 21 |
| DC      |            | \$1.22     | 22 |
| REF     |            | \$2.42     | 23 |
| ROUND   |            | \$0.00     | 24 |
| CANCEL  | No         | 2          | 25 |
|         |            | \$12.97    |    |

- 1 Date/time
- 2 Machine No./consecutive No.
- 3 Report title
- 4 Department report title/reset counter
- 5 Report code
- 6 Department count/amount \*1
- 7 Department total count/total amount
- 8 Fixed total report title/reset counter
- 9 Report code
- 10 Gross total \*2
- 11 Net total \*2
- 12 Cash in drawer \*2
- 13 Charge in drawer \*2
- 14 Check in drawer \*2
- 15 Credit in drawer 1 \*2
- 16 Credit in drawer 2 \*2
- 17 Credit in drawer 3 \*2
- 18 Credit in drawer 4 \*2
- 19 Refund mode \*2
- 20 Number of customer \*2
- 21 Average sales per customer \*2
- 22 Discount total \*2
- 23 Refund key \*2
- 24 Rounding total \*2
- 25 Cancellation

\* 1 If total amount is zero, these items will not be printed.

\* 2 These items can be skipped by programming. See page E-74 "Set code 08".

# To use the cash register's basic function

|        |                     |         |
|--------|---------------------|---------|
| TA1    | \$2,369.69          | 26      |
| TX1    | \$128.86            | 27      |
| TA2    | \$2,172.96          | 28      |
| TX2    | \$217.33            | 29      |
| -----  |                     |         |
| GT     | \$00000000125478.96 | 30      |
| -----  |                     |         |
| Z      | TRANS               | 0001    |
|        |                     | 0001012 |
| CASH   | No 362              | 33      |
|        | \$1,638.04          |         |
| CHARGE | No 56               | 33      |
|        | \$1,174.85          |         |
| RA     | No 4                | 33      |
|        | \$810.00            |         |
| P0     | No 5                | 33      |
|        | \$520.00            |         |
|        | \$5.00              | 33      |
| CORR   | No 14               |         |
|        | \$39.55             | 33      |
| RCT    | No 3                |         |
| NS     | No 5                | 33      |
| -----  |                     |         |

- 26 Taxable 1 amount \*2
- 27 Tax 1 amount \*2
- 28 Taxable 2 amount \*2
- 29 Tax 2 amount \*2
- 30 Grand total \*2
- 31 Function key report title/reset counter
- 32 Report code
- 33 Function key count/amount \*1

\* 1 If total amount is zero, these items will not be printed.

\* 2 These items can be skipped by programming. See pages E-76 "Set code 09" and E-78 "Set code16".

# Advanced programmings and registrations

|                                                                                                  |       |
|--------------------------------------------------------------------------------------------------|-------|
| Advanced registrations.....                                                                      | E-58  |
| Enabling clerk assignment.....                                                                   | E-58  |
| Registrations with clerk assignment.....                                                         | E-59  |
| Single item cash sales .....                                                                     | E-60  |
| Character settings.....                                                                          | E-62  |
| Using character keyboard.....                                                                    | E-62  |
| Using ten key pad .....                                                                          | E-63  |
| Setting characters .....                                                                         | E-65  |
| Setting symbol characters .....                                                                  | E-66  |
| Advanced programmings .....                                                                      | E-70  |
| Programming detail settings .....                                                                | E-71  |
| Programming functions of departments and PLUs in a lump .....                                    | E-81  |
| Programming department functions in a lump .....                                                 | E-81  |
| Programming PLU functions in a lump .....                                                        | E-83  |
| Programming functions of departments and PLUs individually .....                                 | E-84  |
| Programming functions of departments individually.....                                           | E-84  |
| Programming functions of PLUs individually.....                                                  | E-86  |
| Programming functions of transaction keys .....                                                  | E-87  |
| Programming further clerk functions.....                                                         | E-91  |
| Printing programmed data .....                                                                   | E-92  |
| To print programmed unit price or percentage (other than PLU) .....                              | E-92  |
| To print programmed characters (except PLUs) .....                                               | E-93  |
| To print general programming (except PLUs).....                                                  | E-94  |
| To print preset unit price of PLU .....                                                          | E-95  |
| To print preset characters of PLU .....                                                          | E-96  |
| To print PLU programmings .....                                                                  | E-96  |
| Printing various sales reports.....                                                              | E-97  |
| Printing various sales reports.....                                                              | E-97  |
| To print individual department and PLUs .....                                                    | E-101 |
| Periodic sales report.....                                                                       | E-102 |
| Bluetooth setting .....                                                                          | E-105 |
| Setting Bluetooth pairing .....                                                                  | E-105 |
| Using an SD card.....                                                                            | E-107 |
| To format an SD card.....                                                                        | E-108 |
| To store program data in an SD card.....                                                         | E-109 |
| Restoring backup data (automatically backed up setting data)<br>from built in flash memory ..... | E-110 |
| POP setting .....                                                                                | E-110 |
| Handling of the cash drawer .....                                                                | E-111 |
| To lock and unlock the cash drawer.....                                                          | E-111 |
| To pull out the cash drawer (S drawer).....                                                      | E-111 |
| To pull out the cash drawer (M drawer).....                                                      | E-111 |
| To remove coin divider (certain models).....                                                     | E-112 |
| Before you consider it as a problem .....                                                        | E-113 |
| Error code table .....                                                                           | E-113 |
| About HELP guidance.....                                                                         | E-116 |

When “EJ FULL” sign appears on the display..... E-117

In case of power failure..... E-117

In case the register is locked up..... E-117

About the low battery indicator ..... E-118

About open source code ..... E-118


Specifications .....E-119



## Advanced registrations

### Enabling clerk assignment


By assigning a clerk, clerk number or name will be printed on receipts. The following operation enables the register to use the clerk assignment.



| Step | Operation                                                                                                                                                                                                                                                                                                                           |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | <p>Turn the Mode switch to PGM position. The display shows programming top menu.</p> <div>C01 PGM<br/>[DEPT Setting] ▲<br/>[PLU Setting]<br/>[Key Setting]<br/>[Date Setting]<br/>[Clerk Setting]<br/>[Message Setting]<br/>[POP Setting]<br/>[Tax Setting] ▼<br/>Select &amp; &lt;CA/AMT TEND&gt;</div>                            |
| 2    | <p>Using  or  keys, select [General Setting] and press  key.</p> <div>C01 PGM<br/>[PLU Setting] ▲<br/>[Key Setting]<br/>[Date Setting]<br/>[Clerk Setting]<br/>[Message Setting]<br/>[POP Setting]<br/>[Tax Setting]<br/>[General Setting] ▼<br/>Select &amp; &lt;CA/AMT TEND&gt;</div>                                             |
| 3    | <p>Select [Enable Clerk] and press  key.</p> <div>General Setting<br/>Enable Clerk<br/>Journal 1/2 Print<br/>Consecutive No. Reset<br/>EJ Clear&lt;After Daily Z&gt;<br/>EJ/Sales→SD&lt;After XZ&gt;<br/>Prohibit Reg(Stock &lt; 0 )<br/>Min Stock Alert<br/>Select &amp; &lt;CA/AMT TEND&gt; or<br/>Cancel &lt;SUB TOTAL&gt;</div> |
| 4    | <p>Using  or  keys, select [YES] and press  key.</p> <div>Enable Clerk<br/>YES<br/>NO<br/><br/>Select &amp; &lt;CA/AMT TEND&gt; or<br/>Cancel &lt;SUB TOTAL&gt;</div>                                                                                                                                                               |

Registrations with clerk assignment

By signing a clerk on, the clerk name will be printed on receipts and sales reports.



| Step                                                                                                                                                                                                                                             | Operation                                                            | Printout                                                                                                                                        |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Enter the clerk number and press <input type="button" value="CLK#"/> key.                                                                                                                                                                      | <input type="button" value="1"/> <input type="button" value="CLK#"/> | <div><div>* commercial message *</div><div>REG 20-06-2018 11:58</div><div>C01 0001 000123</div><div>1 DEPT01 T1 \$1.00</div></div> <div>1</div> |
| 2 Perform registration operations.<br>The clerk name is printed on receipts and displayed on top of the display.                                                                                                                                 |                                                                      |                                                                                                                                                 |
| 3 To sign a clerk off, enter <input type="button" value="0"/> and <input type="button" value="0"/> <input type="button" value="CLK#"/> press <input type="button" value="CLK#"/> key. Or just press <input type="button" value="SIGN OFF"/> key. | <input type="button" value="0"/> <input type="button" value="CLK#"/> |                                                                                                                                                 |

1: Clerk Name/Machine No./Consecutive No.


Further operation:

You can sign on the register by clerk's secret number instead of clerk number. See page E-33.

# Advanced programmings and registrations

## Single item cash sales

A department key or a PLU programmed as single item sale status finalizes the transaction as soon as it is registered. This feature can be used only in cash sales. To program single item sales status see page E-32.



### Sample operation 1: Simple single item sale

|         |          |             |                                                                          |
|---------|----------|-------------|--------------------------------------------------------------------------|
| Item    | Dept. 01 | \$1.00      | Dept. 01 is programmed as single item sale and unit price is not preset. |
|         | Quantity | 1           |                                                                          |
|         | Preset   | Single item |                                                                          |
| Payment | Cash     | \$1.00      |                                                                          |

| Step                                                                                                                                                 | Operation                   | Printout                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|--------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the unit price then press corresponding department key. The transaction is finalized immediately after the department key depression. | <b>1</b> <b>00</b> <b>1</b> | <div>1 DEPT001            \$1.00<br/>TL                    \$1.00<br/>CASH                \$1.00</div> |

### Sample operation 2: Single item sale with multiplication

|         |          |             |                                                                                                                     |
|---------|----------|-------------|---------------------------------------------------------------------------------------------------------------------|
| Item    | Dept. 01 | \$1.00      | Selling three pieces of items of dept. 01 in which unit price \$1.00 and single item sale status is pre-programmed. |
|         | Quantity | 3           |                                                                                                                     |
|         | Preset   | Single item |                                                                                                                     |
| Payment | Cash     | \$3.00      |                                                                                                                     |

| Step                                                                                                                                              | Operation                                                                                    | Printout                                                                                               |
|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| <b>1</b> Enter the quantity and press  key for multiplication. | <b>3</b>  | <div>3 DEPT001            \$3.00<br/>TL                    \$3.00<br/>CASH                \$3.00</div> |
| <b>2</b> Press corresponding department key. The transaction is finalized immediately.                                                            | <b>1</b>                                                                                     |                                                                                                        |

# Advanced programmings and registrations

## Sample operation 3: Single item sale with another item

|         |          |             |                                                                                                                |
|---------|----------|-------------|----------------------------------------------------------------------------------------------------------------|
| Item 1  | Dept. 03 | \$2.00      | Dept. 03 is a normal department while dept. 01 is programmed as unit price \$1.00 and single item sale status. |
|         | Quantity | 1           |                                                                                                                |
|         | Preset   | Normal      |                                                                                                                |
| Item 2  | Dept. 01 | \$1.00      |                                                                                                                |
|         | Quantity | 1           |                                                                                                                |
|         | Preset   | Single item |                                                                                                                |
| Payment | Cash     | \$3.00      |                                                                                                                |

| Step                                                                                               | Operation                   | Printout                                                                       |
|----------------------------------------------------------------------------------------------------|-----------------------------|--------------------------------------------------------------------------------|
| 1 Register item 1.                                                                                 | <b>2</b> <b>00</b> <b>3</b> | <div>1 DEPT003 \$2.00<br/>1 DEPT001 \$1.00<br/>TL \$3.00<br/>CASH \$3.00</div> |
| 2 Single item sale department key does not finalize the transaction as it is not single item sale. | <b>1</b>                    |                                                                                |
| 3 Press <b>CA/AMT / TEND</b> key to finalize the transaction.                                      | <b>CA/AMT / TEND</b>        |                                                                                |

# Advanced programmings and registrations


## Character settings

This chapter explains how you can program department or PLU descriptions, store messages, key descriptions, report title, total descriptions (such as gross total, net total etc.) and clerk names.

There are two ways to program characters which are using character keyboard and using multi typing of ten key.

### Using character keyboard

#### ■ Character keyboard



- |   |                               |                                                                                                                                           |
|---|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | <b>Alphabet keys</b>          | Used to input characters.                                                                                                                 |
| 2 | <b>Double size letter key</b> | Assigns the next input character to be double sized. After setting a double sized character, press this key again to back to normal size. |
| 3 | <b>Space key</b>              | Sets a space.                                                                                                                             |
| 4 | <b>Delete key</b>             | Clears the last input character.                                                                                                          |
| 5 | <b>Program end key</b>        | Terminates the character programming.                                                                                                     |
| 6 | <b>Character enter key</b>    | Registers the programmed characters.                                                                                                      |
| 7 | <b>CAPS key</b>               | Pressing this key shifts a character from the lowercase letter to upper case letter.                                                      |
| 8 | <b>Shift key</b>              | Pressing this key shifts the character from the uppercase letter to lower case letter.                                                    |

**Example:** To set "Apple Juice"


**A**                      **p p l e**                      **J**                      **u i c e**  
<DBL> <A> <DBL> <Shift> <p> <p> <l> <e> <Space> <CAPS> <J> <Shift> <u> <i> <c> <e> .

# Advanced programmings and registrations

## Using ten key pad

To set characters by using ten key, you need to press one of the ten key repeatedly until desired character appears on the display.

### ■ Multi typing keyboard



#### 1 Alphabet keys

Hitting one of those keys repeatedly changes characters in the order shown in the table below.

|           |                                                                                                                                                                                                           |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>8</b>  | A → B → C → a → b → c → 8 → Ä → Å → Æ → Á → Â → Æ → Å → Ç → â → ä → à → á → æ → á → ã → Ç returns to the beginning                                                                                        |
| <b>9</b>  | D → E → F → d → e → f → 9 → ð → É → Ê → Ë → È → ð → é → ê → ë → è → f returns to the beginning                                                                                                            |
| <b>4</b>  | G → H → I → g → h → i → 4 → Í → Î → Ï → I → Ì → Î → Î → í → i returns to the beginning                                                                                                                    |
| <b>5</b>  | J → K → L → j → k → l → 5 returns to the beginning                                                                                                                                                        |
| <b>6</b>  | M → N → O → m → n → o → 6 → Ñ → Ò → ø → Ó → Ô → Ò → Õ → ñ → ô → ö → ò → ø → ó → õ returns to the beginning                                                                                                |
| <b>1</b>  | P → Q → R → S → p → q → r → s → 1 → þ → þ → ß returns to the beginning                                                                                                                                    |
| <b>2</b>  | T → U → V → t → u → v → 2 → TEL → Ü → Ú → Û → Û → ü → û → ù → ú → µ returns to the beginning                                                                                                              |
| <b>3</b>  | W → X → Y → Z → w → x → y → z → 3 → Ÿ → Ÿ → ŷ returns to the beginning                                                                                                                                    |
| <b>0</b>  | 0                                                                                                                                                                                                         |
| <b>00</b> | (Right cursor)                                                                                                                                                                                            |
| <b>.</b>  | (Delete)                                                                                                                                                                                                  |
| <b>7</b>  | 7 → @ → - → / → : → ! → ? → ~ → ( → ) → * → # → + → , → ^ → ; → < → → = → > → \$ → ¥ → % → & → [ → ] → ' → { →   → } → • → " → . → \ → _ → ` → £ → × → ÷ → i → € → § → ¢ → space returns to the beginning |

## Advanced programmings and registrations


- |   |                               |                                                                                                                                    |
|---|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| 2 | <b>Double size letter key</b> | Assigns the next input character to be double sized. After setting a double sized character, press this key again for normal size. |
| 3 | <b>Space key</b>              | Sets a space.                                                                                                                      |
| 4 | <b>Clear key</b>              | Clears all the characters.                                                                                                         |
| 5 | <b>Delete key</b>             | Clears the last input character.                                                                                                   |
| 6 | <b>Program end key</b>        | Terminates the character programming.                                                                                              |
| 7 | <b>Character enter key</b>    | Registers the programmed characters.                                                                                               |
| 8 | <b>Right cursor key</b>       | Moves the cursor to the right.                                                                                                     |

**Example:** To set **C**LASS a

|       |          |   |          |   |          |   |          |   |          |   |          |   |    |   |   |   |   |         |   |   |   |   |
|-------|----------|---|----------|---|----------|---|----------|---|----------|---|----------|---|----|---|---|---|---|---------|---|---|---|---|
|       | <b>C</b> |   | <b>L</b> |   | <b>A</b> |   | <b>S</b> |   | <b>S</b> |   | <b>a</b> |   |    |   |   |   |   |         |   |   |   |   |
| <DBL> | 8        | 8 | 8        | 5 | 5        | 5 | <DBL>    | 8 | 1        | 1 | 1        | 1 | 00 | 1 | 1 | 1 | 1 | <Space> | 8 | 8 | 8 | 8 |

## Setting characters

The following explanation shows how you can set a name in a PLU. You can also set names to departments, function keys ( ,  ), and clerks by the same method.



### Sample Operation

To set “MILK” to PLU0001 by using ten key pad.

#### Step

**1** Turn the Mode switch to PGM position. The display shows the program top menu.

#### Display

```
C01      PGM
[DEPT Setting]
[PLU Setting]
[Key Setting]
[Date Setting]
[Clerk Setting]
[Message Setting]
[POP Setting]
[Tax Setting]
Select & <CA/AMT TEND>
```

**2** Using  or  keys, select [PLU Setting] and press  key.

```
PLU Setting
Input PLU No.
      PLU No.  [      ]
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

Enter the PLU number in which you wish to set characters and press  key.

**3** On the next screen, make sure that the PLU number you wish to set is selected. If you wish to change it, use  or  keys.

```
PLU Setting
0001. PLU0001
0002. PLU0002
0003. PLU0003
0004. PLU0004
0005. PLU0005
0006. PLU0006
0007. PLU0007
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```

Press  key.


**4** Select the top column of the [PLU Setting screen] and input the character you wish to set. In this example, **6 4 4 4 5 5 5 00 5 5** (for MILK). Then press  key to complete the setting.

```
PLU Setting
0001. [      ]
Unit Price [      ] 0.00 ]
Taxable Status[ NON TAX ]
Group Link [ 00 ]
DEPT Link [ 000 ]
Open PLU [ NO ]
Advanced →go
Select & <CA/AMT TEND> or
Cancel <SUB TOTAL>
```



Setting symbol characters

You can change the symbols or titles of sales reports for example, printing “CASH IN DRW” on the sales reports instead of “CAID” for cash amount in drawer.



| Step                                                                                                                                                                                                                                                              | Operation                      |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <p><b>1</b> Turn the Mode switch to PGM position and select [System Setting] then press  key.</p> <p>[System Setting] is the last column on the programming top menu and is not shown on the first screen. Keep pressing  key until it appears on the screen.</p> | .....                          |
| <p><b>2</b> Enter  and press  key to set the register in the character setting mode.</p>                                                                                                                                                                          |                                |
| <p><b>3</b> Referring the following tables, enter two-digit memory number and program code. Then press  key.</p>                                                                                                                                                  | <br>[Memory No.](Program code) |
| <p><b>4</b> Referring the character entry methods on pages E-62 and E-63, input characters you wish to set and press  key.</p>                                                                                                                                    | .....<br>(Character keys)      |
| <p><b>5</b> If you wish to set in the next memory number, repeat step 4. If you wish to set other memory number than the next number, repeat steps 3 and 4.</p>                                                                                                   |                                |
| <p><b>6</b> Press  key to complete the setting.</p>                                                                                                                                                                                                               |                                |

**Example:** To set “CASH IN DRW” in memory number 3

Press [C][A][S][H][SPACE][I][N][SPACE][D][R][W]

# Advanced programmings and registrations

## Sales report symbols

| Memory No. | Program code | Contents                          | Default character | Memo for your settings |  |  |  |  |  |  |  |  |  |
|------------|--------------|-----------------------------------|-------------------|------------------------|--|--|--|--|--|--|--|--|--|
| 01         | 01           | Gross total                       | GROSS             |                        |  |  |  |  |  |  |  |  |  |
| 02         |              | Net total                         | NET               |                        |  |  |  |  |  |  |  |  |  |
| 03         |              | Cash in drawer                    | CAID              |                        |  |  |  |  |  |  |  |  |  |
| 04         |              | Charge in drawer                  | CHID              |                        |  |  |  |  |  |  |  |  |  |
| 05         |              | Check in drawer                   | CKID              |                        |  |  |  |  |  |  |  |  |  |
| 06         |              | Credit 1 in drawer                | CRID(1)           |                        |  |  |  |  |  |  |  |  |  |
| 07         |              | Credit 2 in drawer                | CRID(2)           |                        |  |  |  |  |  |  |  |  |  |
| 08         |              | Credit 3 in drawer                | CRID(3)           |                        |  |  |  |  |  |  |  |  |  |
| 09         |              | Credit 4 in drawer                | CRID(4)           |                        |  |  |  |  |  |  |  |  |  |
| 10         |              | Cash in drawer for sub currency   | CAID2             |                        |  |  |  |  |  |  |  |  |  |
| 11         |              | Charge in drawer for sub currency | CHID2             |                        |  |  |  |  |  |  |  |  |  |
| 12         |              | Check in drawer for sub currency  | CKID2             |                        |  |  |  |  |  |  |  |  |  |
| 17         |              | Refund mode total                 | RF                |                        |  |  |  |  |  |  |  |  |  |
| 18         |              | Customer count                    | CUST              |                        |  |  |  |  |  |  |  |  |  |
| 19         |              | Average sales per customer        | AVRG              |                        |  |  |  |  |  |  |  |  |  |
| 20         |              | Clerk commission 1 total          | C-1               |                        |  |  |  |  |  |  |  |  |  |
| 21         |              | Clerk commission 2 total          | C-2               |                        |  |  |  |  |  |  |  |  |  |
| 22         |              | Foreign currency cash in drawer   | CECA1             |                        |  |  |  |  |  |  |  |  |  |
| 23         |              | Foreign currency check in drawer  | CECK1             |                        |  |  |  |  |  |  |  |  |  |
| 26         |              | Reduction                         | DC                |                        |  |  |  |  |  |  |  |  |  |
| 27         |              | Coupon                            | COUPON            |                        |  |  |  |  |  |  |  |  |  |
| 28         |              | Item return                       | REF               |                        |  |  |  |  |  |  |  |  |  |
| 29         |              | Rounding for sub currency         | ROUND             |                        |  |  |  |  |  |  |  |  |  |
| 30         |              | Rounding                          | ROUND             |                        |  |  |  |  |  |  |  |  |  |
| 31         |              | Cancellation                      | CANCEL            |                        |  |  |  |  |  |  |  |  |  |
| 33         |              | Taxable amount 1                  | TA1               |                        |  |  |  |  |  |  |  |  |  |
| 34         |              | Tax 1                             | TX1               |                        |  |  |  |  |  |  |  |  |  |
| 35         |              | Taxable amount 2                  | TA2               |                        |  |  |  |  |  |  |  |  |  |
| 36         |              | Tax 2                             | TX2               |                        |  |  |  |  |  |  |  |  |  |
| 37         |              | Taxable amount 3                  | TA3               |                        |  |  |  |  |  |  |  |  |  |
| 38         |              | Tax 3                             | TX3               |                        |  |  |  |  |  |  |  |  |  |
| 39         |              | Taxable amount 4                  | TA4               |                        |  |  |  |  |  |  |  |  |  |
| 40         |              | Tax 4                             | TX4               |                        |  |  |  |  |  |  |  |  |  |
| 41         |              | Taxable amount 5                  | TA5               |                        |  |  |  |  |  |  |  |  |  |
| 42         |              | Tax 5                             | TX5               |                        |  |  |  |  |  |  |  |  |  |
| 43         |              | Taxable amount 6                  | TA6               |                        |  |  |  |  |  |  |  |  |  |
| 44         |              | Tax 6                             | TX6               |                        |  |  |  |  |  |  |  |  |  |
| 45         |              | Taxable amount 7                  | TA7               |                        |  |  |  |  |  |  |  |  |  |
| 46         |              | Tax 7                             | TX7               |                        |  |  |  |  |  |  |  |  |  |
| 47         |              | Taxable amount 8                  | TA8               |                        |  |  |  |  |  |  |  |  |  |
| 48         |              | Tax 8                             | TX8               |                        |  |  |  |  |  |  |  |  |  |
| 49         |              | Taxable amount 9                  | TA9               |                        |  |  |  |  |  |  |  |  |  |
| 50         |              | Tax 9                             | TX9               |                        |  |  |  |  |  |  |  |  |  |
| 51         |              | Taxable amount 10                 | TA10              |                        |  |  |  |  |  |  |  |  |  |
| 52         |              | Tax 10                            | TX10              |                        |  |  |  |  |  |  |  |  |  |

## Advanced programmings and registrations

| Memory No. | Program code | Contents           | Default character | Memo for your settings |  |  |  |  |  |  |  |  |  |
|------------|--------------|--------------------|-------------------|------------------------|--|--|--|--|--|--|--|--|--|
| 53         | 01           | Tax total          | TAX TOTAL         |                        |  |  |  |  |  |  |  |  |  |
| 54         |              | Non taxable amount | NON TAX           |                        |  |  |  |  |  |  |  |  |  |

# Advanced programmings and registrations

## Other symbols

Numbers in ( ) are digits to be used.

| Memory No. | Program code | Contents                                                                                          | Default character       |
|------------|--------------|---------------------------------------------------------------------------------------------------|-------------------------|
| 01         | 23           | main currency symbol (2), @ (2), No.(2), split pricing (2), not used (4), sub currency symbol (2) | \$ @ N o / * *          |
| 02         |              | No. of item sold (2), No. of customers (2), not used (6), multiplication display(2)               | N o C T @ L B * Q T     |
| 03         |              | multiplication symbol (6), not used (6)                                                           | X B U S Y               |
| 04         |              | taxable symbols (3 each)                                                                          | T 1 T 2 T 3 T 4 T 5     |
| 05         |              | taxable symbols (3 each)                                                                          | T 6 T 7 T 8 T 9 T 1 0   |
| 06         |              | taxable symbols (3 each)                                                                          | T 1 2 T 1 3 T 1 4 T 2 3 |
| 08         |              | foreign currency (2 each) not used (8)                                                            | * * * * *               |
| 09         |              | mode symbols (4 each) (REG, RF, not used)                                                         | R E G R F R -           |
| 10         |              | mode symbols (4 each) (PGM, Daily X, Daily Z, Periodic)                                           | P n x Z X Z             |
| 11         |              | mode symbols (4 each) (not used, PGM read)                                                        | T R G P G M X           |
| 12         |              | decimal (1) (for amount/ q'ty), separator (main/sub 1 each), not used (3), square (7)             | . . . . . X             |
| 13         |              | am, pm (3each) ST symbol on main display (2)                                                      | A M P M S T             |
| 16         |              | subtotal symbol on main display (16)                                                              | S U B T O T A L         |
| 17         |              | subtotal symbol for discount/premium (16)                                                         | S U B T O T A L         |
| 18         |              | post receipt total symbol (16)                                                                    | T L                     |
| 19         |              | change symbol (16)                                                                                | C G                     |
| 01         | 20           | grand total symbol (16)                                                                           | G T                     |

## Title of sales reports

| Memory No. | Program code | Contents                      | Default character | Memo for your settings |
|------------|--------------|-------------------------------|-------------------|------------------------|
| 01         | 24           | Fixed total report title      | FIX               |                        |
| 02         |              | Transaction key report title  | TRANS             |                        |
| 03         |              | PLU sales report title        | PLU               |                        |
| 04         |              | Department sales report title | DEPT              |                        |
| 05         |              | Group sales report title      | GROUP             |                        |
| 06         |              | Clerk sales report title      | CASHIER           |                        |
| 08         |              | Hourly sales report title     | HOURLY            |                        |
| 09         |              | Monthly sales report title    | MONTHLY           |                        |
| 16         |              | Flash report title            | FLASH             |                        |

# Advanced programmings and registrations

## Advanced programmings

This section explains how you can program detail settings of the register such as setting register's specific number, whether to reset consecutive number on the receipt after a Reset (Z) report or not, whether to print taxable amounts on receipts or not, etc.


The following table lists what can be programmed in this settings.

| Set code | Settings                                                          | No. of digit to be set |
|----------|-------------------------------------------------------------------|------------------------|
| 02       | Cash register's unit number                                       | 4                      |
| 03       | Whether to reset consecutive number after Reset (Z) report or not | 8                      |
| 04       | Tax system (USA or Canada)                                        | 9                      |
| 05       | Contents of receipt/journal print                                 | 10                     |
| 06       | Calculation and operation methods                                 | 10                     |
| 08       | Contents of sales reports 1                                       | 10                     |
| 09       | Contents of sales reports 2                                       | 10                     |
| 10       | Whether to print taxable amount or not                            | 10                     |
| 15       | Printing methods of sales reports                                 | 10                     |
| 16       | Printing methods of grand total                                   | 7                      |
| 17       | Date/time printing on journals/receipts                           | 4                      |
| 19       | Double height character printing on receipts                      | 7                      |
| 21       | Printing methods of messages                                      | 10                     |
| 27       | Clerk operation selections                                        | 9                      |
| 30       | Receipt message/Compressed journal print selection                | 5                      |
| 34       | Backlight on/off selection                                        | 4                      |

# Advanced programmings and registrations

## Programming detail settings

To program the detail settings of the register, please follow the operations shown below.



| Step                                                                                                                                                                                     | Operation                                                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> Turn the Mode switch to PGM position and select [System Setting] then press <input type="button" value="CA/AMT/TEND"/> key.                                                     | <input type="button" value="▽"/> ..... <input type="button" value="▽"/> <input type="button" value="CA/AMT/TEND"/>                                                       |
| [System Setting] is the last column on the programming top menu and is not shown on the first screen. Keep pressing <input type="button" value="▽"/> key until it appears on the screen. |                                                                                                                                                                          |
| <b>2</b> Enter <b>3</b> and press <input type="button" value="SUB TOTAL"/> key to set the register in the programming mode.                                                              | <b>3</b> <input type="button" value="SUB TOTAL"/>                                                                                                                        |
| <b>3</b> Referring the following tables, enter two-digit set code you wish to program followed by two 2s. "22" is the identification code for programming detail settings.               | <input type="text"/> <input type="text"/> <b>2 2</b><br>[set code]<br>For example, if you wish to program tax system:<br><b>0 4 2 2</b>                                  |
| <b>4</b> Referring the tables below, enter program code of up to 10 digits and press <input type="button" value="CA/AMT/TEND"/> key.                                                     | <input type="text"/> <input type="text"/> ..... <input type="text"/> <input type="text"/> <input type="button" value="CA/AMT/TEND"/><br>[Program code (up to 10 digits)] |
| <b>5</b> Press <input type="button" value="SUB TOTAL"/> key to complete the program.                                                                                                     | <input type="button" value="SUB TOTAL"/>                                                                                                                                 |

### Set code 02 (Machine number)

| Description    | Selection      | Program code                                                                                       | Default value                 |
|----------------|----------------|----------------------------------------------------------------------------------------------------|-------------------------------|
| Machine number | Machine number | <input type="text"/> <input type="text"/> <input type="text"/> <input type="text"/><br>D4 D3 D2 D1 | <b>0 0 0 0</b><br>D4 D3 D2 D1 |

**Example:** To set the register's specific unit number 1234.

Press **3**  **0 2 2 2**  **1 2 3 4**

### Set code 03 (Whether to reset consecutive number after Reset (Z) report or not)

| Description                                                  | Selection         | Program code                                             | Default value                    |
|--------------------------------------------------------------|-------------------|----------------------------------------------------------|----------------------------------|
| Reset consecutive number after daily reset report is issued. | Yes = 0<br>No = 1 | <input type="text"/><br>D8                               | <b>0</b><br>D8                   |
| Must be "0000000" (seven zeros)                              |                   | <input type="text"/> to <input type="text"/><br>D7 to D1 | <b>0</b> to <b>0</b><br>D7 to D1 |

**Example:** Not resetting the consecutive number after Z report printing.

Press **3**  **0 3 2 2**  **1 0 0 0 0 0 0 0 0 0**

# Advanced programmings and registrations

## Set code 04 (Tax system)

| Description                                                                                  | Selection         | Program code                                                                 | Default value                                                                |
|----------------------------------------------------------------------------------------------|-------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| Canadian rounding system<br>Roundings Last digit: 0 to 2 → 0, 3 to 7 → 5, 8 and 9 → 10       | No = 0<br>Yes = 7 | <input type="checkbox"/><br>D10                                              | <input type="text" value="0"/><br>D10                                        |
| US tax system = 1, Canadian tax system = 2 (Default value depends on the country shipped to) | Select 1 or 2     | <input type="checkbox"/><br>D9                                               | <input type="text" value="1"/> or <input type="text" value="2"/><br>D9       |
| Must be "00000000" (eight zeros)                                                             |                   | <input type="text" value="0"/> to <input type="text" value="0"/><br>D8 to D1 | <input type="text" value="0"/> to <input type="text" value="0"/><br>D8 to D1 |

**Example:** To set Canadian tax system with Canadian rounding system.

Press **3**  **0 4 2 2**  **7 2 0 0 0 0 0 0 0 0 0 0**

## Set code 05 (Receipt printing selections)

| Description                                                     | Selection                  | Program code                                                                                             | Default value                                                                                            |
|-----------------------------------------------------------------|----------------------------|----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| Print total line during finalization.                           | a Yes = 0<br>No = 1        | <input type="checkbox"/><br>(a+b) D10                                                                    | <input type="text" value="0"/><br>(a+b) D10                                                              |
| 24- hour system (0) or 12 -hour system (2)                      | b Select<br>0 or 2         |                                                                                                          |                                                                                                          |
| Buffered receipt print (enables key operations during printing) | No = 0<br>Yes = 2          | <input type="checkbox"/><br>D9                                                                           | <input type="text" value="0"/><br>D9                                                                     |
| Skip item prints on journal. (journal skip)                     | No = 0<br>Yes = 1          | <input type="checkbox"/><br>D8                                                                           | <input type="text" value="0"/><br>D8                                                                     |
| Print receipt or journal.                                       | Receipt = 0<br>Journal = 1 | <input type="checkbox"/><br>D7                                                                           | <input type="text" value="0"/><br>D7                                                                     |
| Must be "00"                                                    |                            | <input type="text" value="0"/> <input type="text" value="0"/><br>D6 D5                                   | <input type="text" value="0"/> <input type="text" value="0"/><br>D6 D5                                   |
| Print number of item sold. (item counter)                       | a No = 0<br>Yes = 1        | <input type="checkbox"/><br>(a+b) D4                                                                     | <input type="text" value="0"/><br>(a+b) D4                                                               |
| Print tax symbols.                                              | b Yes = 0<br>No = 2        |                                                                                                          |                                                                                                          |
| Must be "000"                                                   |                            | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D3 D2 D1 | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D3 D2 D1 |

**Example:**

- On a receipt, not printing total amount (a = 1), printing 12 -hour system (b = 2): D10 = 3 (1 + 2).
- Buffered receipt printing: D9 = 2.
- Not printing items on journal (journal skip): D8 = 1.
- Use paper roll as receipts: D7= 0.
- D6 – D5 must be 00.
- Printing number of items (a = 1), not printing tax symbols (b = 2): D4 = 3 (1 + 2).
- D3 – D1 must be 000.

Press **3**  **0 5 2 2**  **3 2 1 0 0 0 0 3 0 0 0 0**

# Advanced programmings and registrations

## Set code 06 (Calculation and operation methods)

| Description                                                                                         | Selection              | Program code                                                                           | Default value                                                                          |
|-----------------------------------------------------------------------------------------------------|------------------------|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| Succeeds the taxable status and commission status of previous item when +/- operation is performed. | a<br>Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D10                                                  | <input type="checkbox"/><br>(a+b) D10                                                  |
| Force money declarations before read(X) or reset (Z) reports operations.                            | b<br>No = 0<br>Yes = 4 |                                                                                        |                                                                                        |
| Force to press <input type="button" value="SUB TOTAL"/> key before finalization.                    | a<br>No = 0<br>Yes = 1 |                                                                                        |                                                                                        |
| Allow finalization when subtotal amount is zero or minus.                                           | b<br>Yes = 0<br>No = 2 | <input type="checkbox"/><br>(a+b+c) D9                                                 | <input type="checkbox"/><br>(a+b+c) D9                                                 |
| Allow multiple refund operation.                                                                    | c<br>Yes = 0<br>No = 4 |                                                                                        |                                                                                        |
| Affects the results of +/-, %+/%- calculations to items. (Net totaling)                             | No = 0<br>Yes = 1      | <input type="checkbox"/><br>D8                                                         | <input type="checkbox"/><br>D8                                                         |
| Include commission in net total.                                                                    | Yes = 0<br>No = 2      | <input type="checkbox"/><br>D7                                                         | <input type="checkbox"/><br>D7                                                         |
| Clears the key buffer when a receipt is issued. (REG mode only)                                     | a<br>No = 0<br>Yes = 1 |                                                                                        |                                                                                        |
| Sounds key catch tone.                                                                              | b<br>Yes = 0<br>No = 2 | <input type="checkbox"/><br>(a+b+c) D6                                                 | <input type="checkbox"/><br>(a+b+c) D6                                                 |
| Allow to issue post receipt, even the original one is issued.                                       | c<br>No = 0<br>Yes = 4 |                                                                                        |                                                                                        |
| Must be "000"                                                                                       |                        | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D5 D4 D3 | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D5 D4 D3 |
| Use <00> key as <000> key.                                                                          | <00> = 0<br><000> = 4  | <input type="checkbox"/><br>D2                                                         | <input type="checkbox"/><br>D2                                                         |
| Must be "0"                                                                                         |                        | <input type="checkbox"/><br>D1                                                         | <input type="checkbox"/><br>D1                                                         |

### Example:

- A +/- operation not succeeds taxable status and commission status (a = 1), amount in drawer should be declared before Z reporting (b = 4): D10 = 5 (1 + 4).
- key must always be pressed for a finalization (a = 1), not allowing zero or minus subtotal in a transaction (b = 2), not allowing multiple refund operations (c = 4): D9 = 7 (1 + 2 + 4).
- Affecting the result of +/-, %+/%- to an item: D8 = 1.
- Not including commission in net total: D7 = 2.
- Clearing key buffer when a receipt is issued (a = 1), not sounding key catch tone (b = 2), issues post receipts even the original receipt is issued (c = 4): D6 = 7 (1 + 2 + 4).
- D5 – D3 must be 000.
- Using 00 key as 000 key D2 = 4.
- D1 must be 0.

Press



# Advanced programmings and registrations

## Set code 08 (Fixed total print control)

| Description                                                                                                    |   | Selection         | Program code                            | Default value                                 |
|----------------------------------------------------------------------------------------------------------------|---|-------------------|-----------------------------------------|-----------------------------------------------|
| Print gross sales total (GROSS) on fixed total report.                                                         | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D10 | <input type="text" value="0"/><br>(a+b+c) D10 |
| Print net sales total (NET) on fixed total report.                                                             | b | Yes = 0<br>No = 2 |                                         |                                               |
| Print cash in drawer (CAID) on fixed total report.                                                             | c | Yes = 0<br>No = 4 |                                         |                                               |
| Print charge in drawer (CHID) on fixed total report.                                                           |   | Yes = 0<br>No = 2 | <input type="checkbox"/><br>D9          | <input type="text" value="5"/><br>D9          |
| Print check in drawer (CKID) on fixed total report.                                                            | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D8    | <input type="text" value="2"/><br>(a+b) D8    |
| Print credit in drawer on (CRID(1) ~ (4)) on fixed total report.                                               | b | Yes = 0<br>No = 4 |                                         |                                               |
| Must be "0"                                                                                                    |   |                   | <input type="text" value="0"/><br>D7    | <input type="text" value="7"/><br>D7          |
| Print RF mode total (RF) on fixed total report.                                                                |   | Yes = 0<br>No = 4 | <input type="checkbox"/><br>D6          | <input type="text" value="3"/><br>D6          |
| Print the net number of customers (CUST) on fixed total report.                                                | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D5    | <input type="text" value="6"/><br>(a+b) D5    |
| Print average sales per customer (AVER) on fixed total report.                                                 | b | Yes = 0<br>No = 2 |                                         |                                               |
| Print tax total                                                                                                |   | Yes = 0<br>No = 1 | <input type="checkbox"/><br>D4          | <input type="text" value="7"/><br>D4          |
| Print commission 1 total (C-1) on fixed total report.                                                          | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D3  | <input type="text" value="7"/><br>(a+b+c) D3  |
| Print commission 2 total (C-2) on fixed total report.                                                          | b | Yes = 0<br>No = 2 |                                         |                                               |
| Print foreign currency cash in drawer (CECA1, CECA2) and check in drawer (CECK1, CECK2) on fixed total report. | c | Yes = 0<br>No = 4 |                                         |                                               |
| Print <MINUS>, <COUPON>, <%-> and mix & match operation net total (DC) on fixed total report.                  | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D2    | <input type="text" value="7"/><br>(a+b) D2    |
| Print total number of <REFUND> operation (RF) on fixed total report.                                           | b | Yes = 0<br>No = 2 |                                         |                                               |
| Print nontaxable totals (NON TAX) on fixed total report.                                                       | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D1  | <input type="text" value="3"/><br>(a+b+c) D1  |
| Print rounded fractions (ROUND) on fixed total report.                                                         | b | Yes = 0<br>No = 2 |                                         |                                               |
| Print number of cancellation (CANCEL) on fixed total report.                                                   | c | Yes = 0<br>No = 4 |                                         |                                               |

# Advanced programmings and registrations

## Example:

- On the fixed total report, not printing gross sales total (a = 1), not printing net sales total (b = 2), not printing cash in drawer. (c = 4): D10 = 7 (1 + 2 + 4).
- Not printing charge in drawer on fixed total report: D9 = 2.
- On fixed total report, not printing check amount in drawer (a = 1), not printing credit amount in drawer (b = 4): D8 = 5 (1 + 4).
- D7 must be always 0.
- Not printing refunded amount in RF mode on fixed total report: D6 = 4.
- Not printing total number of customers on fixed total report (a = 1), not printing average sales amount per customer (b = 2): D5 = 3 (1 + 2).
- Print tax total : D4 = 0.
- On fixed total report, not printing commission 1 amount (a = 1), not printing commission 2 amount (b = 2), not printing amount of foreign currency cash and check (c = 4): D3 = 7 (1 + 2 + 4).
- On fixed total report, not printing net total of <MINUS>, <COUPON>, <%-> etc. (a = 1), not printing <REFUND> and <VOID> amounts (b = 2): D2 = 3 (1 + 2).
- On fixed total report, not printing non-taxable amounts (a = 1), not printing rounded down amount (b = 2), not printing cancelled amount (c = 4): D1 = 7 (1 + 2 + 4).

Press **3** **SUB TOTAL** **0 8 2 2** **SUB TOTAL** **7 2 5 0 4 3 0 7 3 7** **CA / AMT / TEND** **SUB TOTAL**

# Advanced programmings and registrations

## Set code 09 (Fixed total print control 2)

| Description                                                 |   | Selection         | Program code                          | Default value                     |
|-------------------------------------------------------------|---|-------------------|---------------------------------------|-----------------------------------|
| Print taxable amount 1 total on fixed total report. (TA1)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D10 | <input type="checkbox"/> 4<br>D10 |
| Print tax 1 total on fixed total report. (TX1)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 2 total on fixed total report. (TA2)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D9  | <input type="checkbox"/> 4<br>D9  |
| Print tax 2 total on fixed total report. (TX2)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 3 total on fixed total report. (TA3)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D8  | <input type="checkbox"/> 7<br>D8  |
| Print tax 3 total on fixed total report. (TX3)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 4 total on fixed total report. (TA4)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D7  | <input type="checkbox"/> 7<br>D7  |
| Print tax 4 total on fixed total report. (TX4)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 5 total on fixed total report. (TA5)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D6  | <input type="checkbox"/> 7<br>D6  |
| Print tax 5 total on fixed total report. (TX5)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 6 total on fixed total report. (TA6)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D5  | <input type="checkbox"/> 7<br>D5  |
| Print tax 6 total on fixed total report. (TX6)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 7 total on fixed total report. (TA7)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D4  | <input type="checkbox"/> 7<br>D4  |
| Print tax 7 total on fixed total report. (TX7)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 8 total on fixed total report. (TA8)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D3  | <input type="checkbox"/> 7<br>D3  |
| Print tax 8 total on fixed total report. (TX8)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 9 total on fixed total report. (TA9)   | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D2  | <input type="checkbox"/> 7<br>D2  |
| Print tax 9 total on fixed total report. (TX9)              | b | Yes = 0<br>No = 2 |                                       |                                   |
| Print taxable amount 10 total on fixed total report. (TA10) | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D1  | <input type="checkbox"/> 7<br>D1  |
| Print tax 10 total on fixed total report. (TX10)            | b | Yes = 0<br>No = 2 |                                       |                                   |

# Advanced programmings and registrations

## Set code 10 (Print control of taxable amount)

| Description                                 |   | Selection         | Program code                                                                 | Default value                                                                |
|---------------------------------------------|---|-------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| Print taxable amount 1 on receipt/journal.  | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D10                                      | <input type="text" value="0"/><br>D10                                        |
| Print taxable amount 2 on receipt/journal.  | b | Yes = 0<br>No = 2 |                                                                              |                                                                              |
| Print taxable amount 3 on receipt/journal.  | c | Yes = 0<br>No = 4 |                                                                              |                                                                              |
| Print taxable amount 4 on receipt/journal.  | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D9                                       | <input type="text" value="0"/><br>D9                                         |
| Print taxable amount 5 on receipt/journal.  | b | Yes = 0<br>No = 2 |                                                                              |                                                                              |
| Print taxable amount 6 on receipt/journal.  | c | Yes = 0<br>No = 4 |                                                                              |                                                                              |
| Print taxable amount 7 on receipt/journal.  | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b+c) D8                                       | <input type="text" value="0"/><br>D8                                         |
| Print taxable amount 8 on receipt/journal.  | b | Yes = 0<br>No = 2 |                                                                              |                                                                              |
| Print taxable amount 9 on receipt/journal.  | c | Yes = 0<br>No = 4 |                                                                              |                                                                              |
| Print taxable amount 10 on receipt/journal. |   | Yes = 0<br>No = 1 | <input type="checkbox"/><br>D7                                               | <input type="text" value="0"/><br>D7                                         |
| Must be "000000" (six zeros)                | a | Yes = 0<br>No = 1 | <input type="text" value="0"/> to <input type="text" value="0"/><br>D6 to D1 | <input type="text" value="0"/> to <input type="text" value="0"/><br>D6 to D1 |

# Advanced programmings and registrations

## Set code 15 (Printing methods of sales reports)

| Description                                                                                         |   | Selection         | Program code                                                                                 | Default value                                                                                |
|-----------------------------------------------------------------------------------------------------|---|-------------------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| Department zero skip (Departments of sales amount zero are not printed on sales reports.)           | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D10                                                        | <input type="checkbox"/> 0<br>(a+b) D10                                                      |
| Clerk zero skip (Zero amounted clerks are not printed on sales reports.)                            | b | Yes = 0<br>No = 2 |                                                                                              |                                                                                              |
| Transaction key zero skip (Transaction keys of sales amount zero are not printed on sales reports.) | a | Yes = 0<br>No = 1 |                                                                                              |                                                                                              |
| PLU zero skip (Zero amounted PLUs are not printed on sales reports.)                                | b | Yes = 0<br>No = 2 | <input type="checkbox"/><br>(a+b+c) D9                                                       | <input type="checkbox"/> 0<br>(a+b+c) D9                                                     |
| Hourly sales report skip (Zero amounted time zones are not printed on sales reports.)               | c | Yes = 0<br>No = 4 |                                                                                              |                                                                                              |
| Group zero skip (Zero amounted groups are not printed on sales reports.)                            |   | Yes = 0<br>No = 1 | <input type="checkbox"/><br>D8                                                               | <input type="checkbox"/> 0<br>D8                                                             |
| Must be "00"                                                                                        |   |                   | <input type="checkbox"/> 0 <input type="checkbox"/> 0<br>D7 D6                               | <input type="checkbox"/> 0 <input type="checkbox"/> 0<br>D7 D6                               |
| Print PLU numbers on the PLU report.                                                                |   | No = 0<br>Yes = 4 | <input type="checkbox"/><br>D5                                                               | <input type="checkbox"/> 0<br>D5                                                             |
| Print sales ratio on sales reports.                                                                 | a | No = 0<br>Yes = 1 | <input type="checkbox"/><br>(a+b) D4                                                         | <input type="checkbox"/> 0<br>(a+b) D4                                                       |
| Issue double Z reports.                                                                             | b | No = 0<br>Yes = 2 |                                                                                              |                                                                                              |
| Must be "000"                                                                                       |   |                   | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0<br>D3 D2 D1 | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 0<br>D3 D2 D1 |

## Set code 16 (Printing methods of grand total)

| Description                                              |  | Selection         | Program code                                                                                                                                             | Default value                                                                                                                                            |
|----------------------------------------------------------|--|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Print range of consecutive number on fixed total report. |  | No = 0<br>Yes = 1 | <input type="checkbox"/><br>D7                                                                                                                           | <input type="checkbox"/> 0<br>D7                                                                                                                         |
| Must be "00111"                                          |  |                   | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 1 <input type="checkbox"/> 1<br>D6 D5 D4 D3 D2 | <input type="checkbox"/> 0 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 1 <input type="checkbox"/> 1<br>D6 D5 D4 D3 D2 |
| Print grand total on daily sales reset (Z) report.       |  | Yes = 0<br>No = 1 | <input type="checkbox"/><br>D1                                                                                                                           | <input type="checkbox"/> 0<br>D1                                                                                                                         |

# Advanced programmings and registrations

## Set code 17 (Date/time printing on journals/receipts)

| Description                                                           |   | Selection         | Program code                           | Default value                        |
|-----------------------------------------------------------------------|---|-------------------|----------------------------------------|--------------------------------------|
| Print date on journal.                                                | a | Yes = 0<br>No = 2 | <input type="checkbox"/><br>(a+b) D4   | <input type="checkbox"/><br>(a+b) D4 |
| Print consecutive number on receipt/journal.                          | b | Yes = 0<br>No = 4 |                                        |                                      |
| Print time on receipt.                                                | a | Yes = 0<br>No = 1 | <input type="checkbox"/><br>(a+b) D3   | <input type="checkbox"/><br>(a+b) D3 |
| Print time on journal.                                                | b | Yes = 0<br>No = 2 |                                        |                                      |
| Must be "0"                                                           |   |                   | <input type="checkbox"/><br>D2         | <input type="checkbox"/><br>D2       |
| Alert electronic journal near end/end.                                | a | No = 0<br>Yes = 1 | <input type="checkbox"/><br>(a+b+c) D1 | <input type="checkbox"/><br>D1       |
| Reset electronic journal (internal) after issuing daily reset report. | b | Yes = 0<br>No = 2 |                                        |                                      |
| Store sales data and electronic journal data in SD card.              | c | No = 0<br>Yes = 4 |                                        |                                      |

## Set code 19 (Double height character printing on receipts)

| Description                               | Selection         | Program code                                                                                                                                                               | Default value                                                                                                                                                              |
|-------------------------------------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Print receipt in double height characters | No = 0<br>Yes = 1 | <input type="checkbox"/><br>D7                                                                                                                                             | <input type="checkbox"/><br>D7                                                                                                                                             |
| Must be "000000" (six zeros)              |                   | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D6 D5 D4 D3 D2 D1 | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D6 D5 D4 D3 D2 D1 |

## Set code 21 (Printing methods of messages)

| Description                                                                        |   | Selection         | Program code                                                                                                       | Default value                                                                                                      |
|------------------------------------------------------------------------------------|---|-------------------|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Print graphic type logo.<br>(If "No" is selected, character logo will be printed.) |   | No = 0<br>Yes = 2 | <input type="checkbox"/><br>D10                                                                                    | <input type="checkbox"/><br>D10                                                                                    |
| Must be "000"                                                                      |   |                   | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D9 D8 D7                             | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D9 D8 D7                             |
| Print commercial message on receipts in REG/RF mode.                               | a | No = 0<br>Yes = 1 | <input type="checkbox"/><br>(a+b) D6                                                                               | <input type="checkbox"/><br>(a+b) D6                                                                               |
| Print bottom message on receipts in REG/RF mode.                                   | b | No = 0<br>Yes = 2 |                                                                                                                    |                                                                                                                    |
| Must be "0000"                                                                     |   |                   | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D5 D4 D3 D2 | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/><br>D5 D4 D3 D2 |
| Must be "0"                                                                        |   |                   | <input type="checkbox"/><br>D1                                                                                     | <input type="checkbox"/><br>D1                                                                                     |

# Advanced programmings and registrations

## Set code 27 (Clerk operation selections)

| Description            | Selection         | Program code                                                                 | Default value                                                                |
|------------------------|-------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| Allow clerk functions. | No = 0<br>Yes = 4 | <input type="checkbox"/><br>D9                                               | <input type="text" value="0"/><br>D9                                         |
| Must be "00000000"     |                   | <input type="text" value="0"/> to <input type="text" value="0"/><br>D8 to D1 | <input type="text" value="0"/> to <input type="text" value="0"/><br>D8 to D1 |

## Set code 30 (Thermal printer control)

| Description                                                                                                                                                                                | Selection                                                          | Program code                                                                                             | Default value                                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| Select POP image:<br>Effective when D5 is 1; always print same image.                                                                                                                      | Image1 = 1<br>Image2 = 2<br>Image3 = 3<br>Image4 = 4<br>Image5 = 5 | <input type="checkbox"/><br>D6                                                                           | <input type="text" value="0"/><br>D6                                                                     |
| Print condition of POP message.<br>No printing: 0<br>① Always print the same POP message; 1<br>② Print POP when particular item is registered; 2<br>③ Print POP according to the amount; 3 | No = 0<br>① = 1<br>② = 2<br>③ = 3                                  | <input type="checkbox"/><br>D5                                                                           | <input type="text" value="0"/><br>D5                                                                     |
| Journal compressed print (print half height characters)                                                                                                                                    | Yes = 0<br>No = 1                                                  | <input type="checkbox"/><br>D4                                                                           | <input type="text" value="0"/><br>D4                                                                     |
| Must be "000"                                                                                                                                                                              |                                                                    | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D3 D2 D1 | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D3 D2 D1 |

## Set code 34 (Backlight control)


| Description                                                | Selection                          | Program code                                                         | Default value                                                          |
|------------------------------------------------------------|------------------------------------|----------------------------------------------------------------------|------------------------------------------------------------------------|
| Backlight                                                  | Functions = 0<br>Not functions = 1 | <input type="checkbox"/><br>D4                                       | <input type="text" value="0"/><br>D4                                   |
| Must be "0"                                                |                                    | <input type="text" value="0"/><br>D3                                 | <input type="text" value="0"/><br>D3                                   |
| Backlight off timer (01~59 minutes, "00" means always on.) |                                    | <input type="text" value=""/> <input type="text" value=""/><br>D2 D1 | <input type="text" value="2"/> <input type="text" value="0"/><br>D2 D1 |

## Programming functions of departments and PLUs in a lump

There are two methods to set functions of departments or PLUs which are programming at once and programming individual functions.

### Programming department functions in a lump

This method programs function of a department at one time.



| Step                                                                                                                                   | Operation                                 |
|----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.                                                    | .....                                     |
| 2 Enter <b>3</b> and press  key to set the register in the programming mode.                                                           | <b>3</b>                                  |
| 3 You can skip this step if you program in departments 01 through 25. If you wish to program in departments 26 through 50, press  key. |                                           |
| 4 Referring following table, input 12- digit program code.                                                                             | .....<br>[Program code (12 digits)]       |
| 5 Press the department key you wish to program                                                                                         | <br>For example, programming in dept. 26. |
| 6 Repeat steps 3 through 5 if you wish to program functions in another departments.                                                    |                                           |
| 7 Press  key to complete the program.                                                                                                  |                                           |

#### Example:

Programming department 26 as;

- Normal item: D12 = 0.
- D11 through D8 must be 0000.
- US taxable status 1 (a = 1) and 2 (b = 2): D7 = 3 (1 + 2)
- Allowing zero unit price (a = 1), not allowing negative unit price (b = 0), hash item (c = 4): D6 = 5 (1 + 0 + 4).
- D5 must always be 0.
- Limiting minimum entry digit: 3 digits: D4 = 3.
- As this example is for setting functions in a department, D3 should be 0.
- Applying commission 1 (a = 1), not applying commission 2 (b = 0): D2 = 1 (1 + 0).
- D1 must always be 0.

Press **3** **0 0 0 0 0 3 5 0 3 0 1 0**



# Advanced programmings and registrations


## Department and PLU lump set code

| Description                                                                                                            |                           |                                                                                                                                  |   | Selection                                                          | Program code                                                                                                                                 | Default value                                                                                                                                |
|------------------------------------------------------------------------------------------------------------------------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------|---|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Single item sales:<br>Normal item = 0, Single item = 3                                                                 |                           |                                                                                                                                  |   | 0 or 3                                                             | <input type="checkbox"/><br>D12                                                                                                              | <input type="text" value="0"/><br>D12                                                                                                        |
| Must be "0000"                                                                                                         |                           |                                                                                                                                  |   | 0000                                                               | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D11 D10 D9 D8 | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D11 D10 D9 D8 |
| Taxable status                                                                                                         | Taxable status for USA    | Taxable status 1                                                                                                                 | a | No = 0<br>Yes = 1                                                  | <input type="checkbox"/><br>(a+b+c) D7                                                                                                       | <input type="text" value="0"/><br>D7                                                                                                         |
|                                                                                                                        |                           | Taxable status 2                                                                                                                 | b | No = 0<br>Yes = 2                                                  |                                                                                                                                              |                                                                                                                                              |
|                                                                                                                        |                           | Taxable status 3                                                                                                                 | c | No = 0<br>Yes = 4                                                  |                                                                                                                                              |                                                                                                                                              |
|                                                                                                                        | Taxable status for Canada | Non tax = 0, Taxable 1 = 1, Taxable 2 = 2, Taxable 3 = 3, Taxable 4 = 4, Taxable 1 & 2 = 5, Taxable 1 & 3 = 6, Taxable 1 & 4 = 7 |   |                                                                    | <input type="checkbox"/><br>D7                                                                                                               |                                                                                                                                              |
| Enable zero unit price.                                                                                                |                           |                                                                                                                                  | a | No = 0<br>Yes = 1                                                  | <input type="checkbox"/><br>(a+b+c) D6                                                                                                       | <input type="text" value="0"/><br>(a+b+c) D6                                                                                                 |
| Enable negative price.                                                                                                 |                           |                                                                                                                                  | b | No = 0<br>Yes = 2                                                  |                                                                                                                                              |                                                                                                                                              |
| Hash item                                                                                                              |                           |                                                                                                                                  | c | No = 0<br>Yes = 4                                                  |                                                                                                                                              |                                                                                                                                              |
| Department only.<br>POP print file.<br>Effective when set code 30's D5 = 2 (print when particular item is registered). |                           |                                                                                                                                  |   | Image1 = 1<br>Image2 = 2<br>Image3 = 3<br>Image4 = 4<br>Image5 = 5 | <input type="checkbox"/><br>D5                                                                                                               | <input type="text" value="0"/><br>D5                                                                                                         |
| Low digit limitation (LDL) for manually entered unit price.                                                            |                           |                                                                                                                                  |   | Number of digits                                                   | <input type="checkbox"/><br>D4                                                                                                               | <input type="text" value="0"/><br>D4                                                                                                         |
| Open PLU (only for PLU)                                                                                                |                           |                                                                                                                                  |   | No = 0<br>Yes = 4                                                  | <input type="checkbox"/><br>D3                                                                                                               | <input type="text" value="0"/><br>D3                                                                                                         |
| Commission 1 (give commission on items)                                                                                |                           |                                                                                                                                  | a | No = 0<br>Yes = 1                                                  | <input type="checkbox"/><br>(a+b+c) D2                                                                                                       | <input type="text" value="0"/><br>(a+b+c) D2                                                                                                 |
| Commission 2                                                                                                           |                           |                                                                                                                                  | b | No = 0<br>Yes = 2                                                  |                                                                                                                                              |                                                                                                                                              |
| Prepared status (Canadian tax)                                                                                         |                           |                                                                                                                                  | c | Yes = 0<br>No = 4                                                  |                                                                                                                                              |                                                                                                                                              |
| Must be "0"                                                                                                            |                           |                                                                                                                                  |   | 0                                                                  | <input type="text" value="0"/><br>D1                                                                                                         | <input type="text" value="0"/><br>D1                                                                                                         |

# Advanced programmings and registrations

## Programming PLU functions in a lump

This method programs functions of a PLU at one time.




| Step                                                                                       | Operation                                                      |
|--------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| <b>1</b> Turn the Mode switch to PGM position and select [System Setting] then press  key. | .....                                                          |
| <b>2</b> Enter <b>3</b> and press  key to set the register in the programming mode.        | <b>3</b>                                                       |
| <b>3</b> Enter four-digit PLU number then press  key.                                      | <b>0 0 1 4</b><br>For example, to program PLU number fourteen. |
| <b>4</b> Referring the table in the previous section, input 12- digit program code.        | .....<br>[Program code (12 digits)]                            |
| <b>5</b> Press  key.                                                                       |                                                                |
| <b>6</b> Repeat steps 3 through 5 if you wish to program functions in another PLU.         |                                                                |
| <b>7</b> Press  key to complete the program.                                               |                                                                |

Programming functions of departments and PLUs individually

Programming functions of departments individually

This part explains programming methods of each function of departments individually.



| Step                                                                                                                                                                                                       | Operation                                                                                                                                     |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.                                                                                                                        | .....                                                                                                                                         |
| 2 Enter  and press  key to set the register in the programming mode.                                                                                                                                       |                                                                                                                                               |
| 3 Referring the following table, enter two-digit set code you wish to program followed by two 6s. The “66” is the identification code for individual programming of departments and PLUs. Then press  key. | <br>(set code)                                                                                                                                |
| 4 You can skip this step if you program in departments 01 through 25. If you wish to program in departments 26 through 50, press  key.                                                                     |                                                                                                                                               |
| 5 Referring the following table, enter program code and press the department key in which you wish to set.                                                                                                 | <br>This example is for linking dept. 03 to item group 123 assuming set code 11 has been entered in step 3 and  key is not pressed in step 4. |
| 6 If you wish to set the same function in another department, press the corresponding dept. key.                                                                                                           | <br>This example is for setting the same linking group in dept. 04.                                                                           |
| 7 Repeat steps 4 and 5 to set another function in another department.                                                                                                                                      |                                                                                                                                               |
| 8 Press  key to complete the program.                                                                                                                                                                      |                                                                                                                                               |

# Advanced programmings and registrations

## Set code table

| Set code | Description                                               |                           |                                                                                                                                          | Selection               | Program code                                                                              |                               |
|----------|-----------------------------------------------------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|-------------------------------------------------------------------------------------------|-------------------------------|
| 03       | Taxable status                                            | Taxable status for USA    | Always “0”                                                                                                                               |                         | 0                                                                                         | <div>0</div> D2               |
|          |                                                           |                           | Taxable status 1                                                                                                                         | a                       | No = 0<br>Yes = 1                                                                         | <div></div> (a+b+c) D1        |
|          |                                                           |                           | Taxable status 2                                                                                                                         | b                       | No = 0<br>Yes = 2                                                                         |                               |
|          |                                                           | Taxable status 3          | c                                                                                                                                        | No = 0<br>Yes = 4       |                                                                                           |                               |
|          |                                                           | Taxable status for Canada | Non tax = 00, Taxable 1 = 01, Taxable 2 = 02, Taxable 3 = 03, Taxable 4 = 04, Taxable 1 & 2 = 05, Taxable 1 & 3 = 06, Taxable 1 & 4 = 07 |                         | 00 to 07                                                                                  | <div></div> <div></div> D2 D1 |
| 04       | Open PLU (Only for PLU)                                   |                           |                                                                                                                                          | No = 0<br>Yes = 4       | <div></div>                                                                               |                               |
| 05       | Allow unit price 0                                        |                           | a                                                                                                                                        | No = 0<br>Yes = 1       | <div></div> (a+b+c)                                                                       |                               |
|          | Allow negative unit price.                                |                           | b                                                                                                                                        | No = 0<br>Yes = 2       |                                                                                           |                               |
|          | Hash item                                                 |                           | c                                                                                                                                        | No = 0<br>Yes = 4       |                                                                                           |                               |
| 07       | Minimum digit of manual input unit price                  |                           |                                                                                                                                          | Number of minimum digit | <div></div>                                                                               |                               |
| 09       | Commission 1                                              |                           | a                                                                                                                                        | No = 0<br>Yes = 1       | <div></div> (a+b+c)                                                                       |                               |
|          | Commission 2                                              |                           | b                                                                                                                                        | No = 0<br>Yes = 2       |                                                                                           |                               |
|          | Prepared status (Canadian tax)                            |                           | c                                                                                                                                        | Yes = 0<br>No = 4       |                                                                                           |                               |
| 11       | Linking group (000 to 999)                                |                           |                                                                                                                                          | 000 to 999              | <div></div> <div></div> <div></div> D7 D6 D5                                              |                               |
|          | Must be 0                                                 |                           |                                                                                                                                          | 0                       | <div>0</div> D4                                                                           |                               |
|          | Linking dept. (000 to 999) (Only for PLU)                 |                           |                                                                                                                                          | 000 to 999              | <div></div> <div></div> <div></div> D3 D2 D1                                              |                               |
| 15       | Maximum amount of manual input unit price (up to 9999.99) |                           |                                                                                                                                          |                         | <div></div> <div></div> <div></div> <div></div> <div></div> <div></div> D6 D5 D4 D3 D2 D1 |                               |
| 18       | Single item control: Normal item = 0, Single item = 3     |                           |                                                                                                                                          | 0 or 3                  | <div></div>                                                                               |                               |

**Example 1:** To program dept. 01 as USA taxable 1 & 2

**3** SUB TOTAL **0 3 6 6** SUB TOTAL **0 3 1** SUB TOTAL


**Example 2:** To program dept. 02 to allow manual input unit price up to \$99.00.

**3** SUB TOTAL **1 5 6 6** SUB TOTAL **9 9 0 0** **2** SUB TOTAL

# Advanced programmings and registrations

## Programming functions of PLUs individually

This part explains programming methods of each function of PLUs individually.



| Step                                                                                                                                                                                                                                                                   | Operation                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
| <b>1</b> Turn the Mode switch to PGM position and select [System Setting] then press  key.                                                                                                                                                                             | .....                                                                |
| <b>2</b> Enter <b>3</b> and press  key to set the register in the programming mode.                                                                                                                                                                                    | <b>3</b>                                                             |
| <b>3</b> Referring the tables in the proceeding section, enter two-digit set code you wish to program followed by two 6s. The “66” is the identification code for individual programming of departments and PLUs. Then press  key.                                     | <br>(set code)                                                       |
| <b>4</b> Enter PLU number you wish to set and press  key.                                                                                                                                                                                                              | <b>0 0 0 5</b><br>This example is for setting a program in PLU 0005. |
| <b>5</b> Referring the table in the preceding section, enter program code and press  key.                                                                                                                                                                              | .....<br>(Program code)                                              |
| <b>6</b> If you wish to set the same program code in the next PLU number, press  key again.<br><br>Perform step 5 if you wish to set another program code to the next PLU number.<br><br>To program in another PLU number (not next PLU number), repeat steps 4 and 5. |                                                                      |
| <b>7</b> Press  key to complete the settings.                                                                                                                                                                                                                          |                                                                      |

**Example 1:** To set PLU 0001 as “Open PLU”.

Press **3** **0 4 6 6** **0 0 0 1** **4**


**Example 2:** To set PLU0012 to link item group 12 and dept. 04.

Press **3** **1 1 6 6** **0 0 1 2** **0 1 2 0 0 0 4**

# Advanced programmings and registrations

## Programming functions of transaction keys

This section explains how you can program functions in each transaction keys such as ,  or  keys. For example, programming  key to force entry of tendered amount.



| Step                                                                                                                                         | Operation                                                                                                                                                               |
|----------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Turn the Mode switch to PGM position and select [System Setting] then press <input type="button" value="CA/AMT/TEND"/> key.                | <input type="button" value="▽"/> ..... <input type="button" value="▽"/> <input type="button" value="CA/AMT/TEND"/>                                                      |
| 2 Enter <input type="button" value="3"/> and press <input type="button" value="SUB TOTAL"/> key to set the register in the programming mode. | <input type="button" value="3"/> <input type="button" value="SUB TOTAL"/>                                                                                               |
| 3 Referring the following tables, enter the program code then press corresponding transaction key.                                           | <input type="text" value=""/> ..... <input type="text" value=""/> <input type="button" value="−"/><br>(Program code)<br>The above example is for programming minus key. |
| 4 If you wish to program another transaction key, return to step 3.                                                                          |                                                                                                                                                                         |
| 5 Press <input type="button" value="SUB TOTAL"/> key to complete the program.                                                                | <input type="button" value="SUB TOTAL"/>                                                                                                                                |

## Program code tables

**NOTE** Default value of all the program codes are “0”.

Program code for ,  and  keys.

| Description                                                                                                              |   | Selection                                                | Program code                                                         |
|--------------------------------------------------------------------------------------------------------------------------|---|----------------------------------------------------------|----------------------------------------------------------------------|
| Prohibit partial payment.                                                                                                | a | No = 0<br>Yes = 1                                        | <input type="text" value=""/> (a+b+c) D7                             |
| Prohibit tendered amount entry                                                                                           | b | No = 0<br>Yes = 2                                        |                                                                      |
| Force to enter tendered amount.                                                                                          | c | No = 0<br>Yes = 4                                        |                                                                      |
| Print breakdown of VAT.<br>(Option for Single item or Currency exchange (including partial tendering foreign currency).) |   | No = 0<br>Yes = 1                                        | <input type="text" value=""/> D6                                     |
| Must be “0”                                                                                                              |   | 0                                                        | <input type="text" value=""/> D5                                     |
| Maximum amount for subtotal and tendered amount.<br>e.g.) \$90.00, D4 = 9, D3 = 3                                        |   | D4: Maximum value (0 ~ 9)<br>D3: Number of zeros (0 ~ 9) | <input type="text" value=""/> <input type="text" value=""/><br>D4 D3 |
| Maximum amount of change due.                                                                                            |   | Maximum value (0 ~ 9)<br>Number of zeros (0 ~ 9)         | <input type="text" value=""/> <input type="text" value=""/><br>D2 D1 |

**Example 1:** To set  key as prohibiting partial payment (a = 1), not prohibiting tendered amount entry (b = 0), and forcing to enter tendered amount (c = 4): D7 = 5.

Press

# Advanced programmings and registrations

## Program code for and keys

| Description                                        | Selection               | Program code                                                           |
|----------------------------------------------------|-------------------------|------------------------------------------------------------------------|
| Maximum amount.<br>e.g.) \$100.00; D4 = 1, D3 = 4. | Maximum value (0 ~ 9)   | <input type="text" value=""/> <input type="text" value=""/><br>D4 D3   |
|                                                    | Number of zeros (0 ~ 9) |                                                                        |
| Must be "00"                                       | 00                      | <input type="text" value="0"/> <input type="text" value="0"/><br>D2 D1 |

**Example:** To set  key not allowing to enter more than \$9.00.

Press

## Program code for key

| Description                                                                                   |                           |                                                                                                                                          | Selection              | Program code                                                           |
|-----------------------------------------------------------------------------------------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------|------------------------|------------------------------------------------------------------------|
| Taxable status                                                                                | Taxable status for USA    | Always "0"                                                                                                                               | 0                      | <input type="text" value="0"/><br>D8                                   |
|                                                                                               |                           | Taxable status 1                                                                                                                         | a<br>No = 0<br>Yes = 1 | <input type="text" value=""/><br>(a+b+c) D7                            |
|                                                                                               |                           | Taxable status 2                                                                                                                         | b<br>No = 0<br>Yes = 2 |                                                                        |
|                                                                                               |                           | Taxable status 3                                                                                                                         | c<br>No = 0<br>Yes = 4 |                                                                        |
|                                                                                               | Taxable status for Canada | Non tax = 00, Taxable 1 = 01, Taxable 2 = 02, Taxable 3 = 03, Taxable 4 = 04, Taxable 1 & 2 = 05, Taxable 1 & 3 = 06, Taxable 1 & 4 = 07 |                        | <input type="text" value=""/> <input type="text" value=""/><br>D8 D7   |
| Allow credit balance.                                                                         |                           |                                                                                                                                          | No = 0<br>Yes = 1      | <input type="text" value=""/><br>D6                                    |
| Must be "00"                                                                                  |                           |                                                                                                                                          | 00                     | <input type="text" value="0"/> <input type="text" value="0"/><br>D5 D4 |
| Maximum digit of manual input unit price<br>(Setting "9" programs NOT allowing manual entry.) |                           |                                                                                                                                          | Number of digit        | <input type="text" value=""/><br>D3                                    |
| Give commission 1                                                                             |                           | a                                                                                                                                        | No = 0<br>Yes = 1      | <input type="text" value=""/><br>(a+b+c) D2                            |
| Give commission 2                                                                             |                           | b                                                                                                                                        | No = 0<br>Yes = 2      |                                                                        |
| Prepared status (Canadian tax)                                                                |                           | c                                                                                                                                        | Yes = 0<br>No = 4      |                                                                        |
| Must be "0"                                                                                   |                           |                                                                                                                                          | 0                      | <input type="text" value="0"/><br>D1                                   |

# Advanced programmings and registrations

## Program code for key

| Description                                        |                           |                                                                                                                                          | Selection              | Program code                                                                                                                                                                  |
|----------------------------------------------------|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Taxable status                                     | Taxable status for USA    | Always "0"                                                                                                                               | 0                      |  D8                                                                                        |
|                                                    |                           | Taxable status 1                                                                                                                         | a<br>No = 0<br>Yes = 1 |  (a+b+c) D7                                                                                |
|                                                    |                           | Taxable status 2                                                                                                                         | b<br>No = 0<br>Yes = 2 |                                                                                                                                                                               |
|                                                    |                           | Taxable status 3                                                                                                                         | c<br>No = 0<br>Yes = 4 |                                                                                                                                                                               |
|                                                    | Taxable status for Canada | Non tax = 00, Taxable 1 = 01, Taxable 2 = 02, Taxable 3 = 03, Taxable 4 = 04, Taxable 1 & 2 = 05, Taxable 1 & 3 = 06, Taxable 1 & 4 = 07 | 00 to 07               |   D8 D7 |
| Prohibit manual rate entry.                        |                           |                                                                                                                                          | No = 0<br>Yes = 2      |  D6                                                                                        |
| Rounding: Round off = 0, Cut off = 1, Round up = 2 |                           |                                                                                                                                          | 0, 1 or 2              |  D5                                                                                        |
| Must be "00"                                       |                           |                                                                                                                                          | 00                     |   D4 D3 |
| Give commission 1                                  |                           | a                                                                                                                                        | No = 0<br>Yes = 1      |  (a+b+c) D2                                                                                |
| Give commission 2                                  |                           | b                                                                                                                                        | No = 0<br>Yes = 2      |                                                                                                                                                                               |
| Prepared status (Canadian tax)                     |                           | c                                                                                                                                        | Yes = 0<br>No = 4      |                                                                                                                                                                               |
| Must be "0"                                        |                           |                                                                                                                                          | 0                      |  D1                                                                                      |

## Program code for key

| Description                                                                                                                                                                                 | Selection         | Program code                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Allow mode change or clerk change after  key operation as first transaction. (Only for non-add function) | Yes = 0<br>No = 1 |  D7                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Must be "000000"                                                                                                                                                                            | 000000            |       <br>D6 D5 D4 D3 D2 D1 |



# Advanced programmings and registrations

## Program code for key

| Description                                                          | Selection      | Program code                                                                                                                               |
|----------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| Multiplication procedure<br>① Quantity × Amount, ② Amount × Quantity | ① = 0<br>② = 1 | <input type="checkbox"/><br>D6                                                                                                             |
| Roundings: Round off = 0, Cut off = 1, Round up = 2                  | 0, 1, or 2     | <input type="checkbox"/><br>D5                                                                                                             |
| Must be "0000"                                                       | 0000           | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D4 D3 D2 D1 |

## Program code for and keys

| Description                                         | Selection | Program code                                                                                                                                                                                                   |
|-----------------------------------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Taxable status (01 ~ 04) (Taxable 1 if "00" is set) | 01 to 04  | <input type="text" value=""/> <input type="text" value=""/><br>D8 D7                                                                                                                                           |
| Must be "000000"                                    | 000000    | <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/><br>D6 D5 D4 D3 D2 D1 |


## Program code for key.

| Description                                                                       |   | Selection                   | Program code                                                           |
|-----------------------------------------------------------------------------------|---|-----------------------------|------------------------------------------------------------------------|
| Prohibit partial payment.                                                         | a | No = 0<br>Yes = 1           | <input type="text" value=""/><br>(a+b+c) D7                            |
| Prohibit tendered amount entry                                                    | b | No = 0<br>Yes = 2           |                                                                        |
| Force to enter tendered amount.                                                   | c | No = 0<br>Yes = 4           |                                                                        |
| Print breakdown of VAT.                                                           |   | No = 0<br>Yes = 1           | <input type="text" value=""/><br>D6                                    |
| Must be "0"                                                                       |   | 0                           | <input type="text" value="0"/><br>D5                                   |
| Maximum amount for subtotal and tendered amount.<br>e.g.) \$90.00, D4 = 9, D3 = 3 |   | D4: Maximum value (0 ~ 9)   | <input type="text" value=""/> <input type="text" value=""/><br>D4 D3   |
|                                                                                   |   | D3: Number of zeros (0 ~ 9) |                                                                        |
| Must be "00"                                                                      |   | 00                          | <input type="text" value="0"/> <input type="text" value="0"/><br>D2 D1 |

# Advanced programmings and registrations

## Programming further clerk functions

This section explains how you can set further programming for clerks such as setting the register in training mode or setting commission rates given to clerks. In the training mode, the register operates normally but the results will not be stored in the memory. You can use this feature for getting to know the operations of the cash register for yourself or for newly hired clerks.



| Step                                                                                                                                                                                              | Operation                                |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------|
| 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.                                                                                                               | .....                                    |
| 2 Enter <b>3</b> and press  key to set the register in the programming mode.                                                                                                                      | <b>3</b>                                 |
| 3 Enter 2 -digit clerk number followed by 07. The “07” is the identification code for further program of clerks. Then press  key. The example on the right is for programming to clerk number 10. | <b>1 0 0 7</b><br>(Clerk no.)            |
| 4 Referring the following tables, input the set code you wish to program and press  key. The example on the right is for setting a commission rate.                                               | <b>6 8</b><br>(set code)                 |
| 5 Enter the program code and press  key. The example on the right is for setting 8.5% to commission rate 1 and 5% to commission 2.                                                                | <b>0 8 5 0 0 5 0 0</b><br>(program code) |
| 6 If you wish to set the same program to the next clerk number, perform the step 5 again. When you set to another clerk (not next clerk number), repeat steps 3 through 5.                        |                                          |
| 7 Press  key to complete the settings.                                                                                                                                                            |                                          |

### Set code 67 (Training mode)

| Description           | Selection         | Program code                   |
|-----------------------|-------------------|--------------------------------|
| Training mode         | No = 0<br>Yes = 1 | <input type="checkbox"/><br>D6 |
| Must be “00000”       |                   | <b>0 0 0 0</b><br>D5 D4 D3 D2  |
| Registration operable | Yes = 0<br>No = 1 | <input type="checkbox"/><br>D1 |

**Example 1:** To set the clerk number 15 as a clerk being trained.


Press **3** **1 5 0 7** **1 0 0 0 0 0 0**

### Set code 68 (Commission rates)

| Description                 | Selection | Program code                                       |
|-----------------------------|-----------|----------------------------------------------------|
| Commission rate 1 (integer) | 00 to 99  | <input type="text"/> <input type="text"/><br>D8 D7 |
| Commission rate 1 (decimal) | 00 to 99  | <input type="text"/> <input type="text"/><br>D6 D5 |
| Commission rate 2 (integer) | 00 to 99  | <input type="text"/> <input type="text"/><br>D4 D3 |
| Commission rate 2 (decimal) | 00 to 99  | <input type="text"/> <input type="text"/><br>D2 D1 |

Printing programmed data

After programs have been set, you can print the programmed data.



To print programmed unit price or percentage (other than PLU)

Step

- 1 Turn the Mode switch to PGM position and select [System Setting] then press key.
- 2 Enter and press key.
- 3 Press key again. The printer starts to print preset data.

Printout

|          |         |   |
|----------|---------|---|
| P01..... |         | 1 |
| CASH     | @0.00   |   |
| -        | @1.00   | 2 |
| %-       | 10%     |   |
| DEPT001  | 0001-05 | 3 |
|          | @1.00   | 4 |
| DEPT002  | 0002-05 |   |
|          | @2.00   |   |

- 1: Program read symbol
- 2: Transaction key unit price or rate
- 3: Department descriptor/rec-#/05
- 4: Unit price

# Advanced programmings and registrations

## To print programmed characters (except PLUs)


### Step

**1** Turn the Mode switch to PGM position and select [System Setting] then press  key.

**2** Enter  and press  key.

**3** Press  key again. The printer starts to print preset data.

### Printout



|                       |         |    |
|-----------------------|---------|----|
| P02.....              |         | 1  |
| GROSS                 | 0001-01 |    |
| NET                   | 0002-01 |    |
| CAID                  | 0003-01 | 2  |
|                       | 0004-01 |    |
|                       | 0005-01 |    |
| CASH                  | 0001-02 |    |
| CHECK                 | 0002-02 | 3  |
|                       | 0003-02 |    |
|                       | 0004-02 |    |
| DEPT001               | 0001-05 |    |
| DEPT002               | 0002-05 | 4  |
|                       | 0003-05 |    |
|                       | 0004-05 |    |
| GROUP01               | 0001-06 |    |
| GROUP02               | 0002-06 | 5  |
| GROUP03               | 0003-06 |    |
|                       | 0004-06 |    |
| C01                   | 0001-07 |    |
| C02                   | 0002-07 | 6  |
|                       | 0003-07 |    |
|                       | 0004-07 |    |
| GT                    | 0001-20 | 7  |
|                       |         |    |
| • @No/ ** /           |         |    |
| NoCT @LB *QT          | 0002-23 | 8  |
| Y- CUSV               | 0003-23 |    |
|                       | 0001-24 |    |
| FIX                   |         |    |
| TRANS                 | 0002-24 | 9  |
|                       | 0003-24 |    |
|                       | 0004-24 |    |
| DAILY X               | 0001-29 | 10 |
| PERIODIC 1X           | 0002-29 |    |
| PERIODIC 2X           | 0003-29 |    |
|                       | 0004-29 |    |
| 0001-32               |         |    |
| YOUR RECEIPT          |         | 11 |
| 0002-32               |         |    |
| THANK YOU             |         |    |
| 0001-39               |         |    |
| CHARACTER RECALL***** |         | 12 |
| *****                 |         |    |

- 1: Program read symbol
- 2: Fix total character
- 3: Transaction key character
- 4: Department character
- 5: Group character
- 6: Clerk character
- 7: GT character
- 8: Special character
- 9: Report header character
- 10: Batch X/Z character
- 11: Receipt message
- 12: Text recall character

# Advanced programmings and registrations

## To print general programming (except PLUs)

### Step

**1** Turn the Mode switch to PGM position and select [System Setting] then press  key.

**2** Enter **3** and press  key.

**3** Press  key again. The printer starts to print preset data.

### Printout

|          |                |    |
|----------|----------------|----|
| P03..... |                | 1  |
| CASH     | 0001-02        |    |
|          | 00000000000000 | 2  |
| CHECK    | 0002-02        | 3  |
|          | 00000000000000 | 4  |
| FD       | 0003-02        |    |
|          | 00000000000000 |    |
| DEPT001  | 0001-05        | 5  |
|          | 00000000000000 | 6  |
| 11-66    | 00000000       | 7  |
| 15-66    | @1.23          | 8  |
|          | 0002-05        |    |
| C01      | 0001-07        | 9  |
|          | 0000010001     | 10 |
| 67       | 0000000000     | 11 |
| 68       | 00000000       | 12 |
|          | 0001-09        |    |
|          | 00:00 -> 01:00 |    |
|          | 0002-09        |    |
|          | 01:00 -> 02:00 | 13 |
|          | 02:00 -> 03:00 |    |
|          | 0001-22        |    |
|          | 2200000000     |    |
|          | 0002-22        | 14 |
|          | 0000000000     |    |
|          | 0003-22        |    |
|          | 0000000000     |    |
|          | 0001-28        |    |
|          | 0002-28        |    |
|          | 0001-25        |    |
| TX1      | 10.25%         | 15 |
| TX1      | 0000           |    |
| TX1      | 5003           |    |
| DAILY X  | 0001-29        | 16 |
| 00       | 11-12-17-15-00 |    |
|          | 00-00-00-00-00 |    |
| PERIODIC | 1X 0002-29     |    |

- 1: Program read symbol
- 2: Transaction key program
- 3: Key character/rec-#/file-#
- 4: Key program
- 5: Department program/Key character/rec-#/file-#
- 6: Key program
- 7: Address code 11 program
- 8: Address code 15 program
- 9: Clerk program/Clerk name/rec-#/file-#
- 10: Check #/secret-#
- 11: Compulsory
- 12: Commission rate
- 13: Time range program
- 14: General control program
- 15: Tax table
- 16: Batch X/Z program

Printout

|         |                  |    |
|---------|------------------|----|
| 0001-30 |                  | 17 |
| NET     | 0001-01          |    |
|         | 0020-01          |    |
| 0001-38 | 000001           | 18 |
| REG1    | 204-000          | 19 |
| 1       | 001-000          |    |
| 2       | 002-000          |    |
| DEPT001 | 026-051          |    |
| CASH    | 013-001          |    |
| 0001-62 | 000000           | 20 |
|         | 0000000000000000 |    |
|         | 0000000000       |    |
| MC#01   | 0001-91          |    |
|         | 00000000         |    |
| 0001-98 | 0000000000000000 | 21 |
| 0002-98 | 0000000000000000 |    |

- 17: Clerk detail link program
- 18: Arrangement program/Rec-#/file-#/arrange no.
- 19: Key descriptor/rec-#/file-#
- 20: Scheduler program
- 21: I/O parameter table

To print preset unit price of PLU

Step

- 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.
- 2 Enter **6** and press  key to set the register in the programming mode.
- 3 Enter **1 0 4** and press  key.
- 4 Enter starting PLU number and press  key. For example, if you wish to print from PLU number 0001, input **0 0 0 1** .
- 5 Enter the last PLU number and press  key. For example, if you wish to print up to PLU number 0884, input **0 8 8 4** .

Printout

|               |         |   |
|---------------|---------|---|
| P01.....      | 1       |   |
| #0001 - #0884 | 2       |   |
| PLU0001       | 0001-04 | 3 |
|               | @1.00   | 4 |
| PLU0002       | 0002-04 |   |
|               | @2.00   |   |

- 1: Program read symbol
- 2: Range of PLU No.
- 3: PLU name/rec-#/04
- 4: Unit price


# Advanced programmings and registrations

## To print preset characters of PLU

### Step

- 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.
- 2 Enter **6** and press  key to set the register in the programming mode.
- 3 Enter **2 0 4** and press  key.
- 4 Enter starting PLU number and press  key.
- 5 Enter the last PLU number and press  key.

### Printout



```
P02..... 1
          #0001 - #0010 2
PLU0001      0001-04 3
PLU0002      0002-04
PLU0003      0003-04
```


- 1: Program 2 mode symbol  
2: Range of PLU No.  
3: PLU character

## To print PLU programmings

### Step

- 1 Turn the Mode switch to PGM position and select [System Setting] then press  key.
- 2 Enter **6** and press  key to set the register in the programming mode.
- 3 Enter **3 0 4** and press  key.
- 4 Enter starting PLU number and press  key.
- 5 Enter the last PLU number and press  key.

### Printout



```
P03..... 1
          #0001 - #0010 2
PLU0001      0001-04 3
                  0000000000000000 4
11-66          000000 5
13-66          <- 0001-28 6
14-66          0
15-66          @1234.56 7
PLU0003      0002-04
```

- 1: Program 3 mode symbol  
2: Range of PLU No.  
3: PLU name/rec-#/file-#  
4: Address code 01 ~ 10, 18 program  
5: Address code 11 program  
6: Address code 13 program  
7: Address code 15 program

## Printing various sales reports


You can print categorized sales reports such as PLU sales report, item group sales report, hourly sales report etc.

### NOTE

- Please do not perform the reset (Z) report during the business hour as it clears stored sales data from the memory.
- Please see page E-54 for printout sample of a daily report.

## Printing various sales reports

The followings are the example operation for printing an electronic journal (EJ) of February 28, 2018.



### Step

- 1 Turn the Mode switch to X or Z position. The display shows the top menu of sales reports.

### Display

```

X 000003
[DAILY X ]
[PLU ]
[GROUP ]
[HOURLY ]
[MONTHLY ]
[OPEN CHK ]
[FLASH ]
Select <CA/AMT TEND>
0
    
```

- 2 Using  or  keys select the report you wish to obtain. The example on the right is for selecting electronic journal. As it is the lowest column, [EJ ] is hidden from the default top menu. Select it by keep pressing  key.

```

X 000003
[HOURLY ]
[MONTHLY ]
[OPEN CHK ]
[FLASH ]
[Time/Attend ]
[EJ ]
[EJ-SD ]
Select <CA/AMT TEND>
0
    
```

- 3 Input year, month, and day from ten key pad. The journal of assigned date will be printed if you press  key.

```

EJ
Input
DATE [ 28 ]
MONTH [ 02 ]
YEAR 20[ 18 ]
Consecutive No. [ 000000 ]
Select <CA/AMT TEND> or
Cancel <SUB TOTAL>
    
```



# Advanced programmings and registrations

## ■ PLU sales report

|         |     |          |  |   |
|---------|-----|----------|--|---|
| X       | PLU |          |  | 1 |
|         |     | 0000014  |  | 2 |
| PLU0001 |     | 17       |  | 3 |
| 0.53%   |     | \$17.00  |  | 4 |
| #0001   |     |          |  | 5 |
| PLU0100 |     | 42       |  |   |
| 1.03%   |     | \$69.00  |  |   |
| #0100   |     |          |  |   |
| <hr/>   |     |          |  |   |
| TL      |     | 188.61   |  | 6 |
|         |     | \$516.10 |  | 7 |

- 1 Read symbol/report title
- 2 Report code
- 3 PLU name/Quantity
- 4 Sales ratio/PLU amount
- 5 PLU code
- 6 Total Quantity
- 7 Total amount

## ■ Item group sales report

|         |       |            |  |   |
|---------|-------|------------|--|---|
| X       | GROUP |            |  | 1 |
|         |       | 0000016    |  | 2 |
| GROUP01 |       | 203.25     |  | 3 |
| 33.87%  |       | \$1,108.54 |  | 4 |
| GROUP02 |       | 183        |  |   |
| 40.58%  |       | \$1,327.80 |  |   |
| GROUP03 |       | 12         |  |   |
| 0.40%   |       | \$13.25    |  |   |
| GROUP99 |       | 13         |  |   |
| 0.54%   |       | \$17.80    |  |   |
| <hr/>   |       |            |  |   |
| TL      |       | 862        |  | 5 |
|         |       | \$3,272.00 |  | 6 |

- 1 Read symbol/report title
- 2 Report code
- 3 Group No./Quantity
- 4 Sales ratio/group amount
- 5 Total quantity of group
- 6 Group total amount

## ■ Hourly sales report

|              |        |            |  |    |
|--------------|--------|------------|--|----|
| X            | HOURLY |            |  | 1  |
|              |        | 0000019    |  | 2  |
| 00:00->01:00 |        |            |  | 3  |
| CT           |        | 1          |  | 4  |
| GROSS        |        | \$1.10     |  | 5  |
| NET          | No     | 1          |  | 6  |
| 1.90%        |        | \$1.20     |  | 7  |
| <hr/>        |        |            |  |    |
| 23:00->00:00 |        |            |  |    |
| CT           |        | 1          |  |    |
| GROSS        |        | \$3.45     |  |    |
| NET          | No     | 1          |  |    |
| 3.90%        |        | \$3.59     |  |    |
| <hr/>        |        |            |  |    |
| TL           | CT     | 280        |  | 8  |
| GROSS        |        | \$1,937.61 |  | 9  |
| NET          | No     | 25         |  | 10 |
|              |        | \$2,096.80 |  | 11 |

- 1 Read symbol/report title
- 2 Report code
- 3 Time zone
- 4 No. of customers
- 5 Gross sales amount
- 6 No. of receipts
- 7 Sales ratio/net sales amount
- 8 Total No. of customers
- 9 Gross total amount
- 10 Total No. of receipt
- 11 Net total amount

# Advanced programmings and registrations

## ■ Monthly sales report

|         |         |              |    |
|---------|---------|--------------|----|
| X       | MONTHLY |              | 1  |
|         |         | 0000020      | 2  |
| 1.....  |         |              | 3  |
| GROSS   |         | 1236.76      | 4  |
|         |         | \$12,202.57  | 5  |
| NET     | No      | 214          | 6  |
|         |         | \$12,202.57  | 7  |
| 31..... |         |              |    |
| GROSS   |         | 2132         |    |
|         |         | \$14,187.57  |    |
| NET     | No      | 205          |    |
|         |         | \$13,398.76  |    |
| -----   |         |              |    |
| TL      |         |              | 8  |
| GROSS   |         | 9746.63      | 9  |
|         |         | \$161,022.49 | 10 |
|         |         | \$16.52      | 11 |
| NET     | No      | 2351         | 12 |
|         |         | \$161,022.49 | 13 |
|         |         | \$68.49      | 14 |

- 1 Read symbol/report title
- 2 Report code
- 3 Date of month
- 4 Gross symbol/Quantity
- 5 Gross sales amount
- 6 Net symbol/No. of customers
- 7 Net sales amount
- 8 Total symbol
- 9 Gross symbol/Quantity
- 10 Gross sales amount
- 11 Daily gross sales average
- 12 Net symbol/No. of customers
- 13 Net sales amount
- 14 Daily net sales average

## ■ Flash report

|       |       |            |   |
|-------|-------|------------|---|
| X     | FLASH |            | 1 |
|       |       | 0000071    | 2 |
| DECLA |       | \$6,919.04 | 3 |
|       |       | \$0.00     | 4 |
| GROSS |       | 111.15     | 5 |
|       |       | \$7,054.14 |   |
| NET   | No    | 120        | 6 |
|       |       | \$7,263.20 |   |
| CAID  |       | \$6,919.04 | 7 |

- 1 Read report symbol/report title
- 2 Report code
- 3 Declared amount
- 4 Difference
- 5 Gross total
- 6 Net total
- 7 Cash in drawer

### About “Declared money” and “Cash in drawer”

If you programmed the register to force entry of total amount in drawer, you need to count the money in the drawer and input the amount (money declaration) before read (X) or reset (Z) report printing. On the other hand, “Cash in drawer” is the total money in the drawer calculated by the register so that you can compare the actual amount and the calculated amount.

To program money declaration, please see page E-73 “Set code 06”.

■ **Electronic journal**

|      |            |         |         |
|------|------------|---------|---------|
| X    | EJ         |         | 1       |
|      |            | 0000058 | 2       |
| REG  | 06-20-2018 | 11:58   |         |
| C01  | 0001       | 000123  |         |
| 1    | DEPT001    | T1      | \$1.00  |
| 1    | DEPT002    | T1      | \$2.00  |
| 5    | DEPT003    |         | \$5.00  |
|      | 7          | No      | 3       |
| TA1  |            |         |         |
| TX1  |            |         | \$0.15  |
| TX1  |            |         | \$0.10  |
| TL   |            |         | \$8.10  |
| CASH |            |         | \$10.00 |
| CG   |            |         | \$1.90  |
| REG  | 06-20-2018 | 11:59   |         |
| C01  | 0001       | 000124  |         |


- 1 Report header/title
- 2 Report code
- 3 Journal image

## About electronic journal

Instead of printing days' sales journal, the register stores daily sales report in the memory and you can obtain the report by assigning day or consecutive number.

To print individual department and PLUs

Instead of printing sales reports in a lump, you can obtain reports of specific departments or PLUs.



Step

- 1 Turn the Mode switch to X position.
- 2 Just press department keys or enter PLU numbers.  
For example, for Dept.028.  
 for PLUs 1 and 89.
- 3 Press key to exit from individual report printing.


Printout

|         |            |  |   |
|---------|------------|--|---|
| X       | INDIVIDUAL |  | 1 |
| DEPT028 | 38         |  | 2 |
| 8.13%   | \$257.53   |  | 3 |
| PLU0001 | 17         |  | 4 |
| 0.53%   | \$17.00    |  | 5 |
| #0001   |            |  | 6 |
| <hr/>   |            |  |   |
| TL      | 88.61      |  | 7 |
|         | \$516.10   |  | 8 |

- 1: Read symbol/report title
- 2: Department Name/No. of items
- 3: Sales ratio/amount
- 4: PLU Name/No. of items
- 5: Sales ratio/PLU amount
- 6: PLU code
- 7: Total No. of items
- 8: Total amount

## Periodic sales report


Apart from daily report, you can obtain periodic sales report. The register prints total sales data from the last periodic report. Namely, if you do this operation monthly, you can obtain monthly sales reports. The cash register allows you to obtain two kinds of periodic reports so that not only monthly reports, you can also get weekly reports.



### Step

- 1 Turn the Mode switch to X2/Z2 position. The display shows report selection screen.

### Display



- 2 Select a report using  or  keys. 1Z and 2Z clear the accumulated data while 1X and 2X store the sales data remained.
- 3 Press  key. The printer prints out the periodic report.

## Advanced programmings and registrations

|         |          |            |            |    |
|---------|----------|------------|------------|----|
| -----   |          |            |            |    |
| ZZ1     | PERIODIC | 1Z         |            | 1  |
| -----   |          |            |            |    |
| ZZ1     | DEPT     |            | 0001       | 2  |
|         |          |            | 0001115    | 3  |
| DEPT001 |          | 38         |            | 4  |
| 8.13%   |          | \$257.53   |            | 5  |
| DEPT002 |          | 18         |            |    |
|         |          |            |            |    |
|         |          |            | \$1,502.26 |    |
| -----   |          |            |            |    |
| TL      |          | 88.61      |            | 6  |
|         |          | \$1,916.10 |            | 7  |
| -----   |          |            |            |    |
| ZZ1     | FIX      |            | 0001       | 8  |
|         |          |            | 0001111    | 9  |
| GROSS   |          | 981.25     |            | 10 |
|         |          | \$6,574.40 |            |    |
| NET     | No       | 111        |            | 11 |
|         |          | \$7,057.14 |            |    |
| CAID    |          | \$6,919.04 |            | 12 |
| CHID    |          | \$139.04   |            | 13 |
| CKID    |          | \$859.85   |            | 14 |
| CRID(1) |          | \$709.85   |            | 15 |
| CRID(2) |          | \$0.00     |            | 16 |
| CRID(3) |          | \$0.00     |            | 17 |
| CRID(4) |          | \$0.00     |            | 18 |
| -----   |          |            |            |    |
| RF      | No       | 3          |            | 19 |
|         |          | \$10.22    |            |    |
| CUST    | CT       | 111        |            | 20 |
| AVRG    |          | \$63.57    |            | 21 |
| DC      |          | \$1.22     |            | 22 |
| REF     |          | \$2.42     |            | 23 |
| ROUND   |          | \$0.00     |            | 24 |
| CANCEL  | No       | 2          |            | 25 |
|         |          | \$12.97    |            |    |
| -----   |          |            |            |    |
| TA1     |          | \$2,369.69 |            | 26 |
| TX1     |          | \$128.86   |            | 27 |
| TA2     |          | \$2,172.96 |            | 28 |
| TX2     |          | \$217.33   |            | 29 |

- 1 Report title
- 2 Department report title/reset counter
- 3 Report code
- 4 Department Name/No. of items \*1
- 5 Sales ratio/amount \*1
- 6 Total No. of items
- 7 Total amount
- 8 Fixed total report title/reset counter
- 9 Report code
- 10 Gross total \*2
- 11 Net total \*2
- 12 Cash in drawer \*2
- 13 Charge in drawer \*2
- 14 Check in drawer \*2
- 15 Credit in drawer 1 \*2
- 16 Credit in drawer 2 \*2
- 17 Credit in drawer 3 \*2
- 18 Credit in drawer 4 \*2
- 19 Refund mode \*2
- 20 Customer number \*2
- 21 Average sales per customer \*2
- 22 Discount total \*2
- 23 Refund key \*2
- 24 Rounding total \*2
- 25 Cancellation \*2
- 26 Taxable 1 amount \*2
- 27 Tax 1 amount \*2
- 28 Taxable 2 amount \*2
- 29 Tax 2 amount \*2

# Advanced programmings and registrations

|        |         |           |   |
|--------|---------|-----------|---|
| ZZ1    | TRANS   | 0001      | 1 |
|        |         | 0001112   | 2 |
| CASH   | No      | 362       | 3 |
|        |         | ·1,638.04 |   |
| CHARGE | No      | 56        |   |
|        |         | ·1,174.85 |   |
| RC     | No      | 4         |   |
|        |         | ·810.00   |   |
| PD     |         | 5         |   |
|        |         | ·5.00     |   |
| CORR   | No      | 14        |   |
|        |         | ·39.55    |   |
| RCT    | No      | 3         |   |
| NS     | No      | 5         |   |
| ZZ1    | CASHIER | 0001      | 4 |
|        |         | 0001117   | 5 |
| C01    | .....   | 1         | 6 |
| GROSS  |         | 513       |   |
|        |         | ·1,654.10 | 7 |
| NET    | No      | 111       |   |
|        |         | ·1,845.35 | 8 |
| C02    | .....   | 1         | 9 |

- 1 Function key report title/reset counter
- 2 Report code
- 3 Function key count/amount <sup>\*1</sup>
- 4 Clerk report title/reset counter
- 5 Report code
- 6 Clerk name
- 7 Gross total
- 8 Net total
- 9 Clerk name


\* <sup>1</sup> Zero totalled departments/functions (the amount and item numbers are both zero) are not printed.

\* <sup>2</sup> These items can be skipped by programming. See pages E-74 "Set code 08" and E-76 "Set code 09".

# Advanced programmings and registrations

## Bluetooth setting


This setting connects the register and a smartphone by means of Bluetooth.



| Top menu    | Sub menu       |                 | What is to be set   |                                                                                                                                                                 |
|-------------|----------------|-----------------|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [Bluetooth] | System Setting | OFF             |                     | To stop sending X or Z data to a smartphone, set "X data → mobile" and "Z data → mobile" of "Function" "NO". Turns off when not using Bluetooth pairing.        |
|             |                | ON              | Pairing with mobile | Pairs with a smartphone.                                                                                                                                        |
|             |                |                 | Clear paired mobile | Clears pairing settings.                                                                                                                                        |
|             | Functions      | X data → mobile | YES                 | Set YES when sending X data to a smartphone.                                                                                                                    |
|             |                |                 | NO                  |                                                                                                                                                                 |
|             |                | Z data → mobile | YES                 | Set YES when sending Z data to a smartphone. Set YES with Backup if you wish to back up the data in an SD card when data transmission is performed incorrectly. |
|             |                |                 | YES with Backup     |                                                                                                                                                                 |
|             |                |                 | NO                  |                                                                                                                                                                 |

## Setting Bluetooth pairing


The following procedures pair your cash register with your smartphone by Bluetooth connection.




### Step

- 1 Turn the Mode switch to PGM position and select [Bluetooth].

### Display



- 2 Press  key and select [System Setting].





# Advanced programmings and registrations

## Step

**3** Press  key. The display shows "System Setting" [OFF]. Press  key again and select [ON] by  key.

**4** Press  key and select [Pairing with mobile].





**5** Press  key then activate Bluetooth on your smartphone. On the smartphone, find and select the device code of the cash register shown on the display. In this example, 12345678901234.

Note that the device code differs depending on each cash register. Make sure to select the same code shown on the cash register display.

**6** After you select the device code on the smartphone, the cash register then shows a pass key on the display. Enter the pass key (in this example, 123456) on the smartphone. Pass key differs depending on each cash register.

**7** Now your cash register and your smartphone are paired by Bluetooth connection.

## Display



You can perform detail settings or data exchange using Bluetooth connection.  
Please refer to the website <http://web.casio.com/ecr/app/>.



## Using an SD card

### Cautions when using optional SD memory card

This cash register accepts only SD or SDHC memory cards.

- The cash register supports SD cards conforming to SD standard. Capacity of the cards must be less than 2GB for SD card, between 2GB and 32GB for SDHC card.
- \* Please note that we do not guarantee for all the performances and data-handling capacities of SD or SDHC memory cards even the above conditions are satisfied. We recommend that you use new SD card.
- Please do not extract the SD card or turn the power of the cash register off while the register is accessing to the card. It may cause to damage data.
- Recorded data may be damaged or lost by electric noise or static electricity. We recommend that you back up important data.

You can store sales data or program data to an SD card or you can restore the data from SD card to your cash register.

The following table explains what you can do with an SD card.


|              |                                                                                                                  |
|--------------|------------------------------------------------------------------------------------------------------------------|
| Backup→SD    | Stores sales data and program data of register to SD card.                                                       |
| Restore←SD   | Restores sales data and program data from SD card to register.                                                   |
| Program→SD   | Stores program data to SD card.                                                                                  |
| Program←SD   | Restores program data from SD card to register.                                                                  |
| SD Format    | Formats an SD for the first usage.                                                                               |
| Backup→Flash | Stores program data into the register's built-in flash memory (for a case of power failure with flat batteries). |

The following sections explain the operation examples of the features using an SD card.

# Advanced programmings and registrations

## To format an SD card

When you use unformatted new SD card, you must format the SD card first.








### NOTE

It may take time to access to an SD card immediately after it is formatted. All the data stored in the SD card will be cleared if you execute formatting.

### Step

### Display


- 1** Insert an SD card into the SD card slot.
- 2** Turn the Mode switch to PGM position and select [SD card].
- 3** Press  key.  
Select [SD Format] on the SD card setting screen.
- 4** Select [YES] and press  key.  
The register starts to format the SD card.
- 5** Now the SD card is formatted and you can use it for storing cash register data in it.



# Advanced programmings and registrations

## To store program data in an SD card


The following operation explains how you can back up all the program data in an SD card.




### Step

### Display


- 1 Insert an SD card into the SD card slot.
- 2 Turn the Mode switch to PGM position and select [SD card]. Then press  key.




- 3 Select [Program→SD] and press  key.



- 4 Select [YES] and press  key.



- 5 After for a while, the display indicates "Backup complete".



# Advanced programmings and registrations

## Restoring backup data (automatically backed up setting data) from built in flash memory

Other than in an SD card, setting data (except sales data) may be backed up in the built in flash memory as well as in an SD card (printer prints "Data Backup Normal End"). If AC power cord is plugged out while battery power is low, all the setting data will be cleared and the cash register needs to be initialized. In such a case, setting data can be restored if the data is in built in flash memory. Please follow the instructions on the display for reading setting data or initializing the data.

## POP setting

According to the setting conditions, several POP images can be selected and printed on the lower part of receipts.

| Top menu      | Sub menu              |                         |                       | What is to be set                                                                                                                                                                                                                       |
|---------------|-----------------------|-------------------------|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [POP Setting] | Read POP Data         |                         |                       | Reads POP data from an SD card.                                                                                                                                                                                                         |
|               | POP Operation Setting | POP Printing Conditions | Always print Same POP | Always prints the same POP image.                                                                                                                                                                                                       |
|               |                       |                         | Change POP By Amount  | By the amount, POP image can be changed according to the “Setting (by Amount)” setting                                                                                                                                                  |
|               |                       |                         | Change POP By Item    | Prints POP image according to the set POP No. of DEPT Setting.                                                                                                                                                                          |
|               |                       |                         | Do Not Print          | No POP image is printed.                                                                                                                                                                                                                |
|               |                       | Setting (Always same)   |                       | Selects a POP image from five images.                                                                                                                                                                                                   |
|               |                       | Setting (by Amount)     | Amount 1              | Sets condition to print POP message in accordance with the amount. Three kinds of POP images can be set in accordance with the amount.<br>The amount is set by A x 10 <sup>B</sup> .<br>Example<br>• 12.00 A=12,B=2<br>• 100.00 A=1,B=4 |
|               |                       |                         | Amount 2              |                                                                                                                                                                                                                                         |
|               |                       |                         | Amount 3              |                                                                                                                                                                                                                                         |
|               | Print POP image       |                         |                       | Prints set POP image to check.                                                                                                                                                                                                          |


### NOTE

- POP images read by [Read POP Data] must be stored in an SD card beforehand using "ECR Setting tool" of an PC.
- POP images printed by "Setting (by Amount)" are; Amount 1 = image 1, Amount 2 = image 2, and Amount 3 = image 3.
- When several conditions of "Settings (by Amount)" are satisfied, the priority order is Amount 3 > Amount 2 > Amount 1.

## Handling of the cash drawer


### To lock and unlock the cash drawer

Turning the drawer key clockwise locks the drawer and turning counterclockwise unlocks the drawer.




### To pull out the cash drawer (S drawer)

As shown on the right figure, lift the drawer and pull it out. If the cash drawer cannot be opened, make sure that it is unlocked.




### To pull out the cash drawer (M drawer)

**1** Remove the bill coin tray.




**2** Lifting the front part of the drawer, pull it out.




## To remove coin divider (certain models)

For the models with a hook on lower part of coin divider, you can move the coin partition.

**1** Pushing down the hook, lift up the coin partition.



**2** To set the partition, insert it in the groove on the coin case and push it until it is hooked. You can check the state of the hook from the bottom of the coin case.



### NOTE

- There are two kinds of drawers size S and size M.
- Some types of cash drawers cannot remove the coin partition.
- The shape of coin case differs depending on the number of coin partitions.

## Before you consider it as a problem

### Error code table

| Error code | Message                         | Meaning                                                                               | Action                                                                                           |
|------------|---------------------------------|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| E001       | Wrong mode                      | Mode switch position changed before finalization.                                     | Return the mode switch to its original setting and finalize the operation.                       |
| E003       | Wrong operator                  | The signed on clerk differs from the clerk performed the tracking check registration. | Input correct check number or assign the proper clerk number.                                    |
| E004       | Error INIT/FC                   | Initialization or unit lock clear operation in progress.                              | Complete operation.                                                                              |
| E008       | Please sign on                  | Registration without entering a clerk number.                                         | Enter a clerk number.                                                                            |
| E010       | Close the drawer                | The drawer is left open longer than the program time (drawer open alarm).             | Close the drawer.                                                                                |
| E011       | Close the drawer                | Attempt to register while the cash drawer is open.                                    | Close the drawer.                                                                                |
| E016       | Change back to REG mode         | Two consecutive transactions attempted in the refund mode.                            | Switch to another mode and then back to the RF mode for the next transaction.                    |
| E017       | Enter CHK/TBL number            | Attempt made to register an item without inputting a check number.                    | Input a check number.                                                                            |
| E018       | Enter Table number              | Attempt made to register an item without inputting a table number.                    | Input a table number.                                                                            |
| E019       | Enter number of customers       | Finalize operation attempted without entering the number of customer.                 | Enter the number of customer.                                                                    |
| E021       | No DEPT Link                    | No department linked PLU is registered.                                               | Correct the program.                                                                             |
| E026       | Enter condiment/preparation PLU | No condiment/preparation PLU is registered.                                           | Register condiment/preparation PLU.                                                              |
| E029       | In the tender operation         | Item registration is prohibited, while partial tender.                                | Finalize the transaction.                                                                        |
| E031       | Press ST key                    | Finalization of a transaction attempted without confirming the subtotal.              | Press  key. |
| E033       | Enter tendered amount           | Finalize operation attempted without entering amount tender.                          | Enter the amount tendered.                                                                       |
| E035       | Change amount exceeds limit     | Change amount exceeds preset limit.                                                   | Input amount tendered again.                                                                     |
| E036       | Remove money from the drawer    | Contents of the drawer exceed programmed limit.                                       | Perform payout operation.                                                                        |
| E037       | Digit or amount limitation over | High amount lock out/low digit lock out error                                         | Enter correct amount.                                                                            |
| E038       | Perform money declaration       | Read/reset operation without declaring cash in drawer.                                | Perform money declaration.                                                                       |



## Advanced programmings and registrations


| Error code | Message                                        | Meaning                                                                                                                                 | Action                                                                                                                                            |
|------------|------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| E040       | Issue guest receipt                            | Attempt to register a new transaction without issuing a guest receipt.                                                                  | Issue a guest receipt.                                                                                                                            |
| E046       | REG buffer full                                | Registration buffer full.                                                                                                               | Finalize the transaction.                                                                                                                         |
| E049       | CHECK memory full                              | Check tracking index memory full.                                                                                                       | Finalize and close the check number currently used.                                                                                               |
| E050       | DETAIL memory full                             | Check tracking detail memory full.                                                                                                      | Finalize and close the check number currently used.                                                                                               |
| E051       | CHK/TBL No. is occupied                        | Attempt to made use <New Check> to open a new check using a number that is already used for an existing check in check tracking memory. | Finalize and close the check that is currently under the number that you want to use or use a different check number.                             |
| E053       | CHK/TBL No. is not opened                      | Attempt made to use <Old Check> reopen a new check using a number that is not used for an existing check in check tracking memory.      | Use the correct check number (if you want to reopen a check that already exists in check tracking memory) or use <New Check> to open a new check. |
| E075       | Negative balance cannot be finalized           | Attempt to finalize a transaction when balance is less than or equal to zero.                                                           | Register item(s) until the balance becomes positive amount.                                                                                       |
| E101       | PLU maintenance file full. Press <#2> to exit  | PLU direct maintenance/batch maintenance file becomes full.                                                                             | Terminate the maintenance.                                                                                                                        |
| E103       | PLU Code is not exist. Input the PLU Code      | PLU code is not existed in the file.                                                                                                    | Enter proper PLU code.                                                                                                                            |
| E105       | PLU file full                                  | PLU file full                                                                                                                           | Modify the designated item.                                                                                                                       |
| E106       | Item exists in the PLU FILE                    | The designated item has already existed in the PLU file.                                                                                |                                                                                                                                                   |
| E112       | Close the journal platen arm                   | The journal platen arm is opened.                                                                                                       | Close the journal platen arm.                                                                                                                     |
| E114       | Close the receipt platen arm                   | The receipt platen arm is opened.                                                                                                       | Close the receipt platen arm.                                                                                                                     |
| E139       | Negative balance is not allowed                | Attempt to register <--> or <CPN> when the balance becomes negative.                                                                    | Enter proper minus/coupon amount.                                                                                                                 |
| E146       | Arrangement file full                          | Arrangement file is full.                                                                                                               | Set the arrangement properly.                                                                                                                     |
| E164       | Employee No. is not Found in the Employee File | Attempt to enter a wrong employee number which is not set to the employee file.                                                         | Enter proper employee number.                                                                                                                     |
| E200       | Insert SD                                      | SD is not inserted.                                                                                                                     | Set SD.                                                                                                                                           |
| E201       | Illegal Format                                 | Illegally formatted SD                                                                                                                  | Format the SD.                                                                                                                                    |
| E202       | File not found                                 | The designated file is not found in the SD.                                                                                             | Enter proper file name.                                                                                                                           |

## Advanced programmings and registrations

| Error code | Message                                                 | Meaning                                                           | Action                                                                                                                                                                                           |
|------------|---------------------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E204       | Check the write protect switch                          | Write protect switch of the SD card is on.                        | Turn the write protect switch off.                                                                                                                                                               |
| E205       | File already exist.                                     | Cannot write, because designated file has already been in the SD. | Check the operation and retry.                                                                                                                                                                   |
| E220       | (Bluetooth error) No device is connected via Bluetooth. | No device is connected via Bluetooth.                             | Activate Bluetooth on your mobile and connect with the cash register.                                                                                                                            |
| E221       | (Bluetooth error) Bluetooth communication error.        | Bluetooth communication error.                                    | Your mobile may be out of range. Please place your mobile closer to the cash register.<br>If possible, move away microwaves, wireless routers or other Bluetooth devices from the cash register. |

## About HELP guidance


In any Mode switch position, pressing  key prints a guide menu shown below.



Enter the guidance number and press  key. The printer prints the guidance what to be done. For example, enter **0 4** and press  key to print the guidance in case LOW-BATTERY is shown on the display.

## When “EJ FULL” sign appears on the display

When the register shows this sign, issue electronic journal read report (if necessary) and reset the memory immediately.



## In case of power failure

If the power supply to the cash register is cut by a power failure or any other reason, simply wait for power to be restored. The details of any ongoing transaction as well as all sales data in memory are protected by the memory backup batteries. (This is the reason to install the batteries.)

- Power failure during a registration

The subtotal for items registered up to the power failure is retained in memory. You will be able to continue with the registration when power is restored.

- Power failure during printing a read / reset report

The data already printed before the power failure is retained in memory. You will be able to issue a report when power is restored.

- Power failure during printing of a receipt / journal

Printing will resume after power is restored. A line that was being printed when the power failure occurred is printed in full.

- Other

The power failure symbol is printed and any item that was being printed when the power failure occurred is reprinted in full.

## In case the register is locked up

If you make a mistake in operation, the cash register may lock up to avoid damage to programs and preset data. Should it happens, you can use the following procedure to clear the lock up without losing any data.

- 1** Insert the PGM key in the mode switch.
- 2** Turn the mode switch to OFF mode.
- 3** Press down , and turn the mode switch to PGM mode.
- 4** The display shows “0000000000”, then release .
- 5** Press,  then issue a receipt.

## About the low battery indicator

If this indicator appears when you switch the cash register on, it can mean one of three things:

- No memory backup batteries are loaded in the cash register.
- The power of the batteries loaded in the unit is below a certain level.
- The batteries loaded in the unit are dead.



### Important !

Whenever the low battery indicator appears on the display, load a set of two new batteries as soon as possible. If there is a power failure or you unplug the cash register when this indicator appears, you will lose all of your sales data and settings.

**Be sure to keep the power cord of the cash register plugged in whenever you replace the batteries.**

| Category                         | No. of totalizers | Contents                     |                         |                 |                         | Periodic totalizer |
|----------------------------------|-------------------|------------------------------|-------------------------|-----------------|-------------------------|--------------------|
|                                  |                   | Amount (10 digits)           | No. of items (4 digits) | Count (4 digit) | No. of items (4 digits) |                    |
| Department                       | 200               | O *1                         | O *3                    |                 |                         | O                  |
| PLU                              | 3000              | O *1                         | O *3                    |                 |                         |                    |
| Hourly sales                     | 24                | O *1                         |                         | O *4            | O *5                    |                    |
| Monthly sales                    | 31                | O *1                         |                         |                 | O *5                    |                    |
| Clerk                            | 50                | O *1                         |                         |                 | O *5                    |                    |
| Transaction key & fix total      | --                | O *1 or O *3 or O *4 or O *5 |                         |                 |                         | O                  |
| Non resettable grand sales total | 1                 | O *2                         |                         |                 |                         |                    |
| Reset counter                    | 8                 |                              |                         | O *4            |                         | O                  |
| Consecutive No.                  | 1                 |                              |                         |                 | O *5                    |                    |

\* 1 -9,999,999.99 ~ 99,999,999.99

\* 2 -9,999,999,999,999.99 ~ 99,999,999,999,999.99

\* 3 -99,999.999 ~ 999,999.999

\* 4 1 ~ 9999

\* 5 1 ~ 999999

Specifications and design are subject to change without notice.

## About open source code

The software of our product includes the work that is distributed in the Apache License 2.0.

You may obtain a copy of the License at "<http://www.apache.org/licenses/LICENSE-2.0>".

# Advanced programmings and registrations

## Specifications

|                  |                                                                                  |
|------------------|----------------------------------------------------------------------------------|
| Entry            | 10-key system, buffer memory 8 keys (2-key roll over)                            |
| Department       | Full key system                                                                  |
| Main display     | 26 characters x 10 lines, Dept. name, PLU name, Total, Transaction names, Change |
| Customer display | 20 characters x 1 line. Amount 10 digits (zero suppression)                      |

### Printer

|                 |                                                                                                                                                                   |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Receipt/Journal | Thermal alpha-numeric system 24 digits, receipt on/off key<br>Store name or slogan is printed automatically (Receipt)<br>Automatic take up roll winding (Journal) |
| Paper roll      | 58 (W) × 80 (D) mm Φ(Max.)                                                                                                                                        |
| Paper thickness | 0.06 to 0.08 mm                                                                                                                                                   |
| Paper feed      | Receipt or Journal                                                                                                                                                |
| Print speed     | About 20 l/s                                                                                                                                                      |

### Listing capacity

|                 |                  |
|-----------------|------------------|
| Amount          | 9999999999       |
| Quantity        | 9999.999         |
| Tendered amount | 9999999999       |
| Percent         | 99.99            |
| Tax rate        | 9999.9999        |
| Numbers         | 9999999999999999 |

### Chronological data

|                                |                                                                                                                                                                                                           |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Date print                     | Automatic date printout on receipt and journal, automatic calendar                                                                                                                                        |
| Time print                     | Automatic time printout on receipt and journal, 24-hour system/12-hour system                                                                                                                             |
| Alarm                          | Key catch tone, error alarm                                                                                                                                                                               |
| Memory protection battery      | The effective service life of memory protection batteries (two new size AA alkaline batteries) is approximately one year from installation into the machine.                                              |
| Power supply/power consumption | See the rating plate.                                                                                                                                                                                     |
| Operation temperature          | 0°C to 40°C (32°F to 104°F)                                                                                                                                                                               |
| Humidity                       | 10 to 90% RH                                                                                                                                                                                              |
| Dimensions                     | 220 mm (H) × 400 mm (W) × 450 mm (D)<br>(8.6" (H) × 15.7" (W) × 17.7" (D)) with medium size drawer.<br>205 mm (H) × 330 mm (W) × 360 mm (D)<br>(8.0" (H) × 13.0" (W) × 14.1" (D)) with small size drawer. |
| Weight                         | 9 kg (20 lbs.) with medium size drawer<br>5 kg (11 lbs.) with small size drawer.                                                                                                                          |

### Data communication specifications

|                    |                                              |                                                                                |
|--------------------|----------------------------------------------|--------------------------------------------------------------------------------|
| Bluetooth          | Supported version                            | Bluetooth® low energy (Ver. 4.1 +LE)                                           |
|                    | Communication range                          | Approximately 3 m (10ft)<br>(depends on radio wave conditions and environment) |
| External interface | SD/SDHC memory card slot x 1<br>COM port x 2 |                                                                                |

|        |       |
|--------|-------|
| Option | WT-94 |
|--------|-------|

|             |                                                                                                                               |
|-------------|-------------------------------------------------------------------------------------------------------------------------------|
| Accessories | Roll paper, Mode keys, Drawer keys, Magnetic plate*, Manuals<br>*Use this plate for tacking the notes received from customer. |
|-------------|-------------------------------------------------------------------------------------------------------------------------------|

# Other ManualsLib Projects

 [www.manualslib.com](http://www.manualslib.com)

 [www.manualslib.de](http://www.manualslib.de)

 [www.manualslib.es](http://www.manualslib.es)

 [www.manualslib.fr](http://www.manualslib.fr)

 [www.manualslib.nl](http://www.manualslib.nl)

 [www.manualslib.mx](http://www.manualslib.mx)

 [www.manualslib.tech](http://www.manualslib.tech) 30+ Languages