

DIP SW 1

*FACTORY CHOICE

		1 2 3 4 5 6 7 8
NOT USE		OFF ON
PICTURE INDICATE	* NORMAL REVERSE	OFF ON
FUNCTION CHECK	* NORMAL PLAY TEST PATTERN	OFF ON
DEMO SOUND	* ON NO SOUND	OFF ON
*1COIN/1PLAY COIN SW1 1 2 2 1 2 3	*1COIN/1PLAY for 2 1 EUROPE 3 1 4 1	OFF OFF ON ON ON
*1COIN/1PLAY COIN SW2 1 2 2 1 2 3	*1COIN/1PLAY for 1 3 EUROPE 1 4 1 6	OFF OFF ON OFF OFF ON ON ON

DIP SW 2

		1	2	3	4	5	6	7	8
DIFFICULTY	*B NORMAL A EASY C DIFFICULT D MORE DIFFICULT								
EXTRA PLAYER	*300,000 points EACH 200,000 & 500,000 ONLY 300,000 points ONLY NO EXTRA								
NUMBER OF PLAYER	*3 5 2 1								
NO DEATH MODE	* NORMAL PLAY CAN PLAY ONLY ONE PLAYER			OFF ON					
NOT USE									OFF ON

8WAY JOYSTICK SHOOT BUTTON **BOMB BUTTON** 2 P 8WAY JOYSTICK SHOOT BUTTON **BOMB BUTTON**

JAMMA

SOLDER FACE			PARTS FACE
GND	Α	1	GND
GND		2	GND
+5V		3	+5V
+5∨	D	4	+5V
N.C.	Ε	5	N.C.
+12V	F	6	+12V
	Н	7	
COIN COUNTER 2	J	8	COIN COUNTER 1
(COIN LOCK OUT 2)	Κ	9	(COIN LOCK OUT 1)
SP (-)	L	10	SP (+)
N.C.	М	11	N.C.
VIDEO GREEN	Ν	12	VIDEO RED
VIDEO SYNC	Р	13	VIDEO BLUE
SERVICE SW	R	14	VIDEO GND
	s	15	TEST SW
COIN SW 2	Т	16	COIN SW 1
START SW 2	U	17	START SW 1
2P UP	V	18	1P UP
2P DOWN	W	19	1P DOWN
2P LEFT	X	20	1P LEFT
2P RIGHT	Y	21	1P RIGHT
2P PUSH 1	Z	22	1P PUSH 1
2P PUSH 2	а	23	1P PUSH 2
N.C.	b	24	N.C.
N.C.	С	25	N.C.
N.C.	d	26	N.C.
GND	е	27	GND
GND	f	28	GND