


|  |
|--|
|  |
|--|

Rev:  
Id: 1/5

# Fuel level nad temperature control



Sheet: /fuel level and engine temperature control/  
File: fuel\_level\_and\_temperature.kicad\_sch

## Title:

Size: A4


Date:

KiCad E.D.A. 9.0.7


Rev:

Id: 2/5

## USB protection and 3V3 LDO



## CAN transceiver



Sheet: /usb and can controller/  
File: usb\_and\_can\_controler.kicad\_sch

### Title:

Size: A4


Date:

KiCad E.D.A. 9.0.7


Rev:

Id: 3/5


SPEED control




BREAK PADS ERROR control




ABS ERROR control




AIR BAG control




WIPER FLUID ERROR control




EXTRA PIN



BREAKS ERROR control



COOLANT ERROR control



Sheet: /Speed and tell-tales/  
File: Speed\_and\_tell-tales.kicad\_sch

**Title:**

Size: A4


Date:

KiCad E.D.A. 9.0.7


**Rev:**

Id: 4/5


Cluster Power




12V DC Input



Cluster data lines



Cluster Warning-Lights



Sheet: /Cluster plugs/  
File: cluster\_plugs.kicad\_sch

**Title:**

Size: A4

Date:

KiCad E.D.A. 9.0.7

**Rev:**

Id: 5/5