

ecx

M. Skocic

Table of Contents

ecx	1
---------------	---

NAME

ecxcli(1) - Command line for ecx

SYNOPSIS

ecxcli *SUBCOMMAND* [*OPTION...*] *ARG...*

DESCRIPTION

ecxcli is command line interface for computing electro- chemical properties:

- o **EIS** Electrochemical Impedance $Z=f(w)$
- o **Kinetics**
 $j=f(U)$
- o **PEC** $I_{ph}=f(h\nu, U)$

It can also provide the molar masses, isotope compositions and nuclide compositions.

OPTIONS

all:

- usage, -u**
Show usage text and exit.
- help, -h**
Show help text and exit.
- verbose, -V**
Display additional information when availabl
- version, -v**
Show version information and exit.

NAME

ecx - library for electrochemistry

LIBRARY

ecx (**-libecx**, **-lecx**)

SYNOPSIS

```
ecx (Fortran): use ecx
ecx (C): include "ecx.h"
ecx (python): import pyecx
```

DESCRIPTION

ecx a Fortran library for providing a collection of routines for electrochemistry. A C API allows usage from C, or can be used as a basis for other wrappers. A Python wrapper allows easy usage from Python.

It covers:

o kinetics

Nernst, Butler-Volmer

o electrochemical

Impedance, Admittance, Circuit Elements, Equivalent Circuits

o photoelectrochemistry

Photocurrent, Band-gap, space charge.

The C API is defined by adding a prefix to the functions from the Fortran API due to the lack of module/namespace feature in the C language. The functions are therefore following this template: (c_prefix)fortran_func.

Fortran API

o function get_version()result(fptr)

Get the version.

o character(len=:), pointer :: fptr

Version of the library.

o pure elemental function kTe(T)result(r)

Compute the thermal voltage.

o real(dp), intent(in) :: T

Temperature in $\text{\AA}^\circ\text{C}$.

o real(dp) :: r

Thermal voltage in V.

o subroutine z(p, w, zout, e, errstat, errmsg)

Compute the complex impedance.

o real(dp), intent(in) :: p(:)

Parameters defining the element e

o real(dp), intent(in) :: w(:)

Angular frequencies in rad.s^{-1}

o character(len=1), intent(in) :: e

Electrochemical element: R, C, L, Q, O, T, G

o complex(dp), intent(out) :: zout(:)

Complex impedance in Ohms.

o integer(int32), intent(out) :: errstat

Error status

- o character(len=:), intent(out), pointer :: errmsg**
Error message
- o subroutine mm(p, w, zout, n)**
Compute the measurement model.
- o real(dp), intent(in) :: p(:)**
Parameters.
- o real(dp), intent(in) :: w(:)**
Angular frequencies in rad.s-1
- o complex(dp), intent(out) :: zout(:)**
Complex impedance in Ohms.
- o integer(int32), intent(in) :: n**
Number of voigt elements.
- o pure function nernst(E0, z, aox, vox, ared, vred, T)result(E)**
Compute the Nernst electrochemical potential in V.
- o real(dp), intent(in) :: E0**
Standard electrochemical potential in V.
- o integer(int32), intent(in) :: z**
Number of exchanged electrons.
- o real(dp), intent(in) :: aox(:)**
Activities of the oxidants.
- o real(dp), intent(in) :: vox(:)**
Coefficients for the oxidants.
- o real(dp), intent(in) :: ared(:)**
Activities of the reductants
- o real(dp), intent(in) :: vred(:)**
Coefficients for the reductants.
- o real(dp), intent(in) :: T**
Temperature in $\hat{\text{A}}^{\circ}\text{C}$.
- o real(dp) :: E**
Nernst potential in V.
- o pure elemental function sbv(U, OCV, j0, aa, ac, za, zc, A, T)result(I)**
Compute Butler Volmer equation without mass transport.
- o real(dp), intent(in) :: OCV**
Open Circuit Voltage in V.
- o real(dp), intent(in) :: U**
Electrochemical potential in V.
- o real(dp), intent(in) :: j0**
Exchange current density in A.cm-2.
- o real(dp), intent(in) :: aa**
Anodic transfer coefficient.
- o real(dp), intent(in) :: ac**
Cathodic transfer coefficient.
- o real(dp), intent(in) :: za**
Number of exchanged electrons in the anodic branch.

- o real(dp), intent(in) :: zc**
Number of exchnaged electrons in the cathodic branch.
- o real(dp), intent(in) :: A**
Area in cm2.
- o real(dp), intent(in) :: T**
Temperature in $\hat{A}^{\circ}\text{C}$.
- o real(dp) :: I**
Current in A.
- o pure elemental function bv(U, OCV, j0, jdla, jdle, aa, ac, za, zc, A, T)result(I)**
Compute Butler Volmer equation with mass transport.
- o real(dp), intent(in) :: OCV**
Open Circuit Voltage in V.
- o real(dp), intent(in) :: U**
Electrochemical potential in V.
- o real(dp), intent(in) :: j0**
Exchange current density in A.cm-2.
- o real(dp), intent(in) :: jdla**
Anodic diffusion limiting current density in A.cm-2.
- o real(dp), intent(in) :: jdle**
Cathodic diffusion limiting current density in A.cm-2.
- o real(dp), intent(in) :: aa**
Anodic transfer coefficient.
- o real(dp), intent(in) :: ac**
Cathodic transfer coefficient.
- o real(dp), intent(in) :: za**
Number of exchnaged electrons in the anodic branch.
- o real(dp), intent(in) :: zc**
Number of exchnaged electrons in the cathodic branch.
- o real(dp), intent(in) :: A**
Area in cm2.
- o real(dp), intent(in) :: T**
Temperature in $\hat{A}^{\circ}\text{C}$.
- o real(dp) :: I**
Current in A.

C API

- char* **ecx_get_version**(void)
- const double ecx_core_PI
- const double ecx_core_T_K
- void **ecx_core_nm2eV**(double *lambda, double *E, size_t n)
- void **ecx_core_kTe**(double *T, double *kTE, size_t n)
- double **ecx_kinetics_nernst**(double E0, int z, double *aox, double *vox, size_t nox, double *ared, double *vred, size_t nred, double T)
- void **ecx_kinetics_sbv**(double *U, double OCV, double j0, double aa, double ac, double za, double zc, double A, double T, double *i, size_t n)

- void **ecx_kinetics_bv**(double *U, double OCV, double j0, double jdla, double jdlc, double aa, double ac, double za, double zc, double A, double T, double *i, size_t n)
- void **ecx_eis_z**(double *p, double *w, ecx_cdouble *z, char e, size_t k, size_t n, int *errstat, char *(*errmsg))

Python wrappers

- **z**(e:str, w:Union[np.ndarray,array.array,int,float], p:Union[np.ndarray,array.array])->np.ndarray

NOTES

To use ecx within your fpm <<https://github.com/fortran-lang/fpm>> project, add the following lines to your file:

```
[dependencies]
ecx = { git="https://github.com/MilanSkocic/ecx.git" }
```

EXAMPLE

Example in Fortran:

```
program example_in_f
  use iso_fortran_env
  use ecx
  implicit none

  real(real64) :: w(3) = [1.0d0, 1.0d0, 100.0d0]
  real(real64) :: r = 100.0d0
  real(real64) :: p(3) = 0.0d0
  character(len=1) :: e
  integer :: errstat
  complex(real64) :: zout(3)
  character(len=:), pointer :: errmsg

  p(1) = r
  e = "R"
  call z(p, w, zout, e, errstat, errmsg)
  print *, zout
  print *, errstat, errmsg
end program
```

Example in C:

```
int main(void){
  int errstat, i;
  double w[3] = {1.0, 1.0, 1.0};
  double p[3] = {100.00, 0.0, 0.0};
  ecx_cdouble z[3] = {ecx_cbuild(0.0,0.0),
                      ecx_cbuild(0.0, 0.0),
                      ecx_cbuild(0.0, 0.0)};

  char *errmsg;

  ecx_eis_z(p, w, z, 'R', 3, 3, &errstat, &errmsg);

  for(i=0; i<3;i++){
    printf("%f %f 0, creal(z[i]), cimag(z[i]));
  }
  printf("%d %s0, errstat, errmsg);
  return EXIT_SUCCESS;
```

```
}
```

Example in Python:

```
import numpy as np
import pyecx
import matplotlib.pyplot as plt

R = 100
C = 1e-6
w = np.logspace(6, -3, 100)

p = np.asarray([R, 0.0, 0.0])
zr = np.asarray(pyecx.z("R", w, p))
p = np.asarray([C, 0.0, 0.0])
zc = np.asarray(pyecx.z("C", w, p))
zrc = zr*zc / (zr+zc)
print("finish")

fig = plt.figure()
ax = fig.add_subplot(111)

ax.set_aspect("equal")
ax.plot(zrc.real, zrc.imag, "g.", label="R/C")

ax.invert_yaxis()

plt.show()
```

SEE ALSO

complex(7), gsl(3), catanh(3), gnuplot(1), ecx_get_version(3)