ECU1_Architecture_Layers

Application_Layer

- State_Reader
- Communication_Module

On_Board_Layer

- Light_Switch_Module
- Door_Sensor_Module
- Speed_Sensor_Module

Operating_System & Common_Libraries

HAL_Layer

MCAL_Layer

- Timer_Driver
- DIO_Driver
- CAN_Driver