Mac Mini - Clear NVRAM

1. Shut down your Mac mini.

2. Press the power button to turn it on.

3. Immediately press and hold the following keys:

Option (Alt)	Command (Win)	P	R

4. Release the keys after you hear the startup sound twice.