




NOTE: DISCONNECT POSITIVE WIRE FROM ARDUINO USB!!!

MODIFICATIONS ON A19 BOARD:

- remove U13
- remove U9
- connect U9_2 to GND
- remove C1
- remove Q1, C2
- remove U2
- remove U6
- remove U15
- remove U3

Sheet: /	
File: Arduino_shield.kicad_sch	
Title: HP5341A A19 replacement board	
Size: A4	Date: 2023-09-22
KiCad E.D.A. 9.0.1	Rev: 0.2
	Id: 1/1