
实验 1: 最简单的八路跑马灯

1. 试验描述:

先通过对 PA 端口的 8 位从右向左依次置零,实现 8 路 LED 灯依次从上到下点亮,再从左向右把 PA 端口的 8 位置零控制 8 路 LED 灯依次从小到上点亮,构成跑马灯形式,以此掌握 ATmega16 单片机的 I\0 端口操作。


2.系统框图:



图一 硬件电路连接图

元件	个数	大小
ATmega16 芯片	1 个	
电阻	8个	100k
LED灯	8个	

表一 元件清单



3.程序代码:

3.1 ICCAVR 程序

```
#include<iom16v.h>

#define uchar unsigned char

#define uint unsigned int

uchar Led_PA;

void delayms(uint n)

{
   uint i=0,j=0;
   for (i=0;i<n;i++)</pre>
```

```
for (j=0;j<100;j++);</pre>
int main(void)
{
 uchar k;
 DDRA=0xFF;
 PORTA=0xFF;
 while(1)
 {
 Led_PA=0xfe;
 for (k=0; k<8; k++)
  PORTA=Led_PA;
  Led_PA=(Led_PA<<1)|0x01;
  delayms(300);
  PORTA=0xff;
 delayms(300);
 Led_PA=0x7f;
  for (k=0; k<8; k++)</pre>
  PORTA=Led_PA;
  Led_PA=(Led_PA>>1) | 0x80;
  delayms(300);
  PORTA=0xff;
```

```
delayms(300);
}
return 0;
}
```

3.2 CVAVR 程序

```
#include<mega16.h>
#define uchar unsigned char
#define uint unsigned int
uchar Led_PA;
void delayms(uint n)
uint i=0, j=0;
for (i=0;i<n;i++)</pre>
for (j=0;j<100;j++);</pre>
void main(void)
{
uchar k;
DDRA=0xFF;
PORTA=0xFF;
while(1)
```

```
Led_PA=0xfe;
for (k=0; k<8; k++)</pre>
 PORTA=Led PA;
 Led_PA=(Led_PA<<1)|0x01;
 delayms(300);
PORTA=0xff;
delayms(300);
Led_PA=0x7f;
for (k=0; k<8; k++)</pre>
 PORTA=Led_PA;
 Led_PA=(Led_PA>>1) | 0x80;
delayms(300);
PORTA=0xff;
delayms(300);
}
```

4.仿真结果:

如图,8个LED等从左到右依次点亮,在从右到左依次点亮,一直循环下去。

