# Use player options and settings

URL: https://docs.grassfish.com/docs/menu-window

Archiviert am: 2025-07-17 18:43:32

The menu window provides general information and access to additional options and system settings.

IP
192.168.1.117

BoxId
jk-H-mk39

PlayerVersion
11.8.0

LastReboot
2021-12-31T13:00:25

OsVersion
Android 9

SerialNumber
ID1AF1QUKP

WebViewProvider
com.android.chrome: 85.0.4183.101

Device
Rk3399

Build.FINGERPRINT
rockchip/rk3399_mid/rk3399_mid:9/PI/yhf03091754:userdebug/test-keys

Build.DISPLAY

Click on the following icons for additional options:

▶	Start the player.
⚙	Open the settings.

	Select the screen orientation: • Landscape • Landscape reverse • Portrait • Portrait reverse • Auto
	Reset the player.
	Exit player. This shuts down the player software.