Screen controller doesn't work

URL: https://docs.grassfish.com/docs/screen-controller-doesnt-work

Archiviert am: 2025-07-17 18:30:43

Symptoms


Screen controller doesn't work as intended with RS-232. Your screen controller configuration is incorrect.

Resolution

The following steps can help you identify and solve the issue.

Check the configuration

- 1. To ensure that you've added the COM port, go to the player configuration or the configuration group:
 - For an individual player, go to **Channels > Location**. Double-click on your player and select **Edit** next to **Configuration** in the **Edit player** window.
 - For a configuration group, go to **Administration > Player > Configuration groups** and double-click on the configuration group.
- 2. In the **Edit configuration group** window, ensure that **Display extended modules** is selected.
- 3. Under Modules, select ScreenController > Screen.
- 4. Ensure that the **Device Name of monitor 1** matches the name of your COM port.



Check the hardware

In addition to the signal cable, usually an HDMI cable, RS-232 control also requires a control cable that must be connected to the RS-232 interface.

Ensure that this cable is present, correctly connected, and compatible with your system. Otherwise, the IXM One configuration can't take effect.