Get general info

URL: https://docs.grassfish.com/docs/info-window

Archiviert am: 2025-07-17 18:43:37

If the player is not in kiosk mode, you can see the info window. It contains the most important information about the system and the player hardware. For example, a player's IP address or the version of the operating system.

Note

Without user interaction, this window closes after 60 seconds and the player resumes playing spots. If you enter a password, every character counts as an interaction which keeps the window open for an additional 60 seconds.

Access the menu

To access the menu for options and settings, enter the current password at the top of the info window and select **UNLOCK**.

