SMRT Pax Terminal Setup

1) Connect the AC power to the Terminal, and press the **Red X on the Keypad** to turn on the device.
NOTE: Keep powered on 24/7 to ensure proper synchronization with your system. Ensure that the reader is not plugged into an outlet that is controlled by a light switch.

Prior to connecting your Reader to your Wifi please note:
Please ensure that you have a strong Wifi connection that is steady and consistent. Recommend at least 20Mbps (a standard connection) in order for the Terminal to operate smoothly.
If Wifi connection is not strong enough make sure to use an ethernet cable to ensure a consistent connection

2)Connect the Terminal to your WiFi by sliding down from the top of the screen and holding down on the WiFi icon until the list of Available Networks appears.


Select your WiFi Network that you are using


Enter your WiFi Password

Once Connected, the WiFi Icon will appear and be solid White. You are now connected to your Wifi connection.

 3) Tap on the **SMRT Mobile App** located on screen of the Pax Terminal

4) Once SMRT Mobile is open on the Pax Terminal, your device will ask you for an Auth Code.

To get the Auth Code, open SMRT on your Terminal and go to **Settings**, then **Peripherals**

Settings

Peripherals

Pax Terminal Setup

Get Auth Cod

You should see below the Printers a Pax Terminal Setup. Click on **Get Auth Code.**

Enter the Auth code that your Station generates and input via keypad on the PAX Terminal and press Enter.

Click Okay on the Counter Station to exit out of the   Get Auth Code screen.

Your PAX Terminal should now look like this --->

Once completed,**EXIT** SMRT on the Computer and reopen SMRT and log in.

5) To Process a Payment, just enter the amount and **Press Pay**

 The customer will see this screen once prompting for Payment on the PAX Terminal:
And they can swipe, insert, tap, or use Google, Samsung, or Apple Pay to make their payment.