
Stripe Terminal Setup

Setup

- 1. Make sure that the Store has an address and that it is valid.
- 2. Payment Settings



- Create a Stripe merchant and set User to the business' Stripe account (acct_xxx).
 This step is also applicable for online payments with Stripe.
- Add Stripe Terminal to Accepted Payment Methods

3. BBPOS WisePOS E setup

See https://stripe.com/docs/terminal/payments/setup-reader/bbpos-wisepos-e for reference. Turn on the terminal and follow the first time setup instructions. Make sure that the terminal is connected to a Wi-Fi.

Generate pairing code:

• Go to settings on the terminal (swipe from left to right and press Settings)



• When requested, enter the admin PIN 07139




and note the pairing code shown like

4. Hardware Settings

Register the terminal using the generated pairing code (e.g. random-word-sequence)

If you get an error similar to Failed to register reader with error: Please ensure that the store address is correct. You must go into the settings for the store and change the address until it works.



- 5. Verify that pairing was successful
 - The terminal should return to the home screen, which means that it's ready to process payments.



• The Hardware Settings page should look something like below

