J1 deck bus 2x8 to P2 (P100); TCA9546A 0x71 (P99): ch0 own LEDs, ch1 Level block (4 LP5864, touch), ch2 J3 -> M4, ch3 J4 -> W2; chain P3 buttons -> Level knobs -> M4

Chain: U3 (Solo first) -> U4 -> U5 -> Level registers (Level 8 first) -> M4 (J3); W2 (J4) not in the chain; buttons: Note field of SW1–SW21

Level block (R128, from hardware/m2-levels): touch TR0–7 -> 560 R -> TOUCH0–7 = frame MP of ENC1–8 (Level 8 … Level 1); fields Block=Level

