

Royal Oak Park – 8650 112 Ave NW, Calgary, AB T3R 0R5

Section 1.6.1

1. Remove and dispose of existing simulated grass and underlying gravel.
2. Remove existing rubber matting and set aside for re-use.
3. Remove existing insulation and set aside for re-use.
4. Remove and dispose of existing TPO membrane.
5. Inspect existing gypsum board and repair as necessary.
6. Install new 0.5” DensDeck Prime, adhered Insul-Lock HR adhesive, joints staggered with layer beneath.
7. Fire tape seams of DensDeck Prime.
8. Torch-apply new Garland HPR Torch Base.
9. Torch-apply new Garland StressPly IV Plus cap sheet.
10. Picture frame all perimeters and projections using Garland SA Base IV.
11. For picture framing, prime with Pro-Stop FR Primer.
12. Reinforce all vertical seams with Garla-Flex and GarMesh.
13. Once base and cap sheet is installed, perform a flood test with a Garland representative present.
14. Install new drainage mat.
15. Re-install insulation.
16. Install new metal flashings.

Please refer to the cut test photo report in project files for existing roof system composition.

Roofing contractor to carry \$15,000 for removal and reinstallation of metal wall panels.

Roofing contractor to engage with and carry cost for glazing professional to assist in removing and reinstalling metal flashings along walls with windows.