


# IESTI01 – TinyML

## Embedded Machine Learning

20. Motion Classification using  
Arduino Nano-33 BLE Sense



Prof. Marcelo Rovai  
UNIFEI



Set up connection between Arduino Nano  
and Edge Impulse

Login - Edge Impulse

studio.edgeimpulse.com/login

EDGE IMPULSE

Log in

rovai@mjrobot.org

.....

[Forgot your password?](#)

[Log in](#)

Don't have an account? [Sign up](#)



**Start building embedded machine learning models today.**

© 2022 EdgeImpulse Inc. All rights reserved

Select project - Edge Impulse

studio.edgeimpulse.com/studio/select-project

EDGE IMPULSE

MJRoBot (Marcelo Rovai)

# Select project


Select your Edge Impulse project, or create a new one.

NAME	COLLABORATORS
MJRoBot (Marcelo Rovai) / IESTI01 - Nano Motion Classification	?
MJRoBot (Marcelo Rovai) / oi_rovis_kws	
MJRoBot (Marcelo Rovai) / Eggs AI	
MJRoBot (Marcelo Rovai) / Accelerometer-Nano-Ble-IoT	
MJRoBot (Marcelo Rovai) / video_tinyml_raw	
MJRoBot (Marcelo Rovai) / Pico_Motion_Detection	
MJRoBot (Marcelo Rovai) / oi_rovis_kws_meetup	

Create project

Enter a name for your new project

Cancel Create new project



Devices - IESTI01 - Nano Motion Classification

studio.edgeimpulse.com/studio/61345/devices

MJRoBot (Marcelo Rovai)

EDGE IMPULSE

Devices 1

Dashboard

Data acquisition

Impulse design

Create impulse

EON Tuner

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

DEVICES (IESTI01 - NANO MOTION CLASSIFICATION)

Your devices

These are devices that are connected to the Edge Impulse remote management API, or have posted data to the ingestion SDK.

Collect data

You can collect data from development boards, from your own devices, or by uploading an existing dataset.

Connect a fully supported development board 2

Get started with real hardware from a wide range of silicon vendors - fully supported by Edge Impulse.

Browse dev boards 3

Use your mobile phone

Use your computer

Data from any device with the data forwarder

Upload data

Integrate with your cloud

https://docs.edgeimpulse.com/docs/fully-supported-development-boards

Devices - IESTI01 - Nano Motic Overview - Edge Impulse Docu +

docs.edgeimpulse.com/docs/development-platforms/fully-supported-development-boards

EDGE IMPULSE Home Guides API Reference Forum Search...

Getting Started  
API and SDK references  
What is embedded ML, anyway?  
Frequently asked questions

EDGE IMPULSE STUDIO  
Dashboard  
Devices  
Data Acquisition >  
Create Impulse  
Processing blocks >  
Learning Blocks >  
EON Tuner  
Live Classification  
Model Testing  
Deployment  
Organizations >

DEVELOPMENT PLATFORMS  
**Overview**  
Officially supported MCU targets >  
Officially supported CPU/GPU targets >

**Overview**

There is a list of development boards that are fully supported by Edge Impulse. These boards come with a special firmware which enables data collection from all their sensors, allows you to build new ready-to-go binaries that include your trained impulse, and come with examples on integrating your impulse with your custom firmware. These boards are the perfect way to start building Machine Learning solutions on real embedded hardware.

**Officially supported MCU targets**

- [Arduino Nano 33 BLE Sense](#)
- [Arduino Nicla Sense ME](#)
- [Arduino Portenta H7 + Vision Shield](#)
- [Espressif ESP32](#)
- [Himax WE-I Plus](#)
- [Nordic Semi nRF52840 DK](#)
- [Nordic Semi nRF5340 DK](#)
- [Nordic Semi nRF9160 DK](#)
- [Nordic Semi Thingy:91](#)
- [Open MV Cam H7 Plus](#)
- [Silicon Labs xG24 Dev Kit](#)
- [Silicon Labs Thunderboard Sense 2](#)
- [Sony's Spresense](#)
- [ST B-L475E-IOT01A](#)
- [Syntiant Tiny ML Board](#)
- [TI CC1352P Launchpad](#)
- [Raspberry Pi RP2040](#)



# EI/Arduino CLI

The screenshot shows a web browser window displaying the Edge Impulse documentation for the Arduino Nano 33 BLE Sense. The page title is "Arduino Nano 33 BLE Sense". The left sidebar lists various development boards, with "Arduino Nano 33 BLE Sense" highlighted. The main content area describes the board and its features, including its Cortex-M4 microcontroller, motion sensors, microphone, and BLE support. It also mentions the availability from Arduino and its use with the Arduino Tiny Machine Learning Kit. A blue arrow points from the text "Go to 2. Arduino CLI" to the "Installing dependencies" section at the bottom of the page.

(Note that the 1. Edge Impulse CLI is not necessary for Arduino Nano-33. We will use WebUSB instead)


Go to 2. Arduino CLI

## Installing dependencies

To set this device up in Edge Impulse, you will need to install the following software:

1. Edge Impulse CLI.
2. Arduino CLI.
  - Here's an instruction video for Windows.
  - The [Arduino website](#) has instructions for macOS and Linux.

# Arduino CLI



The screenshot shows the "Installation" page for the Arduino CLI on GitHub. The URL in the address bar is [arduino.github.io/arduino-cli/0.19/installation/](https://arduino.github.io/arduino-cli/0.19/installation/). The page has a green header with the title "Installation". On the left, there's a sidebar with links like Home, Installation (which is active), Upgrading, Getting started, Command line completion, How to contribute, FAQ, Command reference, gRPC reference, Configuration, Integration options, Sketch build process, Sketch specification, Library specification, Platform specification, Pluggable discovery specification, and Package index specification. The main content area starts with a "Download" section, which says "Pre-built binaries for all the supported platforms are available for download from the links below." It then provides instructions for using the command line and shows a "Latest release" table:

Platform	32 bit	64 bit
Linux	<a href="#">32 bit</a>	<a href="#">64 bit</a>
Linux ARM	<a href="#">32 bit</a>	<a href="#">64 bit</a>
Windows	<a href="#">32 bit</a>	<a href="#">64 bit</a>
macOS		<a href="#">64 bit</a>

Below the table, there's a "Deprecation notice" message: "Deprecation notice: links in the form <http://downloads.arduino.cc/arduino-cli/arduino-cli-latest-<platform>.tar.bz2> won't be further updated. That URL will provide the version 0.3.7-alpha.preview, regardless of further releases." Further down, there are sections for "Previous versions" (with a note about assets on the releases page) and "Nightly builds" (with a note about builds from the master branch).



See this video for Windows installation: <https://www.youtube.com/watch?v=1jMWsFER-Bc>

# Arduino CLI Installation Summary

## If you're on Windows:

- Unzip the .zip file to C:\Program Files\arduino-cli
- Open System Properties > Advanced > Environment Variables
- Path under "user variables" > Edit
- Add C:\Program Files\arduino-cli

## If you're on macOS:

- I recommend using the curl method or homebrew shown on the installation page:  
<https://arduino.github.io/arduino-cli/0.21/installation/>
- if you use the curl method, it likely installs arduino-cli to ~/bin. That might not be on your path. So, you might need to run: `export PATH=$PATH:~/bin`

Devices - SciTinyML-Motion-A X Arduino Nano 33 BLE Sense - E Installation - Arduino CLI x +

docs.edgeimpulse.com/docs/development-boards/arduino-nano-33-ble-sense

EDGE IMPULSE Guides API Reference Forum Search...

Getting Started

API and SDK references

What is embedded ML, anyway?

Frequently asked questions

DEVELOPMENT BOARDS

Overview

ST B-L475E-IOT01A

**Arduino Nano 33 BLE Sense**

Arduino Portenta H7 + Vision Shield

Open MV Cam H7 Plus

Himax WE-I Plus

Nordic Semi nRF52840 DK

Nordic Semi nRF5340 DK

Nordic Semi nRF9160 DK

Nordic Semi Thingy:91

SiLabs Thunderboard Sense 2


Sony's Spresense

Syntiant Tiny ML Board

Powered By GitBook

**1** **1. Connect the development board to your computer**

Use a micro-USB cable to connect the development board to your computer. Then press RESET twice to launch into the bootloader. The on-board LED should start pulsating to indicate this.



Press RESET twice quickly to launch the bootloader on the Arduino Nano 33 BLE Sense.

**2** **2. Update the firmware**

The development board does not come with the right firmware yet. To update the firmware:

1. Download the latest Edge Impulse firmware, and unzip the file.
2. Open the flash script for your operating system ( `flash_windows.bat` , `flash_mac.command` or `flash_linux.sh` ) to flash the firmware.
3. Wait until flashing is complete, and press the RESET button once to launch the new firmware.

**3** **3. Setting keys**

From a command prompt or terminal, run:

1\_edge-impulse-daemon

# MacOS

```
mjrovai — flash_mac.command — 126x44
Last login: Tue Nov  9 12:15:56 on ttys002
You have new mail.
/Users/mjrovai/Downloads/arduino-nano-33-ble-sense\ \(2\)/flash_mac.command ; exit;

The default interactive shell is now zsh.
To update your account to use zsh, please run `chsh -s /bin/zsh`.
For more details, please visit https://support.apple.com/kb/HT208050.
(base) MacBook-Pro-de-Marcelo:~ mjrovai$ /Users/mjrovai/Downloads/arduino-nano-33-ble-sense\ \(2\)/flash_mac.command ; exit;
Finding Arduino Mbed core...
Finding Arduino Mbed OK
Finding Arduino Nano 33 BLE...
Finding Arduino Nano 33 BLE OK
Flashing board...
Device      : nRF52840-QIAA
Version     : Arduino Bootloader (SAM-BA extended) 2.0 [Arduino:IKXYZ]
Address     : 0x0
Pages       : 256
Page Size   : 4096 bytes
Total Size  : 1024KB
Planes      : 1
Lock Regions: 0
Locked      : none
Security    : false
Erase flash


Done in 0.001 seconds
Write 280848 bytes to flash (69 pages)
[=====] 100% (69/69 pages)
Done in 10.984 seconds

Flashed your Arduino Nano 33 BLE development board.
To set up your development with Edge Impulse, run 'edge-impulse-daemon'
To run your impulse on your development board, run 'edge-impulse-run-impulse'
logout
Saving session...
...copying shared history...
...saving history...truncating history files...
...completed.

[Process completed]
```

3.Nano-33 LED Stop Flashing

1. Press Nano-33 Reset button Twice
2. With Nano-33 LED Flashing:



# Windows 10

```
Prompt de Comando
Microsoft Windows [versão 10.0.19041.1052]
(c) Microsoft Corporation. Todos os direitos reservados.


C:\Users\GUILH>arduino-cli
Arduino Command Line Interface (arduino-cli).

Usage:
  arduino-cli [command]

Examples:
  arduino-cli <command> [flags...]

Available Commands:
  board           Arduino board commands.
  burn-bootloader Upload the bootloader.
  cache           Arduino cache commands.
  compile         Compiles Arduino sketches.
  completion     Generates completion scripts
  config          Arduino configuration commands.
  core            Arduino core operations.
  daemon          Run as a daemon on port 50051
  debug           Debug Arduino sketches.
  help            Help about any command
  lib              Arduino commands about libraries.
  outdated        Lists cores and libraries that can be upgraded
  sketch          Arduino CLI sketch commands.
  update          Updates the index of cores and libraries
  upgrade         Upgrades installed cores and libraries.
  upload          Upload Arduino sketches.
  version         Shows version number of Arduino CLI.
```

1. Press Nano-33 Reset button Twice
2. With Nano-33 LED Flashing:



# Windows 10


```
cmd C:\WINDOWS\system32\cmd.exe
Finding Arduino Mbed core...
arduino:mbed_nano 2.0.0      2.0.0  Arduino Mbed OS Nano Boards
Finding Arduino Mbed core OK
Finding Arduino Nano 33 BLE...
Finding Arduino Nano 33 BLE OK at COM11
arduino:mbed_nano 2.0.0      2.0.0  Arduino Mbed OS Nano Boards
Device      : nRF52840-QIAA
Version     : Arduino Bootloader (SAM-BA extended) 2.0 [Arduino:IKXYZ]
Address     : 0x0
Pages       : 256
Page Size   : 4096 bytes
Total Size  : 1024KB
Planes      : 1
Lock Regions: 0
Locked      : none
Security    : false
Erase flash

Done in 0.002 seconds
Write 525440 bytes to flash (129 pages)
[=====] 100% (129/129 pages)
Done in 22.296 seconds
Flashed your Arduino Nano 33 BLE development board
To set up your development with Edge Impulse, run 'edge-impulse-daemon'
To run your impulse on your development board, run 'edge-impulse-run-impulse'
Pressione qualquer tecla para continuar. . .
```

□ Nano-33 LED Stop Flashing


# Hands-on lab for motion classification

# Case Study: Mechanical Stresses in Transport



## Classes to study

- Maritime
- Terrestrial (or Rail)
- Lift
- Idle



The screenshot shows the Edge Impulse Studio interface for data acquisition. A modal window titled "studio.edgeimpulse.com wants to connect to a serial port" is open, listing available ports:

- cu.Bluetooth-Incoming-Port
- cu.MALS
- cu.RovaisAirPods-Wirelessi
- cu.SOC
- Nano 33 BLE (cu.usbmodem145101) **(highlighted with an orange box)**

A blue arrow labeled "2" points to the "cu.SOC" entry. Another blue arrow labeled "3" points to the "Connect" button at the bottom of the modal. The modal also contains a "Cancel" button and a note: "No data has been collected yet".

In the top right corner of the main studio area, there is a purple header bar with the user profile "MJRoBot (Marcelo Rovai)". To the left of the header, a message says "Choose or development board, or upload your existing datasets - Show options".

The main studio area has a "Record new data" section with a note: "No devices connected to the remote management API." and a "RAW DATA" section with the instruction "Click on a sample to load...".

An orange box labeled "1" highlights the "Connect using WebUSB" button in the top right corner of the main studio area.

**WebUSB works fine with Chrome**

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - [Show options](#)

DATA COLLECTED

Collected data

No data collected yet

Let's collect some data

Record new data

Device ②  
36:17:55:F9:70:F7

Label  
terrestrial

Sample length (ms.)  
10000

Sensor  
Built-in accelerometer

Frequency  
100Hz

Start sampling

RAW DATA  
Click on a sample to load...

The screenshot shows the Edge Impulse Data Acquisition interface. On the left sidebar, under the 'Data acquisition' section, there is a 'Label' field which is highlighted with an orange border. Two large blue arrows point from this highlighted field towards the 'Start sampling' button located on the right side of the interface. The 'Start sampling' button is a dark blue button with white text.

Devices - IESTI01 - Nano Motion Classification

studio.edgeimpulse.com/studio/61345/devices

EDGE IMPULSE

DEVICES (IESTI01 - NANO MOTION CLASSIFICATION)

MJRoBot (Marcelo Rovai)

Your devices

+ Connect a new device

These are devices that are connected to the Edge Impulse remote management API, or have posted data to the ingestion SDK.

NAME	ID	TYPE	SENSORS	REMOTE M...	LAST SEEN
 36:17:55:F9:70:F7	36:17:55:F9:70:F7	ARDUINO_NANO33BLE	Built-in accelerometer, Built-in microphone...	●	Today, 12:26:49

© 2021 EdgeImpulse Inc. All rights reserved

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

EON Tuner

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - [Show options](#)

DATA COLLECTED 10s TRAIN / TEST SPLIT 100% / 0% ⚠

Collected data

SAMPLE NAME	LABEL	ADDED	LENGTH
terrestrial.json.2jbimlk	terrestrial	Today, 13:01:46	10s

Record new data

Device ② Nano

Label terrestrial Sample length (ms.) 10000

Sensor Sensor with 3 axes (accX, accY, accZ) Frequency 100Hz



Start sampling

RAW DATA  
terrestrial.json.2jbimlk

accX accY accZ

<https://studio.edgeimpulse.com/studio/61345/acquisition/training?page=1#>

# Label: terrestrial



EDGE IMPULSE

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED 1m 40s TRAIN / TEST SPLIT 100% / 0%

SAMPLE NAME	LABEL	ADDED	LENGTH
terrestrial.json.2jv...	terrestrial	Today, 14:26:56	10s
terrestrial.json.2jv...	terrestrial	Today, 14:26:29	10s
terrestrial.json.2jv...	terrestrial	Today, 14:26:06	10s
terrestrial.json.2jv...	terrestrial	Today, 14:25:48	10s
terrestrial.json.2jv...	terrestrial	Today, 14:25:29	10s
terrestrial.json.2jv...	terrestrial	Today, 14:25:04	10s
terrestrial.json.2jv...	terrestrial	Today, 14:24:45	10s
terrestrial.json.2jv...	terrestrial	Today, 14:24:21	10s
terrestrial.json.2jvf...	terrestrial	Today, 14:17:45	10s
terrestrial.json.2jv...	terrestrial	Today, 13:01:46	10s

Record new data

Device: Nano

Label: terrestrial

Sample length (ms.): 10000



Sensor: Sensor with 3 axes (accX, accY, accZ)

Frequency: 100Hz

Start sampling

RAW DATA  
terrestrial.json.2jvgelce

# Label: LIFT



studio.edgeimpulse.com/studio/61345/acquisition/training?page=1

EDGE IMPULSE

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

MJRoBot (Marcelo Rovai)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED 3m 20s TRAIN / TEST SPLIT 100% / 0%

SAMPLE NAME	LABEL	ADDED	LENGTH
lift.json.2jvhbt7	lift	Today, 14:42:04	10s
lift.json.2jvh9pe3	lift	Today, 14:41:45	10s
lift.json.2jvh96uh	lift	Today, 14:41:26	10s
lift.json.2jvh8j6q	lift	Today, 14:41:06	10s
lift.json.2jvh80rg	lift	Today, 14:40:47	10s
lift.json.2jvh7g2v	lift	Today, 14:40:30	10s
lift.json.2jvh6uqu	lift	Today, 14:40:12	10s
lift.json.2jvh6c6a	lift	Today, 14:39:53	10s
lift.json.2jvh5qbe	lift	Today, 14:39:35	10s
lift.json.2jvh55hs	lift	Today, 14:39:14	10s
terrestrial.json.2jv...	terrestrial	Today, 14:26:56	10s
terrestrial.json.2jv...	terrestrial	Today, 14:26:29	10s

Record new data

Device Nano

Label lift

Sample length (ms.) 10000

Sensor Sensor with 3 axes (accX, accY, accZ)



Frequency 100Hz

Start sampling

RAW DATA lift.json.2jvhbt7

A line graph titled "RAW DATA lift.json.2jvhbt7". The vertical axis ranges from -20 to 20 with increments of 5. The horizontal axis shows time points at 0, 1040, 2080, 3120, 4160, 5200, 6240, 7280, 8320, and 9360. Three data series are plotted: accX (red), accY (green), and accZ (blue). All three series show a highly oscillatory pattern between approximately -15 and 15 across the entire time range.

# Label: maritime



Data acquisition - IESTI01 - Na +

studio.edgeimpulse.com/studio/61345/acquisition/training?page=1

MJRoBot (Marcelo Rovai)

EDGE IMPULSE

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED 5m 0s TRAIN / TEST SPLIT 100% / 0% ▲

SAMPLE NAME	LABEL	ADDED	LENGTH
maritime.json.2jvi6...	maritime	Today, 14:57:35	10s
maritime.json.2jvi6...	maritime	Today, 14:57:13	10s
maritime.json.2jvi5...	maritime	Today, 14:56:48	10s
maritime.json.2jvi4...	maritime	Today, 14:56:31	10s
maritime.json.2jvi4...	maritime	Today, 14:56:13	10s
maritime.json.2jvi3...	maritime	Today, 14:55:55	10s
maritime.json.2jvi3...	maritime	Today, 14:55:36	10s
maritime.json.2jvi2...	maritime	Today, 14:55:19	10s
maritime.json.2jvi2...	maritime	Today, 14:55:00	10s
maritime.json.2jvi1...	maritime	Today, 14:54:42	10s
lift.json.2jhbt7	lift	Today, 14:42:04	10s
lift.json.2vh9pe3	lift	Today, 14:41:45	10s

Record new data

Device Nano

Label maritime

Sample length (ms.) 10000

Sensor Sensor with 3 axes (accX, accY, accZ)



Frequency 100Hz

Start sampling

RAW DATA maritime.json.2jvi6p3r

accX accY accZ

# Label: idle



Data acquisition - IESTI01 - Na +

studio.edgeimpulse.com/studio/61345/acquisition/training?page=1

MJRoBot (Marcelo Rovai)

EDGE IMPULSE

DATA ACQUISITION (IESTI01 - NANO MOTION CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED 6m 40s TRAIN / TEST SPLIT 100% / 0% ▲

Record new data Connect using WebUSB

Device Nano

Label idle Sample length (ms.) 100000


Sensor Sensor with 3 axes (accX, accY, accZ) Frequency 100Hz

Start sampling

RAW DATA idle.json.2jvif14

SAMPLE NAME	LABEL	ADDED	LENGTH
idle.json.2jvif14	idle	Today, 15:06:09	1m 40s
maritime.json.2jvi6...	maritime	Today, 14:57:35	10s
maritime.json.2jvi6...	maritime	Today, 14:57:13	10s
maritime.json.2jvi5...	maritime	Today, 14:56:48	10s
maritime.json.2jvi4...	maritime	Today, 14:56:31	10s
maritime.json.2jvi4...	maritime	Today, 14:56:13	10s
maritime.json.2jvi3...	maritime	Today, 14:55:55	10s
maritime.json.2jvi3...	maritime	Today, 14:55:36	10s
maritime.json.2jvi2...	maritime	Today, 14:55:19	10s
maritime.json.2jvi2...	maritime	Today, 14:55:00	10s
maritime.json.2jvi1...	maritime	Today, 14:54:42	10s
lift.json.2jhbt7	lift	Today, 14:42:04	10s

accX accY accZ



Dashboard - IESTI01 - Nano M

studio.edgeimpulse.com/studio/61345

EDGE IMPULSE

**Dashboard**

Devices

Data acquisition

Impulse design

- Create impulse

EON Tuner

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

Download block output

No downloads available yet

Performance settings

Use GPU for training

Parallel DSP jobs

Job limit in minutes

DSP file size limit (MB)

Administrative zone

Show Linux deploy options

Save experiments

Danger zone

Perform train / test split

Delete this project

Delete all data in this project

Dashboard - IESTI01 - Nano M

studio.edgeimpulse.com/studio/61345

EDGE IMPULSE

Project info

Project ID 61345

Labeling method One label per da

Latency calculations Cortex-M4F 80M

Download block output

No downloads available yet

Performance settings

Use GPU for training

Parallel DSP jobs

Job limit in minutes

DSP file size limit (MB)

Administrative zone

Show Linux deploy o

Save experiments

Danger zone

Performing split...

Delete this project

Delete all data in this project

?

Perform train / test split

Are you sure you want to rebalance your dataset? This splits all your data automatically between the training and testing set, and resets the categories for all data. This is irrevocable!

Cancel Yes, perform the train / test split

**DATA ACQUISITION - TESTING (EINSTEIN CLASSIFICATION)**

Training data **Test data**

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

**DATA COLLECTED** 40s

TRAIN / TEST SPLIT 90% / 10%

**Collected data**

SAMPLE NAME	LABEL	ADDED	LENGTH
maritime.json.2jvi4...	maritime	Today, 14:56:13	10s
maritime.json.2jvi1...	maritime	Today, 14:54:42	10s
lift.json.2jvh6uqu	lift	Today, 14:40:12	10s
terrestrial.json.2jv...	terrestrial	Today, 13:01:46	10s

Device **Nano**

Label **idle**

Sample length (ms.) **100000**

Sensor **Sensor with 3 axes (accX, accY, accZ)**

Frequency **100Hz**

**Start sampling**


**RAW DATA**


Click on a sample to load...

If automatic split is not good, proceed with manual split

The screenshot shows the Edge Impulse Studio interface. On the left, a sidebar menu includes options like Dashboard, Devices, Data acquisition (which is highlighted with an orange box), Create impulse, EON Tuner, Retrain model, Live classification, Model testing, Versioning, Deployment, Documentation, and Forums. The main area is titled "DATA ACQUISITION - TESTING (IE500 - ACTION CLASSIFICATION)". It displays "DATA COLLECTED 1m 20s" and a "TRAIN / TEST SPLIT 80% / 20%" with pie charts. A callout bubble with an orange arrow points to the "Test data" tab. Below this, a table lists "Collected data" with columns: SAMPLE NAME, LABEL, ADDED, LENGTH. The table contains several rows of data samples. To the right, there's a "Record new data" section with fields for Device (Nano), Label (idle), Sample length (ms.) (20000), Sensor (Sensor with 3 axes (accX, accY, accZ)), Frequency (100Hz), and a "Start sampling" button. At the bottom, a dark blue bar says "RAW DATA Click on a sample to load...".

Dataset is balanced (has representative samples from all classes) and split 80%/20%





Time series data

Axes  
accX, accY, accZ

Window size  
2000 ms.

Window increase  
80 ms.

Frequency (Hz)  
62.5

Zero-pad data

Spectral Analysis

Name  
Spectral Analysis

Input axes  
 accX  
 accY  
 accZ

Neural Network (Keras)

Name  
Neural Network (Keras)


Input features  
 Spectral Analysis

Output features  
4 (idle, lift, maritime, terrestrial)

Output features

4 (idle, lift, maritime, terrestrial)

**Save Impulse**



Spectral Analysis



NN Classifier



Classes

- Lift
- Terrestrial
- Maritime
- Idle

Spectral features - IESTI01 - N

studio.edgeimpulse.com/studio/61345/dsp/spectral-analysis/3

### Raw data

terrestrial.json.2jvgdqv9 (terrestrial)

accX accY accZ

### Raw features

1.6400, -0.9700, 9.8000, 1.7100, -0.6400, 9.8100, 1.8500, -0.4200, 9.7900, 1.7800, -0.5200, 9.7500, 1.7100,...

### Parameters

#### Scaling

Scale axes

#### Filter

Type  Cut-off frequency  Order

#### Spectral power

FFT length  No. of peaks  Peaks threshold  Power edges

Save parameters

### DSP result

#### After filter

#### Frequency domain

#### Spectral power

#### Processed features

1.9614, 0.7937, 2.6663, 0.0000, 0.0000, 0.0000, 0.0000, 0.4550, 0.0489, 0.0025, 0.2078, 2.3810, 0.1...

#### On-device performance

PROCESSING TIME **9 ms.** PEAK RAM USAGE **5 KB**

Spectral features - IESTI01 - N

studio.edgeimpulse.com/studio/61345/dsp/spectral-analysis/3/generate-features

**EDGE IMPULSE**

SPECTRAL FEATURES (IESTI01 - NANO MOTION CLASSIFICATION)

#1 ▾ Click to set a description for this version

Parameters **Generate features**

**Training set**

Data in training set 5m 20s

Classes 4 (idle, lift, maritime, terrestrial)

Window length 2000 ms.

Window increase 80 ms.

Training windows 3,400

**Feature explorer (3,400 samples)**

X Axis accX RMS Y Axis accY RMS Z Axis accZ RMS

idle (blue), lift (orange), maritime (green), terrestrial (red)

**Feature generation output**

Job started  
Creating windows from 25 files...  
[ 0/25] Creating windows from files...  
[ 1/25] Creating windows from files...  
[25/25] Creating windows from files...  
Created 3400 windows: idle: 976, lift: 808, maritime: 808, terrestrial: 808

Creating features  
[ 1/3400] Creating features...  
[ 898/3400] Creating features...  
[1798/3400] Creating features...  
[2704/3400] Creating features...  
[3400/3400] Creating features...  
Created features

Job completed

**On-device performance**

PROCESSING TIME 9 ms. PEAK RAM USAGE 5 KB

© 2021 EdgeImpulse Inc. All rights reserved

MJRoBot (Marcelo Rovai)

### Neural Network settings

#### Training settings

Number of training cycles ?  
30

Learning rate ?  
0.0005

#### Neural network architecture

- Input layer (33 features)**
- Dense layer (20 neurons)
- Dense layer (10 neurons)
- Add an extra layer
- Output layer (4 classes)**

**Start training**

### Model

Model version: ? Quantized (int8) ▼

#### Last training performance (validation set)

<span style="font-size: 2em; color: #00AEEF;">%</span>	<b>ACCURACY</b> <b>99.9%</b>	<span style="font-size: 2em; color: #00AEEF;">graph</span>	<b>LOSS</b> <b>0.01</b>
--	---------------------------------	--	----------------------------

#### Confusion matrix (validation set)


	IDLE	LIFT	MARITIME	TERRESTRIAL
IDLE	<b>100%</b>	0%	0%	0%
LIFT	0%	<b>99.4%</b>	0.6%	0%
MARITIME	0%	0%	<b>100%</b>	0%
TERRESTRIAL	0%	0%	0%	<b>100%</b>
F1 SCORE	1.00	1.00	1.00	1.00

#### Feature explorer (full training set) ?

accX RMS ▼ accY RMS ▼ accZ RMS ▼


Legend:

- idle - correct (light green)
- lift - correct (medium green)
- maritime - correct (dark green)
- terrestrial - correct (bright green)
- lift - incorrect (red)



#### On-device performance ?

<span style="font-size: 2em; color: #00AEEF;">clock</span>	<b>INFERRING TIME</b> <b>1 ms.</b>	<span style="font-size: 2em; color: #E64B19;">memory</span>	<b>PEAK RAM USAGE</b> <b>1.7K</b>	<span style="font-size: 2em; color: #00AEEF;">flash</span>	<b>FLASH USAGE</b> <b>19.0K</b>
--	---------------------------------------	---	--------------------------------------	--	------------------------------------



Model testing - IESTI01 - Nano

studio.edgeimpulse.com/studio/61345/validation

### Test data

Set the 'expected outcome' for each sample to the desired outcome to automatically score the impulse.

SAMPLE NAME	EXPECTED OUTCOME	LENGTH	ACCURACY	RESULT	⋮
terrestrial.json.2...	terrestrial	10s	100%	101 terrestrial	⋮
lift.json.2jhbt7	lift	10s	100%	101 lift	⋮
idle.json.2jvjlvn	idle	20s	100%	226 idle	⋮
maritime.json.2j...	maritime	10s	100%	101 maritime	⋮
maritime.json.2j...	maritime	10s	100%	101 maritime	⋮
lift.json.2jh6uqu	lift	10s	100%	101 lift	⋮
terrestrial.json.2...	terrestrial	10s	100%	101 terrestrial	⋮

**Model testing output**

Classifying data for NN Classifier...  
 Copying features from processing blocks...  
 Copying features from DSP block...  
 Copying features from DSP block OK  
 Copying features from processing blocks OK

Classifying data for float32 model...  
 Scheduling job in cluster...  
 Job started  
 Classifying data for NN Classifier OK

**Job completed**

**Model testing results**


**ACCURACY**  
**100.00%**

	IDLE	LIFT	MARITIME	TERRESTRIAL	UNCERTAIN
IDLE	100%	0%	0%	0%	0%
LIFT	0%	100%	0%	0%	0%
MARITIME	0%	0%	100%	0%	0%
TERRESTRIAL	0%	0%	0%	100%	0%
F1 SCORE	1.00	1.00	1.00	1.00	

**Feature explorer**

accX RMS   accY RMS   accZ RMS

- idle - correct
- lift - correct
- maritime - correct
- terrestrial - correct



Deployment - IESTI01 - Nano Motion Classification

studio.edgeimpulse.com/studio/61345/deployment

EDGE IMPULSE

DEPLOYMENT (IESTI01 - NANO MOTION CLASSIFICATION)

MJRoBot (Marcelo Rovai)

Deploy your impulse

You can deploy your impulse to any device. This makes the model run without an internet connection, minimizes latency, and runs with minimal power consumption. [Read more.](#)

Create library

Turn your impulse into optimized source code that you can run on any device.

C++ library Arduino library Cube.MX CMSIS-PACK

WebAssembly TensorRT library

Build firmware

Or get a ready-to-go binary for your development board that includes your impulse.

ST IoT Discovery Kit Arduino Nano 33 BLE Sense Eta Compute ECM3532 AI Sensor

SiLabs Thunderboard Sense 2 Himax WE-I Plus Nordic nRF52840 DK + IKS02A1

Nordic nRF5340 DK + IKS02A1 Nordic nRF9160 DK + IKS02A1 Nordic Thingy:91

ei-iesti01---nano....zip

Show All

Build output

```
Creating job... OK (ID: 1646786)
Writing templates...
Writing templates OK
Copying Edge Impulse SDK...
Copying Edge Impulse SDK OK
Compiling EON model...
Compiling EON model OK
Removing clutter and updating headers...
Removing clutter and updating headers OK
Creating archive...
Job started
Creating archive OK
Job completed
```

Deployment - IESTI01 - Nano Motion Classification

studio.edgeimpulse.com/studio/61345/deployment

**EDGE IMPULSE**

- Dashboard
- Devices
- Data acquisition
- Impulse design
  - Create impulse
  - Spectral features
  - NN Classifier
- EON Tuner
- Retrain model
- Live classification
- Model testing
- Versioning
- Deployment

**GETTING STARTED**

- Documentation
- Forums

SiLabs Thunderboard Sense 2

Himax WE-I Plus

Nordic nRF52840 DK + IKS02A1

Nordic nRF5340 DK + IKS02A1

Nordic nRF9160 DK + IKS02A1

Nordic Thingy:91

Sony's SpreSense

**Select optimizations (optional)**

Model optimizations can increase on-device performance. Choose from recommended choices for your target. Click [View all optimizations](#) to see more.

**Enable EON™ Compiler**

Same accuracy, up to 50% less RAM usage.

**Available optimizations for NN Classifier**

Optimization	RAM Usage	Latency	Confusion Matrix																				
<b>Quantized (int8) ★</b>	1.1K	1 ms	<table border="1"><tr><td>100</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>0</td><td>100</td><td>0</td><td>0</td><td>0</td></tr><tr><td>0</td><td>0</td><td>100</td><td>0</td><td>0</td></tr><tr><td>0</td><td>0</td><td>0</td><td>100</td><td>0</td></tr></table>	100	0	0	0	0	0	100	0	0	0	0	0	100	0	0	0	0	0	100	0
100	0	0	0	0																			
0	100	0	0	0																			
0	0	100	0	0																			
0	0	0	100	0																			
<b>Unoptimized (float32)</b>	19.0K	100%	<table border="1"><tr><td>100</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>0</td><td>100</td><td>0</td><td>0</td><td>0</td></tr><tr><td>0</td><td>0</td><td>100</td><td>0</td><td>0</td></tr><tr><td>0</td><td>0</td><td>0</td><td>100</td><td>0</td></tr></table>	100	0	0	0	0	0	100	0	0	0	0	0	100	0	0	0	0	0	100	0
100	0	0	0	0																			
0	100	0	0	0																			
0	0	100	0	0																			
0	0	0	100	0																			

Currently selected

This optimization is recommended for best performance.

Click to select

Estimate for Cortex-M4F 80MHz


Build


**Build output**


```
Creating job... OK (ID: 1646786)
Writing templates...
Writing templates OK
Copying Edge Impulse SDK...
Copying Edge Impulse SDK OK
Compiling EON model...
Compiling EON model OK
Removing clutter and updating headers...
Removing clutter and updating headers OK
Creating archive...
Archive OK
```

ei-iesti01---nano....zip

Show All







# Model Inference

/dev/cu.usbmodem145101

Sampling...

Predictions (DSP: 20 ms., Classification: 0 ms., Anomaly: 0 ms.):

```
idle: 0.00000
lift: 0.00000
maritime: 0.00000
terrestrial: 0.99609
```

Starting inferencing in 2 seconds...

Sampling...


Predictions (DSP: 20 ms., Classification: 1 ms., Anomaly: 0 ms.):

```
idle: 0.00000
lift: 0.00000
maritime: 0.00000
terrestrial: 0.99609
```

Starting inferencing in 2 seconds...

Autoscroll  Show timestamp

Both NL & CR 115200 baud Clear output



nano\_ble33\_sense\_accelerometer | Arduino 1.8.16

nano\_ble33\_sense\_accelerometer

```
1/* Edge Impulse Arduino examples
2 * Copyright (c) 2021 EdgeImpulse Inc.
3 *
4 * Permission is hereby granted, free of charge, to any person obtaining a cop
5 * of this software and associated documentation files (the "Software"), to de
6 * in the Software without restriction, including without limitation the right
7 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
8 * copies of the Software, and to permit persons to whom the Software is
9 * furnished to do so, subject to the following conditions:
10 *
11 * The above copyright notice and this permission notice shall be included in
12 * all copies or substantial portions of the Software.
13 *
14 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
15 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
16 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
17 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
18 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FRO
19 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN T
20 * SOFTWARE.
21 */
22
23/* Includes -----
24#include <IESTI01_-_Nano_Motion_Classification_inferencing.h>
25#include <Arduino_LSM9DS1.h>
26
27/* Constant defines -----
28#define CONVERT_G_TO_MS2 9.80665f
29
30/* Private variables -----
31static bool debug_nn = false; // Set this to true to see e.g. features generat
```

Done in 6.027 seconds

reset()

15

Arduino Nano 33 BLE on /dev/cu.usbmodem145101

```
/dev/cu.usbmodem145101
Send


Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 27 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 27 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 27 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 27 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 27 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
Predictions (DSP: 29 ms., Classification: 0 ms., Anomaly: 0 ms.): terrestrial [ 0, 0, 0, 10, 0, 0,
```

Autoscroll  Show timestamp

Both NL & CR

115200 baud

Clear output



```
nano_ble33_sense_accelerometer_continuous | Arduino 1.8.16
nano_ble33_sense_accelerometer_continuous
22
23 /* Includes -----
24 #include <IESTI01_-_Nano_Motion_Classification_inferencing.h>
25 #include <Arduino_LSM9DS1.h>
26
27 /* Constant defines -----
28 #define CONVERT_G_TO_MS2 9.80665f
29
30 /* Private variables -----
31 static bool debug_nn = false; // Set this to true to see e.g. features
32 static uint32_t run_inference_every_ms = 200;
33 static rtos::Thread inference_thread(osPriorityLow);
34 static float buffer[EI_CLASSIFIER_DSP_INPUT_FRAME_SIZE] = { 0 };
35 static float inference_buffer[EI_CLASSIFIER_DSP_INPUT_FRAME_SIZE];
36
37 /* Forward declaration */
38 void run_inference_background();
39
40 /**
41 * @brief      Arduino setup function
42 */
43 void setup()
44{
    // put your setup code here, to run once:
    Serial.begin(115200);
    Serial.println("Edge Impulse Inferencing Demo");

    if (!IMU.begin())
        ei_printf("Failed to initialize IMU!\r\n");
    else
        ei_printf("IMU initialized\r\n");
}
Done uploading.
Done in 6.034 seconds
reset()
```

40

Arduino Nano 33 BLE on /dev/cu.usbmodem145101

TinyML motion classification uses  
on **Real Life**

# Cow Monitoring

## Using the Internet of Things for Agricultural Monitoring


"We aim to deploy a variety of sensors for agricultural monitoring. One of the projects involves using **accelerometer sensors** to monitor activity levels in dairy cows with a view to determining when the cows are on heat or when they are sick."



Ciira wa Maina, Ph.D.

Senior Lecturer  
Department of Electrical and Electronic Engineering  
Dedan Kimathi University of Technology  
Nyeri Kenya  
Email: ciira.maina@dkut.ac.ke

Kenia



<https://sites.google.com/site/cwamainadekut/research>



# Predict and classify common Elephant behavior






Aggressive



Standing



Sleeping



[https://www.hackster.io/dhruvsheth\\_elect-tinyml-and-iot-based-smart-wildlife-tracker-c03e5a#toc-accelerometer-data-models-4](https://www.hackster.io/dhruvsheth_elect-tinyml-and-iot-based-smart-wildlife-tracker-c03e5a#toc-accelerometer-data-models-4)

# Addendum: Using Edge Impulse CLI

**DOCUMENTATION**

- [Getting Started](#)
- [API and SDK references](#)
- [What is embedded ML, anyway?](#)
- [Frequently asked questions](#)

**DEVELOPMENT BOARDS**

- [Overview](#)
- [ST B-L475E-IOT01A](#)
- [Arduino Nano 33 BLE Sense](#)
- [Eta Compute ECM3532 AI Sensor](#)
- [Eta Compute ECM3532 AI Vision](#)
- [OpenMV Cam H7 Plus](#)
- [Himax WE-I Plus](#)
- [Nordic Semi nRF52840 DK](#)
- [Nordic Semi nRF5340 DK](#)
- [SiLabs Thunderboard Sense 2](#)
- [Sony's Spresense](#)
- [Arduino Portenta H7 + Vision shield \(preview\)](#)
- [Raspberry Pi 4](#)
- [NVIDIA Jetson Nano](#)
- [Mobile phone](#)
- [Porting guide](#)

**COMMUNITY BOARDS**

- [Seeed Wio Terminal](#)
- [Agora Product Development Kit](#)

**EDGE IMPULSE FOR LINUX**

## Installation

# Edge Impulse CLI optional Installation

This Edge Impulse CLI is used to control local devices, act as a proxy to synchronise data for devices that don't have an internet connection, and to upload and convert local files. The CLI consists of seven tools:

- [edge-impulse-daemon](#) - configures devices over serial, and acts as a proxy for devices that do not have an IP connection.
- [edge-impulse-uploader](#) - allows uploading and signing local files.
- [edge-impulse-data-forwarder](#) - a very easy way to collect data from any device over a serial connection, and forward the data to Edge Impulse.
- [edge-impulse-run-impulse](#) - show the impulse running on your device.
- [edge-impulse-blocks](#) - create organizational transformation blocks.
- [eta-flash-tool](#) - to flash the Eta Compute ECM3532 AI Sensor.
- [himax-flash-tool](#) - to flash the Himax WE-I Plus.

Connect to devices without the CLI? Recent versions of Google Chrome and Microsoft Edge can connect directly to fully-supported development boards, without the CLI. See [this blog post](#) for more information.

### Installation - macOS and Windows

- 
- 1. Install [Python 3](#) on your host computer.
  - 2. Install [Node.js](#) v14 or higher on your host computer.
    - For Windows users, install the **Additional Node.js tools** when prompted. You may skip this setup if you have Visual Studio 2015 or more.
  - 3. Install the CLI tools via:

```
npm install -g edge-impulse-cli --force
```

You should now have the tools available in your PATH.

### Installation - Linux/Ubuntu and Raspbian OS

**DOCUMENTATION**

Getting Started  
API and SDK references  
What is embedded ML, anyway?  
Frequently asked questions

**DEVELOPMENT BOARDS**

Overview  
ST B-L475E-IOT01A  
Arduino Nano 33 BLE Sense  
Eta Compute ECM3532 AI Sensor  
Eta Compute ECM3532 AI Vision  
OpenMV Cam H7 Plus  
Himax WE-I Plus  
Nordic Semi nRF52840 DK  
Nordic Semi nRF5340 DK  
SiLabs Thunderboard Sense 2  
Sony's Spresense  
Arduino Portenta H7 + Vision shield (preview)  
Raspberry Pi 4  
NVIDIA Jetson Nano  
Mobile phone  
Porting guide

**COMMUNITY BOARDS**

Seeed Wio Terminal  
Agora Product Development Kit

**EDGE IMPULSE FOR LINUX**

## Installation

# Edge Impulse CLI optional Installation

This Edge Impulse CLI is used to control local devices, act as a proxy to synchronise data for devices that don't have an internet connection, and to upload and convert local files. The CLI consists of seven tools:

- [edge-impulse-daemon](#) - configures devices over serial, and acts as a proxy for devices that do not have an IP connection.
- [edge-impulse-uploader](#) - allows uploading and signing local files.
- [edge-impulse-data-forwarder](#) - a very easy way to collect data from any device over a serial connection, and forward the data to Edge Impulse.
- [edge-impulse-run-impulse](#) - show the impulse running on your device.
- [edge-impulse-blocks](#) - create organizational transformation blocks.
- [eta-flash-tool](#) - to flash the Eta Compute ECM3532 AI Sensor.
- [himax-flash-tool](#) - to flash the Himax WE-I Plus.

Connect to devices without the CLI? Recent versions of Google Chrome and Microsoft Edge can connect directly to fully-supported development boards, without the CLI. See [this blog post](#) for more information.

### Installation - macOS and Windows

1. Install [Python 3](#) on your host computer.
2. Install [Node.js](#) v14 or higher on your host computer.

- For Windows users, install the Additional Node.js tools when prompted. You may skip this setup if you have Visual Studio 2015 or more.

3. Install the CLI tools via:


```
npm install -g edge-impulse-cli --force
```

You should now have the tools available in your PATH.

### Installation - Linux/Ubuntu and Raspbian OS



# Alternative Data Capture using EI CLI: \$ edge-impulse-data-forwarder



The screenshot shows the Arduino IDE interface with a sketch titled "Capture\_Ardu33\_Sense\_IMU\_Acc". The code is written in C++ and uses the Arduino library "Arduino\_LSM9DS1.h". The code initializes the IMU, sets up the serial port at 9600 baud, and then enters a loop where it reads acceleration data from the IMU and prints it to the serial port. The print statement includes commas to separate the x, y, and z values.

```
#include <Arduino_LSM9DS1.h>
#define CONVERT_G_TO_MS2 9.80665f
#define FREQUENCY_HZ 100
#define INTERVAL_MS (1000 / (FREQUENCY_HZ + 1))

void setup() {
    Serial.begin(9600);
    while (!Serial);
    Serial.println("Started");

    if (!IMU.begin()) {
        Serial.println("Failed to initialize IMU!");
        while (1);
    }
}


void loop() {
    static unsigned long last_interval_ms = 0;
    float x, y, z;

    if (millis() > last_interval_ms + INTERVAL_MS) {
        last_interval_ms = millis();

        IMU.readAcceleration(x, y, z);

        Serial.print(x * CONVERT_G_TO_MS2);
        Serial.print(',');
        Serial.print(y * CONVERT_G_TO_MS2);
        Serial.print(',');
        Serial.println(z * CONVERT_G_TO_MS2);
    }
}
```

Arduino Nano 33 BLE on /dev/cu.usbmodem145101



The screenshot shows a terminal window on a Mac OS X system. The user has run the command `edge-impulse-data-forwarder`. The terminal displays the default interactive shell (zsh), system login information, and the Edge Impulse data forwarder version (v1.13.16). It then lists the available endpoints: Websocket, API, and Ingestion. Subsequent lines show the forwarder connecting to the serial port (`/dev/tty.usbmodem145101`) and establishing a websocket connection to the remote management endpoint (`wss://remote-mgmt.edgeimpulse.com`). The terminal then prompts the user to select a project to connect the device to, listing several projects owned by "MJRobot (Marcelo Rovai)".

```
mjrovai — node /usr/local/bin/edge-impulse-data-forwarder — 72x42
Last login: Thu Nov  4 19:04:50 on ttys000
You have new mail.

The default interactive shell is now zsh.
To update your account to use zsh, please run `chsh -s /bin/zsh`.
For more details, please visit https://support.apple.com/kb/HT208050.

[(base) MacBook-Pro-de-Marcelo:~ mjrovai$ edge-impulse-data-forwarder
Edge Impulse data forwarder v1.13.16
Endpoints:
  Websocket: wss://remote-mgmt.edgeimpulse.com
  API: https://studio.edgeimpulse.com/v1
  Ingestion: https://ingestion.edgeimpulse.com

[SER] Connecting to /dev/tty.usbmodem145101
[SER] Serial is connected (4A:5A:36:17:55:F9:70:F7)
[WS ] Connecting to wss://remote-mgmt.edgeimpulse.com
[WS ] Connected to wss://remote-mgmt.edgeimpulse.com

? To which project do you want to connect this device?
MJRobot (Marcelo Rovai) / IESTI01 - Covid-19: Detection by Cough
MJRobot (Marcelo Rovai) / TinyML Kit Camera test
MJRobot (Marcelo Rovai) / Harvard - Person Detection
MJRobot (Marcelo Rovai) / Wio - Gesture Recognition
MJRobot (Marcelo Rovai) / Cifar10_Image_Classification
MJRobot (Marcelo Rovai) / Bean Disease Classifier
MJRobot (Marcelo Rovai) / SciTinyML-Motion-Anomaly-Project
MJRobot (Marcelo Rovai) / 1-Hands-On-SciTinyML-Motion-Project
MJRobot (Marcelo Rovai) / ESP32-Motion-Classification
MJRobot (Marcelo Rovai) / ESP32_KWS_Project
MJRobot (Marcelo Rovai) / IESTI01 - Nano Motion Classification
MJRobot (Marcelo Rovai) / Motion-Project
MJRobot (Marcelo Rovai) / Blender - Motion Detection
MJRobot (Marcelo Rovai) / Key_Word_Spotting
MJRobot (Marcelo Rovai) / Oi_Rovis_Key_Word_Spotting
MJRobot (Marcelo Rovai) / Sound-Classification-Blender-Faucet
MJRobot (Marcelo Rovai) / oi_rovics_kws
MJRobot (Marcelo Rovai) / Eggs AI
MJRobot (Marcelo Rovai) / Accelerometer-Nano-Ble-IoT
MJRobot (Marcelo Rovai) / video_tinyml_raw
(Move up and down to reveal more choices)
```

```
mjrovai — node /usr/local/bin/edge-impulse-data-forwarder — 117x26
(base) MacBook-Pro-de-Marcelo:~ mjrovai$ 
(base) MacBook-Pro-de-Marcelo:~ mjrovai$ 
(base) MacBook-Pro-de-Marcelo:~ mjrovai$ edge-impulse-data-forwarder
[Edge Impulse data forwarder v1.13.16
[Endpoints:
[ Websocket: wss://remote-mgmt.edgeimpulse.com
  API:      https://studio.edgeimpulse.com/v1
  Ingestion: https://ingestion.edgeimpulse.com

[SER] Connecting to /dev/tty.usbmodem145101
[SER] Serial is connected (4A:5A:36:17:55:F9:70:F7)
[WS ] Connecting to wss://remote-mgmt.edgeimpulse.com
[WS ] Connected to wss://remote-mgmt.edgeimpulse.com

? To which project do you want to connect this device? MJRobot (Marcelo
Rovai) / IESTI01 - Nano Motion Classification
[SER] Detecting data frequency...
[SER] Detected data frequency: 100Hz

? 3 sensor axes detected (example values: [-0.13, -0.34, 9.81]). What do y
ou want to call them? Separate the names with ','; accX, accY, accZ
? What name do you want to give this device? Nano
[WS ] Device "Nano" is now connected to project "IESTI01 - Nano Motion Classification"
[WS ] Go to https://studio.edgeimpulse.com/studio/61345/acquisition/training to build your machine learning model!

```

Devices - IESTI01 - Nano Motion Classification

studio.edgeimpulse.com/studio/61345/devices

EDGE IMPULSE

DEVICES (IESTI01 - NANO MOTION CLASSIFICATION)

MJRoBot (Marcelo Rovai)

Your devices

+ Connect a new device

These are devices that are connected to the Edge impulse remote management API, or have posted data to the ingestion SDK.

NAME	ID	TYPE	SENSORS	REMOTE M...	LAST SEEN
 Nano	4A:5A:36:17:55:F9:70:F7	DATA_FORWARDER	 Sensor with 3 axes (accX, accY, accZ)		Today, 12:42:15
 36:17:55:F9:70:F7	36:17:55:F9:70:F7	ARDUINO_NANO33BLE	 Built-in accelerometer, Built-in microphone		Today, 12:26:49

© 2021 EdgeImpulse Inc. All rights reserved

GETTING STARTED

Documentation

Forums

# Reading Material

# Main references

- [Harvard School of Engineering and Applied Sciences - CS249r: Tiny Machine Learning](#)
- [Professional Certificate in Tiny Machine Learning \(TinyML\) – edX/Harvard](#)
- [Introduction to Embedded Machine Learning - Coursera/Edge Impulse](#)
- [Computer Vision with Embedded Machine Learning - Coursera/Edge Impulse](#)
- Fundamentals textbook: “[Deep Learning with Python](#)” by François Chollet
- Applications & Deploy textbook: “[TinyML](#)” by Pete Warden, Daniel Situnayake
- Deploy textbook “[TinyML Cookbook](#)” by Gian Marco Iodice

I want to thank **Shawn Hymel** and **Edge Impulse**, **Pete Warden** and **Laurence Moroney** from Google, Professor **Vijay Janapa Reddi** and **Brian Plancher** from Harvard, and the rest of the **TinyMLEdu** team for preparing the excellent material on TinyML that is the basis of this course at UNIFEI.

The IESTI01 course is part of the [TinyML4D](#), an initiative to make TinyML education available to everyone globally.

Thanks



UNIFEI