

- ① Start the kernel
 - ② Crash window
- Why it panic?

RPI
↓

zimage U-boot bootcode.bin bcm2701.dtb

- ① clone kernel
- ② Add your Configuration

export ARCH = arm or

```
fady@android:~/kernel/linux$ make vexpress_defconfig
*** Can't find default configuration "arch/x86/configs/vexpress_defconfig"!
```

you
will face this error

- ③ Compile
- export CROSS_COMPILE = ~/x-tool / —
make -j12

- ④ take the zimage file and copy to the FAT partition

```
fady@android:~/kernel/linux/arch/arm/boot$ ls
bootp compressed deflate_xip_data.sh dts Image install.sh Makefile zImage
```

Sd Card
FAT

- ⑤ Copy dtb → FAT Sd card

```
fady@android:~/kernel/linux/arch/arm/boot/dts/arm$ ls
arm-realview-eb-11mp-bbrevd-ctrevb.dts  arm-realview-pba8.dts  versatile-ab-lb2.dts
arm-realview-eb-11mp-bbrevd.dts        arm-realview-pbx-a9.dts  versatile-pb.dts
arm-realview-eb-11mp-ctrevb.dts        arm-realview-pbx.dtsi    vexpress-v2m.dtsi
arm-realview-eb-11mp.dts               dtbs-list               vexpress-v2m-rs1.dtsi
arm-realview-eb-a9mp-bbrevd.dts        integratordp.dts        vexpress-v2p-ca15-a7.dtb
arm-realview-eb-a9mp.dts               integratordp-in-pd1.dts  vexpress-v2p-ca15-a7.dts
arm-realview-eb-bbrevd.dts             integratordp.dts        vexpress-v2p-ca15-tci.dtb
arm-realview-eb-bbrevd.dtsi            integratordtsi          vexpress-v2p-ca15-tci.dts
arm-realview-eb.dts                   Makefile                vexpress-v2p-ca5s.dtb
arm-realview-eb.dtsi                 nps2-an385.dts          vexpress-v2p-ca5s.dts
arm-realview-eb-mp.dtsi               nps2-an399.dts          vexpress-v2p-ca9.dtb
arm-realview-pb1176.dts               nps2.dtsi              vexpress-v2p-ca9.dts
arm-realview-pb11mp.dts               versatile-ab.dts
```

Sd card
FAT

