$\blacksquare$ 

Guides

Current

**Buzzer Mute Mode** 

# **Buzzer Mute Mode**

With Beeper Mute Mode you can silence the buzzer as long it's not needed.

Setup a switch to activate beeper and deactivate beeper mute mode. We can do that in the "Modes" tab of the Configurator.

### Eg.:

```
AUX5 < 1500 -> 'Beeper mute' is active, 'Beeper' is inactive. AUX5 > 1500 -> 'Beeper mute' is inactive, 'Beeper' is active.
```

#### Youtube

- Joshua Bardwell
  - Ivan Efimov

# **Community**

- Discord
- **IntoFPV**

#### Links

- Oscar Liang
- VitroidFPV

# **Feeds**

- **B** RSS
- **Ы** Atom
- NOSL 61



Copyright © 2025 All rights reserved Team Betaflight

Built with Docusaurus

made with **vitroidFPV** and **un!t**