Guides

Current

OSD & CMS Adjusting Screen

OSD & CMS Adjusting Screen

Adjusting CMS Screen

Different display devices have different characteristics, so you may be experiencing inconvenience such as displayed items truncated at the right edge, top most line is only displayed lower half, and so on.

There are CLI variables that you can tweak to fit the content inside your screen.

MAX/AB7456 based FC-integrated (SPI-connected) OSD specific


vcd_v_offsetAdjust the vertical position of the first row.vcd_h_offsetAdjust the horizontal position of the left edge.displayport_max7456_col_adjustAdjust number of characters in a line.displayport_max7456_row_adjustAdjust number of rows on the screen.

External OSD (DISPLAYPORT capable MWOSD and others)

displayport_msp_col_adjust Adjust number of characters in a line.

displayport_msp_row_adjust Adjust number of rows on the screen.

Example



Original Screen



Screen with displayport_max7456_col_adjust = -2

Youtube

■ Joshua Bardwell

Links

Oscar Liang

Ivan Efimov



Community

Discord

IntoFPV

Feeds

™ RSS

₼ Atom

NOST 69



Copyright © 2025 All rights reserved Team Betaflight

Built with Docusaurus

made with ♥ by VitroidFPV and un!t