

Globex Widget 3000 — Product Manual

Fictional sample document.

Overview

Thank you for choosing the Globex Widget 3000, a fictional device used here as sample documentation. This manual covers setup, features, troubleshooting and warranty.

Getting Started

1. Remove the Widget 3000 from its packaging. 2. Charge the device fully before first use using the included USB-C cable. 3. Press and hold the power button for 3 seconds to turn it on. 4. Follow the on-device prompts to pair with the Globex companion app.

Battery & Charging

The Widget 3000 has a battery life of approximately 8 hours of continuous use. A full charge takes about 90 minutes. The battery indicator turns amber when below 20% and green when fully charged.

Key Features

The Widget 3000 is water-resistant to IPX5, supports Bluetooth 5.2, and includes three brightness modes. The device weighs 180 grams.

Troubleshooting

If the Widget 3000 becomes unresponsive, perform a hard reset by holding the power button for 10 seconds until the indicator blinks red. If pairing fails, ensure Bluetooth is enabled and the device is within 5 metres. For persistent issues, contact Globex support at support@example.com or 1-555-0177.

Warranty

The Widget 3000 includes a 12-month limited warranty covering manufacturing defects. The warranty does not cover accidental damage or water damage beyond the IPX5 rating.