
LEFT SENSOR
VCC GND SDA SCL
CODING CAR RED
VER 1
FRONT SENSOR
VCC GND SDA SCL
QR SCANNER
TRIG ECHO GND VCC
LEFT LED
32 GND
FRONT LED
16 GND
RIGHT LED
17 GND
START/STOP/REST
BUTTON
34 GND
QR SCAN BUTTON
CONNECTED DIRECTLY
TO QR SCANNER
5V GND
X1
USB
micro B
ESP-WROOM-32
3V3 GND D15 LED D4 RX2 TX2 D5 D18 D19 SDA SCL D23
VCC GND SCL SDA
VCC GND SDA SCL
TRIG ECHO GND VCC
DEST SENSORS
QR SCANNER
TB6612FNG
PWMA
AIN2
AIN1
STBY
BIN1
BIN2
PWMB
GND
VM
VCC
GND
AO1
AO2
BO2
BO1
GND
MOTOR1
MOTOR2
RIGHT SENSOR
VCC GND SDA SCL