



installation guide





Step by Step Project Guide



Measurements and Dimensions of the roof.




Appropriate Design.



Cutting and welding works in Rooflint's workshop.






Rooflint




Visit the Room.



Have a look at the room. Prepare the device.

Start of Installation.




4


www.rooflint.com

Install the base frame and the lamp stand with a spirit level.





Secure the foil with clamps and heat it up with a heat gun.



Insert the foil into the base frame.


Rooflint

5


www.rooflint.com

Rooflint





Plug in the lights.




When installation is finished, air the room.

www.rooflint.com



End of Work.



Handing over

7

MAINTENANCE PROCESS

Rooflint





Do not touch the foil with sharp items

Do not set foil on fire

Do not cut off

Do not color the surface







www.rooflint.com

If necessary, use a soft cloth and glass cleaner wipe.







9





























11