


Mimio MyBot Planetary Exploration Kit Building Instructions







Planetary Exploration Kit Build Instructions


Use these step-by-step instructions to assemble the MyBot Planetary Exploration Kit robot from the components shown above (and detailed on the following pages).

Copyright 2018-2020, Boxlight Robotics, All Rights Reserved

No part of this document may be copied, published in print or shared online or otherwise publicly released without the express written consent of Boxlight Robotics.

Note: Specifications listed are subject to change without notice.

Illustrated List of Components Needed



11-4116

M4 x 16mm Screw

45-1300

6V Battery Pack

08-0007

Axle Hub


Illustrated List of Components Needed



X1 45-2018 Color Sensor



x1 45-2007 Touch Sensor





x1 45-2100 19mm Ball Caster






x2 45-1400 Wheel and Screw

X1 15-0016 Box for Spare Fasteners TIP: Use this box to store any extra fasteners and small parts. You can use them with future activities and configurations for your MyBot Robot!







































9 (


































































17 – Wiring

