RGB Matrix Screen

Frame assembly

Overall Steps

- Fit the frame (pre-assembly)
- 2. Measure & cut flat bar
- 3. Measure and flat bar mount placement & drill holes
- 4. Ensure frame has true right angles at corners

(Diagrams in appendix)

Safety warning



Some procedures require the use of power tools, such as a high-speed circular cutting device and power drill. Use of these tools can present a safety hazard to eyes, ears and hands! Cutting and drilling with metal can and will produce sparks and smoke.



The following safety rules are non-negotiable and must be followed!



- •Use of all power tools <u>must</u> <u>be performed outdoors</u> on cement
- •Use of power tools <u>must only be performed by qualified personnel</u>
- •Required safety gear:
 - Impact resistant safety glasses
 - Hearing protection
 - Cut-resistant leather gloves
 - Closed toe footwear
 - Long-sleeve shirt
 - Pants



Safety iconography



Review and adhere to all safety warnings and procedures



Impact resistant eye protection required



Cut-resistant leather gloves required



Hearing protection required

Required tools



High-speed mandrel saw (Dremel works well)



Mandrel metal cutting saw (with "EZ" attachment)



3mm Allen Wrench / Hex Key (x 6)




Cordless power drill



4 - 5mm drill bit


Fit frame (pre-assembly)


- 1. Unbox all frame parts and hardware
- 2. Group like-parts together
 - a. 80/20 bars
 - b. Screws
 - c. Brackets
- 3. Get familiar with frame assembly
 - a. Arrange 80/20 bars for assembly
 - b. Do this for both layers



Fit frame (pre-assembly)

- 1. Unbox all frame parts and hardware
- 2. Group like-parts together
 - a. 80/20 bars
 - b. Screws, nuts bolts
 - c. Brackets
 - d. Plates





Parts List :: CR office

Structural



2020 bar [20mm x 20mm x 768mm] Quantity: 3



2040 bar [20mm x 40mm x 1000mm] Quantity: 8



2040 bar [20mm x 40mm x 768mm] Quantity: 6



Zinc plated flat bar [950mm x 35mm x 1mm] Quantity: 5

Mounting hardware



5310 screw [9.32mm x 10mm] [3mm hex head] Quantity: 220



14122 T-nut fastening block [used with 13-5310 screw] Quantity: 220



4165 Eight hole Flat plate [80mm x 40mm] Quantity: 4



4167 Four hole flat plate [80mm x 80mm] Quantity: 20



4119 Two hole corner bracket Quantity: 33



4113 4 hole corner bracket Quantity: 8



20-4081 5 hole outside elbow bracket Quantity: 4

Parts List :: RO & US office

Structural



2020 bar [20mm x 20mm x 640mm] Quantity: 3



2040 bar [20mm x 40mm x 640mm] Quantity: 8



2040 bar [20mm x 40mm x 840mm] Quantity: 6



Zinc plated flat bar [640mm x 35mm x 1mm] Quantity: 5

Mounting hardware



5310 screw [9.32mm x 10mm] [3mm hex head] Quantity: 220



14122 T-nut fastening block [used with 13-5310 screw] Quantity: 220



4165 Eight hole Flat plate [80mm x 40mm] Quantity: 4



4167 Four hole flat plate [80mm x 80mm] Quantity: 20



4119 Two hole corner bracket Quantity: 33



4113 4 hole corner bracket Quantity: 8





20-4081 5 hole outside elbow bracket Quantity: 4

Measure and cut flat bar

- 1. Measure and mark flat bar at 964 mm
- 2. Cut flat bar at mark
- Use flat size of rotary blade to smooth out rough edges at cut.
- 4. Place flat bar inside of frame to confirm fitment and adjust cuts as needed.


Flat bar should rest up to 2mm inside of vertical 80/20 bars







Frame Assembly Appendix

Frame 80/20 Layers




Frame 80/20 Layer 1 exploded















Frame 80/20 Layer 2 exploded






















front


Frame 80/20 Layer 3 exploded



(Layer 3 assembled rear)









Screen dimensions

Physical dimensions:

- RGB Matrix panel:
 - o 160mm x 160mm
- RGB Matrices (assembled):
 - 800mm x 640mm
- Frame (front) :
 - 840mm x 680mm
- Frame (side) :
 - o 120mm x 680mm

