
مشـــــــروع ذراع الروبــــــوت الخشبيـــــــة

%|_`! |\$|_`!

هيا نبدأ رحلتنا إلى الفضاء معاً!









Wooden Arm Robot Booklet


Copyright © 2024 FabPak. All rights reserved.

مشــــــروع ذراع الروبـــــوت الخشبي

هيا نبدأ رحلتنا إلى الفضاء معاً!




Make sure that all the pieces are inside the box:





هيا نبدأ رحلتنا إلى الفضاء معاً!








مشـــــــروع ذراع الروبـــــوت الخشبيـــــ


هيا نبدأ رحلتنا إلى الفضاء معاً!



Attach the bolts to their places in the Servo Piece (4 pieces) and the Upper Plate:



Attach the Middle Plate to the Servo, then mount the Upper Plate and the Lower Plate on the Servo and secure them with






مشـــــــروع ذراع الروبـــــوت الخشبيــــــ


هيا نبدأ رحلتنا إلى الفضاء معاً!



Secure the Servo Piece on the Base with 1 cm bolts (nuts should be placed in the servo piece):



Secure the 2 Rings on the Base using 1 cm bolts and nuts:








مشـــــــروع ذراع الروبــــــوت الخشبيــــــــ

هيا نبدأ رحلتنا إلى الفضاء معاً!



Connect the two parts you assembled in the last steps:






مشـــــــروع ذراع الروبــــــوت الخشبيـــــــة


هيا نبدأ رحلتنا إلى الفضاء معاً!



Place the Battery Holder on top of the Servo, align its holes with the ones in the Upper Plate, then secure it with 1 cm bolts:



Remove the double sided tape of the Breadboard and secure it on the Upper Plate:







هيا نبدأ رحلتنا إلى الفضاء معاً!



Secure the Servo on the Right Plate using 1 cm bolts (You don't need to use nuts) and attach the Servo Piece:









هيا نبدأ رحلتنا إلى الفضاء معاً!



Secure the Servo on the Left Plate using 1 cm bolts (You don't need to use nuts) and attach the Servo Piece:



Secure the Left Arm on the Servo Piece using and attach the Vertical Support Arm to the Plate using a 1 cm bolt and nut and attach Back Support Arm to the Left Arm using and a 3 cm bolt and nut:






هيا نبدأ رحلتنا إلى الفضاء معاً!



Connect the two side parts with the assembled base in the slots in the Lower Plate as follows:






مشـــــــروع ذراع الروبــــــوت الخشبيـــــــة

هيا نبدأ رحلتنا إلى الفضاء معاً!










مشـــــــروع ذراع الروبــــــوت الخشبيـــــــ

هيا نبدأ رحلتنا إلى الفضاء معاً!



Secure the Right Plate and the Left Plate further by using 1 cm bolts through the nuts in the t-slots* in the Upper Plate, Attach the 2 Side Piece to the Upper Plate via the slots and secure them with 1 cm bolts and nuts on the Left Plate and the Right Plate:



t-slots: Slots with the shape of a T, it consists of a slot for bolts to pass through to a nut securely placed in the slot.




مشـــــــروع ذراع الروبــــــوت الخشبيـــــــ

هيا نبدأ رحلتنا إلى الفضاء معاً!



Attach the Connceting Piece to the Vertical Support Arm using 1 cm bolt and nut and the Upper Arm to the Right Arm Support and then connect them together with Piece 1 and a 3 cm bolt and nut:




Don't Forget to Ask For Help From an Adult!



هيا نبدأ رحلتنا إلى الفضاء معاً!



Attach the other Upper Arm on the Right Arm using a 1 cm bolt and nut, then align it with the other Upper Arm and the Back Support Arm and connect all 3 using Piece 2 and a 3 cm bolt and nut:






مشــــــروع ذراع الروبـــــوت الخشبيــــــة

هيا نبدأ رحلتنا إلى الفضاء معاً!



Attach the Horizontal Support Arm on the Connecting Piece using a 1 cm bolt and nut, then bring the last Servo and connect it to the Right Support and Left Support via the slots and connect them all using 3 cm bolts and nuts and Piece 1:






هيا نبدأ رحلتنا إلى الفضاء معاً!



Last step, attach the Claw* to the Servo:






The claw is assembled on your own as an assessment, try to figure it out your self!



مشــــــروع ذراع الروبـــــوت الخشبيــــــة

هيا نبدأ رحلتنا إلى الفضاء معاً!





Good Job!

Now you can move to assembling the electronic circuit on the Breadboard and start righting the Code!









Wooden Arm Robot Booklet

