## Part-1

O LEA.

LEA means Load effective address.

If we use the in LEA it means we can go new line.

offset

handling the overloading of the mor instruction.

3 difference.

Data in a library fronction.

We we use Data register in emusos6

we have must ussign . Data as a

library function.





## 3 ASSUME DS: DATA CS: CODE.

It is used to imform the emu8086 that cs cotain the code and DS contains the Data.

BX, SI, DI, BP this 4 register for accessing memory.

Ex. mor bx, offset armay 2

mor [bx], 26

mor [bx+1], 10

mor [bx+9], 9

24 MOV Bx, 30h MOV DI, 10 h LEA SI, Σ BX+DI]