2017-09-19

- The words of a computer's language are called **instructions**, and its vocabulary is called an **instruction set**.
- **Stored-program concept**: The idea that instructions and data of many types can be stored in memory as *numbers*, leading to the stored-program computer.
- MIPS instruction set architecture:
 - Operands: registers, memory words.
 - Operators: arithmetic, data transfer, logical, conditional branch, unconditional jump.
- Design principles:
 - Simplicity favors regularity.
 - Smaller is faster.
 - Good design demands good compromises.
- **Word**: The natural unit of access in a computer; corresponds to the size of a register in the MIPS architecture.

• Registers:

Name	Register number	Usage	Preserved on call?
\$zero	0	The constant value 0	n.a.
\$v0-\$v1	2–3	Values for results and expression evaluation	no
\$a0-\$a3	4–7	Arguments	no
\$t0-\$t7	8–15	Temporaries	no
\$s0 - \$s7	16–23	Saved	yes
\$t8-\$t9	24–25	More temporaries	no
\$gp	28	Global pointer	yes
\$sp	29	Stack pointer	yes
\$fp	30	Frame pointer	yes
\$ra	31	Return address	yes

• It is the compiler's job to associate program variables with registers.

• Memory words:

- To access a word in memory, the instruction must supply the memory *address*.
- Expression in assembly language: offset(\$base register).
- Data transfer instructions: A command that moves data between memory and registers.
 - *Load* values from memory into registers.
 - Store result from register to memory.
- Alignment restriction: A requirement that data be aligned in memory on natural boundaries,

- e.g. multiples of 4 bytes in MIPS.
- The process of putting less commonly used variables (or those needed later) into memory is called **spilling** registers.
- Constants or immediate operands:
 - Constant data specified in an instruction.
 - Immediate operand avoids a load instruction.
- Endianness:
 - Big-endian: most-significant bit at least address of a word.
 - Little-endian: least-significant bit at least address of a word.
- Binary numbers:
 - Two's complement: $x + \bar{x} = -1$
 - **Sign extension**: replicate the sign bit to the left.
- Instructions are kept in the computer as a series of high and low electronic signals and may be represented as *numbers*.
- Machine language: the numeric version of instructions.
- The instruction formats are distinguished by the values in the first field (op).
- The desire to keep all instructions the same size is in conflict with the desire to have as many registers as possible.
- Most instruction sets today have 16 or 32 general purpose registers.
- **Binary compatibility** often leads industry to align around a small number of instruction set architectures.
- Instruction fields:
 - op: operation code (opcode).
 - rs: first source register number.
 - rt: second source register number.
 - *rd*: register destination operand.
 - *shamt*: shift amount.
 - funct: function code.
 - o constant or address.
- **Instruction format**: a form of representation of an instruction composed of fields of binary numbers.

Name	Bit Fields						Notes
	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits	(32 bits total)
R-Format	ор	rs	rt	rd	shmt	funct	Arithmetic, logic
I-format	ор	rs	rt	address/immediate (16)		liate (16)	Load/store, branch, immediate
J-format	ор		target address (26)			Jump	

Operators and operations:

Category	Instruction	Example	Meaning	Comments
Arithmetic	add	add \$s1,\$s2,\$s3	\$s1 = \$s2 + \$s3	Three register operands
	subtract	sub \$s1,\$s2,\$s3	\$s1 = \$s2 - \$s3	Three register operands
	add immediate	addi \$s1,\$s2,20	\$s1 = \$s2 + 20	Used to add constants
Data transfer	load word	lw \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Word from memory to register
	store word	sw \$s1,20(\$s2)	Memory[\$s2 + 20] = \$s1	Word from register to memory
	load half	1h \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Halfword memory to register
	load half unsigned	1hu \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Halfword memory to register
	store half	sh \$s1,20(\$s2)	Memory[\$s2 + 20] = \$s1	Halfword register to memory
	load byte	1b \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Byte from memory to register
	load byte unsigned	1bu \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Byte from memory to register
	store byte	sb \$s1,20(\$s2)	Memory[\$s2 + 20] = \$s1	Byte from register to memory
	load linked word	11 \$s1,20(\$s2)	\$s1 = Memory[\$s2 + 20]	Load word as 1st half of atomic swap
	store condition, word	sc \$s1,20(\$s2)	Memory[\$s2+20]=\$s1;\$s1=0 or 1	Store word as 2nd half of atomic swap
	load upper immed.	lui \$s1,20	\$s1 = 20 * 2 ¹⁶	Loads constant in upper 16 bits
	and	and \$s1,\$s2,\$s3	\$s1 = \$s2 & \$s3	Three reg. operands; bit-by-bit AND
	or	or \$s1,\$s2,\$s3	\$s1 = \$s2 \$s3	Three reg. operands; bit-by-bit OR
Logical	nor	nor \$s1,\$s2,\$s3	\$s1 = ~ (\$s2 \$s3)	Three reg. operands; bit-by-bit NOR
	and immediate	andi \$s1,\$s2,20	\$s1 = \$s2 & 20	Bit-by-bit AND reg with constant
	or immediate	ori \$s1,\$s2,20	\$s1 = \$s2 20	Bit-by-bit OR reg with constant
	shift left logical	sll \$s1,\$s2,10	\$s1 = \$s2 << 10	Shift left by constant
	shift right logical	srl \$s1,\$s2,10	\$s1 = \$s2 >> 10	Shift right by constant
Conditional branch	branch on equal	beq \$s1,\$s2,25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch
	branch on not equal	bne \$s1,\$s2,25	if (\$s1!= \$s2) go to PC + 4 + 100	Not equal test; PC-relative
	set on less than	slt \$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than; for beq, bne
	set on less than unsigned	sltu \$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than unsigned
	set less than immediate	slti \$s1,\$s2,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant
	set less than immediate unsigned	sltiu \$s1,\$s2,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant unsigned
Unconditional jump	jump	j 2500	go to 10000	Jump to target address
	jump register	jr \$ra	go to \$ra	For switch, procedure return
	jump and link	jal 2500	\$ra = PC + 4; go to 10000	For procedure call

- **Basic block**: a sequence of instructions without branches (except possibly at the end), and without branch targets or branch labels (except possibly at the beginning).
- MIPS compilers use the slt, slti, beq, bne, and the fixed value of \$zero to create all relative conditions, and therefore, avoid higher cost of more complicated branch on less than.

```
if (s0 <= s1) else: slt $t0, $s1, $s0; bne $t0, $zero, else</li>
if (s0 < s1) else: slt $t0, $s0, $s1; beq $t0, $zero, else</li>
```

- Treating signed numbers as if they were unsigned gives us a low cost way of checking if $0 \le x < y$, which matches the index out-of-bounds check for arrays.
- Implementing *switch* is via a sequence of conditional tests, or via a **jump address table** (or **jump table**), a table of addresses of alternative instruction sequences.
- Jump register (jr) instruction is an unconditional jump to the address specified in a register.
- **Procedure** (or **function**): a stored subroutine that performs a specific task based on the parameters with which it is provided.
- **Program counter (PC)** is the register that contains the address of the instruction in the program being executed.

- **Jump-and-link (jal)** instruction jumps to an address and simultaneously saves the address of the following instruction in register \$ra.
- The jump register (jr) jumps to the address stored in register \$ra.
- The ideal data structure for spilling registers is a *stack*, which "grow" from higher addresses to lower addresses.
- The **stack pointer (\$sp)** is adjusted by one word for each register that is saved or restored.
- **Temporary registers (\$t0**—**\$t9)** are not preserved by the callee (called procedure) on a procedure call.
- **Saved registers (\$s0-\$s7)** must be preserved on a procedure call (if used, the callee saves and restores them).
- One solution to nested procedures is to push all the other registers that must be preserved onto the stack.
- The stack is also used to store variables that are local to the procedure but do not fit in registers, such as local arrays or structures.
- **Procedure frame** (or **activation record**): the segment of the stack containing a procedure's saved registers and local variables.
- Frame pointer (\$fp) points to the first word of the frame of a procedure.
- A frame pointer offers a stable base register within a procedure for local memory-references.
- The stack is adjusted only on entry and exit of the procedure.
- The MIPS memory allocation for program and data (from low to high): reserved, text segment (machine code), static data segment, heap, stack.
- Three choices for representing a string:
 - The first position of the string is reserved to give the length of a string.
 - An accompanying variable has the length of the string (as in a structure).
 - The last position of a string is indicated by a character used to mark the end of a string.
- MIPS' instructions to move bytes and halfwords: load byte (lb), store byte (sb), load half (lh), store half (sh).
- The MIPS instruction set includes the **instruction load upper immediate (lui)** specifically to set the upper 16 bits of a constant in a register.
 - Load the upper 16 bits using *lui*.
 - Insert the lower 16 bits using *ori*.
- Either the compiler or the assembler must break large constants into pieces and then reassemble them into a register.
- The size of address is 16 bits in I-format or 26 bits in J-format.
- Addressing modes: addressing mode One of several addressing regimes delimited by their varied use of operands and/or addresses.
 - **Immediate addressing**: the operand is a constant within the instruction itself.

- **Register addressing**: the operand is a register.
- **Base or displacement addressing**: the operand is at the memory location whose address is the sum of a register and a constant in the instruction.
- **PC-relative addressing**: the branch address is the sum of the PC and a constant in the instruction, i.e. branch address = program counter + register.
- **Pseudodirect addressing**: the jump address is the 26 bits of the instruction concatenated with the upper bits of the PC.
- Conditional branches are found in loops and in if statements, so they tend to branch to a nearby instruction.
- If a branch target is too far away to be encoded with 16-bit offset, assembler rewrites the code and makes use of jump (j) instruction.