

CM110 to AST-XE-175EX

Mounting Instructions

1049535

The CM110 should be mounted such that the knob on the AS201 light source does not interfere with the CM110 output at the exit slit.

The CM110 to AS201 Adaptor **part** # **4-2212** is threaded into the AS201 light source. Situate the CM110 with the RS-232 and power cable connections closest to the power switch located on the AS201 light source (see photo below). The CM110 mounts to the adaptor with three #6-32 sockethead set screws spaced at 120 degrees intervals.

