Q – 1 :-Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.


Ans - Follow these 5 easy steps to connect a webcam, install its driver, and take a photo.

Step 1: Connect the USB webcam




- Take your USB webcam.
- Plug it into the computer's USB port.
- Make sure it is connected properly.
- Check if the webcam light turns on.

Step 2: Install the driver



- **Wait for Windows to detect the webcam.**
- **Windows may install the driver automatically.**
- **If it does not, download the driver from the webcam manufacturer's website.**
- **Restart your computer if needed.**


Step 3: Open the Camera app



- **Click the Start button.**


- **Type Camera in the search box.**
- **Open the Camera app.**
- **Select your USB webcam if needed.**

Step 4: Check the webcam



- **Look at the screen.**
- **Check if your face appears.**
- **Make sure the picture is clear.**
- **Adjust the webcam if needed.**

Step 5: Take a photo



- **Look at the camera preview.**
- **Click the white camera button.**
- **Your photo will be captured.**
- **Open the Pictures folder and check the saved photo.**

Task completed!

Result: The webcam is connected, the driver is installed, the camera is working, and a photo has been captured successfully.

Note: These are real-world reference photos showing the process, not a photo taken from your own computer.

Q – 2 :- Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation


Ans-Follow these simple steps to connect a printer, install its driver, and print a test page using Windows 10.

Step 1: Connect the printer




- **Switch ON the printer.**
- **Connect the USB cable to your computer.**
- **For a network printer, connect it to the same Wi-Fi network as your computer.**
- **Check that the printer has power.**

Step 2: Install the printer driver




- **Open the printer manufacturer's website.**
- **Find your printer model.**
- **Download the correct Windows 10 driver.**
- **Open the downloaded file.**
- **Follow the installation instructions.**

Step 3: Add the printer to Windows




- **Click Start.**
- **Open Settings.**
- **Select Devices.**
- **Click Printers & scanners.**
- **Select Add a printer or scanner.**
- **Choose your printer and click Add device.**

Step 4: Open printer properties




- **Open Printers & scanners.**
- **Select your installed printer.**
- **Click Manage.**
- **Select Printer properties.**

Step 5: Print a test page



- **Open the General tab.**
- **Click Print Test Page.**
- **Wait for the printer to print the page.**
- **Check that the text and images look clear.**

Step 6: Check the result



- **Check whether the page came out.**
- **Make sure the printing is clear.**
- **Check that there are no missing lines or blank areas.**

Installation successful!

Final Result: The printer is connected, the correct driver is installed, Windows detects the printer, and the test page prints successfully.

Conclusion: Connecting the printer, installing its driver, adding it to Windows, and printing a test page helps confirm that the printer is working correctly.

**Q -3 :-Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

Hint: Check for error icons and use the 'Scan for hardware changes' option after reconnecting.**

Ans-Fix "Printer Not Detected" Using Device Manager

Here is a simple practical activity to find and fix a printer connection problem in Windows 10.


Step 1: Unplug the USB cable




- **Turn ON the printer.**
- **Unplug the USB cable from the computer.**
- **The computer may stop detecting the printer.**
- **This simulates a connection problem.**

Step 2: Open Device Manager

- **Right-click the Start button.**
- **Select Device Manager.**
- **A list of computer devices will appear.**



Step 3: Check for printer errors




- **Look for Printers or Print queues.**
- **Check for a yellow warning sign.**
- **The printer may disappear from the list when unplugged.**
- **This shows that Windows is not detecting the printer.**

Step 4: Reconnect the USB cable




- **Plug the USB cable back into the computer.**
- **Make sure both ends are connected properly.**
- **Keep the printer switched ON.**

Step 5: Scan for hardware changes



- **Open Device Manager.**
- **Click the Action menu.**
- **Select Scan for hardware changes.**
- **Wait for Windows to detect the printer again.**

Step 6: Check the printer



- **Check if the printer appears in Device Manager.**
- **Make sure there is no yellow warning sign.**
- **Open Settings → Devices → Printers & scanners.**

- **Check whether the printer is listed and ready.**
- **Print a test page.**

Problem solved!

Final Result: Windows detects the printer again after reconnecting the USB cable and scanning for hardware changes.

Conclusion: Unplugging and reconnecting the USB cable, checking Device Manager, and scanning for hardware changes can help fix a "Printer Not Detected" problem.

**Q – 4 :-A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications.


Hint: Check if another app is using the webcam or if Zoom permissions are enabled.**

Ans-Fix Webcam Not Working in Zoom

Problem: The webcam works in the Windows Camera app, but the video is not showing in Zoom.

Follow these simple steps to fix the problem.

Step 1: Check the webcam in the Camera app



- **Click the Start button.**
- **Search for Camera.**
- **Open the Camera app.**
- **Check if your face appears on the screen.**


Check: If the video works, the webcam is connected properly.

Step 2: Close other apps using the webcam

- **Close the Camera app.**
- **Close Skype, Microsoft Teams, or other video apps.**
- **Make sure no other app is using the webcam.**

- **Open Zoom again.**


Check: Is another app using the webcam?




Step 3: Check Windows camera permissions

- **Open Settings.**
- **Click Privacy.**
- **Select Camera.**
- **Turn ON Allow apps to access your camera.**
- **Make sure desktop apps can access the camera.**

Check: Is camera permission turned ON?



Step 4: Check Zoom camera settings




- **Open Zoom.**
- **Click your profile picture.**

- **Select Settings.**
- **Click Video.**
- **Select the correct webcam from the camera list.**

Check: Is the correct camera selected?


Step 5: Restart Zoom



- **Close Zoom completely.**
- **Open Zoom again.**
- **Join a test meeting.**
- **Turn on the video by clicking Start Video.**

Check: Can you see your video now?

Step 6: Update Zoom and restart the computer



- **Open Zoom.**
- **Click your profile picture.**
- **Select Check for Updates.**
- **Install any available update.**
- **Restart your computer.**
- **Open Zoom and test the webcam again.**

Check: Is the webcam working in Zoom?

Problem solved!

Final result



- **Webcam works in the Windows Camera app.**
- **Webcam works in Zoom.**
- **Video is clear and visible.**
- **Both applications can use the webcam.**

Conclusion: Close other apps, enable camera permissions, select the correct webcam in Zoom, and restart Zoom. These steps usually fix webcam video problems.