
DroneMEX

Motor Assembly




DroneMEX

Motor Layout

Layout:

To identify the clockwise and counterclockwise motors look for the motors wires that do not match these are the clockwise motors.

Arrange your motors as so:



DroneMEX


Motor Guide

Step 1:

Start with the front left motor (SEE MOTOR LAYOUT)

Insert 1 screw through the bottom of the frame arm(The non-flat side). Key the motor into the sunken part of the duct.

TOP



Step 2:

Place the motor and duct onto the drone frame. Make sure that the motor wires are pointing towards the middle of the drone. Bolt the screw into the motor.

