



POWER PRODUCTS


PQV-150ST-A




Part	Part No.	Description	Qty
1	90311-1600E34	Nut M16	1
2	90683-A100310-0000	Bush	1
3	40050-A100110-QC00	Bracket assy for output shaft	1
3-1	90571-4000-06	Circlip-A	1
3-2	90682-2505-Z0	Oil seal	1
3-3	40051-A100110-0000	Bracket	1
3-4	90541-1712-Z0	Deep groove ball bearing	1
3-5	90571-4000-06	Circlip-A	1
4	90683-A100210-0000	Bush	1
5	24020-A100110-0000	Chain wheel comp	1
6	10000-A100510-W300	Engine (with "Kanuni"brand)	1
7	50026-A100110-0000	Bolt	1
8	11100-00001-00	Dust Proof Cover, Engine	1
9	90311-1000A34	Hexagon flange locked nut	1
10	90007-0855-04	Hexagon flange bolt-B	1
11	90007-0840-04	Hexagon flange bolt-B	1




Part	Part No.	Description	Qty
1	GY6-125-000001	Vent Pipe Clip	1
2	GY6-125-000002	Cooling Fan Cover	1
3	GY6-125-000003	Start Motor Wire Clip	1
4	GY6-125-000004	Carburettor Cooling Pipe	1
5	GY6-125A-000005	Cover A	1
6	GY6-125-000006	Oil Seal, Cover A	1
7	GY6-125-000007	Cover B	1
8	GY6-125A-000008	High Voltage Wire Clip	1
9	GY6-125-000009	Oil Seal, Cover B	1
10	GY6-125-000010	Rubber Plug	1
11	GY6-125-000011	Bolt ST5×16	4
12	GY6-125-000012	Bolt M6×25	3
13	GY6-125-000013	Oil Spill Pipe Clip	1
14	GY6-125-000014	Rubber Plug (B)	1



Part	Part No.	Description	Qty
1	GY6-125A-000107	Vent Pipe Component	1
2	GY6-125A-000102	Cylinder Head Cover	1
3	GY6-125A-000103	Gasket, Cylinder Head Cover	1
4	GY6-125-000105	Bolt M6×25	5
5	GY6-125-000108	Bolt ST4×8	4
6	GY6-125A-000109	Vent Press Plate	1
7	GY6-125A-000110	Washer, Vent Valve Pipe A	1
8	GY6-125A-000111	Vent Valve Pipe	1
9	GY6-125A-000112	Bolt M6×18	2
10	GY6-125A-000113	Washer, Vent Valve Pipe B	1
11	GY6-125A-000114	Reed Valve Component	1
12	GY6-125A-000115	Seat Cover, Reed Valve Component	1
13	GY6-125A-000116	Bolt M6×40	2




Part	Part No.	Description	Qty
1	GY6-150A-000201	Cylinder Head	1
2	GY6-125-000202	Camshaft Fixing Seat	1
3	GY6-150-000203	Intake Valve Pipe	1
4	GY6-150-000204	Vent Valve Pipe	1
5	GY6-150-000205	Gasket, Cylinder Head	1
6	GY6-125-000206	Gasket, Heat Insulation Plate	1
7	GY6-125-000207	Carburettor Heat Insulation Plate	1
8	12510-A100110-0000	Intake Pipe	1
9	GY6-125-000209	Intake Pipe Clip	1
10	GY6-125-000210	Washer 8	4
11	GY6-125-000211	O Form Ring 27×2.0	1
12	GY6-125-000212	O Form Ring 9×1.6	2
13	GY6-125-000213	Double End Bolt M6×32	2
14	GY6-125-000214	Double End Bolt M6×60	2
15	GY6-125-000215	Bolt, Intake Pipe Clip	1
16	GY6-125-000216	Nut M6	2




Part	Part No.	Description	Qty
17	GY6-125-000217	Nut M8	4
18	GY6-125-000218	Position Pin 10×16	4
19	GY6-125-000219	Bolt M6×100	2
20	GY6-125-000220	Spark Plug A7TC、A7RTC	1


Camshaft, Valve



Part	Part No.	Description	Qty
1	GY6-125-000301	Valve Oil Seal	2
2	GY6-125-000302	Camshaft	1
3	GY6-125-000303	Stopper Plate	1
4	GY6-125-000316	Valve Rocker Component	2
4-1	GY6-125-000304	Valve Rocker	2
4-2	GY6-125-000314	Rod Adjusting Bolt	2
4-3	GY6-125-000315	Fixing Nut, Adjusting Bolt	2
5	GY6-125-000305	Rocker Shaft, Intake Valve	1
6	GY6-125-000306	Rocker Shaft, Vent Valve	1
7	GY6-150-000307	Intake Valve	1
8	GY6-150-000308	Vent Valve	1
9	GY6-125-000309	Valve Outer Spring	2
10	GY6-125-000310	Valve Inner Spring	2
11	GY6-125-000311	Valve Spring Keeper	2
12	GY6-125-000312	Spring Seat	2
13	GY6-125-000313	Valve Lock Clasp	4




Part	Part No.	Description	Qty
1	GY6-125-000401	Inner Chain, Camshaft	1
2	GY6-125-000402	Chain Pull Rod	1
3	GY6-125-000403	Chain Regulator	1
4	GY6-125-000404	Gasket, Chain Regulator	1
5	GY6-125-000405	Bolt, Pull Rod	1
6	GY6-125-000406	Chain Guide	1
7	GY6-125-000407	Bolt, M6×22	2
8	GY6-125-000408	Bolt, M6×6	1
9	GY6-125-000409	O Form Ring 15.5×1.5	1
10	GY6-125-000410	O Form Ring 15.5×1.5	1




Cylinder

Part	Part No.	Description	Qty
1	GY6-150-000501	Cylinder	1
2	GY6-150-000502	Gasket, Cylinder	1
3	GY6-125-000503	Washer	1
4	GY6-125-000504	Position Pin 10×16	2
5	GY6-125-000505	Bolt M6×12	1




Part	Part No.	Description	Qty
1	GY6-125-000601	Right Crankcase Cover	1
2	GY6-125-000602	Gasket, Right Crankcase Cover	1
3	GY6-125-000603	Nut Cover, Oil Filter Net	1
4	GY6-125-000604	Oil Filter Net	1
5	GY6-125-000605	Spring, Oil Filter Net	1
6	GY6-125-000617	Engine Oil Dipstick Component	1
7	GY6-125-000607	Cable Clip	1
8	GY6-125-000608	Oil Seal 19.8×30×5	1
9	GY6-125-000609	O Form Ring 30.8×3.1	1
10	GY6-125-000611	Position Pin 8x14	1
11	GY6-125-000612	Bolt M6×32	1
12	GY6-125-000613	Bolt M6×95	4
13	GY6-125-000614	Bolt M6×100	1
14	GY6-125-000615	Bolt M6×110	2
15	GY6-125-000616	Bolt M6×40	1




Part	Part No.	Description	Qty
1	GY6-125-000701	Cooling Fan	1
2	GY6-125-000702	Alternator	1
3	GY6-125-000703	Fly Wheel	1
4	GY6-125-000704	Rotor Loop	1
5	GY6-125-000705	Washer 12	1
6	GY6-125-000706	Bolt M5×12	2
7	GY6-125-000707	Nut M12	1
8	GY6-125-000708	Bolt M6×18	4
9	GY6-125-000709	Bolt M6×20	2


Engine Oil Pump




Part	Part No.	Description	Qty
1	GY6-125-000801	Engine Oil Pump	1
1-1	GY6-125-000804	Shaft, Oil Pump	1
1-2	GY6-125-000802	Oil Pump Body	1
1-3	GY6-125-000812	Position Pin 4×6.5	1
1-4	GY6-125-000808	Outer Rotor, Oil Pump	1
1-5	GY6-125-000807	Inner Rotor, Oil Pump	1
1-6	GY6-125-000803	Flat Plate	1
1-7	GY6-125-000810	Bolt M3×10	1
2	GY6-125-000805	Drive Gear, Oil Pump	1
3	GY6-125-000806	Drive Chain, Oil Pump	1
4	GY6-125-000809	Compact Plate, Engine Oil	1
5	GY6-125-000811	Nut M6	1
6	GY6-125-000813	Bolt M6×12	2
7	GY6-125-000814	Bolt M6×25	2




Part	Part No.	Description	Qty
1	GY6-125-000901	Start Speed-down Gear	1
2	GY6-125-000902	Shaft, Start Speed-down Gear	1
3	GY6-125-000903	Start Clutch Gear	1
4	GY6-125-000922	Clutch Cover	1
4-1	GY6-125-000912	Inner Hexangular Bolt M6x12	3
4-2	GY6-125-000904	Clutch Cover	1
4-3	GY6-125-000906	Roller Spring	3
4-4	GY6-125-000907	Roller Spring Cover	3
4-5	GY6-125-000917	Roller 10×10	3
4-6	GY6-125-000905	Flange, Start Clutch	1
5	GY6-125-000908	Start Motor	1
5-1	GY6-125-000919	O Form Ring	1
5-2	GY6-125-000920	Bolt M5×8	1
6	GY6-125-000909	Start Motor Wire	1
6-1	GY6-125-000910	Jacket A, Start Motor Wire	1
6-2	GY6-125-000911	Jacket B, Start Motor Wire	1




Part	Part No.	Description	Qty
7	GY6-125-000913	Lock Nut M22×1	1
8	GY6-125-000914	Washer 18×31×1	1
9	GY6-125-000915	Position Pin 5×6	1
10	GY6-125-000916	Woodruff Key	1
11	GY6-125-000918	Needle Bearing 28x37x17	1
12	GY6-125-000921	Bolt M6×16	1




Part	Part No.	Description	Qty
1	GY6-150-001101	Left Crankcase Cover	1
2	GY6-125-001102	Vent Guide Plate	1
3	GY6-125-001103	Position Plate	2
4	GY6-125-001104	Throttle Cable Clip	1
5	GY6-125-001105	Brake Cable Clip	1
6	GY6-125-001106	Oil Spill Pipe Clip	1
7	GY6-125-001107	Gasket, Left Crankcase cover	1
8	GY6-125-000118	Bolt ST4×8	4
9	GY6-125-001109	Bolt M6×40	6
10	GY6-125-001110	Bolt M6×65	2
11	GY6-125-001111	Main Stand Fixing Plate	1



Part	Part No.	Description	Qty
1	GY6-125-001201	Nut M12	1
2	GY6-125-001202	Fan, Drive Plate	1
3	GY6-125-001203	Bush	1
4	GY6-125-001204	Drive Plate	1
4-1	GY6-125-001223	Ring Clip 28 mm	2
4-2	GY6-125-001224	Sleeve 28	1
5	GY6-125-001205	Roller	6
6	GY6-125-001220	Washer 12	1
7	GY6-125-001207	Slope Plate	1
8	GY6-125-001208	Border Part, Slope Plate	3
9	GY6-125-001209	Start Driven Gear	1




Part	Part No.	Description	Qty
1	GY6-125-001301	Clutch Cover	1
2	GY6-125-001322	Drive Plate Component	1
2-1	GY6-125-001302	Drive Plate	1
2-2	GY6-125-001306	Clutch Shock-proof Rubber	3
2-3	GY6-125-001304	Clutch Spring	3
2-4	GY6-125-001305	Clutch Heft Assembly	1
2-5	GY6-125-001303	Clutch Side Cover	1
2-6	GY6-125-001318	Ring Clip 7mm	3
3	GY6-150-001307	Drive Belt	1
4	GY6-125-001308	Driven Belt Disc Component	1
4-1	GY6-125-001323	Driven Belt Disc	1
4-2	GY6-125-001325	Bearing 6902U	1
4-3	GY6-125-001326	Inner Ring Clip 28mm	1
4-4	GY6-125-001324	Needle Bearing	1
5	GY6-125-001309	Slip Driven Belt Disc	1
6	GY6-125-001310	Rolling Guide Pin	3




Part	Part No.	Description	Qty
7	GY6-125-001311	Roller	3
8	GY6-125-001312	Drive Spring	1
9	GY6-125-001313	Oil Seal Sleeve	1
10	GY6-125-001314	Sleeve	1
11	GY6-125-001315	Nut M12	1
12	GY6-125-001316	Nut M28	1
13	GY6-125-001317	Washer 12	1
14	GY6-125-001319	Oil Seal 34×41×4	2
15	GY6-125-001320	O Form Ring	2






Part	Part No.	Description	Qty
1	GY6-150A-001401	Gear Chamber Cover	1
2	GY6-150A-001402	Gear Shift Shaft Component	1
3	GY6-150A-001403	Position Plate	2
4	GY6-150A-001404	Washer 14×24×1	1
5	GY6-150A-001405	Gear Shift Drum Component	1
6	GY6-150A-001406	Fork	1
7	GY6-150A-001407	Bearing 6203	1
8	GY6-150A-001408	Fork Shaft	1
9	GY6-150A-001409	Drive Shaft	1
10	GY6-150A-001410	Washer 17×26×2	1
11	GY6-150A-001411	Middle Shaft Component	1
12	GY6-150A-001412	Bearing 6202	1
13	GY6-150A-001413	Output Shaft Component	1
14	GY6-150A-001414	Shift Gear Component	1
15	GY6-150A-001415	Oil Seal 32×52×7	1
16	GY6-150A-001416	Bearing 6205RS	1




Part	Part No.	Description	Qty
17	GY6-150A-001417	Bearing 6004	1
18	GY6-150A-001418	Below Bush, Rear Buffer	1
19	GY6-150A-001419	Bolt M6×40	2
20	GY6-150A-001420	Bolt M6×35	10
21	GY6-150A-001421	Oil Seal 14x22x5	1
22	GY6-150A-001422	Gear Switch	1
23	GY6-150A-001423	Bolt M6×12	1
24	GY6-150A-001424	Oil Seal 14x26x6	1
25	GY6-150A-001425	Bolt M6×25	1
26	GY6-150A-001426	Bolt M6×14	2
27	GY6-150A-001427	Cable Clip	1
28	GY6-150A-001428	Gear Lever Component	1

Crankcase




Part	Part No.	Description	Qty
1	GY6-125-001501	Right Crankcase Component	1
2	GY6-125-001502	Rubber Bush, Engine Hanger	2
3	GY6-150A-0015001	Left Crankcase Component	1
4	GY6-125-001506	Below Bush, Rear Buffer	1
5	GY6-125-001409	Special Bolt	1
6	GY6-125-001410	Washer 8	1
7	GY6-125-001411	Oil Seal 20x32x6	1
8	GY6-125-001520	Oil Drain Bolt	2
9	GY6-125-001521	Washer 12	2
10	GY6-150A-001502	Position Ball 9.5	1
11	GY6-150A-001503	Position Bolt Spring	1
12	GY6-150A-001504	Position Bolt Washer	1
13	GY6-150A-001505	Position Bolt	1
14	GY6-125-001512	Oil Seal 19.8×30×5	1
15	GY6-125-001514	Position Plate	2
16	GY6-125-001508	Double End Bolt M8×187.5	2




Crankcase

Part	Part No.	Description	Qty
17	GY6-125-001509	Double End Bolt M8×195.5	2
18	GY6-125-001515	Bolt M6×50	2
19	GY6-125-001503	Crankcase Gasket	1
20	GY6-150A-001506	Bearing 6204	1
21	GY6-150A-001507	Bearing 6202	1
22	GY6-150A-001508	Bearing 6203	2
23	GY6-150A-001509	Vent	1
24	GY6-150A-001510	Gasket, Main Shaft Cover	1




Crankshaft, Piston

Part	Part No.	Description	Qty
1	GY6-125-001601	Camshaft	1
2	GY6-150-001602	Piston Ring Component	1
3	GY6-150-001603	Piston	1
4	GY6-150-001604	Piston Pin	1
5	GY6-125-001605	Woodruff Key 25×14×4	1
6	GY6-125-001606	Piston Pin Clip	2



Part	Part No.	Description	Qty
1	16100-A100110-0000	Carburettor Assembly (for off road)	1
1-1	GY6-125-001720	Cross Groove Round Bolt ST4x8	2
1-2	GY6-125-001717	Stator	1
1-3	GY6-125-001713	Top Cover	1
1-4	GY6-125-001710	Throttle Compression Spring	1
1-5	GY6-125-001707	Throttle Assembly	1
1-6	GY6-150-001702	Fuel Pin Assembly	1
1-7	GY6-125-001714	Throttle Component	2
1-8	GY6-125-001725	Pipe Clip (D7)	2
1-9	GY6-125-001723	Bolt With Washer ST4×10	2
1-10	GY6-125-001711	Cross Groove Round Bolt ST5x12	2
1-11	GY6-125-001709	Choke Assembly	1
1-12	GY6-125-001727	Rubber Pipe	1
1-13	GY6-125-001706	Idle Speed Adjusting Bolt Assembly	1
1-14	GY6-150-001730	Sub Spray Hole	1
1-15	GY6-150-001716	Main Spray Pipe	1




Part	Part No.	Description	Qty
1-16	GY6-150-001729	Main Spray Hole	1
1-17	GY6-125-001712	Seal Gasket Assembly	1
1-18	GY6-125-001719	Vent	1
1-19	GY6-125-001705	Mix Ratio Adjusting Bolt Assembly	1
1-20	GY6-125-001721	Cross Groove Round Bolt ST4x4	4
1-21	GY6-125-001718	Adjusting Valve Cover	1
1-22	GY6-125-001708	Start Auto-Adjustment Valve Assembly	1
1-23	GY6-150-001715	Foam Pipe	1
1-24	GY6-125-001703	Floater Assembly	1
1-25	GY6-125-001722	Bolt With Washer ST4×8	2
1-26	GY6-125-001724	Bolt With Washer ST5×12	2
1-27	GY6-125-001704	Floater Chamber Assembly	1
1-28	GY6-125-001726	Pipe Clip (D8)	2
1-29	GY6-125-001728	Rubber Pipe	1

Part	Part No.	Description	Qty
1	90111-A200110-0000	Screw	8
2	80049-A1A0110-Q200	Bumper Upper Protective Plate	1
3	80025-A1A0110-Q200	Bumper Lower Protective Plate	1
4	33120-A1A0110-0000	front Right Turn Signal	1
4-1	90303-1000-32	Nut	1
4-2	90403-1000-32	Spring Washer	1
4-3	90404-1000-32	Washer	1
4-4	33093-A1A0110-0000	Holder, Turning Light	1
4-5	90723-A100410-0000	Bulb	1
4-6	33095-A100110-0000	Shade, Turning Light Lenses	1
4-7	33092-A100110-0000	Shade, Turning Light	1
4-8	90263-0325-82	Tapping Screw	1
5	33240-A100110-0000	Side Reflector	2
5-1	33241-A100110-0000	Side Reflector Piece	2
5-2	90408-0600-32	Washer	2
5-3	90403-0600-32	Spring Washer	2


Part	Part No.	Description	Qty
5-4	90303-0600-32	Nut	2
6	58210-A1A0110-QC00	Front Carrier	1
7	33090-A1A0110-0000	front left Turning Light	1
7-1	90303-1000-32	Nut	1
7-2	90403-1000-32	Spring Washer	1
7-3	90404-1000-32	Washer	1
7-4	33093-A1A0110-0000	Holder, Turning Light	1
7-5	90723-A100410-0000	Bulb	1
7-6	33095-A100110-0000	Shade, Turning Light Lenses	1
7-7	33092-A100110-0000	Shade, Turning Light	1
7-8	90263-0325-82	Tapping Screw	1
8	58410-A1A0110-QC00	Bumper	1
9	90310-0800-34	Nut	6

Chassis and Accessories




Part	Part No.	Description	Qty
1	90001-0835-04	Bolt	2
2	50009HA100110-QC00	Rear Connect Plate ,Engine	1
2-1	(USE) Assy	Shock Cushion, Engine Plate	2
2-2	(USE) Assy	Rear Connect Plate Assy, Engine	1
3	90001-0616-04	Bolt	4
4	90001-0816-04	Bolt	4
5	80009-A1A0110-QC00	Bracket, Front Fender	2
6	80014-A1A0110-QC00	Rear Bracket, Front Fender	1
7	90001-1055-04	Bolt	4
8	50038-A1A0110-0000	Shock Absorption Cushion, Main Footrest	4
9	90001-0835-04	Bolt	6
10	50004HA100120-QC00	Upper Connect Plate, Engine	1
11	90001-0612-04	Bolt	3
12	50127-A100110-QC00	Fixing Plate, Air Filter	1
13	50100-A1A0110-QC00	Chassis Welding Parts Assembly	1
14	50007HA100120-QC00	Upper Right Connect Plate, Engine	1







Part	Part No.	Description	Qty
15	80016-A1A0110-QC00	Rear Right Bracket, Front Fender	1
16	56110-A1A0110-QC00	Left Main Footrest Welding Components	1



Part	Part No.	Description	Qty
1	33240-A100110-0000	Side Reflector	2
1-1	(USE) Assy	Side Reflector Piece	2
1-2	(USE) Assy	Washer	2
1-3	(USE) Assy	Spring Washer	2
1-4	(USE) Assy	Nut	2
2	58310-A1A0110-QC00	Rear Carrier	1
3	33260-A100210-0000	Rear Reflector	1
3-1	33262-A100110-0000	Rear Reflector Plate	1
3-2	90408-0600-32	Washer	1
3-3	90403-0600-32	Spring Washer	1
3-4	90303-0600-32	Nut	1
4	90007-0816-04	Bolt	4
5	33140-A100110-0000	Rear Left Turning Light	1
5-1	(USE) Assy	Nut	1
5-2	(USE) Assy	Spring Washer	1
5-3	(USE) Assy	Washer	1



Part	Part No.	Description	Qty
5-4	(USE) Assy	Holder, Turning Light	1
5-5	90723-A100410-0000	Bulb	1
5-6	(USE) Assy	Shade, Turning Light Lenses	1
5-7	(USE) Assy	Shade, Turning Light	1
5-8	(USE) Assy	Tapping Screw	1
6	33150-A100110-0000	Rear Right Turning Light	1
6-1	(USE) Assy	Nut	1
6-2	(USE) Assy	Spring Washer	1
6-3	(USE) Assy	Washer	1
6-4	(USE) Assy	Holder, Turning Light	1
6-5	90723-A100410-0000	Bulb	1
6-6	(USE) Assy	Shade, Turning Light Lenses	1
6-7	(USE) Assy	Shade, Turning Light	1
6-8	(USE) Assy	Tapping Screw	1
7	50394-A1A0110-QC00	Chassis End Piece	1
8	90007-0820-34	Bolt	4



Part	Part No.	Description	Qty
9	33280-A100110-0000	Taillight	1
91	(USE) Assy	Tapping Screw	2
92	(USE) Assy	Shade, Taillight	1
93	90723-A100310-0000	Bulb	1
94	(USE) Assy	Holder, Taillight	1
95	(USE) Assy	Washer	2
96	(USE) Assy	Washer	2
97	(USE) Assy	Spring Washer	2
98	(USE) Assy	Nut	2


Front Plastic Cover




Part	Part No.	Description	Qty
1	90103-A100110-0000	Cross Groove Round Screw	6
2	90732-A100110-0000	Clip Nut	6
3	90107-4212-04	Tapping Screw	2
4	90001-0616-04	Bolt	1
5	80005-A1A0110-Q200	Front Fender	1
5	80005-A1A0110-Q100	Front Fender	1
6	80031-A1A0110-Q200	PANEL,FRONT	1




Part	Part No.	Description	Qty
1	90111-A200110-0000	Screw	4
2	90406-0600-04	Washer	4
3	90731-A100110-0000	Rubber Washer	4
4	31115-A100110-0000	Battery Band	1
5	82011-A1A00110-Q2	Rear Fender	1
5	82531-A300100-0001	Rear Fender	1
6	31143-A100210-0000	cushion battery	5



Part	Part No.	Description	Qty
1	90111-A100110-0000	Screw	7
2	90406-0600-04	Washer	7
3	90731-A100110-0000	Rubber Washer	7
4	90305-0600-34	Nut	7
5	90001-0816-04	Bolt	4
6	82026-A1A0110-Q200	Left Main Footrest	1




Part	Part No.	Description	Qty
1	90111-A100110-0000	Screw	7
2	90406-0600-04	Washer	7
3	90731-A100110-0000	Rubber Washer	7
4	90305-0600-34	Nut	7
5	90001-0816-04	Bolt	4
6	82027-A1A0110-Q200	Right Main Footrest	1




Part	Part No.	Description	Qty
1-1	(USE) Assy	Headlight Seat	1
1-2	(USE) Assy	Headlight Seat	1
1-3	(USE) Assy	Connecting Clump, Headlight Bracket	2
1-4	(USE) Assy	Tapping Screw	4
1-5	(USE) Assy	Clip Reed, Headlight Lens	2
1-6	90723-A1A0110-0000	Bulb(Special)	2
1-7	33272-A1A0110-0000	Shade, Headlight	1
1-8	33270-A1A0210-0000	LIGHT ASSY.,HEAD	1

Part	Part No.	Description	Qty
1	54101-A100110-Q200	Handlebar Rubber Grip	2
2	54200-A1A0110-0000	Greaser Components	1
3	45040-A1A0110-0000	Front Brake Cable	2
4	16040-A100110-0000	Throttle Cable Assy	1
5	93310-A100110-Q200	Right Rear-view Mirror	1
6	54110-A100110-H500	Tube Assy, Handle	1
7	93210-A100110-Q200	Left Rear-view Mirror	1
8	47200-A1A0110-0000	Rear Disc Brake	1
8-1	(USE) Assy	Bolt, Handlebar	2
8-2	(USE) Assy	Handlebar Pipe Clip	1
8-3	(USE) Assy	LEVER COMP.,LEFT STEERING HANDLE	1
8-4	(USE) Assy	TUBE COMP.,DISC-BRAKE	1
8-5	(USE) Assy	CALIPER ASSY.,REAR BRAKE	1
8-6	47259-A1A0110-0000	Piece, Disc Brake Friction	1
8-7	47261-A1A0110-0000	Piece 2, Disc Brake Friction	1
9	35400-A1A0110-0000	Left Switch Components	1




Part	Part No.	Description	Qty
9	35400-A100110-0000	Left Switch Components	1
10	35160-A100110-0000	Switch assembly	
11	06030-A100210-0000	SHOE SET,REAR BRAKE	

Steering Assembly and Meter




Part	Part No.	Description	Qty
1	90007-0855B04	Bolt M8×1×55	4
2	37020-A100110-QB00	Meter Bracket	1
3	54811-A100110-G100	Handlebar Pipe Clip	2
4	54812-A100110-G100	Handlebar Pipe Clip Seat	1
5	37100-A1A0110-0000	Meter Assembly	1
6	35300-A100110-0000	Ignition Switch Assembly	1
7	80019-A100110-Q200	Fairing black	1
7	80019-A100110-Q100	Fairing red	1
8	54815-A100110-Q200	Steering Stem Clip	2
9	54822-A100110-0000	Steering Stem Dust Proof Washer	2
10	90305-0800-34	Nut M8	1
11	90683-A100110-0000	Bush	2
12	54065-A1A0110-0000	DISC,TENSION	1
13	54824-A100110-0000	Lock Stop Gasket	1
14	90004-0865-04	Bolt M8×65	1
15	90004-0860-04	Bolt M8×60	1

Steering Assembly and Meter




Part	Part No.	Description	Qty
16	54801-A100120-0000	Steering Stem Components	1
17	54400-A100110-0000	Steering Rod Component	2
17-1	(USE) Assy	Steering Rod Ball Pin Components	2
17-2	(USE) Assy	Steering Rod	2
17-3	(USE) Assy	Steering Rod Ball Pin Components	2
17-4	(USE) Assy	Washer 10	4
17-5	(USE) Assy	Spring Washer 10	4
17-6	(USE) Assy	Nut M10	4
18	90501-2525-04	Pin 2.5×25	5
19	90408-1000-34	Washer 10	1
20	90315-1000-34	Nut M10	1
21	90111-A200110-0000	Bolt M6×16	2
22	90103-A100110-0000	Bolt M5×12	2

Front Axle Assembly




Part	Part No.	Description	Qty
1	52308HA100110-0000	Right Knuckle	1
2	52400-A100110-QC00	Swing Arm Assembly	2
3	90310-1000-34	Nut M10	12
4	90001-1060-04	Bolt M10×60	8
5	52100-A100110-R500	Front Shock Absorber Red	2
5	52100-A100110-H100	Front Shock Absorber Black	2
6	90001-1040-04	Bolt M10×40	4
7	52301HA100110-0000	Left Knuckle	1
8	90403-1200-04	Spring Washer 12	4
9	90307-1200-74	Nut M12	4
10	90501-2525-04	Pin 2.5×25	4
11	52600-A100110-QC00	Left Below Swing Arm Assembly	1
12	52700-A100110-QC00	Right Below Swing Arm Assembly	1

Front Wheel Assembly




Part	Part No.	Description	Qty
1	44200-A1A0110-W300	Right Front Wheel Assy (for off road model)	1
2	45240-A100110-0000	Brake Drum Assembly	2
3	45301-A100110-0000	BRAKE ,FRONT RIGHT	1
3-1	45230-A100110-0000	Brake Shoe Components	2
3-2	(USE) Assy	returning spring	2
3-3	(USE) Assy	Oil Seal	1
3-4	(USE) Assy	camshaft	1
3-5	(USE) Assy	cap	1
3-6	(USE) Assy	Nut M6	1
3-7	(USE) Assy	Washer 6	1
3-8	(USE) Assy	Brake Arm	1
3-9	(USE) Assy	Brake Indicator	1
3-10	(USE) Assy	Bolt M6×35	1
4	45201-A100110-0000	BRAKE ,FRONT LEFT	1
4-1	45230-A100110-0000	Brake Shoe Components	2
4-2	(USE) Assy	returning spring	2

Front Wheel Assembly




Part	Part No.	Description	Qty
4-3	(USE) Assy	Oil Seal	1
4-4	(USE) Assy	camshaft	1
4-5	(USE) Assy	PANEL COMP.,FRONT LEFT BRAKE	1
4-6	(USE) Assy	Nut M6	1
4-7	(USE) Assy	Washer 6	1
4-8	(USE) Assy	Brake Arm	1
4-9	(USE) Assy	Brake Indicator	1
4-10	(USE) Assy	Bolt M6×35	1
5	45240-A100110-0000	Brake Drum Assembly	1
5-1	(USE) Assy	Bearing 6003	2
5-2	(USE) Assy	Bush	1
5-3	(USE) Assy	Brake Drum	1
5-4	(USE) Assy	Brake Drum Gum Cover	1
5-5	(USE) Assy	Oil Seal	1
5-6	(USE) Assy	Bush	1
6	44100-A1A0110-W300	Wheel Assembly (for off road r	1


Front Wheel Assembly



Part	Part No.	Description	Qty
6-1	44110-A1A0110-W300	Front Hub	1
6-2	44160-A1A0110-0000	Front Tire (for off road model)	1
6-3	(USE) Assy	Tire Valve	1
7	90408-1500-04	Washer 15	2
8	90305-EA00110-0000	Nut M8	8
9	90307-1400E74	Nut M14	2
10	90501-2532-04	Pin 2.5×32	2
11	44001-A100110-Q200	Hub Decorative Cover	2
12	45300-A100120-0000	BRAKE ASSY.,FRONT RIGHT	1
13	45200-A100120-0000	BRAKE ASSY.,FRONT LEFT	1




Part	Part No.	Description	Qty
1	90001-1055-04	Bolt M10×55	2
2	90310-1000-34	Nut M10	2
3	53200-A100110-R500	Rear Shock Absorber Red	1
3	53200-A100110-H100	Rear Shock Absorber Black	1
4	90001-0885-04	Bolt M8×85	2
5	53430-A100110-QC00	Rear Fork Welding Components	1
6	41040-A100110-QC00	Rear Suspension Protection Shelf	1
7	90001-0816-04	Bolt M8×16	2
8	90001-0612-04	Bolt M6×12	1
9	90684-A100110-QC00	Cable Clip	1
10	90311-1200A34	Nut	1
11		Rear Fork Rubber Washer	2
12		bearing	2
13	90724-A100110-0000	Liner Pipe	1
14	53018-A100110-0000	Rear Fork Shaft	1
15	90406-0600-04	Washer 6	1




Part	Part No.	Description	Qty
16	90103-0616-04	Bolt M6×16	1
17	53015-A100110-0000	Clip Chain	1
18	90001-0860-04	Bolt M8×60	1
19	14405-A100110-0000	tension pulley	1
20	14402-A100110-0000	spring	1
21	14432-A100110-0000	spacer	1
22	90311-0800-34	Nut	1
	53400-A100210-QC00		1


Part	Part No.	Description	Qty
1	41001-A100110-0000	Rear Axle	1
2	42014-A100110-0000	Sprocket Seat	1
3	42011-A100110-0000	Sprocket	1
4	90109-A100210-0000	Bolt M8×20	4
5	41100-A100110-0000	Rear Axle Housing Components	1
5-1	(USE) Assy	Rolling Seal Ring	2
5-2	(USE) Assy	circlip-A	1
5-3	(USE) Assy	Bearing	2
5-4	(USE) Assy	Oil Nozzle	2
5-5	(USE) Assy	Rear Axle Housing	1
5-6	(USE) Assy	Liner Pipe	1
5-7	(USE) Assy	Bush	1
6	37012-A100110-0000	Sensor Connecting Wire	1
7	43020-A100110-G100	Rear Disc Brake Pump Support	1
8	90001-0885-04	Bolt M8×85	1
9	90310-0800-34	Nut M8	1



Part	Part No.	Description	Qty
10	90102-0820-04	Bolt M8×16	4
11	90403-0800-04	Washer 8	4
12	37013-A100110-0000	Sensor Sense Organ	1
13	47003-A1A0110-0000	Rear Brake Disc	1
14	45030-A100110-0000	Rear Brake Disc Seat	1
15	41005-A100110-0000	Rear Axle Fixing Nut M28	1
16	41004-A100110-0000	Rear Axle Locknut M28	1
17	90710-A100110-0000	Chain	1




Part	Part No.	Description	Qty
1	42200-A1A0110-W300	Right Rear Wheel Assembly	1
2	42150-A1A0110-0000	Connecting Disc, Rear Wheel	2
3	42100-A1A0110-W300	Left Rear Wheel Assembly(Silver)	1
3-1	42110-A1A0110-W300	Rear Hub	2
3-2	42160-A1A0110-0000	Rear Tire	1
3-3	(USE) Assy	Tire Valve	2
4	90406-1700-04	Washer 17	2
5	90305-1000-34	Nut M10	8
6	90307-1600E74	Nut M16	2
7	90501-0335-04	Pin 3.0×35	2
8	44001-A100110-Q200	Hub Decorative Cover	2




Part	Part No.	Description	Qty
1	17100-A100110-0000	Air Filter	1
1-1	(USE) Assy	Nut M5	2
1-2	(USE) Assy	Case Cover, Air Filter	2
1-3	(USE) Assy	Bolt	1
1-4	(USE) Assy	Air inlet	1
1-5	(USE) Assy	Nut M10	1
1-6	(USE) Assy	Air Filter Case	1
1-7	(USE) Assy	Framework, Filter Element	1
1-8	(USE) Assy	Liner Pipe	1
1-9	17151-A100110-0000	Element, Air Filter	1
1-10	(USE) Assy	Trap Valve, Air Filter	1
1-11	(USE) Assy	Ноор	1

Exhaust System




Part	Part No.	Description	Qty
1	18150-A1A0110-QA00	Exhaust Pipe	1
2	18101-A1A0110-0000	Muffler Seal Washer	1
3	90740-a1a0110-0000	Muffler Hoop	1
4	90007-0825-05	Bolt M8×25	2
5	18160-A1A0110-QA00	Muffler Body	1
6	18011-A100110-0000	Muffler Cushion Washer	2
7	90683-A100510-0000	Bush	2
8	90406-0800-04	Washer 8	2
9	90007-0835-04	Bolt M8×35	2
10	18140-A1A0110-QA00	Hot-Proof Cover	1
11		Bolt M6×10	2
12		Washer 6	2
13		Washer 6	2
14		Exhaust Seal Washer	1
15	90318-0600-04	Nut M6	2

Part	Part No.	Description	Qty
1	16804-A100110-0000	Fuel Vapour Pipe	1
2	16730-A100110-Q200	Diack Flastic Fuel Falls Cover	1
3	16603-A100210-0000	Fuel Damping Strip	2
4	90001-0685-04	Bolt M6×85	1
5	90683-A100410-0000	Bush	3
6	90733-A100110-0000	I-Shaped Rubber Ring	2
7	90685-A100110-0000	Pipe Clip	1
8	90686-A100110-0000	oil pipe	1
9	90103-0616-04	Bolt M6×16	1
10	16750-A100110-0000	Fuel Cock Assy	1
11	90686-A100210-0000	oil pipe	1
12	16510-A100110-0000	Fuel Filter	1
13	90685-A100510-0000	Pipe Clip	5
14	90686-A100310-0000	oil pipe	1
15	16620-A100110-Q200	Fuel Tank	1




Part	Part No.	Description	Qty
16	90305-0600-34	Nut M6	1
17	16602-A100110-0000	Damping Washer, Fuel Tank	1
18	90001-0630-04	Bolt M6×30	1
19	16603-A100110-0000	Fuel Damping Strip	1

Electric Appliance System



Part	Part No.	Description	Qty
1	31230-A1A0110-0000	Main Wire	1
2	90001-0612-04	Bolt M6×12	2
3	39010-A100210-0000	Horn	1
4	30800-A100110-0000	Flasher	1
5	35060-A100110-0000	Trip Relay	1
6	30700-A100110-0000	CDI	1
7	30400-A100110-0000	Ignition Coil	1
8	90001-0616-04	Bolt M6×16	2
9	30500-A100110-0000	Start Relay	1
10	31110-A100110-0000	Battery-GS	1
11	30600-A100110-0000	Rectifier	1
12	90001-0620-04	Bolt M6×20	2
13		Insurance pipe	2
14	90727-A100110-Q800	Band 2×150	2
15	90727-A100210-Q800	Band 3×170	4
16	90727-A100310-Q800	Band	8



Part	Part No.	Description	Qty
1	58100-A1A0110-0000	Seat Assembly	1
2	58108-a1a0110-0000	Fixing Block, Seat Lock Hook	1
3	90504-0830-04	Pin	1
4	90303-0600-34	Nut	2
5	58107-A1A0110-0000	Spring, Seat Lock Hook	1
6	58104-A1A0110-0000	Seat Lock Hook	1
7	90501-0225-04	Split pin	1
8	90403-0600-04	Spring Washer	2