



Freq-uency(Hz)	**Vin**			**Vout**			$\Delta t(T_1 - T_2)$		
	220Ω	**2.2k Ω**	**4.7k Ω**	**220Ω**	**2.2k Ω**	**4.7kΩ**	**220Ω**	**2.2k Ω**	**4.7k Ω**
100	10.8V	11.0V	11.0V	154mV	1.46V	3.0V	-2.4ms	-2.4ms	-2.4ms
500	10.6V	10.4V	10.4V	736mV	5.68V	8.4V	-440µs	-320µs	-120µs
1000	10.0V	10.0V	9.9V	1.54V	8.2V	9.6V	-220µs	-80.6µs	-59µs
2000	6.88V	6.88V	10.1V	3.72V	9.2V	9.9V	-64.0µs	-8.0µs	0
4000	9.20V	9.20V	10.0V	2.56V	8.8V	9.6V	48.0µs	16.0µs	7.0µs


Vout/Vin 220	**Vout/Vin 2200**	**Vout/Vin 4700**	**ω_l**	**$\emptyset_0$ 220 Ω**	**$\emptyset_0$ 2200 Ω**	**$\emptyset_0$ 4700 Ω**
0.014259	0.132727	0.272727	2	-86.4	-62.4	-86.4
0.069434	0.546154	0.807692	2.69897	-79.2	-41.6	-21.6
0.154	0.82	0.969697	3	-79.2	-20.956	-21.24
0.540698	1.337209	0.980198	3.30103	-46.08	-4.16	0
0.278261	0.956522	0.96	3.60206	69.12	16.64	10.08









Figure 4
File Edit View Insert Tools Desktop Window Help
Magnitude, R = 220 Ω
|Vout/Vin|
Frequency (Hz)


Figure 5
File Edit View Insert Tools Desktop Window Help
Phase, R = 220 Ω
Phase (deg)
Frequency (Hz)


Figure 6
File Edit View Insert Tools Desktop Window Help
Magnitude, R = 2200 Ω
|Vout/Vin|
Frequency (Hz)


Figure 7
File Edit View Insert Tools Desktop Window Help
Phase, R = 2200 Ω
Phase (deg)
Frequency (Hz)


Figure 8
File Edit View Insert Tools Desktop Window Help
Magnitude, R = 4700 Ω
|Vout/Vin|
Frequency (Hz)


Figure 9
File Edit View Insert Tools Desktop Window Help
Phase, R = 4700 Ω
Phase (deg)
Frequency (Hz)