OptiPeople

1. Power on datalogger and MiFi router
2. Mount sensor on magnetic foot.
3. Point sensor onto moving object that should define uptime/unit counter

Login to OptiCloud platform

1. Digital port 1 (D1)
2. Digital port 2 (D2)
3. Ethernet port
4. Power

1. Create customer account
2. Create factory
3. Add device
4. Add machine
5. Configure machine
6. Configure shifts
7. Configure Waste

1 **2** **3** **4**

WIFI through MiFi
Default
SSID: Optilink Pass: Optipeople

Number next to WIFI icon indicates that a device is connected to the router.

Within 10min it connects to the database as well.

1. Digital port 1 (D1)
2. Digital port 2 (D2)
3. Ethernet port
4. Power