Communication in Electronic Systems

Lecture 5: Introduction to Communication Systems

Lecturer: Petar Popovski

TA: Junya Shiraishi, João H. Inacio de Souza

email: petarp@.es.aau.dk





Course Overview: Part 2. Communication and Networking

- MM5: Introduction to Communication Systems
- MM6: Simple Multiuser Systems
- MM7: Layered System Design. Network Topology and Architecture
- MM8: Networking and Transport Layers
- MM9: Introduction to Security
- MM10: Packets and Digital Modulation
- MM11: Communication waveforms
- MM12: Workshop on modulation and link operation



objectives

- learn the basic principles of communications and networks
- learn how to make mathematical models to analyze their performance and understand tradeoffs
- get insights into how some practical protocols operate




outline

- information, bits, and messages
- communication channels
- basic communication over ideal binary channel
- communication under random errors
- example of a RS232 link



the complex connectivity ecosystem




- many different types of connections
 - compare Bluetooth vs. satellite
 - data speed for streaming vs.data speed for texting
 - device capability
 - ...




communication system: what does it take for it to work?

system



- system model
 - a simplified version of reality
 - capable of capturing the important details





communication actors and messages

- the actors
 - introducing Alice, Bob and the friends (Carol, Dave, Eve, ...)
 - also from the opposite side: Zoya, Yoshi, Xia, ...
- what does it mean to communicate data from Alice to Bob?
 - Bob knows that Alice can be in one of two states (happy or sad),
 but does not know in which state Alice is now
 - the uncertainty of Bob can be resolved if Alice sends a message containing happy or sad



defining a bit of information

- in the previous example we did not speak about how much uncertain is Bob about the mood of Alice
 - in order to quantify this uncertainty, we can introduce a probability model for Alice's mood Prob(happy)=0.7 and Prob(sad)=0.3
 - the uncertainty for Bob is highest when

Prob(happy)=Prob(sad)=0.5

this brings us to a definition of a data bit

a single bit of information corresponds to learning about the state of a system that can have two equally probable states



representing messages (1)

- in general, Alice can be in M different states
 - each state corresponds to a different message
- we can represent each of these states using the symbols 0 and 1
 - one possible representation

state 0	state 1	state 2	state 3	
0	01	011	0111	

- but is not good, as we are striving to minimize the number of symbols that we should sent think of each symbol 0 or 1 having some (equal) cost
 - average number of symbols sent:

$$\frac{M+1}{2}$$



representing messages (2)

- we can do better
 - for simplicity, assume M=2^d, where d is an integer
 - we can represent the states through a d-bit binary number representation

state 0	state 1	state 2	state 3	
0000	0001	0010	0011	

here we need on average log₂(M) bits

representing messages by a certain set of symbols is called source coding

source coding (1)

- let us now assume that there are 8 different messages for Alice
- but they have different probability

Msg #	1	2	3	4	5	6	7	8
Prob	1/4	1/4	1/12	1/12	1/12	1/12	1/12	1/12
Coding	000	001	010	011	100	101	110	111

- probability that the first symbol is 0: 2/4 + 2/12 = 3/4
- probability that the first symbol is 1: 1/4
- the first symbol does not contain 1 bit of information, but less
- the average message length is 3 symbols



source coding (2)

Msg#	1	2	3	4	5	6	7	8
Prob	1/4	1/4	1/12	1/12	1/12	1/12	1/12	1/12
Code 1	00	01	1000	1001	1010	1011	11 <mark>0</mark> 0	1101
Code 2	00	01	1000	1001	1010	1011	110	111
Code 3	00	01	0110	0111	1000	1011	110	111

- an idea known since the Morse code:
- use less symbols for more probable messages
- average number of symbols for Code 2 and Code 3:

34 / 12 < 3


Yet, Code 2 is good, but Code 3 not.

exercises (5 min)

- calculate the average number of symbols per message
- why is Code 3 not so efficient?



communication channel



 communication channel is any physical or logical object that can represent more than one state



here we are interested in electronic communication

we can encode a message in chair arrangement

Petar Popovski, Communication in Electronic Systems, Fall 2024



limits on the communication channels


- the communication channel has physical limitations on the amount of bits it can carry
 - how many bits can we send by smoke signals
- two limits
 - speed by which symbols can be sent
 - limit on the shortest smoke signal duration



- the number of states that can be reliably differentiated when the symbols are received
 - smoke signals destroyed by wind


a model of a communication system

- introduced by C. E. Shannon in 1948
- there are also adversarial channels





a binary communication channel




- a black box that gets 0 or 1 as an input and provides 0 or 1 at the output
 - due to noise, sending 0 can result in receiving 1
- this model does not say how fast we can send 0 or 1, it is decided by other parameters of the whole system
 - the diagram depicts how the channel behaves in a single channel use

ideal binary channel

each T seconds Alice can decide to send or not to send a pulse to Bob

pulse=1 no pulse=0

Bob receives the pulse perfectly






how to communicate messages over this channel

- let us assume that Alice has 8 different 3-bit messages
- two fundamentally different situations
 - Alice periodically transmits 3-bit messages
 - Alice transmits a new 3-bit message only upon being triggered by an event

Alice sends data to Bob periodically


- here we assume that there has been a setup phase in the past through which Alice and Bob agreed several things:
 - common numbering of the slots used to send the bits
 - Alice sends messages to Bob with a period of S slots, where S>3
 - the first message is sent in slots 1,2,3
 - the second message is sent in slots S+1, S+2, S+3...
- with these agreements
 the only uncertainty for Bob is
 the content of the message bits



Petar Popovski, Communication in Electronic Systems, Fall 2024

Alice sends data to Bob upon an event trigger (1)

- this is more complicated, as now there is an uncertainty also on the moment when the message is sent, not only on the message content
- we can still use the trick with predefined periodic structure moments when the message starts
 - however, there is a problem..



Alice sends data to Bob upon an event trigger (2)

- we can solve this by expanding our set of possible messages!
 - the new set has 9 messages
 - messages 1-8 are the messages containing data
 - message 9 is "no data"
 - we can now encode the messages by prefixing each data message with 1


msg	1	2	3	4	5	6	7	8	9
code	1000	1001	1010	1011	1100	1101	1110	1111	0

Alice sends data to Bob upon an event trigger (3)

- the previous solution is not always good
 - let us assume that T=1 ms
 - thus, if we sent information bit in every slot, we get a data rate of 1 [kbps] kilobits per second
 - let us assume that the period of transmission is S=10
 - if 3 bits are sent each 10 ms, the data rate is 300 [bps] bits per second
- assume that on average one event occurs per second
 - a data rate of 3 [bps] should suffice!
- however, the events do not occur regularly and may occur in a burst
 - for example, 1000 events within an interval of 10 ms and then no event for the coming 1000 seconds



Alice sends data to Bob upon an event trigger (4)




- sending these events using transmissions with period 10 will take in total 10 seconds
 - this means that many of the events experience a large delay from the occurrence until being reported.
 - the highest delay is 10 seconds
 - what would be the expected/average delay?



Alice sends data to Bob upon an event trigger (5)

- an idea: start packet transmission at any time
 - use "1" to denote the packet start = a preamble; and send the 3 bits afterwards
 - this enables on-demand transmission
 - one packet takes 4 ms, all packets will be sent in 4 s
 - this decreases the maximal delay from 10 s to 4 s
 - what is the average delay?




making data packets with variable length (1)

- the transmission methods described previously can be used whenever the packet length is fixed in advance
- packet length can vary
 - different applications using the same communication system
 - variable length compression (described before)
- we present one possible way to deal with it
 - introduce bits in the packet to tell what is the length of the data part


general principle: any flexibility (starting time, packet length, etc.) is paid by extra signaling

making data packets with variable length (2)


- we need to fix the assumption of the minimal and the maximal packet length
 - this will fix the number of bits required to indicate the packet length
 - example:
 - minimal number of data bits is 1;
 maximal number of data bits is 16.
 - this will fix the number of packet length bits to 4




communications under random errors



random transmission errors






- in our model all bits are equal
- however, the effect of the errors are not equal for all bits in the packet
 - if the preamble bit is error, then the whole packet is lost
 - if Alice send nothing, but Bob erroneously receives 1, then he will erroneously decode a packet (likely 000)

counting the errors (1)


- Bit Error Rate (BER)
 - number of bits in error divided by the number of transmitted bits
 - key performance indicator for digital communication systems
 - affected by noise, interference, synchronization problems, channel fading



$$p_{\text{BER}} = \frac{3}{8} = 37.5\%$$

counting the errors (2) -Packet Error Ratio (PER)


- packet error: at least one bit is flipped after delivering at the receiver
- specific example (2 bits)



1 st bit	2 nd bit	Received packet	Probability
x_1	x_2	Success	5/8 *5/8
$\overline{x_1}$	x_2	Failure	3/8 *5/8
x_1	$\overline{x_2}$	Failure	5/8 *3/8
$\overline{x_1}$	$\overline{x_2}$	Failure	3/8 *3/8

counting the errors (3)

- Packet Error Ratio (PER)
 - ratio of packets not successfully received
 - the PER depends on the BER
 - if one bit is erroneous, the entire packet is erroneous too



$$p_{\text{PER}} = 1 - (1 - p_{\text{BER}})(1 - p_{\text{BER}}) \dots (1 - p_{\text{BER}})$$


= $1 - (1 - p_{\text{BER}})^N$


things we will do to deal with errors

- introduce a mechanism to detect errors
 - Bob will know if the received packet has errors or not
- introduce a feedback link
 - Bob can tell Alice if the packet has errors
- improve the reliability of the preamble
 - the packet is not missed if 1 is interpreted as 0
- enable Alice to retransmit a packet again
 - eventually the packet arrives at Bob

error detection (1)

- in order to detect errors, we must put additional redundancy to the packet
 - otherwise, any received packet is valid
 - we want errors to result in something that Bob recognizes as an invalid packet
- parity check
- the simplest way to detect one error
- a single redundant bit is required






error detection (2)

- parity check is a very weak error detection code
 - if errors occur in two different bit positions, then the packet is accepted as correct
- CRC (Cyclic Redundancy Check) codes
 - come in different bit lengths, e. g. 8, 16, 32
 - very high probability to detect errors
 - the packet is in error if bit errors occur in the CRC bits or the other bits in the packet
 - yet, it is not perfect
 - there is always a probability of undetected error
 - the value of the K check bits is a function of the other M bits
 - it must happen that 2^(M-K) bit combinations have exactly the same parity check

throughput

- def: the expected number of messages successfully delivered to the receiver per unit time
 - Symbol/s or bits/s
- preliminary
 - the sender transmits packet with *n* bit with *R* bps
 - use the PER derived in the previous slides




feedback link from Bob (1)

- assumption: data is only flowing from Alice to Bob
- Bob needs to be able to send
 - ACK (acknowledgement) if the packet is correct
 - NACK (not acknowledgement) otherwise
- how can the transmission by Bob be done?
 - a separate cable to carry the signals from Bob to Alice
 - transmission over the same cable, but not simultaneously
 - Time Division Duplex (TDD)
 - full-duplex transmission over the same cable with echo cancellation
- we will assume TDD operation
 - largely applicable in wireless communication

feedback link from Bob (2)


- in a TDD operation, Alice and Bob agree upon the following protocol
 - after each packet sent by Alice, Bob starts his transmission
- Bob needs to send 1 bit (ACK or NACK)
 - but this is highly unreliable, Alice is not even able to detect if there is an error
- we assume that the ACK/NACK packet sent by Bob has a length of 1 byte more reliable transmission (to be elaborated later)
 - still only 1 data bit for Alice (ACK or NACK)
 - Q: does the ACK/NACK bit carry one bit of information?

how should the TDD protocol work



feedback link from Bob (3)

- what can go wrong if Bob does not detect an error?
 - the obvious one erroneous data will be passed on to Bob
 - the less obvious one: the protocol can break down
 - for example, Bob incorrectly detects the packet length



Automatic Retransmission ReQuest (ARQ) protocol (1)

- upon receiving NACK, Alice resends the same packet
 - repeats this until receiving ACK for this packet
 - this is a stop-and-wait ARQ protocol
- note that NACK can be implicit
 - if no ACK arrives, Alice resends the same packet
 - this solves the situation when Bob erroneously detects the packet length




Automatic Retransmission reQuest (ARQ) protocol (2)

- a different challenge
 - error in ACK/NACK reception
- Example
 - Alice sends (1)(0101)(1)(011101)
 - Bob receives it correctly and sends ACK
 - error occurs and Alice receives NACK
 - Alice retransmits the packet (1)(0101)(1)(011101)
 - the problem: Bob thinks this is a new packet with data bits (011101), not a retransmission of the old one


ARQ with sequence number (1)

- the problem is solved by a sequence number
- using a single-bit sequence number
 - Alice assigns modulo-2 numbers to the data packets in its queue



- Bob does not send ACK/NACK, but sends a bit to say which sequence bit value he expects next
- Alice increases the sequence number modulo
 2 only when it is sure that Bob has received it

ARQ with sequence number (2)



ARQ performance

- lacktriangle probability of successful reception at the k-th attempt using the p_{PER}

$$p_k = p_{\text{PER}} \dots p_{\text{PER}} (1 - p_{\text{PER}}) = p_{\text{PER}}^{k-1} (1 - p_{\text{PER}})$$

average number of delay

$$\bar{T} = (T_{data} + T_{ack})p_1 + 2(T_{data} + T_{ack})p_2 + \dots = \sum_{k=0}^{\infty} k(T_{data} + T_{ack})p_k = \frac{T_{data} + T_{ack}}{1 - p_{\text{PFR}}}$$

two-way connection and piggybacking

- we now make Alice and Bob "equal"
 - Bob is also able to send data
 - Alice is able to send ACK/NACK (or ARQ sequence bits) to Bob
- packet format
 - the other seq bit is piggybacked on the data

preamble	data length	own seq bit	other seq bit	parity bit	data
----------	-------------	-------------	------------------	------------	------


few remarks

- the described packet is usually called **frame**, thus differentiating from a data packet
- it is common that a packet contains an integer number of bytes
 - then a frame preamble is certain sequence of bits rather than one bit
 - packet length is given in number of bytes
 - stronger error detection code is added
- we fix now the frame structure as follows

preamble	pkt length		other seq number	CRC error detection	data
1 byte	6 bits	1 bit	1 bit	1 byte	1-64 bytes


practical example - RS232

- invented in 1960
- based on serial communication, 1 to 1 communication
- made with modems in mind, but also used for other appliances like printer, memory devices, motors, and other serial connections
- Data Communication Equipment(DCE) and Data Terminal Equipment(DTE)



bit transmission and voltage levels

- binary communication
 - starts with a logical 0 for transmission
 - 3 to 15V for logical 0, -3 to -15 V for logical 1
 - sending an "A" (010000010) over RS232
- baud rate: the number of changes of the signal per second
- bud rate can be less, equal to or larger than the bit rate



data rate and distance


- asynchronous protocol no clock reference needed at sender and receiver
 - Baud Rate (=bit rate in RS232) between the two must be the same
 - available capacity (Baud Rate) depends on distance

Baud Rate	Cable length
2400 bps	900m
4800 bps	300m
9600 bps	150m
19200 bps	15m
115200 bps	5m

notable pins (Male)

- flow control
 - Request to send(7) / clear to send(8)
- data pins
 - Received data(2) / transmit data(3)
- ground (5)
 - Common ground to infer voltage level from

RS232 Pinout





summary and outlook

- model of a system is simplified, good-enough version
- information as an abstract entitythat can be mapped to different physical carriers
- we have shown how to gradually build a serial link over a binary channel
- control information vs. data
- elementary protocol with retransmissions
- example of an RS232 links

