#### **Communication Systems**

(Lecture 4, part 2 Communicationsystems)

#### Gert Frølund Pedersen Aalborg University



## Radio Propagation channel

Classical: Bandlimited + AWGN

E.g. the satellite channel

Wireless: Bandlimited + Multipath (+ AWGN)

E.g. mobile channel and small wireless devices etc.




#### Satellite channel

- Line-of-sight radiopropagation
  E.g. links from earth to satellite and return
- Linking a transmitter and a receiver with freespace propagation
- Satellite offers global coverage but low capacity.
- Mathematical simple



#### Wireless channel


- Non line-of-sight condition
- Received signal is the sum (or integration) made by the antenna of the signals arriving from different directions due to reflection, scatters and diffraction.
- Mathematical complex






## Satellite systems - frequency

- Frequency 1 GHz to 14 GHz
- Low attenuation due to rain (primary signal degrader)
- Insignificant sky background noise (noise from galactic, solar, terrestrial has lowest level between 1 and 10 GHz)
- Interference level a problem between 1-6 GHz =>use 10 to 14 GHz





#### Satellite system



Note that the time delay for a satellite in the geostationary orbit is very long.

Distance earth to satellite is approx 36.000 KM =>

Return delay is speed of light times distance:

$$2 \cdot d / c = 2 \cdot 36000 \cdot 10^3 / 3 \cdot 10^8 = 0.24s$$



#### Satellite system

• Dedicated satellite links with high antenna gain.

Expensive TX and RX earth stations but less expensive satellite (low power).

Broadcast satellite with less antenna gain =>
 Expensive TX earth station and satellites (high power) but less expensive RX earth stations.

 Larger cover area.

#### Satellite systems – Link budget

#### Consist of:

1. Resources for TX and RX.

Antennas, Tx-power and receiver sensitivity.

- 2. Propagation loss.
- 3. Noise sources.



## Satellite systems – Link budget

Example: Link budget for a satellite link at 10 GHz to a satellite in geostationary orbit transmitting with 10 Watt to a receiver with a sensitivity of -130 dBm.

1. Propagation loss=

$$\left[\frac{\lambda}{4\pi d}\right]^2 = \left[\frac{c/f}{4\pi d}\right]^2 = \left[\frac{3\cdot 10^8/10^{10}}{4\pi\cdot 36\cdot 10^6}\right]^2 \Box 4.4\cdot 10^{-21} \Box -203dB$$

2.  $P_{\text{received Isotropic}} = 40 \text{ dBm-}203\text{dB} = -163 \text{ dBm}$ 



#### Satellite system – Link budget Example

3. Minimum antenna gain needed -130dBm-(-163dBm)= 33dBi

Can a 0.5 meter disc do the job?

Max Gain for a disc-antenna of 0.5 meter in diameter?



#### Satellite system – Link budget Example

3. Minimum antenna gain needed -130dBm-(-163dBm)= 33dBi

Can a 0.5 meter disc do the job?

Max Gain for a disc-antenna of 0.5 meter in diameter? => use the maximum efficient area

$$A_{em} = \frac{\lambda^2}{4\pi} \cdot G_0 = \frac{(c/f)^2}{4\pi} \cdot G = \frac{0.03^2}{4\pi} \cdot 2000 = 0.1432m^2$$
$$A_{physical} = \pi \cdot r^2 = 0.196m^2$$



## Communication Systems channel (or mobile channel)

Due to the nature of the signal its characterisation need:

- 1. Practical measurements
- 2. Statistical analysis

To find e.g.

- 1. Mean signal strength
- 2. Signal variability



#### Cellular radio


Compared to fixed systems additional we need:

- 1. Radio resource management.
- 2. Mobility management.

Cell size?


Rural: 5 to 30 Km

Indoor microcell: 25 to 100m





## Cellular radio – physical cell






## Cellular concept

#### Frequency reuse:

One high power and high elevated BS =>

- 1. Low capacity
- 2. Large area with interference
- Larger reuse factor => less interference but low capacity.

Frequency is expensive! e.g. 5G auction!



- Transmission range of cell No.1
- Border of a cell
- Cluster of cells using different frequencies




#### Cellular concept

#### Cell splitting:

Create flexibility – first coverage then capacity *and only* where needed.

Changes to the network are only made locally (in the particular cell where more capacity is needed)






## Wireless propagation

The antenna is moving and the static description used for the 2-ray model can not be used directly.

The signal is timevarying!






Wireless propagation - fading

The sum of all incoming waves are integrated by the antenna => the signal strength changes easy a 100 times for a movement of half a wavelength!

The signal is also space varying!



Gert Frølund Pedersen gfp@es.aau.dk

Communication Systems 5. semester.


## Doppler shift

The frequency changes slightly when moving with high speed towards the transmitter (frequency increases), or in general in any direction as:

$$\upsilon = \frac{v}{\lambda} \cos(\alpha)$$

Ex.: GSM1800, V=250 km/h

$$\upsilon = \frac{v}{\lambda}\cos(\alpha) = \frac{250*1000/3600}{c/1.8 \cdot 10^9} \le \pm 417Hz$$






#### Delay spread (or echoes)

Due to the different path lengths for the different multipaths some waves arrive later than others which results in time spreading of the signal!


If the echoes arrive so late that the next symbol is started on the earlier paths => troubles!

Equalizer is needed!





## Delay spread (or echoes)






#### Timing of mobile stations

Due to the different distance between the mobiles and the basestation, each mobile need to know the distance in time to the basestation. Otherwise interference is introduced!

Ex:  $R=30Km \Rightarrow time difference = R/c=100\mu s$ 

In GSM each timeslot is 577µs and max cell radius 36 km.





#### Mobile system need to take care of


- Radio resource management
- Mobility management
- Fading and fast time varying channel
- Frequency changes due to velocity Doppler
- Echoes due to multipaths
- Timing due to different distances to the base




#### Mobile system example

# GSM











## GSM system – RF spec.

Frequency: GSM400, 850, 900, 1800, 1900 (MHz)

GSM900:

Uplink 890 – 925 MHz


Downlink 935 – 960MHz


Frequency spacing 200kHz =>

124 Ch (374 for 1800)

MS Tx power, class 5, 2Watt peak power (1 Watt for 1800).

Receiver sensitivity -102 dBm







How does GSM take care of the 6 listed issues?, viz:

- 1. Radio resource management.
- 2. Mobility management.
- 3. Fading and fast time varying channel.
- 4. Frequency changes due to velocity Doppler.
- 5. Echoes due to multipaths.
- 6. Timing due to different distances to the base.



#### Radio Resource management

- 1. Each MS measure signalstrength and signal quality from neighbour cells (using the broadcast channel). This information is reported to the BS (each approx. 0.5s).
- 2. Each MS can regulate the transmit power in steps of 2 dB in a 20 dB range and are instructed by the BS.
- 3. Each MS can Tx and Rx on all channels and more frequency bands (e.g. GSM900, GSM1900) controlled by the BS




#### Mobility management

- 1. Each MS listen to the broadcast channel on the BS with the best propagation condition and decodes the ID and the area code of the BS. If the MS finds that it enters a new area it request an update in the HLR (Home Location Register) or VLR (Visitor Location Register).
- 2. Each MS can report when it is turned "off" and "on".



#### Fading – and fast time varying channel

1. Each burst (of 577µs) contains a centre part for estimating the mobile channel. Knowing the channel is like a filter and can be "unconvolved" by signal processing.




2. Using frequency hopping (change frequency channel each burst). Helps slow moving users out of a fade.



#### Fading – and fast time varying channel

3. Using interleaving and channel coding.



4. Using diversity – utilise that there are more paths between BS and MS – e.g. in time or more antennas (antenna diversity).



#### Doppler and Delayspread.


1. Max Doppler is in the range of 0.5 to 1 kHz and the frequency channel spacing is 200 KHz. A small guard frequency band can take care of this.

2. Late Echoes are in the range of 16μs in mountain areas and the symboltime is 3.7μs. Therefore channel equalisation is needed and the information is known from the channel estimation made in each received burst.



Timing – due to different distances to the base.

Each MS need absolute timing (to know the timeslot no).



1 Hyperframe = 2 715 648 TDMA-Frames = 3h 28min 53s 760ms


Gert Frølund Pedersen gfp@es.aau.dk

Communication Systems 5. semester.



## GSM system — Timing/Synchronisation

Each MS need synchronisation which is obtained by receiving and decoding a synchronisation burst from the broadcast channel. The MS is instructed to set its "Timeadvancement" when addressing the BS (up to 64bit time)



#### GSM – ca

| log. Channel | Mobile Station | Base Stat | ion   |
|--------------|----------------|-----------|---|
| PCH          | +              |           | Paging of the mobile station                        |
| RACH         |                |           | Channel request                                     |
| AGCH         | +              |           | Channel assignment                                  |
| SDCCH        |                |           | Answer to the paging from the network               |
|              |                |           | This is already transmitted on the assigned channel |
| SDCCH        | +              |           | Authentication request from the network             |
| SDCCH        |                |           | Authentication response from the mobile station     |
| SDCCH        | +              |           | Request to transmit in the ciphered mode            |
| SDCCH        |                |           | Acknowledgment of the ciphered mode                 |
| SDCCH        | -              |           | Setup message for the incoming call                 |
| SDCCH        |                |           | Confirmation  |
| SDCCH        | ·              |           | Assignment of a traffic channel                     |
| FACCH        |                |           | Acknowledgment of the traffic channel               |
| FACCH        |                | <b></b> → | Alerting (now the caller gets the ringing sound)    |
| FACCH        |                |           | Connect message when the mobile is off-hook         |
| FACCH        | -              |           | Acceptance of the connect message                   |
| TCH          | ·              |           | Exchange of user data (speech)                      |



#### GSM – Where is decision taken

| MS      | BTS | BSC           | (G)MSC    | VLR       | HLR | Action   |
|---------|-----|---------------|-----------|-----------|-----|--|
|         | · — | $\rightarrow$ |           |           |     | Channel Request  |
|         | -   | _             |           |           |     | Channel activation command                                       |
|         | -   | $\rightarrow$ |           |           |     | Channel activation acknowledge                                   |
| +       |     |               |           |           |     | Channel Assignment   |
|         | ·   | <b>→</b> —    | <b>→</b>  |           |     | Location Update Request  |
| -       |     | _ ←           |           |           |     | Authentication Request   |
|         | · — | <b>→</b> —    | <b></b> → |           |     | Authentication Response  |
|         |     |               | ←         | <b></b> → |     | Comparison of the Authentication para<br>meters                  |
| <b></b> |     | - ←           | _         |           |     | Assignment of the new area and the tem<br>porary identity (TMSI) |
|         | ·   | → —           |           |           |     | Acknowledgment of the new area and th temporary identity (TMSI)  |
|         |     |               | <b>←</b>  |           |     | Entry of the new area and identity into the VLR and HLR          |
| -       |     | _             |           |           |     | Channel Release  |

