





U.S. Department of Transportation

Federal Aviation Administration

Aviation Maintenance Technician Handbook—Airframe

2023

U.S. Department of Transportation

Federal Aviation Administration

Flight Standards Service

Preface

The Aviation Maintenance Technician Handbook—Airframe (FAA-H-8083-31B) is one of a series of three handbooks for persons preparing for certification as an airframe or powerplant mechanic. This handbook provides basic information on principles, fundamentals, and technical procedures in the subject matter areas relating to the airframe rating. It is designed to aid students enrolled in a formal course of instruction, as well as the individual who is studying on their own. Since the knowledge requirements for the airframe and powerplant ratings closely parallel each other in some subject areas, the chapters which discuss fire protection systems and electrical systems contain some material which is also duplicated in the Aviation Maintenance Technician Handbook—Powerplant (FAA-H-8083-32B).

This handbook contains information on airframe construction features, assembly and rigging, fabric covering, structural repairs, and aircraft welding. The handbook also contains an explanation of the units that make up the various airframe systems. Because there are so many different types of aircraft in use today, it is reasonable to expect that differences exist in airframe components and systems. To avoid undue repetition, the practice of using representative systems and units is carried out throughout the handbook. Subject matter treatment is from a generalized point of view and should be supplemented by reference to manufacturers' manuals or other textbooks if more detail is desired. This handbook is not intended to replace, substitute for, or supersede official regulations or manufacturers' instructions. Occasionally the word "must" or similar language is used where the desired action is deemed critical. The use of such language is not intended to add to, interpret, or relieve a duty imposed by Title 14 of the Code of Federal Regulations (14 CFR).

The subject of Human Factors is contained in the Aviation Maintenance Technician Handbook—General (FAA-H-8083-30) (as revised).

This handbook is available for download, in PDF format, from www.faa.gov.

This handbook is published by the United States Department of Transportation, Federal Aviation Administration, Airman Testing Standards Branch, AFS-630, P.O. Box 25082, Oklahoma City, OK 73125.

Comments regarding this publication should be emailed to AFS630comments@faa.gov.

Acknowledgments

The Aviation Maintenance Technician Handbook—Airframe (FAA-H-8083-31B) was produced by the Federal Aviation Administration (FAA). The FAA wishes to acknowledge the following contributors:

Mr. Chris Brady (www.b737.org.uk) for images used throughout this handbook

Captain Karl Eiríksson for image used in Chapter 1

Cessna Aircraft Company for image used in Chapter 1

Mr. Andy Dawson (www.mossie.org) for images used throughout Chapter 1

Mr. Bill Shemley for image used in Chapter 1

Mr. Bruce R. Swanson for image used in Chapter 1

Mr. Burkhard Domke (www.b-domke.de) for images used throughout Chapter 1 and 2

Mr. Chris Wonnacott (www.fromtheflightdeck.com) for image used in Chapter 1

Mr. Christian Tremblay (www.zodiac640.com) for image used in Chapter 1

Mr. John Bailey (www.knots2u.com) for image used in Chapter 1

Mr. Rich Guerra (www.rguerra.com) for image used in Chapter 1

Mr. Ronald Lane for image used in Chapter 1

Mr. Tom Allensworth (www.avsim.com) for image used in Chapter 1

Navion Pilots Association's Tech Note 001 (www.navionpilots.org) for image used in Chapter 1

U.S. Coast Guard for image used in Chapter 1

Mr. Tony Bingelis and the Experimental Aircraft Association (EAA) for images used throughout Chapter 2

Mr. Benoit Viellefon (www.johnjohn.co.uk/compare-tigermothflights/html/tigermoth_bio_aozh.html) for image used in Chapter 3

Mr. Paul Harding of Safari Seaplanes-Bahamas (www.safariseaplanes.com) for image used in Chapter 3

Polyfiber/Consolidated Aircraft Coatings for images used throughout Chapter 3

Stewart Systems for images used throughout Chapter 3

Superflite for images used throughout Chapter 3

Cherry Aerospace (www.cherryaerospace.com) for images used in Chapters 4 and 7

Raytheon Aircraft (Structural Inspection and Repair Manual) for information used in Chapter 4

Mr. Scott Allen of Kalamazoo Industries, Inc. (www.kalamazooind.com) for image used in Chapter 4

Miller Electric Mfg. Co. (www.millerwelds.com) for images used in Chapter 5

Mr. Aaron Novak, contributing engineer, for charts used in Chapter 5

Mr. Bob Hall (www.pro-fusiononline.com) for image used in Chapter 5

Mr. Kent White of TM Technologies, Inc. for image used in Chapter 5

Safety Supplies Canada (www.safetysuppliescanada.com) for image used in Chapter 5

Smith Equipment (www.smithequipment.com) for images used in Chapter 5

Alcoa (www.alcoa.com) for images used in Chapter 7

Mr. Chuck Scott (www.itwif.com) for images used throughout Chapter 8

Mr. John Lagerlof of Paasche Airbrush Co. (paascheairbrush.com) for image used in Chapter 8

Mr. Philip Love of Turbine Products, LLC (www.turbineproducts.com) for image used in Chapter 8

Consolidated Aircraft Coatings for image used in Chapter 8

Tianjin Yonglida Material Testing Machine Co., Ltd for image used in Chapter 8

Mr. Jim Irwin of Aircraft Spruce & Specialty Co. (www.aircraftspruce.com) for images used in Chapters 9, 10, 11, 13, 14, 15

Mr. Kevan Hashemi for image used in Chapter 9

Mr. Michael Leasure, Aviation Multimedia Library (www2.tech.purdue.edu/at/courses/aeml) for images used in Chapters 9, 13, 14

Aircraft Owners and Pilots Association (AOPA) (www.aopa.org) for image used in Chapter 10

Cobra Systems Inc. (www.cobrasys.com) for image used in Chapter 10

www.free-online-private-pilot-ground-school.com for image used in Chapters 10, 16

DAC International (www.dacint.com) for image used in Chapter 10

Dawson Aircraft Inc. (www.aircraftpartsandsalvage.com) for images used throughout Chapter 10

Mr. Kent Clingaman for image used in Chapter 10

TECNAM (www.tecnam.com) for image used in Chapter 10

TGH Aviation-FAA Instrument Repair Station (www.tghaviation.com) for image used in Chapter 10

The Vintage Aviator Ltd. (www.thevintageaviator.co.nz) for image used in Chapter 10

ACK Technologies Inc. (www.ackavionics.com) for image used in Chapter 11

ADS-B Technologies, LLC (www.ads-b.com) for images used in Chapter 11

Aviation Glossary (www.aviationglossary.com) for image used in Chapter 11

AT&T Archives and History Center for image used in Chapter 11

Electronics International Inc. (www.buy-ei.com) for image used in Chapter 11

Excelitas Technologies (www.excelitas.com) for image used in Chapter 11

Freestate Electronics, Inc. (www.fse-inc.com) for image used in Chapter 11

AirTrafficAtlanta.com for image used in Chapter 11

Western Historic Radio Museum, Virginia City, Nevada (www.radioblvd.com) for image used in Chapter 11

Avidyne Corporation (www.avidyne.com) for image used in Chapter 11

Kintronic Laboratories (www.kintronic.com) for image used in Chapter 11

Mr. Dan Wolfe (www.flyboysalvage.com) for image used in Chapter 11

Mr. Ken Shuck (www.cessna150.net) for image used in Chapter 11

Mr. Paul Tocknell (www.askacfi.com) for image used in Chapter 11

Mr. Stephen McGreevy (www.auroralchorus.com) for image used in Chapter 11

Mr. Todd Bennett (www.bennettavionics.com) for image used in Chapter 11

National Oceanic and Atmospheric Administration, U.S. Department of Commerce for image used in Chapter 11

RAMI (www.rami.com) for image used in Chapter 11

Rockwell Collins (www.rockwellcollins.com) for image used in Chapter 11, Figure 11-73

Sarasota Avionics International (www.sarasotaavionics.com) for images used in Chapter 11

Southeast Aerospace, Inc. (www.seaerospace.com) for image used in Chapter 11

Sporty's Pilot Shop (www.sportys.com) for image used in Chapter 11

Watts Antenna Company (www.wattsantenna.com) for image used in Chapter 11

Wings and Wheels (www.wingsandwheels.com) for image used in Chapter 11

Aeropin, Inc. (www.aeropin.com) for image used in Chapter 13

Airplane Mart Publishing (www.airplanemart.com) for image used in Chapter 13

Alberth Aviation (www.alberthaviation.com) for image used in Chapter 13

AVweb (www.avweb.com) for image used in Chapter 13

Belle Aire Aviation, Inc. (www.belleaireaviation.com) for image used in Chapter 13

Cold War Air Museum (www.coldwarairmuseum.org) for image used in Chapter 13

Comanche Gear (www.comanchegear.com) for image used in Chapter 13

CSOBeech (www.csobeech.com) for image used in Chapter 13

Desser Tire & Rubber Co., Inc. (www.desser.com) for image used in Chapter 13

DG Flugzeugbau GmbH (www.dg-flugzeugbau.de) for image used in Chapter 13

Expedition Exchange Inc. (www.expeditionexchange.com) for image used in Chapter 13

Fiddlers Green (www.fiddlersgreen.net) for image used in Chapter 13

Hitchcock Aviation (hitchcockaviation.com) for image used in Chapter 13

KUNZ GmbH aircraft equipment (www.kunz-aircraft.com) for images used in Chapter 13

Little Flyers (www.littleflyers.com) for images used in Chapter 13

Maple Leaf Aviation Ltd. (www.aircraftspeedmods.ca) for image used in Chapter 13

Mr. Budd Davisson (Airbum.com) for image used in Chapter 13

Mr. C. Jeff Dyrek (www.yellowairplane.com) for images used in Chapter 13

Mr. Jason Schappert (www.m0a.com) for image used in Chapter 13

Mr. John Baker (www.hangar9aeroworks.com) for image used in Chapter 13

Mr. Mike Schantz (www.trailer411.com) for image used in Chapter 13

Mr. Robert Hughes (www.escapadebuild.co.uk) for image used in Chapter 13

Mr. Ron Blachut for image used in Chapter 13

Owls Head Transportation Museum (www.owlshead.org) for image used in Chapter 13

PPI Aerospace (www.ppiaerospace.com) for image used in Chapter 13

Protective Packaging Corp. (www.protectivepackaging.net, 1-800-945-2247) for image used in Chapter 13

Ravenware Industries, LLC (www.ravenware.com) for image used in Chapter 13

Renold (www.renold.com) for image used in Chapter 13

Rotor F/X, LLC (www.rotorfx.com) for image used in Chapter 13

SkyGeek (www.skygeek.com) for image used in Chapter 13

Taigh Ramey (www.twinbeech.com) for image used in Chapter 13

Texas Air Salvage (www.texasairsalvage.com) for image used in Chapter 13

The Bogert Group (www.bogert-av.com) for image used in Chapter 13

W. B. Graham, Welded Tube Pros LLC (www.thefabricator.com) for image used in Chapter 13

Zinko Hydraulic Jack (www.zinkojack.com) for image used in Chapter 13

Aviation Institute of Maintenance (www.aimschool.com) for image used in Chapter 14

Aviation Laboratories (www.avlab.com) for image used in Chapter 14

AVSIM (www.avsim.com) for image used in Chapter 14

Eggenfellner (www.eggenfellneraircraft.com) for image used in Chapter 14

FlightSim.Com, Inc. (www.flightsim.com) for image used in Chapter 14

Fluid Components International LLC (www.fluidcomponents.com) for image used in Chapter 14

Fuel Quality Services, Inc. (www.fqsinc.com) for image used in Chapter 14

Hammonds Fuel Additives, Inc. (www.biobor.com) for image used in Chapter 14

Jeppesen (www.jeppesen.com) for image used in Chapter 14

MGL Avionics (www.mglavionics.com) for image used in Chapter 14

Mid-Atlantic Air Museum (www.maam.org) for image used in Chapter 14

MISCO Refractometer (www.misco.com) for image used in Chapter 14

Mr. Gary Brossett via the Aircraft Engine Historical Society (www.enginehistory.org) for image used in Chapter 14

Mr. Jeff McCombs (www.heyeng.com) for image used in Chapter 14

NASA for image used in Chapter 14

On-Track Aviation Limited (www.ontrackaviation.com) for image used in Chapter 14

Stewart Systems for image used in Chapter 14

Prist Aerospace Products (www.pristaerospace.com) for image used in Chapter 14

The Sundowners, Inc. (www.sdpleecounty.org) for image used in Chapter 14

Velcon Filters, LLC (www.velcon.com) for image used in Chapter 14

Aerox Aviation Oxygen Systems, Inc. (www.aerox.com) for image used in Chapter 16

Biggles Software (www.biggles-software.com) for image used in Chapter 16

C&D Associates, Inc. (www.aircraftheater.com) for image used in Chapter 16

Cobham (Carleton Technologies Inc.) (www.cobham.com) for image used in Chapter 16

Cool Africa (www.coolafrica.co.za) for image used in Chapter 16

Cumulus Soaring, Inc. (www.cumulus-soaring.com) for image used in Chapter 16

Essex Cryogenics of Missouri, Inc. (www.essexind.com) for image used in Chapter 16

Flightline AC, Inc. (www.flightlineac.com) for image used in Chapter 16

IDQ Holdings (www.idqusa.com) for image used in Chapter 16

Manchester Tank & Equipment (www.mantank.com) for image used in Chapter 16

Mountain High E&S Co. (www.MHoxygen.com) for images used throughout Chapter 16

Mr. Bill Sherwood (www.billzilla.org) for image used in Chapter 16

Mr. Boris Comazzi (www.flightgear.ch) for image used in Chapter 16

Mr. Chris Rudge (www.warbirdsite.com) for image used in Chapter 16

Mr. Richard Pfiffner (www.craggyaero.com) for image used in Chapter 16

Mr. Stephen Sweet (www.stephensweet.com) for image used in Chapter 16

Precise Flight, Inc. (www.preciseflight.com) for image used in Chapter 16

SPX Service Solutions (www.spx.com) for image used in Chapter 16

SuperFlash Compressed Gas Equipment (www.oxyfuelsafety.com)

Mr. Tim Mara (www.wingsandwheels.com) for images used in Chapter 16

Mr. Bill Abbott for image used in Chapter 17

Additional appreciation is extended to Dr. Ronald Sterkenburg, Purdue University; Mr. Bryan Rahm, Dr. Thomas K. Eismain, Purdue University; Mr. George McNeill, Mr. Thomas Forenz, Mr. Peng Wang, and the National Oceanic and Atmospheric Administration (NOAA) for their technical support and input.

Table of Contents

Chapter 1		Main Rotor System	1-42
Aircraft Structures		Rigid Rotor System	1-42
A Brief History of Aircraft Structures	1-1	Semirigid Rotor System	1-42
General	1-4	Fully Articulated Rotor System	
Major Structural Stresses	1-5	Antitorque System	
Fixed-Wing Aircraft	1-7	Controls	
Fuselage	1-7		
Truss-Type	1-7	Chapter 2	
Monocoque Type	1-7	Aerodynamics, Aircraft Assembly, & Rigging	
Semimonocoque Type		Introduction	
Reinforced Shell Type		Basic Aerodynamics	2-1
Pressurization		The Atmosphere	
Wings		Pressure	
Wing Configurations		Density	2-2
Wing Structure		Humidity	
Wing Spars1		Aerodynamics & the Laws of Physics	2-2
Wing Ribs1		Velocity & Acceleration	
Wing Skin 1-		Newton's Laws of Motion	
Nacelles1		Bernoulli's Principle & Subsonic Flow	2-3
Empennage1		Airfoil	2-3
Flight Control Surfaces1		Shape of the Airfoil	2-4
Primary Flight Control Surfaces1		Angle of Incidence	2-5
Ailerons 1-		Angle of Attack (AOA)	2-5
Elevator1		Boundary Layer	2-6
Rudder1		Thrust & Drag	2-6
Dual Purpose Flight Control Surfaces1		Center of Gravity (CG)	2-8
Secondary or Auxiliary Control Surfaces 1-		The Axes of an Aircraft	2-8
Flaps1		Stability & Control	2-8
Slats1		Static Stability	2-8
		Dynamic Stability	2-10
Spoilers & Speed Brakes 1-		Longitudinal Stability	2-10
Tabs1-		Directional Stability	
Other Wing Features 1-		Lateral Stability	
Landing Gear1		Dutch Roll	
Tail Wheel Gear Configuration1		Primary Flight Controls	2-10
Tricycle Gear Configuration1		Trim Controls	
Maintaining the Aircraft 1-		Auxiliary Lift Devices	.2-11
Location Numbering Systems 1-		Lift Augmenting	
Access & Inspection Panels1		Lift Decreasing	
Helicopter Structures		Winglets	
Airframe1		Canard Wings	
Fuselage1		Wing Fences	
Landing Gear or Skids		Control Systems for Large Aircraft	
Powerplant & Transmission1		Mechanical Control	
Turbine Engines1		Hydromechanical Control	
Transmission1-	-41	Fly-By-Wire Control	2-14

High-Speed Aerodynamics	2-14	Reciprocating Engine	2-33
Rotary-Wing Aircraft Assembly & Rigging	2-15	Turbine Engine	2-34
Configurations of Rotary-Wing Aircraft	2-16	Transmission System	2-34
Autogyro		Main Rotor Transmission	
Single Rotor Helicopter		Clutch	2-34
Dual Rotor Helicopter		Centrifugal Clutch	
Types of Rotor Systems		Belt Drive Clutch	2-35
Fully Articulated Rotor	2-17	Freewheeling Unit	2-35
Semirigid Rotor		Airplane Assembly & Rigging	2-36
Rigid Rotor		Rebalancing of Control Surfaces	2-36
Forces Acting on the Helicopter		Static Balance	2-36
Torque Compensation		Dynamic Balance	2-36
Gyroscopic Forces		Rebalancing Procedures	
Helicopter Flight Conditions		Rebalancing Methods	
Hovering Flight		Aircraft Rigging	
Translating Tendency or Drift	2-21	Rigging Specifications	
Ground Effect	2-21	Type Certificate Data Sheet	
Coriolis Effect (Law of Conservation of		Maintenance Manual	
Angular Momentum)	2-21	Structural Repair Manual (SRM)	
Vertical Flight	2-22	Manufacturer's Service Information	
Forward Flight	2-22	Airplane Assembly	
Translational Lift	2-23	Aileron Installation	
Effective Translational Lift (ETL)	2-23	Flap Installation	
Dissymmetry of Lift	2-23		
Autorotation	2-26	Empennage Installation	
Rotorcraft Controls	2-27	Cohla Systems	
Swash Plate Assembly	2-27	Cable Systems	
Collective Pitch Control		Cable Inspection	
Throttle Control	2-28	Cable System Installation	
Governor/Correlator	2-28	Push Rods (Control Rods)	2-44
Cyclic Pitch Control	2-28	Torque Tubes	2-46
Antitorque Pedals		Cable Drums	2-46
Stabilizer Systems	2-29	Rigging Checks	2-46
Bell Stabilizer Bar System	2-29	Structural Alignment	2-47
Offset Flapping Hinge	2-29	Cable Tension	2-50
Stability Augmentation Systems (SAS)		Control Surface Travel	2-50
Helicopter Vibration	2-30	Checking & Safetying the System	2-52
Extreme Low Frequency Vibration	2-30	Biplane Assembly & Rigging	
Low Frequency Vibration	2-30	Aircraft Inspection	
Medium Frequency Vibration	2-30	Purpose of Inspection Programs	
High Frequency Vibration		Performing an Airframe Conformity &	
Rotor Blade Tracking		Airworthiness Inspection	2-58
Flag & Pole		Required Inspections	2-59
Electronic Blade Tracker		Preflight	
Tail Rotor Tracking		Periodic Maintenance Inspections	
Marking Method		Altimeter & Static System Inspections in	
Electronic Method		Accordance with 14 CFR Part 91, Section	
		91.411	2-61
Rotor Blade Preservation & Storage		Air Traffic Control (ATC) Transponder	
Helicopter Power Systems		Inspections	2-61
Powerplant	∠-33	Emergency Locator Transmitter (ELT)	

Operational & Maintenance Practices in		Seams	3-14
Accordance with Advisory Circular (AC)		Fabric Cement	3-17
91-44	2-61	Fabric Heat Shrinking	3-17
Annual & 100-Hour Inspections	2-62	Attaching Fabric to the Wing Ribs	
Preparation	2-62	Rib Lacing	
Other Aircraft Inspection & Maintenance		Rings, Grommets, & Gussets	
Programs	2-64	Finishing Tapes	
Continuous Airworthiness Maintenance		Coating the Fabric	
Program (CAMP)	2-65	Polyester Fabric Repairs	
Title 14 CFR part 125, section 125.247,		Applicable Instructions	
Inspection Programs & Maintenance	2-65	Repair Considerations	
Piston-Engine & Turbine-Powered		Cotton-Covered Aircraft	
Helicopter Inspections	2-66	Fiberglass Coverings	
Light Sport Aircraft & Aircraft Certificated	0.00	r iborgidos covernigo	0 2-1
as Experimental	2-66	Chapter 4	
Observation 0		Aircraft Metal Structural Repair	
Chapter 3		Aircraft Metal Structural Repair	4-1
Aircraft Fabric Covering	2.4	Stresses in Structural Members	
General History		Tension	
Fabric Terms		Compression	
Legal Aspects of Fabric Covering		Shear	
Approved Materials		Bearing	
Fabric		Torsion	
Other Fabric Covering Materials		Bending	
Anti-Chafe Tape		_	
Reinforcing Tape		Tools for Sheet Metal Construction & Repair	
Rib Bracing		Layout Tools	
Surface Tape		Scales	
Rib Lacing Cord		Combination Square	
Sewing Thread		Dividers	
Special Fabric Fasteners	3-5	Rivet Spacers	
Grommets	3-6	Marking Tools	
Inspection Rings	3-6	Pens	
Primer	3-6	Scribes	
Fabric Cement	3-6	Punches	
Fabric Sealer	3-6	Prick Punch	
Fillers	3-6	Center Punch	4-5
Topcoats		Automatic Center Punch	4-5
Available Covering Processes		Transfer Punch	4-6
Determining Fabric Condition—Repair or		Drive Punch	4-6
Recover?	3-8	Pin Punch	4-6
Fabric Strength	3-8	Chassis Punch	4-6
How Fabric Breaking Strength is Determined	d 3-9	Awl	4-6
Fabric Testing Devices		Hole Duplicator	
General Fabric Covering Process	3-10	Cutting Tools	
Blanket Method vs. Envelope Method		Circular-Cutting Saws	
Preparation for Fabric Covering Work		Kett Saw	
Removal of Old Fabric Coverings		Pneumatic Circular-Cutting Saw	
Preparation of the Airframe Before Covering	3-12	Reciprocating Saw	
Attaching Polyester Fabric to the Airframe		Cut-off Wheel	
		Gut-Oil Wileel	4-0

Nibblers	4-8	Drop Hammer	4-24
Shop Tools	4-9	Hydropress Forming	4-25
Squaring Shear	4-9	Spin Forming	
Throatless Shear	4-9	Forming with an English Wheel	
Scroll Shears	4-10	Piccolo Former	
Rotary Punch Press	4-10	Shrinking & Stretching Tools	
Band Saw		Shrinking Tools	4-26
Disc Sander		Stretching Tools	4-26
Belt Sander		Manual Foot-Operated Sheet Metal Shrin	ıker 4-26
Notcher		Hand-Operated Shrinker & Stretcher	4-27
Wet or Dry Grinder		Dollies & Stakes	4-27
Grinding Wheels		Hardwood Form Blocks	4-27
_		V-Blocks	4-27
Hand Cutting Tools Straight Snips		Shrinking Blocks	
		Sandbags	
Aviation Snips		Sheet Metal Hammers & Mallets	
Files		Sheet Metal Holding Devices	
Die Grinder		Clamps & Vises	
Burring Tool		C-Clamps	
Hole Drilling		Vises	
Portable Power Drills		Reusable Sheet Metal Fasteners	
Pneumatic Drill Motors		Cleco Fasteners	
Right Angle & 45° Drill Motors		Hex Nut & Wing Nut Temporary Sheet	4-23
Two Hole	4-15	Fasteners	4-20
Drill Press		Aluminum Alloys	
Drill Extensions & Adapters		Structural Fasteners	
Extension Drill Bits	4-16	Solid Shank Rivet	
Straight Extension	4-16	Description	
Angle Adapters	4-16	Installation of Rivets	
Snake Attachment	4-16	Rivet Installation Tools	
Types of Drill Bits	4-16	Riveting Procedure	
Step Drill Bits	4-16	Countersunk Rivets	
Cobalt Alloy Drill Bits	4-17	Evaluating the Rivet	
Twist Drill Bits	4-17	Removal of Rivets	
Drill Bit Sizes	4-17		
Drill Lubrication	4-17	Replacing Rivets	4-45
Reamers	4-17	National Advisory Committee for	
Drill Stops	4-17	Aeronautics (NACA) Method of Double Flush Riveting	4-45
Drill Bushings & Guides	4-17	Special Purpose Fasteners	
Drill Bushing Holder Types	4-19	Blind Rivets	
Drilling Large Holes	4-20		4-47
Chip Chasers	4-20	Pin Fastening Systems (High-Shear Fasteners)	4_40
Forming Tools	4-20	Lockbolt Fastening Systems	
Bar Folding Machine	4-21	Blind Bolts	
Cornice Brake			
Box & Pan Brake (Finger Brake)		Rivet Nut	
Press Brake		Blind Fasteners (Nonstructural)	
Slip Roll Former		Forming Process	
Rotary Machine		Forming Operations & Terms	
Stretch Forming	4-24	Stretching	4-5/

Shrinking	4-57	Repairability of Sheet Metal Structure	
Bumping	4-58	Structural Support During Repair	
Crimping	4-58	Assessment of Damage	
Folding Sheet Metal		Inspection of Riveted Joints	
Layout & Forming		Inspection for Corrosion	
Terminology		Damage Removal	
Layout or Flat Pattern Development		Repair Material Selection	
Making Straight Line Bends		Repair Parts Layout	4-92
Bending a U-Channel	4-61	Rivet Selection	4-92
Using a J-Chart to Calculate Total		Rivet Spacing & Edge Distance	4-92
Developed Width		Corrosion Treatment	4-92
Using a Sheet Metal Brake to Fold Metal		Approval of Repair	4-92
Step 1: Adjustment of Bend Radius		Repair of Stressed Skin Structure	4-93
Step 2: Adjusting Clamping Pressure	4-69	Patches	4-93
Step 3: Adjusting the Nose Gap	4-70	Typical Repairs for Aircraft Structures	4-97
Folding a Box	4-71	Floats	
Relief Hole Location	4-72	Corrugated Skin Repair	4-97
Layout Method	4-72	Replacement of a Panel	
Open & Closed Bends	4-72	Outside the Member	
Open End Bend (Less Than 90°)	4-73	Inside the Member	
Closed End Bend (More Than 90°)	4-73	Edges of the Panel	
Hand Forming	4-73	Repair of Lightening Holes	
Straight Line Bends	4-73	Repairs to a Pressurized Area	
Formed or Extruded Angles		•	
Flanged Angles		Stringer Repair	
Shrinking		Former or Bulkhead Repair	
Stretching		Longeron Repair	
Curved Flanged Parts		Spar Repair	
Forming by Bumping		Rib & Web Repair	
Joggling		Leading Edge Repair	
Lightening Holes		Trailing Edge Repair	
Working Stainless Steel		Specialized Repairs	
Working Inconel® Alloys 625 & 718		Inspection Openings	4-108
Working Magnesium			
Working Titanium		Chapter 5	
Description of Titanium		Aircraft Welding	
Basic Principles of Sheet Metal Repair		Introduction	
Maintaining Original Strength		Types of Welding	
Shear Strength & Bearing Strength		Gas Welding	
Maintaining Original Contour		Electric Arc Welding	
Keeping Weight to a Minimum		Shielded Metal Arc Welding (SMAW)	
Flutter & Vibration Precautions		Gas Metal Arc Welding (GMAW)	
Inspection of Damage		Gas Tungsten Arc Welding (GTAW)	
Types of Damage & Defects		Electric Resistance Welding	
Classification of Damage		Spot Welding	
Negligible Damage		Seam Welding	
Damage Repairable by Patching		Plasma Arc Welding (PAW)	
Damage Repairable by Insertion		Plasma Arc Cutting	
Damage Necessitating Replacement of		Gas Welding & Cutting Equipment	
Parts	4-90	Welding Gases	5-6

Acetylene	5-6	TIG Welding 4130 Steel Tubing	5-22
Argon	5-6	TIG Welding Stainless Steel	5-22
Helium	5-6	TIG Welding Aluminum	5-23
Hydrogen	5-7	TIG Welding Magnesium	5-23
Oxygen		TIG Welding Titanium	5-23
Pressure Regulators		Arc Welding Procedures, Techniques, &	
Welding Hose		Welding Safety Equipment	5-24
Check Valves & Flashback Arrestors		Multiple Pass Welding	5-26
		Techniques of Position Welding	5-26
Torches		Flat Position Welding	5-27
Equal Pressure Torch		Bead Weld	5-27
Injector Torch		Groove Weld	5-27
Cutting Torch	5-8	Fillet Weld	
Torch Tips	5-8	Lap Joint Weld	
Welding Eyewear	5-8	•	
Torch Lighters	5-9	Vertical Position Welding	
Filler Rod	5-9	Overhead Position Welding	
Equipment Setup	5-10	Expansion & Contraction of Metals	
Gas Cylinders		Welded Joints Using Oxy-Acetylene Torch	
Regulators		Butt Joints	
Hoses		Tee Joints	
		Edge Joints	
Connecting Torch		Corner Joints	
Select the Tip Size		Lap Joints	5-30
Adjusting the Regulator Working Pressure		Repair of Steel Tubing Aircraft Structure by	
Lighting & Adjusting the Torch		Welding	
Different Flames		Dents at a Cluster Weld	
Neutral Flame	5-12	Dents Between Clusters	5-31
Carburizing Flame	5-12	Tube Splicing with Inside Sleeve	
Oxidizing Flame	5-12	Reinforcement	5-32
Soft or Harsh Flames	5-13	Tube Splicing with Outer Split Sleeve	
Handling of the Torch		Reinforcement	
Oxy-acetylene Cutting		Landing Gear Repairs	
Shutting Down the Gas Welding Equipment		Engine Mount Repairs	
Gas Welding Procedures & Techniques		Rosette Welding	5-35
Correct Forming of a Weld			
Characteristics of a Good Weld		Chapter 6	
Oxy-Acetylene Welding of Ferrous Metals		Aircraft Wood & Structural Repair	
Steel (Including SAE 4130)		Introduction	
Chrome Molybdenum		Wood Aircraft Construction & Repairs	
Stainless Steel		Inspection of Wood Structures	
Oxy-Acetylene Welding of Nonferrous Metals		External & Internal Inspection	
		Glued Joint Inspection	6-3
Aluminum Welding		Wood Condition	6-4
Magnesium Welding		Repair of Wood Aircraft Structures	6-6
Brazing & Soldering		Materials	
Torch Brazing of Aluminum		Suitable Wood	6-7
Torch Brazing of Aluminum		Defects Permitted	
Soldering		Defects Not Permitted	6-7
Aluminum Soldering		Glues (Adhesives)	
Silver Soldering		Definition of Terms Used in the Glue	
Gas Tungsten Arc Welding (TIG Welding)	5-21	Process	6-10
		***************************************	-

Preparation of Wood for Gluing	6-10	Paste Adhesives	7-10
Preparing Glues for Use	6-11	Foaming Adhesives	7-10
Applying the Glue/Adhesive	6-11	Description of Sandwich Structures	7-10
Pressure on the Joint	6-11	Properties	
Testing Glued Joints	6-12	Facing Materials	7-10
Repair of Wood Aircraft Components		Core Materials	
Wing Rib Repairs		Honeycomb	7-11
Wing Spar Repairs		Foam	7-11
Bolt & Bushing Holes		Balsa Wood	7-12
Plywood Skin Repairs		Manufacturing & In-Service Damage	7-12
Fabric Patch		Manufacturing Defects	7-12
Splayed Patch		Fiber Breakage	7-13
Surface Patch		Matrix Imperfections	7-13
Plug Patch		Delamination & Debonds	7-13
The Back of the Skin is Accessible for	0 20	Combinations of Damages	7-13
Repair	6-23	Flawed Fastener Holes	
The Back of the Skin Is Not Accessible for		In-Service Defects	7-13
Repair	6-24	Corrosion	
·		Nondestructive Inspection (NDI) of Composites	7-15
Chapter 7		Visual Inspection	
Advanced Composite Materials		Audible Sonic Testing (Coin Tapping)	7-15
Description of Composite Structures	7-1	Automated Tap Test	7-15
Introduction	7-1	Ultrasonic Inspection	7-16
Laminated Structures	7-1	Through Transmission Ultrasonic Inspection	7-16
Major Components of a Laminate	7-1	Pulse Echo Ultrasonic Inspection	7-16
Strength Characteristics	7-1	Ultrasonic Bond Tester Inspection	7-17
Fiber Orientation	7-1	Phased Array Inspection	7-17
Warp Clock	7-2	Radiography	
Fiber Forms	7-2	Thermography	
Roving	7-2	Neutron Radiography	7-18
Unidirectional (Tape)	7-3	Moisture Detector	7-18
Bidirectional (Fabric)	7-3	Composite Repairs	7-19
Nonwoven (Knitted or Stitched)	7-3	Layup Materials	
Types of Fiber	7-5	Hand Tools	7-19
Fiberglass		Air Tools	7-19
Kevlar		Caul Plate	7-19
Carbon/Graphite	7-5	Support Tooling & Molds	7-19
Boron		Vacuum Bag Materials	7-19
Ceramic Fibers		Release Agents	7-19
Lightning Protection Fibers		Bleeder Ply	7-19
Matrix Materials		Peel Ply	7-21
Thermosetting Resins		Layup Tapes	7-21
Thermoplastic Resins		Perforated Release Film	
Curing Stages of Resins		Solid Release Film	
Pre-Impregnated Products (Prepregs)		Breather Material	
Dry Fiber Material		Vacuum Bag	
Thixotropic Agents		Vacuum Equipment	
Adhesives		Vacuum Compaction Table	
Film Adhesives		Heat Sources	

Oven 1-22	Fasteners Used with Composite Laminates	7-45
Autoclave 7-22	Corrosion Precautions	7-45
Heat Bonder & Heat Lamps7-23	Fastener Materials	7-45
Heat Press Forming7-24	Fastener System for Sandwich Honeycomb	
Thermocouples7-24	Structures (SPS Technologies Comp Tite)7	7-45
Types of Layups7-25	Hi-Lok® & Huck-Spin® Lockbolt Fasteners7	7-45
Wet Layups 7-25	Eddie-Bolt® Fasteners7	7-46
Prepreg	Cherry's E-Z Buck® (CSR90433) Hollow	
Co-curing	Rivet7	7-47
Secondary Bonding7-27	Blind Fasteners	7-47
Co-bonding	Blind Bolts	7-48
Layup Process (Typical Laminated Wet Layup)7-28	Fiberlite7	7-49
Layup Techniques	Screws & Nutplates in Composite Structures 7	7-49
Bleedout Technique	Machining Processes & Equipment	7-49
No Bleedout	Drilling	
Ply Orientation Warp Clock	Countersinking	7-51
Mixing Resins	Cutting Processes & Precautions	
Saturation Techniques	Cutting Equipment	
Fabric Impregnation With a Brush or	Repair Safety	
Squeegee7-30	Eye Protection7	
Fabric Impregnation Using a Vacuum Bag 7-30	Respiratory Protection	
Vacuum Bagging Techniques7-31	Skin Protection	
Single Side Vacuum Bagging7-31	Fire Protection	
Envelope Bagging7-31	Transparent Plastics	
Alternate Pressure Application	Optical Considerations	
Shrink Tape	Identification	
C-Clamps	Storage & Handling	
	Forming Procedures & Techniques	
Shotbags & Weights	Heating7	
Curing of Composite Materials	Forms	
Room Temperature Curing	Forming Methods	
Elevated Temperature Curing	Sawing & Drilling	
Composite Honeycomb Sandwich Repairs 7-33	Sawing & Dilling	
Damage Classification	Drilling	
Sandwich Structures	Cementing	
Minor Core Damage (Filler & Potting Repairs)	Application of Cement	
Damage Requiring Core Replacement &	• •	
Repair to One or Both Faceplates	Repairs	
Solid Laminates	Cleaning 7	
Bonded Flush Patch Repairs	Windshield Installation	
Trailing Edge & Transition Area Patch	Installation Procedures	
Repairs7-39	installation riocedures	-51
Resin Injection Repairs	Chapter 8	
Composite Patch Bonded to Aluminum	Aircraft Painting & Finishing	
Structure7-40	Introduction	8-1
Fiberglass Molded Mat Repairs7-40	Finishing Materials	
Radome Repairs	Acetone	
•	Alcohol	
External Bonded Patch Repairs7-41 Bolted Repairs7-43	Benzene	
DUILEU REDAIIS		

Methyl Ethyl Ketone (MEK)	8-1	Pinholes	
Methylene Chloride	8-2	Sags & Runs	
Toluene	8-2	Orange Peel	
Turpentine		Fisheyes	
Mineral Spirits	8-2	Sanding Scratches	
Naphtha	8-2	Wrinkling	8-14
Linseed Oil	8-2	Spray Dust	
Thinners	8-2	Painting Trim & Identification Marks	
Varnish	8-2	Masking & Applying the Trim	
Primers	8-2	Masking Materials	8-15
Wash Primers	8-3	Masking for the Trim	8-15
Red Iron Oxide	8-3	Display of Nationality & Registration Marks .	8-16
Gray Enamel Undercoat		Display of Marks	8-16
Urethane	8-3	Location & Placement of Marks	8-17
Epoxy	8-3	Size Requirements for Different Aircraft	8-17
Zinc Chromate	8-3	Decals	
Identification of Paints	8-3	Paper Decals	
Dope	8-3	Metal Decals with Cellophane Backing	
Synthetic Enamel		Metal Decals With Paper Backing	
Lacquers	8-4	Metal Decals with No Adhesive	
Polyurethane		Vinyl Film Decals	
Urethane Coating		Removal of Decals	
Acrylic Urethanes		Paint System Compatibility	
Methods of Applying Finish		Paint Touchup	
Dipping		Identification of Paint Finishes	
Brushing	8-4	Surface Preparation for Touchup	
Spraying	8-4	Stripping the Finish	
Finishing Equipment	8-5	Chemical Stripping	
Paint Booth	8-5		
Air Supply	8-5	Plastic Media Blasting (PMB)	
Spray Equipment	8-5	New Stripping Methods	
Air Compressors	8-5	Safety in the Paint Shop	
Large Coating Containers	8-6	Storage of Finishing Materials	
System Air Filters	8-6	Protective Equipment for Personnel	8-21
Miscellaneous Painting Tools & Equipment	8-6		
Spray Guns		Chapter 9	
Fresh Air Breathing Systems		Aircraft Electrical System	0.4
Viscosity Measuring Cup		Introduction	
Mixing Equipment		Ohm's Law	
Preparation		Current	9-2
Surfaces		Conventional Current Theory & Electron	0.3
Primer & Paint		Theory	
		Electromotive Force (Voltage)	
Spray Gun Operation		Resistance	
Adjusting the Spray Pattern		Factors Affecting Resistance	
Applying the Finish		Electromagnetic Generation of Power	
Common Spray Gun Problems		Alternating Current (AC) Introduction	
Sequence for Painting a Single-Engine or Light Twin Airplane		Definitions	
Common Paint Troubles		Opposition to Current Flow of AC	
Poor Adhesion		Resistance	
Blushing	8-13	Inductive Reactance	9-11
1.00.4.30.00.04	()- [+)		

Capacitive Reactance	9-13	Alternator Circuit	9-47
Impedance	9-14	External Power Circuit	9-48
Parallel AC Circuits	9-18	Starter Circuit	9-49
Power in AC Circuits	9-19	Avionics Power Circuit	9-49
True Power	9-19	Landing Gear Circuit	9-50
Apparent Power		AC Supply	
Power Factor		Light Multiengine Aircraft	
Aircraft Batteries		Paralleling Alternators or Generators	
Types of Batteries	9-20	Power Distribution on Multiengine Aircraft	
Lead-Acid Batteries		Large Multiengine Aircraft	
NiCd Batteries	9-21	AC Power Systems	
Capacity	9-22	Wiring Installation	
Aircraft Battery Ratings by Specification		Wiring Diagrams	
Storing & Servicing Facilities		Block Diagrams	
Battery Freezing		Pictorial Diagrams	
Temperature Correction		Schematic Diagrams	
Battery Charging		Wire Types	
Battery Maintenance		Conductor	
Battery & Charger Characteristics		Plating	
		Insulation	
Aircraft Battery Inspection		Wire Shielding	
Ventilation Systems		Wire Substitutions	
Installation Practices		Areas Designated as Severe Wind &	5-07
Troubleshooting		Moisture Problem (SWAMP)	9-68
DC Generators & Controls		Wire Size Selection	
Generators		Current Carrying Capacity	
Construction Features of DC Generators		Allowable Voltage Drop	
Types of DC Generators		Wire Identification	
Generator Ratings		Placement of Identification Markings	
DC Generator Maintenance		Types of Wire Markings	
Generator Controls		Wire Installation & Routing	
Theory of Generator Control		Open Wiring	
Functions of Generator Control Systems	9-33	Wire Groups & Bundles & Routing	
Generator Controls for High-Output		Conduit	
Generators	9-34	Wire Shielding	
Generator Controls for Low-Output	0.24	Lacing & Tying Wire Bundles	
Generators		Tying	
DC Alternators & Controls		Wire Termination	
DC Alternators		Stripping Wire	
Alternator Voltage Regulators		Terminal Strips	
Solid-State Regulators		·	
Power Systems		Terminal Lugs	
AC Alternators		Emergency Splicing Repairs	
Alternator Drive		Junction Boxes	
AC Alternators Control Systems		AN/MS Connectors	
Aircraft Electrical SystemsSmall Single-Engine Aircraft		Coaxial Cable	
Battery Circuit		Wire Inspection	
Generator Circuit		Electrical System Components	
Contract Charles	0 47	Switches Type of Switches	
		TYPE OF SWILLIES	७-७/

loggie & Rocker Switches 9-97	AC Synchro Systems	. 10-26
Rotary Switches 9-98	Remote Indicating Fuel & Oil Pressure	
Precision (Micro) Switches9-98	Gauges	. 10-27
Relays & Solenoids (Electromagnetic	Mechanical Movement Indicators	. 10-28
Switches)9-98	Tachometers	
Solenoids 9-98	Mechanical Tachometers	. 10-28
Relays 9-98	Electric Tachometers	. 10-29
Current Limiting Devices 9-98	Synchroscope	. 10-31
Fuses 9-99	Accelerometers	. 10-31
Circuit Breakers 9-99	Stall Warning & Angle of Attack (AOA)	
Aircraft Lighting Systems9-100	Indicators	
Exterior Lights 9-100	Temperature Measuring Instruments	
Position Lights9-100	Non-Electric Temperature Indicators	
Anticollision Lights 9-101	Electrical Temperature Measuring Indication	
Landing & Taxi Lights 9-101	Electrical Resistance Thermometer	. 10-36
Wing Inspection Lights	Ratiometer Electrical Resistance	
Interior Lights	Thermometers	
Maintenance & Inspection of Lighting	Thermocouple Temperature Indicators	. 10-37
Systems 9-103	Turbine Gas Temperature Indicating	
3,5133	Systems	
Chapter 10	Total Air Temperature Measurement	
Aircraft Systems	Direction Indicating Instruments	
Introduction	Magnetic Compass	
Classifying Instruments 10-2	Vertical Magnetic Compass	
Flight Instruments	Remote Indicating Compass	. 10-43
Engine Instruments 10-3	Remote Indicating Slaved Gyro Compass	40.44
Navigation Instruments 10-3	(Flux Gate Compass)	
Pressure Measuring Instruments 10-3	Solid State Magnetometers	
Types of Pressure 10-6	Sources of Power for Gyroscopic Instruments.	
Pressure Instruments 10-7	Vacuum Systems	
Engine Oil Pressure 10-7	Venturi Tube Systems	
Manifold Pressure 10-8	Engine-Driven Vacuum Pump	
Engine Pressure Ratio (EPR) 10-9	Typical Pump-Driven System	. 10-47
Fuel Pressure10-9	Twin-Engine Aircraft Vacuum System	40.40
Hydraulic Pressure10-10	Operation	. 10-49
Vacuum Pressure	Pressure-Driven Gyroscopic Instrument	40.50
Pressure Switches	Systems	. 10-50
Pitot-Static Systems10-11	Electrically-Driven Gyroscopic Instrument Systems	10 51
Pitot Tubes & Static Vents10-11	Principles of Gyroscopic Instruments	
Air Data Computers (ADC) & Digital Air	Mechanical Gyros	
Data Computers (DADC)	Solid State Gyros & Related Systems	
Pitot-Static Pressure-Sensing Flight	Ring Laser Gyros (RLG)	
Instruments	Microelectromechanical-Based Attitude &	. 10 02
Altimeters & Altitude	Directional Systems	10_53
Vertical Speed Indicator	Other Attitude & Directional Systems	
Airspeed Indicators	-	
Remote Sensing & Indication	Common Gyroscopic Instruments Vacuum-Driven Attitude Gyros	
Synchro-Type Remote-Indicating	Electric Attitude Indicators	
Instruments	Gyroscopic Direction Indicator or Directional	. 10-00
DC Selsyn Systems	Gyro (DG)	. 10-56
	, , , -,	

Turn Coordinators 10-56	Analog Versus Digital Electronics	11-3
Turn-and-Slip Indicator10-57	Noise	11-3
Autopilot Systems10-58	Analog Electronics	11-4
Basis for Autopilot Operation 10-59	Electron Control Valves	11-4
Autopilot Components	Basic Analog Circuits	11-17
Sensing Elements	Digital Electronics	11-24
Computer & Amplifier 10-60	Radio Communication	11-29
Output Elements	Radio Waves	11-29
Command Elements	Types of Radio Waves	
Feedback or Follow-up Element 10-61	Loading Information onto a Radio Wave	
Autopilot Functions	Amplitude Modulation (AM)	
Yaw Dampening 10-63	Frequency Modulation (FM)	
Automatic Flight Control System (AFCS) 10-63	Single Sideband (SSB)	
Flight Director Systems	Radio Transmitters & Receivers	
Electronic Instruments	Transmitters	
Electronic Attitude Director Indicator (EADI) 10-64	Receivers	
Electronic Horizontal Situation Indicators	Transceivers	
(EHSI)	Antennas	
Electronic Flight Information Systems		
Electronic Flight Instrument System (EFIS) 10-68	Length	
Electronic Centralized Aircraft Monitor (ECAM)	Polarization, Directivity, & Field Pattern	
	Types	
Engine Indicating & Crew Alerting System (EICAS)10-70	Transmission Lines	
Flight Management System (FMS)	Radio Navigation	
Warnings & Cautions	VOR Navigation System	
Annunciator Panels	Automatic Direction Finder (ADF)	
Aural Warning Systems	Radio Magnetic Indicator (RMI)	
Clocks	Instrument Landing Systems (ILS)	
Instrument Housings & Handling	Localizer	
Instrument Installations & Markings	Glideslope	
Instrument Panels	Compass Locators	
Instrument Mounting	Marker Beacons	
Instrument Power Requirements	Distance Measuring Equipment (DME)	
Instrument Range Markings	Area Navigation (RNAV)	
Maintenance of Instruments & Instrument	Radar Beacon Transponder	
Systems	Transponder Tests & Inspections	
Altimeter Tests	Altitude Encoders	
Pitot-Static System Maintenance & Tests 10-81	Collision Avoidance Systems	11-55
Tachometer Maintenance10-81	Traffic Collision Avoidance Systems (TCAS)11-56
Magnetic Compass Maintenance &	ADS-B	11-57
Compensation 10-82	Radio Altimeter	11-59
Vacuum System Maintenance 10-83	Weather Radar	.11-60
Autopilot System Maintenance 10-83	Emergency Locator Transmitter (ELT)	.11-63
LCD Display Screens 10-84	Testing Considerations for 406 MHz ELTs 406 MHz Testing	
Chapter 11	Long Range Aid to Navigation System	01
Communication & Navigation	(LORAN)	11-67
Introduction11-1	Global Positioning System (GPS)	
Avionics in Aviation Maintenance11-1	Wide Area Augmentation System (WAAS)	
History of Avionics11-1	3 (
Fundamentals of Electronics11-3		

Inertial Navigation System (INS)/Inertial		Filter Differential Pressure Indicators	12-14
Reference System (IRS)	11-69	Pumps	12-14
Aircraft Communication Addressing &		Hand Pumps	12-15
Reporting System (ACARS)	11-70	Power-Driven Pumps	12-15
Installation of Communication & Navigation	44 =0	Classification of Pumps	12-16
Equipment	11-70	Constant-Displacement Pumps	12-16
Approval of New Avionics Equipment	44.70	Gear-Type Power Pump	12-16
Installations		Gerotor Pump	
Considerations		Piston Pump	
Cooling & Moisture		Vane Pump	
Vibration Isolation		Variable-Displacement Pump	
Reducing Radio Interference			
Shielding		Valves	
Isolation		Flow Control Valves	
Bonding		Pressure Control Valves	
Static Discharge Wicks		Shuttle Valves	
Installation of Aircraft Antenna Systems		Accumulators	
Transmission Lines		Types of Accumulators	
Maintenance Procedures	11-75	Heat Exchangers	
Ohamtau 10		Actuators	
Chapter 12		Linear Actuators	12-32
Hydraulic & Pneumatic Power Systems	40.4	Rotary Actuators	12-33
Aircraft Hydraulic Systems		Hydraulic Motor	12-33
Hydraulic Fluid		Ram Air Turbine (RAT)	
Viscosity		Power Transfer Unit (PTU)	
Chemical Stability		Hydraulic Motor-Driven Generator (HMDG).	
Flash Point		Seals	
Fire Point		V-Ring Packings	
Types of Hydraulic Fluids		U-Ring	
Mineral-Based Fluids		O-Rings	
Polyalphaolefin-Based Fluids		Backup Rings	
Phosphate Ester-Based Fluid		Gaskets	
Intermixing of Fluids			
Compatibility with Aircraft Materials		Seal Materials	
Hydraulic Fluid Contamination		O-Ring Installation	
Contamination Check		Wipers	
Contamination Control		Large Aircraft Hydraulic Systems	12-37
Hydraulic System Flushing		Boeing 737 Next Generation Hydraulic	
Health & Handling		System	
Basic Hydraulic Systems		Reservoirs	
Open Center Hydraulic Systems	12-5	Pumps	12-39
Closed-Center Hydraulic Systems		Filter Units	12-39
Hydraulic Power Systems	12-7	Power Transfer Unit (PTU)	12-39
Evolution of Hydraulic Systems	12-7	Landing Gear Transfer Unit	12-41
Hydraulic Power Pack System	12-7	Standby Hydraulic System	
Hydraulic System Components	12-7	Indications	
Reservoirs	12-7	Boeing 777 Hydraulic System	
Filters	12-12	Left & Right System Description	
Micron-Type Filters	12-13	Center Hydraulic System	
Maintenance of Filters	12-13		
Filter Bypass Valve	12-14	Aircraft Pneumatic Systems High-Pressure Systems	
· ·			12-4/

Pneumatic System Components 12-47	Inboard Wheel Half	. 13-34
Emergency Backup Systems 12-49	Outboard Wheel Half	. 13-35
Medium-Pressure Systems 12-51	Wheel Inspection	. 13-36
Low-Pressure Systems 12-51	On Aircraft Inspection	. 13-36
Pneumatic Power System Maintenance 12-51	Proper Installation	. 13-36
	Off Aircraft Wheel Inspection	
Chapter 13	Aircraft Brakes	
Aircraft Landing Gear Systems	Types & Construction of Aircraft Brakes	
Landing Gear Types13-1	Single Disc Brakes	
Landing Gear Arrangement	Dual-Disc Brakes	
Tail Wheel-Type Landing Gear 13-2	Multiple-Disc Brakes	
Tandem Landing Gear13-2	Segmented Rotor-Disc Brakes	
Tricycle-Type Landing Gear 13-3	Carbon Brakes	
Fixed & Retractable Landing Gear 13-4		
Shock Absorbing & Non-Shock Absorbing	Expander Tube Brakes	
Landing Gear13-6	Brake Actuating Systems	
Leaf-Type Spring Gear13-6	Independent Master Cylinders	
Rigid13-7	Boosted Brakes	
Bungee Cord13-7	Power Brakes	
Shock Struts	Emergency Brake Systems	
Shock Strut Operation	Parking Brake	
Servicing Shock Struts	Brake Deboosters	
Bleeding Shock Struts	Anti-Skid	
Landing Gear Alignment, Support, & Retraction 13-14	System Operation	. 13-60
Alignment	Wheel Speed Sensors	. 13-61
Support	Control Units	. 13-61
Small Aircraft Retraction Systems	Anti-Skid Control Valves	. 13-63
Large Aircraft Retraction Systems 13-20	Touchdown & Lock Wheel Protection	. 13-64
Emergency Extension Systems 13-21	Auto Brakes	. 13-64
Landing Gear Safety Devices	Anti-Skid System Tests	. 13-65
Safety Switch13-22	Anti-Skid System Maintenance	
Ground Locks	Brake Inspection & Service	
Landing Gear Position Indicators 13-23	On Aircraft Servicing	
Nose Wheel Centering	Lining Wear	
Landing Gear System Maintenance 13-24	Air in the Brake System	
Landing Gear Rigging & Adjustment	Bleeding Master Cylinder Brake Systems	
Adjusting Landing Gear Latches 13-26		
Gear Door Clearances	Bleeding Power Brake Systems	
Drag & Side Brace Adjustment 13-27	Off Aircraft Brake Servicing & Maintenance	
Landing Gear Retraction Test	Replacement of Brake Linings	
Nose Wheel Steering Systems	Brake Malfunctions & Damage	
Small Aircraft	Overheating	
Large Aircraft	Dragging	
Shimmy Dampers	Chattering or Squealing	
Steering Damper	Aircraft Tires & Tubes	
Piston-Type	Tire Classification	
Vane-Type	Types	
	Ply Rating	
Non-Hydraulic Shimmy Damper	Tube-Type or Tubeless	
Aircraft Wheels	Bias Ply or Radial	. 13-75
vvideli Constitucion 1.534		

Tire Construction	. 13-76	Turbine Engine Fuel Issues	14-9
Bead	. 13-76	Aircraft Fuel Systems	14-9
Carcass Plies	. 13-76	Small Single-Engine Aircraft Fuel Systems	14-9
Tread	. 13-76	Gravity Feed Systems	14-9
Sidewall	. 13-78	Pump Feed Systems	14-10
Tire Inspection on the Aircraft	. 13-78	High-Wing Aircraft with Fuel Injection	
Inflation		System	14-10
Tread Condition	. 13-79	Small Multiengine (Reciprocating) Aircraft	
Sidewall Condition	. 13-83	Fuel Systems	
Tire Removal	. 13-83	Low-Wing Twin	
Tire Inspection Off of the Aircraft	. 13-85	High-Wing Twin	14-12
Tire Repair & Retreading		Large Reciprocating-Engine Aircraft Fuel	
Tire Storage	. 13-86	Systems	
Aircraft Tubes	. 13-87	Jet Transport Aircraft Fuel Systems	
Tube Construction & Selection	. 13-87	Helicopter Fuel Systems	
Tube Storage & Inspection	. 13-87	Fuel System Components	
Tire Inspection	. 13-87	Fuel Tanks	
Tire Mounting	. 13-87	Rigid Removable Fuel Tanks	
Tubeless Tires	. 13-87	Bladder Fuel Tanks	
Tube-Type Tires	. 13-89	Integral Fuel Tanks	
Tire Balancing	. 13-90	Fuel Lines & Fittings	
Operation & Handling Tips	. 13-90	Fuel Valves	
Taxiing	. 13-91	Hand-Operated Valves	
Braking & Pivoting	. 13-91	Cone Valves	
Landing Field & Hangar Floor Condition	. 13-91	Poppet Valves	
Takeoffs & Landings	. 13-91	Manually-Operated Gate Valves	
Hydroplaning	. 13-92	Motor-Operated Valves	
O		Solenoid-Operated Valves	
Chapter 14		Fuel Pumps	
Aircraft Fuel Systems	111	Hand-Operated Fuel Pumps	
Basic Fuel System Requirements Fuel System Independence		Centrifugal Boost Pumps	
Fuel System Lightning Protection		Ejector Pumps	
Fuel Flow		Pulsating Electric Pumps	
Fuel Storage System		Vane-Type Fuel Pumps	
Fuel Storage Refilling or Recharging System		Fuel Filters	
Types of Aviation Fuel		Fuel Heaters & Ice Prevention	
Reciprocating Engine Fuel—AVGAS		Fuel System Indicators	
Volatility		Fuel Quantity Indicating Systems	
Vapor Lock	14-3	Fuel Flow Meters	
Carburetor Icing		Fuel Temperature Gauges	
Aromatic Fuels		Fuel Pressure Gauges	
Detonation		Pressure Warning Signal	
Surface Ignition & Preignition		Valve-In-Transit Indicator Lights	
Octane & Performance Number Rating		Fuel System Repair	
Fuel Identification		Troubleshooting the Fuel System	
Purity		Location of Leaks & Defects	
Turbine Engine Fuels		Fuel Leak Classification	14-45
Turbine Fuel Volatility		Replacement of Gaskets, Seals, &	44.40
Turbine Engine Fuel Types		Packings	14-46
. 3. 3.1.0 Engino i doi Typoo			

Fuel Tank Repair 14	1-46 Iniet Fiiter	-18
Welded Tanks14	1-46 Construction & Installation of Deice Boots 15	-18
Riveted Tanks14	1-47 Inspection, Maintenance, & Troubleshooting	
Soldered Tanks14	of Rubber Deicer Boot Systems15	-20
Bladder Tanks14	1-47 Operational Checks 15	-20
Integral Tanks14	4-47 Adjustments 15	-20
Fire Safety14	T 11 1 0 45	-20
Fuel System Servicing14	1 ()	-21
Checking for Fuel System Contaminants 14		
Water14		-22
Solid Particle Contaminants14	Dona allan Daina Overtana	-22
Surfactants	Floatratharmal Brandler Davida System 45	
Microorganisms14	Chamical Propoller Doice 15	-23
	Ground Deicing of Aircraft	
Foreign Fuel Contamination	Frost Removal 15	-24
Detection of Contaminants	Deicing & Anti-Icing of Transport Type	
Fuel Contamination Control	AllClait13	-24
Fueling & Defueling Procedures14	icc a dilow reliioval	-25
Fueling14	1 All 1 Control Systems	-26
Defueling	Williagiliela Wibel Oystellig	-26
Fire Hazards When Fueling or Defueling 14	1-57 Chemical Rain Repellent15	-26
Chapter 15	Windshield Surface Seal Coating15	-27
Ice & Rain Protection	Pneumatic Rain Removal Systems15	-27
Ice Control Systems1	Windshield Frost, Fog, & Ice Control Systems 15-	-28
Icing Effects	15.1 Electric 15	
Ice Detector System	15-3	
Ice Prevention		
Wing & Stabilizer Anti-Icing Systems	Water & Waste Tank Ice Prevention 15	-30
Thermal Pneumatic Anti-icing	15 /	
Wing Anti-Ice (WAI) System1		
Leading Edge Slat Anti-Ice System	Cabin Environmental Control Systems	
Thermal Electric Anti-Icing	1 Tryslology of Flight	
Chemical Anti-Icing1	45.0	
Wing & Stabilizer Deicing Systems15	- 11	
Sources of Operating Air	= 12	
Turbine Engine Bleed Air	Typervertilation	
Pneumatic Deice Boot System for GA Aircraft 15	5 12	
GA System Operation	= 12	
Deice System for Turboprop Aircraft	TOTHIS OF OXYGET & CHARACTERISTICS	
Deicing System Components	5 15	
Wet-Type Engine-Driven Air Pump	5_16	
Dry-Type Engine-Driven Air Pump	Themical of Solid Oxygen	6-4
Oil Separator	Onboard Oxygen Generating Systems	
Control Valve	- 40	
	- 40	
Deflate Valve	- 12	
Distributor Valve	- 1-	
Timer/Control Unit	- 47	
Regulators & Relief Valves15		
Manifold Assembly 15	5-18 Servicing Gaseous Oxygen16	-16

Filling LOX Systems	. 16-19	Chapter 17	
Inspection of Masks & Hoses	. 16-19	Fire Protection Systems	
Replacing Tubing, Valves, & Fittings	. 16-19	Introduction	
Prevention of Oxygen Fires or Explosions	. 16-20	Classes of Fires	
Oxygen System Inspection & Maintenance	16-20	Requirements for Overheat & Fire Protection	
Aircraft Pressurization Systems	. 16-21	Systems	
Pressure of the Atmosphere	. 16-21	Fire Detection/Overheat Systems	
Temperature & Altitude	. 16-22	Thermal Switch System	
Pressurization Terms	. 16-22	Thermocouple System	
Pressurization Issues	. 16-23	Continuous-Loop Systems	
Sources of Pressurized Air	. 16-24	Fenwal System	
Reciprocating Engine Aircraft	. 16-24	Kidde System	
Turbine Engine Aircraft	. 16-25	Pressure Type Sensor Responder Systems .	
Control of Cabin Pressure	. 16-27	Pneumatic Continuous-Loop Systems	
Pressurization Modes	. 16-27	Fire Zones	17-7
Cabin Pressure Controller	. 16-29	Smoke, Flame, & Carbon Monoxide Detection	47.0
Cabin Air Pressure Regulator & Outflow		Systems	
Valve	. 16-30	Smoke Detectors	
Cabin Air Pressure Safety Valve Operation	16-31	Light Refraction Type	
Pressurization Gauges	. 16-32	Ionization Type	
Pressurization Operation		Flame Detectors	
Air Distribution		Carbon Monoxide Detectors	17-8
Cabin Pressurization Troubleshooting		Extinguishing Agents & Portable Fire	17.0
Air Conditioning Systems		Extinguishers Halogenated Hydrocarbons	
Air Cycle Air Conditioning		Inert Cold Gases	
System Operation		Dry Powders	
Pneumatic System Supply		Water	
Component Operation		Flight Deck & Cabin Interiors	
Water Separator		Extinguisher Types	
Cabin Temperature Control System		Installed Fire Extinguishing Systems	
Vapor Cycle Air Conditioning		CO ₂ Fire Extinguishing Systems	
Theory of Refrigeration		Halogenated Hydrocarbons Fire	
Vapor Cycle Air Conditioning System	. 10-42	Extinguishing Systems	17-11
Components	16-44	Containers	
Vapor Cycle Air Conditioning Servicing	. 10 44	Discharge Valves	
Equipment	16-50	Pressure Indication	
System Servicing		Two-Way Check Valve	. 17-12
Technician Certification		Discharge Indicators	. 17-12
Aircraft Heaters		Thermal Discharge Indicator (Red Disc)	. 17-13
Bleed Air Systems		Yellow Disc Discharge Indicator	. 17-13
Electric Heating Systems		Fire Switch	. 17-13
Exhaust Shroud Heaters		Cargo Fire Detection	. 17-13
Combustion Heaters		Cargo Compartment Classification	. 17-13
Combustion Air System		Class A	. 17-13
Ventilating Air System		Class B	. 17-13
Ignition System		Class C	
Controls		Class E	
		Cargo & Baggage Compartment Fire	
Safety Features		Detection & Extinguisher System	. 17-14
Maintenance & Inspection	. 10-61	Smoke Detector System	

Glossary	
Fire Prevention	17-20
Agent Containers	
Discharge Cartridges	17-19
Container Pressure Check	17-19
Fire Extinguisher System Maintenance	17-19
Fire Detection System Troubleshooting	17-18
Fire Detection System Maintenance	17-17
Lavatory Fire Extinguisher System	17-17
Lavatory Smoke Detector System	17-16
Lavatory Smoke Detectors	17-16

Chapter 1 Aircraft Structures

A Brief History of Aircraft Structures

The history of aircraft structures underlies the history of aviation in general. Advances in materials and processes used to construct aircraft have led to their evolution from simple wood truss structures to the sleek aerodynamic flying machines of today. Combined with continuous powerplant development, the structures of "flying machines" have changed significantly.

The key discovery that "lift" could be created by passing air over the top of a curved surface set the development of fixed and rotary-wing aircraft in motion. George Cayley




Figure 1-1. George Cayley, the father of aeronautics (top) and a flying replica of his 1853 glider (bottom).

developed an efficient cambered airfoil in the early 1800s, as well as successful manned gliders later in that century. He established the principles of flight, including the existence of lift, weight, thrust, and drag. It was Cayley who first stacked wings and created a tri-wing glider that flew a man in 1853.

Earlier, Cayley studied the center of gravity of flying machines, as well as the effects of wing dihedral. Furthermore, he pioneered directional control of aircraft by including the earliest form of a rudder on his gliders. [Figure 1-1]

In the late 1800s, Otto Lilienthal built upon Cayley's discoveries. He manufactured and flew his own gliders on over 2,000 flights. His willow and cloth aircraft had wings designed from extensive study of the wings of birds. Lilienthal also made standard use of vertical and horizontal fins behind the wings and pilot station. Above all, Lilienthal proved that man could fly. [Figure 1-2]

Octave Chanute, a retired railroad and bridge engineer, was active in aviation during the 1890s. [Figure 1-3] His interest was so great that, among other things, he published a definitive work called "Progress in Flying Machines." This was the culmination of his effort to gather and study all of the information available on aviation. With the assistance of others, he built gliders similar to Lilienthal's and then his own. In addition to his publication, Chanute advanced aircraft structure development by building a glider with stacked wings incorporating the use of wires as wing supports.

The work of all of these men was known to the Wright Brothers when they built their successful, powered airplane in 1903. The first of its kind to carry a man aloft, the Wright Flyer had thin, cloth-covered wings attached to what was primarily truss structures made of wood. The wings contained forward and rear spars and were supported with both struts and wires. Stacked wings (two sets) were also part of the Wright Flyer. [Figure 1-4]

Powered heavier-than-air aviation grew from the Wright design. Inventors and fledgling aviators began building their own aircraft. Early on, many were similar to that constructed by the Wrights using wood and fabric with wires and struts to support the wing structure. In 1909, Frenchman Louis Bleriot produced an aircraft with notable design differences. He built a successful mono-wing aircraft. The wings were still supported by wires, but a mast extending above the



Figure 1-2. Master of gliding and wing study, Otto Lilienthal (top) and one of his more than 2,000 glider flights (bottom).

fuselage enabled the wings to be supported from above, as well as underneath. This made possible the extended wing length needed to lift an aircraft with a single set of wings. Bleriot used a Pratt truss-type fuselage frame. [Figure 1-5]

More powerful engines were developed, and airframe structures changed to take advantage of the benefits. As early as 1910, German Hugo Junkers was able to build an aircraft with metal truss construction and metal skin due to the availability of stronger powerplants to thrust the plane forward and into the sky. The use of metal instead of wood for the primary structure eliminated the need for external wing braces and wires. His J-1 also had a single set of wings (a monoplane) instead of a stacked set. [Figure 1-6]



Figure 1-3. Octave Chanute gathered and published all of the aeronautical knowledge known to date in the late 1890s. Many early aviators benefited from this knowledge.



Figure 1-4. The Wright Flyer was the first successful powered aircraft. It was made primarily of wood and fabric.



Figure 1-5. The world's first mono-wing by Louis Bleriot.

Leading up to World War I (WWI), stronger engines also allowed designers to develop thicker wings with stronger spars. Wire wing bracing was no longer needed. Flatter, lower wing surfaces on high-camber wings created more lift. WWI expanded the need for large quantities of reliable aircraft. Used mostly for reconnaissance, stacked-wing tail draggers



Figure 1-6. The Junker J-1 all metal construction in 1910.

with wood and metal truss frames with mostly fabric skin dominated the wartime sky. [Figure 1-7] The Red Baron's Fokker DR-1 was typical.

In the 1920s, the use of metal in aircraft construction increased. Fuselages able to carry cargo and passengers were developed. The early flying boats with their hull-type construction from the shipbuilding industry provided the blueprints for semimonocoque construction of fuselages. [Figure 1-8] Truss-type designs faded. A tendency toward cleaner mono-wing designs prevailed.

Into the 1930s, all-metal aircraft accompanied new lighter and more powerful engines. Larger semimonocoque fuselages were complimented with stress-skin wing designs. Fewer truss and fabric aircraft were built. World War II (WWII) brought about a myriad of aircraft designs using all metal technology. Deep fuel-carrying wings were the norm, but the desire for higher flight speeds prompted the development of thin-winged aircraft in which fuel was carried in the fuselage. The first composite structure aircraft, the De Havilland Mosquito, used a balsa wood sandwich material in the construction of the fuselage. [Figure 1-9] The fiberglass radome was also developed during this period.

After WWII, the development of turbine engines led to higher altitude flight. The need for pressurized aircraft pervaded aviation. Semimonocoque construction needed to be made even stronger as a result. Refinements to the



Figure 1-7. World War I aircraft were typically stacked-wing fabric-covered aircraft like this Breguet 14 (circa 1917).




Figure 1-8. The flying boat hull was an early semimonocoque design like this Curtiss HS-2L.

all-metal semimonocoque fuselage structure were made to increase strength and combat metal fatigue caused by the pressurization-depressurization cycle. Rounded window and door openings were developed to avoid weak areas where cracks could form. Integrally machined copper alloy aluminum skin resisted cracking and allowed thicker skin and controlled tapering. Chemical milling of wing skin structures provided great strength and smooth high-performance surfaces. Variable contour wings became easier to construct. Increases in flight speed accompanying jet travel brought about the need for thinner wings. Wing loading also increased greatly. Multispar and box beam wing designs were developed in response.

In the 1960s, ever larger aircraft were developed to carry passengers. As engine technology improved, the jumbo jet was engineered and built. Still primarily aluminum with a



Figure 1-9. The De Havilland Mosquito used a laminated wood construction with a balsa wood core in the fuselage.

semimonocoque fuselage, the sheer size of the airliners of the day initiated a search for lighter and stronger materials from which to build them. The use of honeycomb constructed panels in Boeing's airline series saved weight while not compromising strength. Initially, aluminum core with aluminum or fiberglass skin sandwich panels were used on wing panels, flight control surfaces, cabin floor boards, and other applications.

A steady increase in the use of honeycomb and foam core sandwich components and a wide variety of composite materials characterizes the state of aviation structures from the 1970s to the present. Advanced techniques and material combinations have resulted in a gradual shift from aluminum to carbon fiber and other strong, lightweight materials. These new materials are engineered to meet specific performance requirements for various components on the aircraft. Many airframe structures are made of more than 50 percent advanced composites, with some airframes approaching



Figure 1-10. The nearly all composite Cessna Citation Mustang very light jet (VLJ).

100 percent. The term "very light jet" (VLJ) has come to describe a new generation of jet aircraft made almost entirely of advanced composite materials. [Figure 1-10] It is possible that noncomposite aluminum aircraft structures will become obsolete as did the methods and materials of construction used by Cayley, Lilienthal, and the Wright Brothers.

General

An aircraft is a device that is used for, or is intended to be used for, flight in the air. Major categories of aircraft are airplane, rotorcraft, glider, and lighter-than-air vehicles. [Figure 1-11] Each of these may be divided further by major distinguishing features of the aircraft, such as airships and balloons. Both are lighter-than-air aircraft but have differentiating features and are operated differently.

The concentration of this handbook is on the airframe of aircraft; specifically, the fuselage, booms, nacelles, cowlings,



Figure 1-11. Examples of different categories of aircraft, clockwise from top left: lighter-than-air, glider, rotorcraft, and airplane.

fairings, airfoil surfaces, and landing gear. Also included are the various accessories and controls that accompany these structures. Note that the rotors of a helicopter are considered part of the airframe since they are actually rotating wings. By contrast, propellers and rotating airfoils of an engine on an airplane are not considered part of the airframe.

The most common aircraft is the fixed-wing aircraft. As the name implies, the wings on this type of flying machine are attached to the fuselage and are not intended to move independently in a fashion that results in the creation of lift. One, two, or three sets of wings have all been successfully utilized. [Figure 1-12] Rotary-wing aircraft such as helicopters are also widespread. This handbook discusses features and maintenance aspects common to both fixedwing and rotary-wing categories of aircraft. Also, in certain cases, explanations focus on information specific to only one or the other. Glider airframes are very similar to fixedwing aircraft. Unless otherwise noted, maintenance practices described for fixed-wing aircraft also apply to gliders. The same is true for lighter-than-air aircraft, although thorough coverage of the unique airframe structures and maintenance practices for lighter-than-air flying machines is not included in this handbook.

The airframe of a fixed-wing aircraft consists of five principal units: the fuselage, wings, stabilizers, flight control surfaces, and landing gear. [Figure 1-13] Helicopter airframes consist of the fuselage, main rotor and related gearbox, tail rotor (on helicopters with a single main rotor), and the landing gear.

Airframe structural components are constructed from a wide variety of materials. The earliest aircraft were constructed primarily of wood. Aircraft structures were later made of steel tubing and are now most commonly made of aluminum. Many newly certified aircraft are built from molded composite materials, such as carbon fiber. Structural members of an aircraft's fuselage include stringers, longerons, ribs, bulkheads, and more. The main structural member in a wing is called the wing spar.

The skin of aircraft can also be made from a variety of materials, ranging from impregnated fabric to plywood, aluminum, or composites. Under the skin and attached to the structural fuselage are the many components that support airframe function. The entire airframe and its components are joined by rivets, bolts, screws, and other fasteners. Welding, adhesives, and special bonding techniques are also used.

Major Structural Stresses

Aircraft structural members are designed to carry a load or to resist stress. In designing an aircraft, every square inch of wing and fuselage, every rib, spar, and even each metal fitting



Figure 1-12. A monoplane (top), biplane (middle), and tri-wing aircraft (bottom).

must be considered in relation to the physical characteristics of the material of which it is made. Every part of the aircraft must be planned to carry the load to be imposed upon it.

A single member of the structure may be subjected to a combination of stresses. In most cases, the structural members are designed to carry end loads rather than side loads: that is, to be subjected to tension or compression rather than bending.

The determination of such loads is called stress analysis. Although planning the design is not the function of the aircraft technician, it is, nevertheless, important that the technician understand and appreciate the stresses involved in order to avoid changes in the original design through improper repairs.

The term "stress" is often used interchangeably with the word "strain." While related, they are not the same thing. External loads or forces cause stress. Stress is a material's




Figure 1-13. Principal airframe units.

internal resistance, or counterforce, that opposes deformation. The degree of deformation of a material is strain. When a material is subjected to a load or force, that material is deformed, regardless of how strong the material is or how light the load is.

There are five major stresses [Figure 1-14] to which all aircraft are subjected:

- Tension
- Compression
- Torsion
- Shear
- Bending

Tension is the stress that resists a force that tends to pull something apart. [Figure 1-14A] The engine pulls the aircraft forward, but air resistance tries to hold it back. The result is tension, which stretches the aircraft. The tensile strength of a material is measured in pounds per square inch (psi) and is calculated by dividing the load (in pounds) required to pull the material apart by its cross-sectional area (in square inches).

Compression is the stress that resists a crushing force. [Figure 1-14B] The compressive strength of a material is also measured in psi. Compression is the stress that tends to

shorten or squeeze aircraft parts.

Torsion is the stress that produces twisting. [Figure 1-14C] While moving the aircraft forward, the engine also tends to twist it to one side, but other aircraft components hold it on course. Thus, torsion is created. The torsion strength of a material is its resistance to twisting or torque.

Shear is the stress that resists the force tending to cause one layer of a material to slide over an adjacent layer. [Figure 1-14D] Two riveted plates in tension subject the rivets to a shearing force. Usually, the shearing strength of a material is either equal to or less than its tensile or compressive strength. Aircraft parts, especially screws, bolts, and rivets, are often subject to a shearing force.

Bending stress is a combination of compression and tension. The rod in *Figure 1-14E* has been shortened (compressed) on the inside of the bend and stretched on the outside of the bend. A single member of the structure may be subjected to a combination of stresses. In most cases, the structural members are designed to carry end loads rather than side loads. They are designed to be subjected to tension or compression rather than bending.

Strength or resistance to the external loads imposed during operation may be the principal requirement in certain




Figure 1-14. The five stresses that may act on an aircraft and its parts.

structures. However, there are numerous other characteristics in addition to designing to control the five major stresses that engineers must consider. For example, cowling, fairings, and similar parts may not be subject to significant loads requiring a high degree of strength. However, these parts must have streamlined shapes to meet aerodynamic requirements, such as reducing drag or directing airflow.

Fixed-Wing Aircraft

Fuselage

The fuselage is the main structure or body of the fixed-wing aircraft. It provides space for cargo, controls, accessories, passengers, and other equipment. In single-engine aircraft, the fuselage houses the powerplant. In multiengine aircraft, the engines may be either in the fuselage, attached to the fuselage, or suspended from the wing structure. There are two

general types of fuselage construction: truss and monocoque.

Truss-Type

A truss is a rigid framework made up of members, such as beams, struts, and bars to resist deformation by applied loads. The truss-framed fuselage is generally covered with fabric. The truss-type fuselage frame is usually constructed of steel tubing welded together in such a manner that all members of the truss can carry both tension and compression loads. [Figure 1-15] In some aircraft, principally the light, single-engine models, truss fuselage frames may be constructed of aluminum alloy and may be riveted or bolted into one piece, with cross-bracing achieved by using solid rods or tubes.

Monocoque Type

The monocoque (single shell) fuselage relies largely on the




Figure 1-15. A truss-type fuselage. A Warren truss uses mostly diagonal bracing.

strength of the skin or covering to carry the primary loads. The design may be divided into three classes:

- 1. Monocoque
- 2. Semimonocoque
- Reinforced shell

Different portions of the same fuselage may belong to either of the three classes, but most modern aircraft are considered to be of semimonocoque type construction.

The true monocoque construction uses formers, frame assemblies, and bulkheads to give shape to the fuselage. [Figure 1-16] The heaviest of these structural members are located at intervals to carry concentrated loads and at points where fittings are used to attach other units such as wings, powerplants, and stabilizers. Since no other bracing members are present, the skin must carry the primary stresses and keep the fuselage rigid. Thus, the biggest problem involved in monocoque construction is maintaining enough strength while keeping the weight within allowable limits.

Semimonocoque Type

To overcome the strength/weight problem of monocoque construction, a modification called semimonocoque construction was developed. It also consists of frame assemblies, bulkheads, and formers as used in the monocoque design but, additionally, the skin is reinforced by longitudinal members called longerons. Longerons usually extend across several frame members and help the skin support primary bending loads. They are typically made of aluminum alloy either of a single piece or a built-up construction. The longerons are supplemented by other longitudinal members called stringers.

Stringers are typically more numerous and lighter in weight




Figure 1-16. An airframe using monocoque construction.

than the longerons. They come in a variety of shapes and are usually made from single piece aluminum alloy extrusions or formed aluminum. Stringers have some rigidity but are chiefly used for giving shape and for attachment of the skin. Stringers and longerons together prevent tension and compression from bending the fuselage. [Figure 1-17]

Other bracing between the longerons and stringers can also be used. Often referred to as web members, these additional support pieces may be installed vertically or diagonally. It must be noted that manufacturers use different nomenclature to describe structural members. For example, there is often little difference between some rings, frames, and formers. One manufacturer may call the same type of brace a ring or




Figure 1-17. The most common airframe construction is semimonocoque.

a frame. Manufacturer instructions and specifications for a specific aircraft are the best guides.

The semimonocoque fuselage is constructed primarily of alloys of aluminum and magnesium, although steel and titanium are sometimes found in areas of high temperatures. Individually, not one of the aforementioned components is strong enough to carry the loads imposed during flight and landing. But, when combined, those components form a strong, rigid framework. This is accomplished with gussets, rivets, nuts and bolts, screws, and even friction stir welding. A gusset is a type of connection bracket that adds strength. [Figure 1-18]

To summarize, in semimonocoque fuselages, the strong, heavy longerons hold the bulkheads and formers, and these, in turn, hold the stringers, braces, web members, etc. All are designed to be attached together and to the skin to achieve the full-strength benefits of semimonocoque design. It is important to recognize that the metal skin or covering carries part of the load. The fuselage skin thickness can vary with the load carried and the stresses sustained at a particular location.

The advantages of the semimonocoque fuselage are many. The bulkheads, frames, stringers, and longerons facilitate the design and construction of a streamlined fuselage that is both rigid and strong. Spreading loads among these structures and the skin means no single piece is failure critical. This means that a semimonocoque fuselage, because of its stressed-skin construction, may withstand considerable damage and still be strong enough to hold together.

Fuselages are generally constructed in two or more sections. On small aircraft, they are generally made in two or three sections, while larger aircraft may be made up of as many as six sections or more before being assembled.



Figure 1-18. Gussets are used to increase strength.

Reinforced Shell Type

The reinforced shell has the skin reinforced by a complete framework of structural members.

Pressurization

Many aircraft are pressurized. This means that air is pumped into the cabin after takeoff and a difference in pressure between the air inside the cabin and the air outside the cabin is established. This differential is regulated and maintained. In this manner, enough oxygen is made available for passengers to breathe normally and move around the cabin without special equipment at high altitudes.

Pressurization causes significant stress on the fuselage structure and adds to the complexity of design. In addition to withstanding the difference in pressure between the air inside and outside the cabin, cycling from unpressurized to pressurized and back again on each flight causes metal fatigue. To deal with these impacts and the other stresses of flight, nearly all pressurized aircraft are semimonocoque in design. Pressurized fuselage structures undergo extensive periodic inspections to ensure that any damage is discovered and repaired. Repeated weakness or failure in an area of structure may require that section of the fuselage be modified or redesigned.

Wings

Wing Configurations

Wings are airfoils that, when moved rapidly through the air, create lift. They are built in many shapes and sizes. Wing design can vary to provide certain desirable flight characteristics. Control at various operating speeds, the amount of lift generated, balance, and stability all change as the shape of the wing is altered. Both the leading edge and the trailing edge of the wing may be straight or curved, or one edge may be straight and the other curved. One or both edges may be tapered so that the wing is narrower at the tip than at the root where it joins the fuselage. The wing tip may be square, rounded, or even pointed. *Figure 1-19* shows a number of typical wing leading and trailing edge shapes.

The wings of an aircraft can be attached to the fuselage at the top, mid-fuselage, or at the bottom. They may extend perpendicular to the horizontal plane of the fuselage or can angle up or down slightly. This angle is known as the wing dihedral. The dihedral angle affects the lateral stability of the aircraft. *Figure 1-20* shows some common wing attach points and dihedral angle.

Wing Structure

The wings of an aircraft are designed to lift it into the air. Their particular design for any given aircraft depends on a number of factors, such as size, weight, use of the aircraft,




Figure 1-19. Various wing design shapes yield different performance.




Figure 1-20. Wing attach points and wing dihedrals.

desired speed in flight and at landing, and desired rate of climb. The wings of aircraft are designated left and right, corresponding to the left and right sides of the operator when seated in the flight deck. [Figure 1-21]

Often wings are of full cantilever design. This means they are built so that no external bracing is needed. They are supported internally by structural members assisted by the skin of the aircraft. Other aircraft wings use external struts or wires to assist in supporting the wing and carrying the aerodynamic and landing loads. Wing support cables and struts are generally made from steel. Many struts and their attach fittings have fairings to reduce drag. Short, nearly vertical supports called jury struts are found on struts that attach to the wings a great distance from the fuselage. This serves to subdue strut movement and oscillation caused by the air flowing around the strut in flight. *Figure 1-22* shows samples of wings using external bracing, also known as semicantilever wings. Cantilever wings built with no external




Figure 1-21. "Left" and "right" on an aircraft are oriented to the perspective of a pilot sitting in the flight deck.

bracing are also shown.

Aluminum is the most common material from which to construct wings, but they can be wood covered with fabric, and occasionally a magnesium alloy has been used. Moreover, modern aircraft are tending toward lighter and stronger materials throughout the airframe and in wing construction. Wings made entirely of carbon fiber or other composite materials exist, as well as wings made of a combination of materials for maximum strength to weight performance.

The internal structures of most wings are made up of spars and stringers running spanwise and ribs and formers or bulkheads running chordwise (leading edge to trailing edge). The spars are the principle structural members of a wing. They support all distributed loads, as well as concentrated weights such as the fuselage, landing gear, and engines. The skin, which is attached to the wing structure, carries part of the loads imposed during flight. It also transfers the stresses to the wing ribs. The ribs, in turn, transfer the loads to the wing spars. [Figure 1-23]

In general, wing construction is based on one of three fundamental designs:

- 1. Monospar
- 2. Multispar
- 3. Box beam

Modification of these basic designs may be adopted by various manufacturers.

The monospar wing incorporates only one main spanwise or longitudinal member in its construction. Ribs or bulkheads supply the necessary contour or shape to the airfoil. Although the strict monospar wing is not common, this type of design modified by the addition of false spars or light shear webs along the trailing edge for support of control surfaces is sometimes used.

The multispar wing incorporates more than one main longitudinal member in its construction. To give the wing contour, ribs or bulkheads are often included.




Figure 1-22. Externally braced wings, also called semicantilever wings, have wires or struts to support the wing. Full cantilever wings have no external bracing and are supported internally.




Figure 1-23. Wing structure nomenclature.

The box beam type of wing construction uses two main longitudinal members with connecting bulkheads to furnish additional strength and to give contour to the wing. [Figure 1-24] A corrugated sheet may be placed between the bulkheads and the smooth outer skin so that the wing can better carry tension and compression loads. In some cases, heavy longitudinal stiffeners are substituted for the upper surface of the wing and stiffeners on the lower surface corrugated sheets. A combination of corrugated sheets on the upper surface of the wing and stiffeners on the lower surface is sometimes used. Air transport category aircraft often utilize box beam wing construction.

Wing Spars

Spars are the principal structural members of the wing. They correspond to the longerons of the fuselage. They run parallel to the lateral axis of the aircraft, from the fuselage toward the tip of the wing, and are usually attached to the fuselage by wing fittings, plain beams, or a truss.

Spars may be made of metal, wood, or composite materials depending on the design criteria of a specific aircraft. Wooden spars are usually made from spruce. They can be generally classified into four different types by their cross-sectional configuration. As shown in *Figure 1-25*, they may be (A) solid, (B) box-shaped, (C) partly hollow, or (D) in the form of an I-beam. Lamination of solid wood spars is often used to increase strength. Laminated wood can also be found in box-shaped spars. The spar in *Figure 1-25E* has had material removed to reduce weight but retains the strength of a rectangular spar. As can be seen, most wing spars are basically rectangular in shape with the long dimension of the cross-section oriented up and down in the wing.

Currently, most manufactured aircraft have wing spars made of solid extruded aluminum or aluminum extrusions riveted together to form the spar. The increased use of




Figure 1-24. Box beam construction.




Figure 1-25. Typical wooden wing spar cross-sections.

composites and the combining of materials should make airmen vigilant for wings spars made from a variety of materials. *Figure 1-26* shows examples of metal wing spar cross-sections.

In an I-beam spar, the top and bottom of the I-beam are called the caps and the vertical section is called the web. The entire spar can be extruded from one piece of metal but often it is built up from multiple extrusions or formed angles. The web forms the principal depth portion of the spar and the cap strips (extrusions, formed angles, or milled sections) are attached to it. Together, these members carry the loads caused by wing bending, with the caps providing a foundation for attaching the skin. Although the spar shapes in *Figure 1-26* are typical, actual wing spar configurations assume many forms. For example, the web of a spar may be a plate or a truss as shown in *Figure 1-27*. It could be built up from lightweight materials with vertical stiffeners employed for strength. [Figure 1-28]

It could also have no stiffeners but might contain flanged holes for reducing weight while maintaining strength. Some metal and composite wing spars retain the I-beam concept but use a sine wave web. [Figure 1-29]

Additionally, fail-safe spar web design exists. Fail-safe means that should one member of a complex structure fail, some other part of the structure assumes the load of the failed member and permits continued operation. A spar with fail-safe construction is shown in *Figure 1-30*. This spar is made in two sections. The top section consists of a cap riveted to the upper web plate. The lower section is a single extrusion consisting of the lower cap and web plate. These two sections are spliced together to form the spar. If either section of this type of spar breaks, the other section can still carry the load. This is the fail-safe feature.

As a rule, a wing has two spars. One spar is usually located near the front of the wing, and the other about two-thirds of the distance toward the wing's trailing edge. Regardless of type, the spar is the most important part of the wing. When other structural members of the wing are placed under load, most of the resulting stress is passed on to the wing spar.

False spars are commonly used in wing design. They are longitudinal members like spars but do not extend the entire spanwise length of the wing. Often, they are used as hinge




Figure 1-26. Examples of metal wing spar shapes.




Figure 1-27. A truss wing spar.




Figure 1-28. A plate web wing spar with vertical stiffeners.




Figure 1-29. A sine wave wing spar can be made from aluminum or composite materials.

attach points for control surfaces, such as an aileron spar. **Wing Ribs**

Ribs are the structural crosspieces that combine with spars and stringers to make up the framework of the wing. They usually extend from the wing leading edge to the rear spar or to the trailing edge of the wing. The ribs give the wing its cambered shape and transmit the load from the skin and stringers to the spars. Similar ribs are also used in ailerons,




Figure 1-30. A fail-safe spar with a riveted spar web.

elevators, rudders, and stabilizers.

Wing ribs are usually manufactured from either wood or metal. Aircraft with wood wing spars may have wood or metal ribs while most aircraft with metal spars have metal ribs. Wood ribs are usually manufactured from spruce. The three most common types of wooden ribs are the plywood web, the lightened plywood web, and the truss types. Of these three, the truss type is the most efficient because it is strong and lightweight, but it is also the most complex to construct.

Figure 1-31 shows wood truss web ribs and a lightened plywood web rib. Wood ribs have a rib cap or cap strip fastened around the entire perimeter of the rib. It is usually made of the same material as the rib itself. The rib cap stiffens and strengthens the rib and provides an attaching surface for the wing covering. In Figure 1-31A, the cross-section of a wing rib with a truss-type web is illustrated. The dark rectangular sections are the front and rear wing spars. Note that to reinforce the truss, gussets are used. In Figure 1-31B, a truss web rib is shown with a continuous gusset. It provides greater support throughout the entire rib with very little additional weight. A continuous gusset stiffens the cap strip in the plane of the rib. This aids in preventing buckling and helps to obtain better rib/ skin joints where nail-gluing is used. Such a rib can resist the driving force of nails better than the other types. Continuous gussets are also more easily handled than the many small separate gussets otherwise required. Figure 1-31C shows a rib with a lighten plywood web. It also contains gussets to support the web/cap strip interface. The cap strip is usually laminated to the web, especially at the leading edge.

A wing rib may also be referred to as a plain rib or a main rib. Wing ribs with specialized locations or functions are given names that reflect their uniqueness. For example, ribs that are located entirely forward of the front spar that are used to shape and strengthen the wing leading edge are called nose ribs or false ribs. False ribs are ribs that do not span the entire




Figure 1-31. Examples of wing ribs constructed of wood.

wing chord, which is the distance from the leading edge to the trailing edge of the wing. Wing butt ribs may be found at the inboard edge of the wing where the wing attaches to the fuselage. Depending on its location and method of attachment, a butt rib may also be called a bulkhead rib or a compression rib if it is designed to receive compression loads that tend to force the wing spars together.

Since the ribs are laterally weak, they are strengthened in some wings by tapes that are woven above and below rib sections to prevent sidewise bending of the ribs. Drag and anti-drag wires may also be found in a wing. In *Figure 1-32*, they are

shown crisscrossed between the spars to form a truss to resist forces acting on the wing in the direction of the wing chord. These tension wires are also referred to as tie rods. The wire designed to resist the backward forces is called a drag wire; the anti-drag wire resists the forward forces in the chord direction. *Figure 1-32* illustrates the structural components of a basic wood wing.

At the inboard end of the wing spars is some form of wing attach fitting as illustrated in *Figure 1-32*. These provide a strong and secure method for attaching the wing to the fuselage. The interface between the wing and fuselage is often covered with a fairing to achieve smooth airflow in this area. The fairing(s) can be removed for access to the wing attach fittings. [Figure 1-33]

The wing tip is often a removable unit, bolted to the outboard end of the wing panel. One reason for this is the vulnerability of the wing tips to damage, especially during ground handling and taxiing. Figure 1-34 shows a removable wing tip for a large aircraft wing. Others are different. The wing tip assembly is of aluminum alloy construction. The wing tip cap is secured to the tip with countersunk screws and is secured to the interspar structure at four points with 1/4-inch diameter bolts. To prevent ice from forming on the leading edge of the wings of large aircraft, hot air from an engine is often channeled through the leading edge from wing root to wing tip. A louver on the top surface of the wing tip allows this warm air to be




Figure 1-32. *Basic wood wing structure and components.*



Figure 1-33. Wing root fairings smooth airflow and hide wing attach fittings.

exhausted overboard. Wing position lights are located at the center of the tip and are not directly visible from the flight deck. As an indication that the wing tip light is operating, some wing tips are equipped with a Lucite rod to transmit the light to the leading edge.

Wing Skin

Often, the skin on a wing is designed to carry part of the flight and ground loads in combination with the spars and ribs. This is known as a stressed-skin design. The all-metal, full cantilever wing section illustrated in *Figure 1-35* shows the structure of one such design. The lack of extra internal or external bracing requires that the skin share some of the load. Notice the skin is stiffened to aid with this function.

Fuel is often carried inside the wings of a stressed-skin aircraft. The joints in the wing can be sealed with a special fuel resistant sealant enabling fuel to be stored directly inside the structure. This is known as wet wing design. Alternately, a fuel-carrying bladder or tank can be fitted inside a wing. Figure 1-36 shows a wing section with a box beam structural design such as one that might be found in a transport category aircraft. This structure increases strength while reducing weight. Proper sealing of the structure allows fuel to be stored in the box sections of the wing.

The wing skin on an aircraft may be made from a wide variety of materials such as fabric, wood, or aluminum. But a single thin sheet of material is not always employed. Chemically




Figure 1-34. A removable metal wing tip.




Figure 1-35. The skin is an integral load carrying part of a stressed skin design.




Figure 1-36. Fuel is often carried in the wings.

milled aluminum skin can provide skin of varied thicknesses. On aircraft with stressed-skin wing design, honeycomb structured wing panels are often used as skin. A honeycomb structure is built up from a core material resembling a bee hive's honeycomb which is laminated or sandwiched between thin outer skin sheets. *Figure 1-37* illustrates honeycomb panes and their components. Panels formed like this are lightweight and very strong. They have a variety of uses on the aircraft, such as floor panels, bulkheads, and control surfaces, as well as wing skin panels. *Figure 1-38* shows the locations of honeycomb construction wing panels on a jet transport aircraft.

A honeycomb panel can be made from a wide variety of materials. Aluminum core honeycomb with an outer skin of aluminum is common. But honeycomb in which the core is an Arimid[®] fiber and the outer sheets are coated Phenolic[®] is common as well. In fact, a myriad of other material combinations such as those using fiberglass, plastic, Nomex[®],

Kevlar[®], and carbon fiber all exist. Each honeycomb structure possesses unique characteristics depending upon the materials, dimensions, and manufacturing techniques employed. *Figure 1-39* shows an entire wing leading edge formed from honeycomb structure.

Nacelles

Nacelles (sometimes called "pods") are streamlined enclosures used primarily to house the engine and its components. They usually present a round or elliptical profile to the wind thus reducing aerodynamic drag. On most single-engine aircraft, the engine and nacelle are at the forward end of the fuselage. On multiengine aircraft, engine nacelles are built into the wings or attached to the fuselage at the empennage (tail section). Occasionally, a multiengine aircraft is designed with a nacelle in line with the fuselage aft of the passenger compartment. Regardless of its location, a nacelle contains the engine and accessories, engine mounts, structural members, a firewall, and skin and cowling on the




Figure 1-37. The honeycomb panel is a staple in aircraft construction. Cores can be either constant thickness (A) or tapered (B). Tapered core honeycomb panels are frequently used as flight control surfaces and wing trailing edges.

exterior to fare the nacelle to the wind.

Some aircraft have nacelles that are designed to house the landing gear when retracted. Retracting the gear to reduce wind resistance is standard procedure on high-performance/high-speed aircraft. The wheel well is the area where the landing gear is attached and stowed when retracted. Wheel wells can be located in the wings and/or fuselage when not part of the nacelle. *Figure 1-40* shows an engine nacelle incorporating the landing gear with the wheel well extending into the wing root.

The framework of a nacelle usually consists of structural members similar to those of the fuselage. Lengthwise members, such as longerons and stringers, combine with horizontal/vertical members, such as rings, formers, and bulkheads, to give the nacelle its shape and structural integrity. A firewall is incorporated to isolate the engine compartment from the rest of the aircraft. This is basically a

stainless steel or titanium bulkhead that contains a fire in the confines of the nacelle rather than letting it spread throughout the airframe. [Figure 1-41]

Engine mounts are also found in the nacelle. These are the structural assemblies to which the engine is fastened. They are usually constructed from chrome/molybdenum steel tubing in light aircraft and forged chrome/nickel/molybdenum assemblies in larger aircraft. [Figure 1-42]

The exterior of a nacelle is covered with a skin or fitted with a cowling which can be opened to access the engine and components inside. Both are usually made of sheet aluminum or magnesium alloy with stainless steel or titanium alloys being used in high-temperature areas, such as around the exhaust exit. Regardless of the material used, the skin is typically attached to the framework with rivets.

Cowling refers to the detachable panels covering those areas




Figure 1-38. Honeycomb wing construction on a large jet transport aircraft.

into which access must be gained regularly, such as the engine and its accessories. It is designed to provide a smooth airflow over the nacelle and to protect the engine from damage. Cowl panels are generally made of aluminum alloy construction. However, stainless steel is often used as the inner skin aft of the power section and for cowl flaps and near cowl flap openings. It is also used for oil cooler ducts. Cowl flaps are moveable parts of the nacelle cowling that open and close to regulate engine temperature.

There are many engine cowl designs. Figure 1-43 shows an exploded view of the pieces of cowling for a horizontally opposed engine on a light aircraft. It is attached to the nacelle by means of screws and/or quick release fasteners. Some large reciprocating engines are enclosed by "orange peel" cowlings which provide excellent access to components inside the nacelle. [Figure 1-44] These cowl panels are attached to the forward firewall by mounts which also serve as hinges for opening the cowl. The lower cowl mounts are

secured to the hinge brackets by quick release pins. The side and top panels are held open by rods and the lower panel is retained in the open position by a spring and a cable. All of the cowling panels are locked in the closed position by overcenter steel latches which are secured in the closed position by spring-loaded safety catches.

An example of a turbojet engine nacelle can be seen in *Figure 1-45*. The cowl panels are a combination of fixed and easily removable panels which can be opened and closed during maintenance. A nose cowl is also a feature on a jet engine nacelle. It guides air into the engine.

Empennage

The empennage of an aircraft is also known as the tail section. Most empennage designs consist of a tail cone, fixed aerodynamic surfaces or stabilizers, and movable aerodynamic surfaces.




Figure 1-39. A wing leading edge formed from honeycomb material bonded to the aluminum spar structure.



Figure 1-40. Engine nacelle incorporating the landing gear with the wheel well extending into the wing root.



Figure 1-41. An engine nacelle firewall.

The tail cone serves to close and streamline the aft end of most fuselages. The cone is made up of structural members like those of the fuselage; however, cones are usually of lighter construction since they receive less stress than the fuselage. [Figure 1-46]

The other components of the typical empennage are of heavier construction than the tail cone. These members include fixed surfaces that help stabilize the aircraft and movable surfaces that help to direct an aircraft during flight. The fixed surfaces are the horizontal stabilizer and vertical stabilizer. The movable surfaces are usually a rudder located at the aft edge of the vertical stabilizer and an elevator located at the aft edge the horizontal stabilizer. [Figure 1-47]

The structure of the stabilizers is very similar to that which is used in wing construction. *Figure 1-48* shows a typical vertical stabilizer. Notice the use of spars, ribs, stringers, and skin like those found in a wing. They perform the same functions shaping and supporting the stabilizer and transferring stresses. Bending, torsion, and shear created by air loads in flight pass from one structural member to another. Each member absorbs some of the stress and passes the remainder on to the others. Ultimately, the spar transmits any overloads to the fuselage. A horizontal stabilizer is built



Figure 1-42. Various aircraft engine mounts.




Figure 1-43. Typical cowling for a horizontally opposed reciprocating engine.

the same way.

The rudder and elevator are flight control surfaces that are also part of the empennage discussed in the next section of this chapter.

Flight Control Surfaces

The directional control of a fixed-wing aircraft takes place around the lateral, longitudinal, and vertical axes by means of flight control surfaces designed to create movement about these axes. These control devices are hinged or movable surfaces through which the attitude of an aircraft is controlled during takeoff, flight, and landing. They are usually divided into two major groups: 1) primary or main flight control surfaces and 2) secondary or auxiliary control surfaces.




Figure 1-44. Orange peel cowling for large radial reciprocating engine.



Figure 1-45. Cowling on a transport category turbine engine nacelle.




Figure 1-46. The fuselage terminates at the tail cone with similar but more lightweight construction.




Figure 1-47. Components of a typical empennage.




Figure 1-48. Vertical stabilizer.

Primary Flight Control Surfaces

The primary flight control surfaces on a fixed-wing aircraft include: ailerons, elevators, and the rudder. The ailerons are attached to the trailing edge of both wings and when moved, rotate the aircraft around the longitudinal axis. The elevator is attached to the trailing edge of the horizontal stabilizer. When it is moved, it alters aircraft pitch, which is the attitude about the horizontal or lateral axis. The rudder is hinged to the trailing edge of the vertical stabilizer. When the rudder changes position, the aircraft rotates about the vertical axis (yaw). *Figure 1-49* shows the primary flight controls of a light aircraft and the movement they create relative to the three axes of flight.

Primary control surfaces are usually similar in construction to one another and vary only in size, shape, and methods of attachment. On aluminum light aircraft, their structure is often similar to an all-metal wing. This is appropriate because the primary control surfaces are simply smaller aerodynamic devices. They are typically made from an aluminum alloy structure built around a single spar member or torque tube to which ribs are fitted and a skin is attached. The lightweight ribs are, in many cases, stamped out from flat aluminum sheet stock. Holes in the ribs lighten the assembly. An aluminum skin is attached with rivets. *Figure 1-50* illustrates this type of structure, which can be found on the primary control surfaces of light aircraft as well as on medium and heavy aircraft.




Figure 1-49. Flight control surfaces move the aircraft around the three axes of flight.




Figure 1-50. Typical structure of an aluminum flight control surface.



Figure 1-51. Composite control surfaces and some of the many aircraft that utilize them.

Primary control surfaces constructed from composite materials are also commonly used. These are found on many heavy and high-performance aircraft, as well as gliders, home-built, and light-sport aircraft. The weight and strength advantages over traditional construction can be significant. A wide variety of materials and construction techniques are employed. *Figure 1-51* shows examples of aircraft that use composite technology on primary flight control surfaces. Note that the control surfaces of fabric-covered aircraft often have fabric-covered surfaces just as aluminum-skinned (light) aircraft typically have all-aluminum control surfaces. There is a critical need for primary control surfaces to be balanced so they do not vibrate or flutter in the wind.

Performed to manufacturer's instructions, balancing usually consists of assuring that the center of gravity of a particular device is at or forward of the hinge point. Failure to properly balance a control surface could lead to catastrophic failure. *Figure 1-52* illustrates several aileron configurations with their hinge points well aft of the leading edge. This is a common design feature used to prevent flutter.

Ailerons

Ailerons are the primary flight control surfaces that move the aircraft about the longitudinal axis. In other words, movement of the ailerons in flight causes the aircraft to roll. Ailerons are usually located on the outboard trailing edge of each of the wings. They are built into the wing and are calculated as part of the wing's surface area. *Figure 1-53* shows aileron locations on various wing tip designs.

Ailerons are controlled by a side-to-side motion of the control stick in the flight deck or a rotation of the control yoke. When the aileron on one wing deflects down, the aileron on the opposite wing deflects upward. This amplifies the movement of the aircraft around the longitudinal axis. On the wing on which the aileron trailing edge moves downward, camber is increased, and lift is increased. Conversely, on the other wing, the raised aileron decreases lift. [Figure 1-54] The result is a sensitive response to the control input to roll the aircraft.

The pilot's request for aileron movement and roll are transmitted from the flight deck to the actual control surface in a variety of ways depending on the aircraft. A system of control cables and pulleys, push-pull tubes, hydraulics, electric, or a combination of these can be employed. [Figure 1-55]

Simple, light aircraft usually do not have hydraulic or electric fly-by-wire aileron control. These are found on heavy and high-performance aircraft. Large aircraft and some highperformance aircraft may also have a second set of ailerons located inboard on the trailing edge of the wings. These




Figure 1-52. Aileron hinge locations are very close to but aft of the center of gravity to prevent flutter.




Figure 1-53. Aileron location on various wings.




Figure 1-54. Differential aileron control movement. When one aileron is moved down, the aileron on the opposite wing is deflected upward.

are part of a complex system of primary and secondary control surfaces used to provide lateral control and stability in flight. At low speeds, the ailerons may be augmented by the use of flaps and spoilers. At high speeds, only inboard aileron deflection is required to roll the aircraft while the other control surfaces are locked out or remain stationary. *Figure 1-56* illustrates the location of the typical flight control surfaces found on a transport category aircraft.




Figure 1-55. Transferring control surface inputs from the flight deck.

Elevator

The elevator is the primary flight control surface that moves the aircraft around the horizontal or lateral axis. This causes the nose of the aircraft to pitch up or down. The elevator is hinged to the trailing edge of the horizontal stabilizer and typically spans most or all of its width. It is controlled in the flight deck by pushing or pulling the control stick or yoke forward or aft.

Light aircraft use a system of control cables and pulleys or push-pull tubes to transfer flight deck inputs to the movement of the elevator. High-performance and large aircraft typically employ more complex systems. Hydraulic power is commonly used to move the elevator on these aircraft. On aircraft equipped with fly-by-wire controls, a combination of electrical and hydraulic power is used.

Rudder

The rudder is the primary control surface that causes an aircraft to yaw or move about the vertical axis. This provides directional control and thus points the nose of the aircraft in the direction desired. Most aircraft have a single rudder hinged to the trailing edge of the vertical stabilizer. It is controlled by a pair of foot-operated rudder pedals in the flight deck. When the right pedal is pushed forward, it deflects the rudder to the right which moves the nose of the aircraft to the right. The left pedal is rigged to simultaneously move aft. When the left pedal is pushed forward, the nose of the aircraft moves to the left.

As with the other primary flight controls, the transfer of the movement of the flight deck controls to the rudder varies with the complexity of the aircraft. Many aircraft incorporate the directional movement of the nose or tail wheel into the rudder control system for ground operation. This allows the operator




Figure 1-56. Typical flight control surfaces on a transport category aircraft.

to steer the aircraft with the rudder pedals during taxi when the airspeed is not high enough for the control surfaces to be effective. Some large aircraft have a split rudder arrangement. This is actually two rudders, one above the other. At low speeds, both rudders deflect in the same direction when the pedals are pushed. At higher speeds, one of the rudders becomes inoperative as the deflection of a single rudder is aerodynamically sufficient to maneuver the aircraft.

Dual Purpose Flight Control Surfaces

The ailerons, elevators, and rudder are considered conventional primary control surfaces. However, some aircraft are designed with a control surface that may serve a dual purpose. For example, elevons perform the combined functions of the ailerons and the elevator. [Figure 1-57]

A movable horizontal tail section, called a stabilator, is a control surface that combines the action of both the horizontal stabilizer and the elevator. [Figure 1-58] Basically, a stabilator is a horizontal stabilizer that can also be rotated about the horizontal axis to affect the pitch of the aircraft.

A ruddervator combines the action of the rudder and elevator. [Figure 1-59] This is possible on aircraft with V-tail empennages where the traditional horizontal and vertical stabilizers do not exist. Instead, two stabilizers angle upward and outward from the aft fuselage in a "V" configuration. Each contains a movable ruddervator built into the trailing




Figure 1-57. Elevons.

edge. Movement of the ruddervators can alter the movement of the aircraft around the horizontal and/or vertical axis. Additionally, some aircraft are equipped with flaperons. [Figure 1-60] Flaperons are ailerons which can also act as flaps. Flaps are secondary control surfaces on most wings, discussed in the next section of this chapter.

Secondary or Auxiliary Control Surfaces

There are several secondary or auxiliary flight control surfaces. Their names, locations, and functions of those for most large aircraft are listed in *Figure 1-61*.

Flaps

Flaps are found on most aircraft. They are usually inboard



Figure 1-58. A stabilizer and index marks on a transport category aircraft.




Figure 1-59. Ruddervator.

on the wings' trailing edges adjacent to the fuselage. Leading edge flaps are also common. They extend forward and down from the inboard wing leading edge. The flaps are lowered to increase the camber of the wings and provide greater lift and control at slow speeds. They enable landing at slower speeds and shorten the amount of runway required for takeoff and landing. The amount that the flaps extend and the angle they form with the wing can be selected from the flight deck. Typically, flaps can extend up to 45–50°. *Figure 1-62* shows various aircraft with flaps in the extended position.

Flaps are usually constructed of materials and with techniques used on the other airfoils and control surfaces of a particular aircraft. Aluminum skin and structure flaps are the norm on light aircraft. Heavy and high-performance aircraft flaps may also be aluminum, but the use of composite structures is also common.

There are various kinds of flaps. Plain flaps form the trailing edge of the wing when the flap is in the retracted position. [Figure 1-63A] The airflow over the wing continues over the upper and lower surfaces of the flap, making the trailing edge of the flap essentially the trailing edge of the wing. The plain flap is hinged so that the trailing edge can be lowered. This



Figure 1-60. Flaperons.

increases wing camber and provides greater lift.

A split flap is normally housed under the trailing edge of the wing. [Figure 1-63B] It is usually just a braced flat metal plate hinged at several places along its leading edge. The upper surface of the wing extends to the trailing edge of the flap. When deployed, the split flap trailing edge lowers away from the trailing edge of the wing. Airflow over the top of the wing remains the same. Airflow under the wing now follows the camber created by the lowered split flap, increasing lift.

Fowler flaps not only lower the trailing edge of the wing when deployed but also slide aft, effectively increasing the area of the wing. [Figure 1-63C] This creates more lift via the increased surface area, as well as the wing camber. When stowed, the Fowler flap typically retracts up under the wing trailing edge similar to a split flap. The sliding motion of a Fowler flap can be accomplished with a worm drive and flap tracks.

An enhanced version of the Fowler flap is a set of flaps that actually contains more than one aerodynamic surface. *Figure 1-64* shows a triple-slotted flap. In this configuration, the flap consists of a fore flap, a mid flap, and an aft flap. When deployed, each flap section slides aft on tracks as it lowers. The flap sections also separate leaving an open slot between the wing and the fore flap, as well as between each of the flap sections. Air from the underside of the wing flows through these slots. The result is that the laminar flow on the upper surfaces is enhanced. The greater camber and effective wing area increase overall lift.

Heavy aircraft often have leading edge flaps that are used in conjunction with the trailing edge flaps. [Figure 1-65] They can be made of machined magnesium or can have an aluminum or composite structure. While they are not installed or operate independently, their use with trailing edge flaps can greatly increase wing camber and lift. When stowed, leading edge flaps retract into the leading edge of the wing.

Secondary/Auxiliary Flight Control Surfaces		
Name	Location	Function
Flaps	Inboard trailing edge of wings	Extends the camber of the wing for greater lift and slower flight. Allows control at low speeds for short field takeoffs and landings.
Trim tabs	Trailing edge of primary flight control surfaces	Reduces the force needed to move a primary control surface.
Balance tabs	Trailing edge of primary flight control surfaces	Reduces the force needed to move a primary control surface.
Anti-balance tabs	Trailing edge of primary flight control surfaces	Increases feel and effectiveness of primary control surface.
Servo tabs	Trailing edge of primary flight control surfaces	Assists or provides the force for moving a primary flight control.
Spoilers	Upper and/or trailing edge of wing	Decreases (spoils) lift. Can augment aileron function.
Slats	Mid to outboard leading edge of wing	Extends the camber of the wing for greater lift and slower flight. Allows control at low speeds for short field takeoffs and landings.
Slots	Outer leading edge of wing forward of ailerons	Directs air over upper surface of wing during high angle of attack. Lowers stall speed and provides control during slow flight.
Leading edge flap	Inboard leading edge of wing	Extends the camber of the wing for greater lift and slower flight. Allows control at low speeds for short field takeoffs and landings.
NOTE: An aircraft may possess none, one, or a combination of the above control surfaces.		

Figure 1-61. Secondary or auxiliary control surfaces and respective locations for larger aircraft.



Figure 1-62. *Various aircraft with flaps in the extended position.*




Figure 1-63. Various types of flaps.




Figure 1-64. Triple-slotted flap.




Figure 1-65. Leading edge flaps.

The differing designs of leading edge flaps essentially provide the same effect. Activation of the trailing edge flaps automatically deploys the leading edge flaps, which are driven out of the leading edge and downward, extending the camber of the wing. *Figure 1-66* shows a Krueger flap, recognizable by its flat mid-section.

Slats

Another leading edge device which extends wing camber is a slat. Slats can be operated independently of the flaps with their own switch in the flight deck. Slats not only extend out of the leading edge of the wing increasing camber and lift, but most often, when fully deployed leave a slot between their trailing edges and the leading edge of the wing. [Figure 1-67] This increases the angle of attack at which the wing will maintain its laminar airflow, resulting in the ability to fly the aircraft slower with a reduced stall speed, and still maintain control.

Spoilers & Speed Brakes

A spoiler is a device found on the upper surface of many heavy and high-performance aircraft. It is stowed flush to the wing's upper surface. When deployed, it raises up into the airstream and disrupts the laminar airflow of the wing, thus reducing lift.

Spoilers are made with similar construction materials and techniques as the other flight control surfaces on the aircraft. Often, they are honeycomb-core flat panels. At low speeds, spoilers are rigged to operate when the ailerons operate to assist with the lateral movement and stability of the aircraft. On the wing where the aileron is moved up, the spoilers also raise thus amplifying the reduction of lift on that wing. [Figure 1-68] On the wing with downward aileron deflection, the spoilers remain stowed. As the speed of the aircraft increases, the ailerons become more effective and the spoiler interconnect disengages.

Spoilers are unique in that they may also be fully deployed on both wings to act as speed brakes. The reduced lift and increased drag can quickly reduce the speed of the aircraft in



Figure 1-66. Side view (left) and front view (right) of a Krueger flap on a Boeing 737.