


Use Docker to Compile Linux for ESP32-S3

Created by Liz Clark



https://learn.adafruit.com/docker-esp32-s3-linux

Last updated on 2024-06-03 03:53:58 PM EDT

© Adafruit Industries Page 1 of 25

Table of Contents

Overview	3
• Parts	
Install Docker	5
Docker Test Image	6
Docker ESP32-S3 Linux Image	9
Upload the Files to the ESP32-S3	13
 esptool ESP-IDF Prep the Metro ESP32-S3 Binary Files File System and Kernel 	
Boot Linux on the ESP32-S3	16
WiFi Customize	
Customize with menuconfig	18
Boot into Linux	
Customize with ESP-IDF menuconfig	22
Partition TableESP-IDF menuconfig	

© Adafruit Industries Page 2 of 25


Overview

Have you ever wanted to run Linux on a microcontroller like the ESP32-S3? GitHub user jcmvbkbc (https://adafru.it/18Uf) has a Linux for ESP32-S3 script (https://adafru.it/18UB) that lets you do just that! However, compiling it can be tricky depending on your operating system with all of the toolchain dependencies. Don't worry though because there is a way around all of that: a Docker container (https://adafru.it/18UC)! A container is a lightweight and fast virtual computer. The best part is it's easy for people to run no matter what operating system they are on. It's also much simpler and smaller than VirtualBox because it has only the bare essentials.

In this guide, you'll setup and install Docker, run a test Dockerfile to create a test container, run the ESP32-S3 Linux Dockerfile, upload the compiled files to the ESP32-S3 and then perform the ultimate skateboard trick: boot Linux on an ESP32-S3!

This version of Linux is barebones, the file system is utilizing cramfs (https://adafru.it/18UD), so don't expect it to be like booting up a Raspberry Pi with Raspberry Pi OS. You'll access it over serial and you'll only be able to do super basic things but you'll learn a ton along the way.

Parts



Adafruit Metro ESP32-S3 with 16 MB Flash 8 MB PSRAM

What's Metro-shaped and has an ESP32-S3 WiFi module? What has a STEMMA QT connector for I2C devices and a Lipoly charger circuit? What has your favorite Espressif WiFi...

https://www.adafruit.com/product/5500


©Adafruit Industries Page 3 of 25



USB to TTL Serial Cable - Debug / Console Cable for Raspberry Pi

The cable is easiest way ever to connect to your microcontroller/Raspberry Pi/WiFi router serial console port. Inside the big USB plug is a USB<->Serial conversion chip and at...


https://www.adafruit.com/product/954



Break-away 0.1" 36-pin strip male header -Black - 10 pack

Breakaway header is like the duct tape of electronics. It's great for connecting things together, soldering to perf-boards, fits into any breakout or breadboard, etc. We go through...

https://www.adafruit.com/product/392




USB Type A to Type C Cable - approx 1 meter / 3 ft long

As technology changes and adapts, so does Adafruit. This USB Type A to Type C cable will help you with the transition to USB C, even if you're still...


https://www.adafruit.com/product/4474

© Adafruit Industries Page 4 of 25


Install Docker



Go to the Docker website (https://adafru.it/18UE) and download the Docker version for your operating system. Then, launch the installer file that downloads.




After installation finishes, you may be prompted to logout of your system to finish setting things up.




When Docker launches for the first time, you'll be prompted with a service agreement. Click **Accept**.


© Adafruit Industries Page 5 of 25



Then you'll be prompted to sign up for a Docker account. Click the **Sign Up** button to create an account.



After creating an account on the Docker website, you'll be prompted to login for the first time. After logging in, you'll need to select a plan. There is a free plan for Docker (**Personal**) and everything covered in this guide works with the free tier.



Then you can log into the Docker desktop application, where you can access your containers and images.

Next, you'll create a test Docker image to get used to how Docker works and check your workflow.

Docker Test Image

Before you go diving into compiling the Linux kernel, you can run this quick test Docker image to get familiar with Docker.

© Adafruit Industries Page 6 of 25

```
FADockerfile - Notepad++
File Edit Search View Encoding Language Settings Tools Macro Run Plugins Window ?

| Deckerfile 2|
| FROM ubuntu:22.04
| RUN apt-get update | Contraction | Con
```


First, you're going to create a Dockerfile file. These files are run to create the Docker images and they use their own syntax. Copy and paste the following text into your preferred text editor:

```
FROM ubuntu:22.04

RUN apt-get update

ENTRYPOINT ["tail", "-f", "/dev/null"]
```

Then, save the file as **Dockerfile** with no file extension. The Dockerfile you just created builds an Ubuntu 22.04 system. Then, it runs apt-get update and opens a terminal window for you to interact with the system. If you were to leave out the ENTRYPOINT line, the image would simply run apt-get update and then close down.




Next, open up a terminal and navigate to the folder where you just saved your Dockerfile. Run the following command to build the image:


```
docker build -t docker_test .
```

This tells docker to build the Dockerfile as an image and tag it (name it) as docker_test.


© Adafruit Industries Page 7 of 25



After running the command, you'll see Docker go through a series of build steps and then finish.




Go to your Docker desktop application and click on the **Images** tab. You should see your **docker_test** image that you just built.




The image is static, similar to creating a USB drive with installation media if you've ever done a fresh install of Windows or Linux on hardware. To deploy the image that you just built, click on the **Play** button next to the image name. A dialog box will open and you'll click **Run**.

© Adafruit Industries Page 8 of 25



This launches your image into a container. The container is where your virtual computer lives and runs. It is given the name of an adjective along with the name of a scientist as a nickname by default.

If you click on the **Terminal** tab in the container, you can interact with your new Ubuntu image.



On the main Containers page, you can start or stop your container from running by clicking the **Play** or **Stop** buttons on the right-hand side of the window.

Now that you've created your first Dockerfile, image and container, you can try using Docker to compile Linux for the ESP32-S3.

Docker ESP32-S3 Linux Image

To begin, you'll save the Dockerfile below to a folder on your local filesystem. Name it as **Dockerfile** with no file extension, just like you did on the <u>Test Image page</u> (https://adafru.it/18UF).

© Adafruit Industries Page 9 of 25

```
# install autoconf 2.71
RUN wget https://ftp.gnu.org/gnu/autoconf/autoconf-2.71.tar.xz && \
    tar -xf autoconf-2.71.tar.xz && \
    cd autoconf-2.71 && \
    ./configure --prefix=`pwd`/root && \
    make && \
    make install
ENV PATH="$PATH:/app/autoconf-2.71/root/bin"
# dynconfig
RUN git clone https://github.com/jcmvbkbc/xtensa-dynconfig -b original --depth=1 &&
    git clone https://github.com/jcmvbkbc/config-esp32s3 esp32s3 --depth=1 && ∖
    make -C xtensa-dynconfig ORIG=1 CONF DIR=`pwd` esp32s3.so
ENV XTENSA GNU CONFIG="/app/xtensa-dynconfig/esp32s3.so"
# ct-ng cannot run as root, we'll just do everything else as a user
RUN useradd -d /app/build -u 3232 esp32 && mkdir build && chown esp32:esp32 build
USER esp32
# toolchain
RUN cd build && \
    git clone https://github.com/jcmvbkbc/crosstool-NG.git -b xtensa-fdpic --depth=1
    cd crosstool-NG && \
    ./bootstrap && \
    ./configure --enable-local && \
    ./ct-ng xtensa-esp32s3-linux-uclibcfdpic && \
    CT_PREFIX=`pwd`/builds ./ct-ng build || echo "Completed" # the complete ct-ng
build fails but we still get what we wanted!
RUN [ -e build/crosstool-NG/builds/xtensa-esp32s3-linux-uclibcfdpic/bin/xtensa-
esp32s3-linux-uclibcfdpic-gcc ] || exit 1
# kernel and rootfs
RUN cd build && \
    git clone https://github.com/jcmvbkbc/buildroot -b xtensa-2023.02-fdpic --depth=1
    make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3
esp32s3wifi defconfig && \
    buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-
str TOOLCHAIN EXTERNAL PATH `pwd`/crosstool-NG/builds/xtensa-esp32s3-linux-
uclibcfdpic && \
    buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-
str TOOLCHAIN EXTERNAL PREFIX '$(ARCH)-esp32s3-linux-uclibcfdpic' && \
    buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-
str TOOLCHAIN EXTERNAL CUSTOM_PREFIX '$(ARCH)-esp32s3-linux-uclibcfdpic' && \
    make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3
RUN [ -f build/build-xtensa-2023.02-fdpic-esp32s3/images/xipImage -a -f build/build-
xtensa-2023.02-fdpic-esp32s3/images/rootfs.cramfs ] || exit 1
# bootloader
ENV IDF PATH="/app/build/esp-hosted/esp hosted ng/esp/esp driver/esp-idf"
RUN cd build && \
    git clone https://github.com/jcmvbkbc/esp-hosted -b shmem --depth=1 && \
    cd esp-hosted/esp_hosted_ng/esp/esp_driver && cmake . && \
    cd esp-idf && . ./export.sh && \
    cd ../network_adapter && idf.py set-target esp32s3 && \
    cp sdkconfig.defaults.esp32s3 sdkconfig && idf.py build
# move files over
RUN cd build && mkdir release && \
    cp esp-hosted/esp hosted ng/esp/esp driver/network adapter/build/bootloader/
bootloader.bin release && \
    cp esp-hosted/esp_hosted_ng/esp/esp_driver/network_adapter/build/
partition table/partition-table.bin release && \
    cp esp-hosted/esp hosted ng/esp/esp driver/network adapter/build/
```

©Adafruit Industries Page 10 of 25

```
network_adapter.bin release && \
    cp build-xtensa-2023.02-fdpic-esp32s3/images/xipImage release && \
    cp build-xtensa-2023.02-fdpic-esp32s3/images/rootfs.cramfs release

# keep docker running so we can debug/rebuild :)
USER root
ENTRYPOINT ["tail", "-f", "/dev/null"]

# grab the files with `docker cp CONTAINER_NAME:/app/build/release/\* .`
# now you can burn the files from the 'release' folder with:
# python esptool.py --chip esp32s3 -p /dev/ttyUSB0 -b 921600 --before=default_reset --after=hard_reset write_flash 0x0 bootloader.bin 0x10000 network_adapter.bin 0x8000 partition-table.bin
# next we can burn in the kernel and filesys with parttool, which is part of esp-idf # parttool.py write_partition --partition-name linux --input xipImage
# parttool.py write_partition --partition-name rootfs --input rootfs.cramfs
```

As you can see, this Dockerfile is a lot more detailed than the test image that you just ran. It installs all of the toolchains and dependencies on an Ubuntu build and then runs the script to compile the files needed to load onto the ESP32-S3.

```
PS Flasg32+3_linux docker build -t esp32-15_linux .

[c] Building 1804.6 (18/18) FINISHED

Cocker:Cefault


Still S
```

The steps for building are the same though. Open a terminal window, navigate to the folder where you saved the Dockerfile and enter:

```
docker build -t esp32-s3 linux .
```

This builds the image and names it **esp32-s3_linux**.


© Adafruit Industries Page 11 of 25



After building, go to the Docker desktop app and look under Images. Select your newly created esp32-s3_linux image and click the Play button. Then click Run to start a container with the image.




Once the container opens, go to the **Terminal** tab. You'll be able to interact with the Ubuntu machine that has your compiled files for the ESP32-S3.



If you change directories to the releases folder (cd /app/build/releases) you'll see the kernel, file system and binary files that will be loaded onto your ESP32-S3. To use these files, you'll need to copy them to your local filesystem out of the Docker container.


© Adafruit Industries Page 12 of 25



To do this, go back to a terminal window on your local desktop and navigate to the directory where you saved the Dockerfile. Enter the following command:

docker cp CONTAINER-NAME:/app/ build/release/ bin files

Replace CONTAINER-NAME with the name of your container in the Docker app. This copies the /release folder from your container in Docker to a folder called / bin_files.



Open the file location on your computer. You should see the five files now stored locally in the folder. This will allow you to use esptool and the ESP-IDF to load the files onto your ESP32-S3.

Upload the Files to the ESP32-S3

You will need two utilities from Espressif installed on your computer in order to upload the compiled files onto the ESP32-S3: esptool and the ESP-IDF.

esptool

You'll use esptool to upload the binary files to the ESP32-S3. esptool is installed with pip. Open a terminal window and enter:

pip install esptool

For more information on esptool, you can check out the <u>documentation from</u> Espressif (https://adafru.it/18Va).

©Adafruit Industries Page 13 of 25

Espressif Documentation for esptool

https://adafru.it/18Va

ESP-IDF


The kernel and filesystem are written to the ESP32-S3 using parttool.py, which is a tool included in the ESP-IDF. You can install the ESP-IDF as a part of your IDE or separately on your local computer. Espressif has documentation and installers (https://adafru.it/18Vb) on their site.

ESP-IDF Installers and Installation Documentation

https://adafru.it/18Vb


Prep the Metro ESP32-S3

Now you finally get to play with hardware. You'll use the Metro ESP32-S3, which has 16 MB of Flash and 8 MB of PSRAM making it perfect for this skateboard trick.



You'll want to upload the files that you just built over hardware UART. The RX and TX hardware UART pins are accessible next to the ESP32-S3 module on the board. Solder two headers to those pins.

© Adafruit Industries Page 14 of 25



Break-away 0.1" 36-pin strip male header -Black - 10 pack

Breakaway header is like the duct tape of electronics. It's great for connecting things together, soldering to perf-boards, fits into any breakout or breadboard, etc. We go through...

https://www.adafruit.com/product/392




USB to TTL Serial Cable - Debug / Console Cable for Raspberry Pi

The cable is easiest way ever to connect to your microcontroller/Raspberry Pi/WiFi router serial console port. Inside the big USB plug is a USB<->Serial conversion chip and at...

https://www.adafruit.com/product/954

Attach a USB to serial cable to the Metro ESP32-S3. You should see the board power up once you plug in the USB cable.



USB RX to ESP32-S3 TX (white wire)
USB TX to ESP32-S3 RX (green wire)
USB power to ESP32-S3 VIN (red wire)
USB ground to ESP32-S3 GND (black wire)

Binary Files

First, you'll upload the three binary files (bootloader.bin, network_adapter.bin and partition-table.bin) to the ESP32-S3 with esptool.

© Adafruit Industries Page 15 of 25

Put the Metro ESP32-S3 into bootloader mode by holding down the boot button, pressing the reset button and then releasing the boot button. Then, open a terminal window and navigate to the directory where you saved the exported files from the Docker container. Enter this command to upload the three files to the ESP32-S3:

```
python esptool.py --chip esp32s3 -p YOUR-PORT-HERE -b 921600 --before=default_reset
--after=hard_reset write_flash 0x0 bootloader.bin 0x10000 network_adapter.bin
0x8000 partition-table.bin
```

Replace YOUR-PORT-HERE with the USB port number that the ESP32-S3 is attached to. On Linux or Mac it may look like /dev/ttyUSB0. On Windows, it will be COM followed by a number. For example, COM3.

File System and Kernel

Next, you'll use the ESP-IDF terminal to upload the file system and kernel file. Open an ESP-IDF terminal window and navigate to the directory where you saved the exported files from the Docker container. First, put the Metro ESP32-S3 into bootloader mode by holding down the boot button, pressing the reset button and then releasing the boot button. Then upload the kernel file (xiplmage) first with:

```
parttool.py write_partition --partition-name linux --input xipImage
```

Put the Metro ESP32-S3 into bootloader mode again and then upload the file system file (rootfs.cramfs) with:


```
parttool.py write_partition --partition-name rootfs --input rootfs.cramfs
```

Next you'll boot into Linux on an ESP32-S3!


Boot Linux on the ESP32-S3

You'll be able to log into Linux on the ESP32-S3 by using a serial connection.

© Adafruit Industries Page 16 of 25



Using your preferred serial client, open a serial connection with the hardware UART port on the ESP32-S3 at a 115200 baudrate.



Press the reset button on the ESP32-S3. In your serial monitor, you should see Linux booting up. When its ready, it will prompt you for a login. Enter root. This will bring you to the filesystem.

You may see spurious FW_MAIN print statements randomly pop up in your serial monitor. This is the WiFi core printing status messages and is normal for this build.

WiFi

To connect to WiFi, enter the following commands:

Replace YOUR-SSID-HERE and YOUR-SSID-PASSWORD-HERE with your network SSID and SSID password. This creates a wpa_supplicant configuration file in the /tmp folder that will let you connect to a secured network.

© Adafruit Industries Page 17 of 25

You can test your network connection by pinging a URL with:

```
ping google.com
```

Press Control + C to stop pinging the URL. You should see packets transmitted.

Customize

Otherwise there isn't a lot more that you can do with this Linux installation. The following page will show you how to run the <u>Buildroot menuconfig</u> (https://adafru.it/18Vc) in the Docker container to customize the image and recompile it.

Customize with menuconfig

You've booted Linux on an ESP32-S3 and now you want to add some customization. You can do that with the menuconfig tool in /buildroot. This lets you select options to include in your kernel and filesystem. After running menuconfig, you'll rebuild the files and upload them to the ESP32-S3 partition tables so that you can boot into your new Linux image.

First you'll clean up the previously compiled files by running make clean in the / buildroot directory.

```
cd /app/build/buildroot
make clean
```

Next, you'll run some commands to rebuild the filesystem and kernel. You're essentially re-running commands manually that are performed in the Dockerfile. First, you'll go up one level in the directory with:

```
cd ..
```

Then you'll clean the previous compilation run with:

```
make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3 clean
```

©Adafruit Industries Page 18 of 25


Run the following commands to prep the .config file. This file contains all of the build settings.

```
make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3 esp32s3wifi_defconfig
buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-str
TOOLCHAIN_EXTERNAL_PATH `pwd`/crosstool-NG/builds/xtensa-esp32s3-linux-uclibcfdpic
buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-str
TOOLCHAIN_EXTERNAL_PREFIX '$(ARCH)-esp32s3-linux-uclibcfdpic'
buildroot/utils/config --file build-xtensa-2023.02-fdpic-esp32s3/.config --set-str
TOOLCHAIN_EXTERNAL_CUSTOM_PREFIX '$(ARCH)-esp32s3-linux-uclibcfdpic'
```

Then you'll enter the **menuconfig** tool with:

```
make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3 menuconfig
```

This opens a GUI tool that you can navigate with the arrow keys on your keyboard.





Start by going to **Target options** and making sure that the image is being built for the correct target.

Target Architecture: Xtensa

Target Architecture Variant: **Dynamic**

Xtensa processor configuration

Target Architecture Endianness: Little endian


(*) MMU support

Target Binary Format: ELF


©Adafruit Industries Page 19 of 25



Navigate to the **System configuration** menu. On this page, you'll edit the **hostname** and **welcome banner**.




Select **System hostname** and enter the hostname that you would like for your system to have. Highlight **OK** and hit **enter** to confirm.



Select the System banner and enter the custom welcome message you'd like to see when you log into the system.

Highlight **OK** and hit **enter** to confirm.

© Adafruit Industries Page 20 of 25



Select **Save** on the main GUI. This will open a dialog box showing that you are saving to the **.config** file. Select **OK** to confirm.

Now you'll use make to compile all of the build settings and build the filesystem and kernel files.

```
make -C buildroot 0=`pwd`/build-xtensa-2023.02-fdpic-esp32s3

[ -f build/build-xtensa-2023.02-fdpic-esp32s3/images/xipImage -a -f build/build-xtensa-2023.02-fdpic-esp32s3/images/rootfs.cramfs ] || exit 1
```

You'll move the files to the /release folder with:

```
cd build

cp build-xtensa-2023.02-fdpic-esp32s3/images/xipImage release
cp build-xtensa-2023.02-fdpic-esp32s3/images/rootfs.cramfs release
```

You'll move the files from Docker to your local filesystem by opening a terminal on your local system, navigating to the directory where you want the files to be and entering:

```
docker cp YOUR-CONTAINER-NAME-HERE:/app/build/release bin_files
```

This is the same step that you did earlier with the unmodified files. Next, you'll flash the **xipImage** and **rootfs.cramfs** files using **parttool.py** in the ESP-IDF as described on the Upload Files page (https://adafru.it/18Vd).

© Adafruit Industries Page 21 of 25

Boot into Linux

```
COM3-PuTTY

[ 3.215638] devtmpfs: mounted
[ 3.219734] Freeing unused kernel image (initmem) memory: 8K
[ 3.22365] This architecture does not have kernel memory protection.
[ 3.230399] Run /sbin/init as init process
[ 3.232858] with arguments:
[ 3.2435793] /sbin/init
[ 3.240101] with environment:
[ 3.241630] HOME=/
[ 3.24360] TERM=linux

Starting syslogd: OK
Starting klogd: OK
Starting klogd: OK
Starting retwork: Successfully initialized wpa_supplicant
I (14200) FW_MAIN: Scan request

OK
Starting inetd: OK

you're running linux on an esp32-s3
metro_esp32-s3 login: root
~ # I (21830) FW_MAIN: Scan request
```

Log into the ESP32-S3 over serial to see your Linux system in action. If all went well, you should be greeted with your custom welcome message and hostname.

Customize with ESP-IDF menuconfig

On the previous page you customized the kernel and filesystem with buildroot's menuconfig tool. The ESP-IDF has a similar menuconfig (https://adafru.it/18Ve) that lets you adjust parameters for the targeted ESP chip, such as flash size and partition table. Just like how you recompiled the file system and kernel, you can recompile the bootloader, partition table and network adapter .bin files using the following steps.

Partition Table


The partition table in an ESP-IDF project determines the file structure on the ESP32 chip. In the Docker container, the partition table file is located in /app/build/esp-hosted/esp_hosted_ng/esp_driver/network_adapter/partition_table.esp32s3

The default partition table is setup as follows:

## Label	type	ST	Offset	Length
nvs,	data,	nvs,	0x0000a000,	0x00005000

©Adafruit Industries Page 22 of 25

phy_init,	data,	phy,	0x0000f000,	0x00001000
factory,	app,	factory,	0x00010000,	0x000f0000
linux,	0x40,	0x0,	0x00100000,	0x00300000
rootfs,	0x40,	0x1,	0x00400000,	0x00400000



You can edit the partition table directly in the Docker container by going to the **Files** tab and navigating to the file location. **Right-click** on the partition table file and you can edit it in the text editor that opens at the bottom of the screen.

The changes to the partition table only take effect after recompiling the ESP-IDF project. These steps are outlined next.

ESP-IDF menuconfig

To recompile the ESP-IDF generated .bin files, you'll run the ESP-IDF steps from the Dockerfile. In the **Terminal tab** in your Docker container, run these commands:

```
cd esp-hosted/esp_hosted_ng/esp/esp_driver & amp; & amp; cmake .
cd esp-idf & amp; & amp; . ./export.sh
cd ../network_adapter & amp; & amp; idf.py set-target esp32s3
cp sdkconfig.defaults.esp32s3 sdkconfig
```

Then enter the **menuconfig tool** with:

```
idf.py menuconfig
```

© Adafruit Industries Page 23 of 25


```
SDK tool configuration --->

Build type --->
Application manager --->
Bootloader config --->
Security features --->
Serial flasher config --->
Partition Table --->
Example Configuration --->
Compiler options --->
Compatibility options --->
Compatibility options --->

(Space/Enter) Toggle/enter [ESC] Leave menu [S] Save [O] Load [?] Symbol Linfo [/] Jump to symbol [E] Toggle show-help mode [C] Toggle show-name mode [A] Toggle show-all mode [O] Quit (prompts for save) [O] Save minital config (advanced)
```




You can change the flash size to match your target board by navigating to **Serial flasher config - flash size**. There you can select the flash size on your board. In the case of the Metro ESP32-S3, its **16MB**.



You can also change or confirm your partition table by navigating to the **Partition Table** page.

© Adafruit Industries Page 24 of 25



When you're finished, save your configuration as **sdkconfig** (the default option) and then **exit menuconfig**.

Next you'll build your project with:

```
idf.py build
```

Finally you'll copy your generated .bin files to the /releases folder in the Docker container:

```
cd /app/build

cp esp-hosted/esp_hosted_ng/esp/esp_driver/network_adapter/build/bootloader/
bootloader.bin release
cp esp-hosted/esp_hosted_ng/esp/esp_driver/network_adapter/build/partition_table/
partition-table.bin release
cp esp-hosted/esp_hosted_ng/esp/esp_driver/network_adapter/build/
network_adapter.bin release
```

And copy the newly generated .bin files to your local filesystem, just as you did <u>earlier</u> in the guide. (https://adafru.it/18Vf)

```
docker cp CONTAINER-NAME:/app/build/release/ bin_files
```

Now you can load your new .bin files onto your ESP32-S3 using esptool. (https://adafru.it/18Vd)

© Adafruit Industries Page 25 of 25