

Rooms协议文档

设备发现协议

代码块

```
1  //请求组播设备发现    224.0.2.251:6565
2  //请求消息体    Discovery
3  {
4      "method":"DeviceDiscovery"
5  }
6
7
8  //请求响应
9  {
10     "model":"ROOMS",          //ROOMS, AIR, DECODE, CAMERA
11     "sn":"AW0BLCAB9A99000080",
12     "version":"V1.0.0.0.R.240909",
13     "name":"ROOMS_PLUS",
14     "ipv4":"192.168.16.23",
15     "protocols":[
16         {
17             "type":"ws",        //    http/ws,  目前只支持websocket协议, pp:私有协议
18             "port":"8080"       // 50362 私有协议端口
19         }
20     ]
21 }
```

协议介绍

该协议作为我司设备/平台之间互联互通协议，协议内容基于json文本格式实现，提供完善的会话控制，请求/响应，事件通知等机制。且与具体网络传输层协议解耦，可使用http/websocket/udp等协议实现，目前该协议设备端支持了websocket传输。

通用字段介绍

op(报文类型)

该字段常用值解析

字段值	值解析
0	Hello 用于握手，创建会话
1	HelloAck 握手响应报文类型
5	Subscribe 订阅请求
6	Event 事件通知请求
7	Request 资源方法请求
8	RequestResponse 请求的响应报文
14	bye 结束会话请求报文
15	byeAck bye请求的响应报文

协议框架固定字段信息描述

字段	字段介绍
adxdpVersion	版本信息
rpcVersion	版本信息
supportedMethods	支持的方法集合
supportedEvents	支持的事件集合
op	操作类型
d	请求描述体
method	请求方法名称
sid	会话id,握手请求创建sid，后续所有消息都需要携带该字段
params	请求参数
id	请求id,每一个method请求，都需要携带该字段，用来唯一标识一个请求，响应的报文也要携带该字段
status	请求响应的状态信息

code	错误码
comment	错误描述信息
result	请求结果信息
event	事件名称
data	事件内容信息

常用错误码

代码块

```
1
2     enum RequestStatus {
3         /**
4          * Unknown status, should never be used.
5          *
6          * @enumIdentifier Unknown
7          * @enumValue 0
8          * @enumType RequestStatus
9          * @rpcVersion -1
10         * @initialVersion 5.0.0
11         * @api enums
12         */
13         Unknown = 0,
14
15         /**
16          * For internal use to signify a successful field check.
17          *
18          * @enumIdentifier NoError
19          * @enumValue 10
20          * @enumType RequestStatus
21          * @rpcVersion -1
22          * @initialVersion 5.0.0
23          * @api enums
24          */
25         NoError = 10,
26
27         /**
28          * The requestHandler has succeeded.
29          *
30          * @enumIdentifier Success
31          * @enumValue 100
```

```
32      * @enumType RequestStatus
33      * @rpcVersion -1
34      * @initialVersion 5.0.0
35      * @api enums
36      */
37      Success = 100,
38
39      /**
40       * The `requestType` field is missing from the requestHandler data.
41       *
42       * @enumIdentifier MissingRequestType
43       * @enumValue 203
44       * @enumType RequestStatus
45       * @rpcVersion -1
46       * @initialVersion 5.0.0
47       * @api enums
48       */
49      MissingRequestType = 203,
50
51      /**
52       * The requestHandler type is invalid or does not exist.
53       *
54       * @enumIdentifier UnknownRequestType
55       * @enumValue 204
56       * @enumType RequestStatus
57       * @rpcVersion -1
58       * @initialVersion 5.0.0
59       * @api enums
60       */
61      UnknownRequestType = 204,
62
63      /**
64       * Generic error code.
65       *
66       * Note: A comment is required to be provided by obs-websocket.
67       *
68       * @enumIdentifier GenericError
69       * @enumValue 205
70       * @enumType RequestStatus
71       * @rpcVersion -1
72       * @initialVersion 5.0.0
73       * @api enums
74       */
75      GenericError = 205,
76
77      /**
78       * The requestHandler batch execution type is not supported.
79       *
80       * @enumIdentifier UnsupportedRequestBatchExecutionType
81       * @enumValue 206
```

```

79      * @enumType RequestStatus
80      * @rpcVersion -1
81      * @initialVersion 5.0.0
82      * @api enums
83      */
84      UnsupportedRequestBatchExecutionType = 206,
85      /**
86       * The server is not ready to handle the requestHandler.
87       *
88       * Note: This usually occurs during OBS scene collection change or
      exit. Requests may be tried again after a delay if this code is given.
89       *
90       * @enumIdentifier NotReady
91       * @enumValue 207
92       * @enumType RequestStatus
93       * @rpcVersion -1
94       * @initialVersion 5.3.0
95       * @api enums
96       */
97      NotReady = 207,
98
99      /**
100     * A required requestHandler field is missing.
101     *
102     * @enumIdentifier MissingRequestField
103     * @enumValue 300
104     * @enumType RequestStatus
105     * @rpcVersion -1
106     * @initialVersion 5.0.0
107     * @api enums
108     */
109     MissingRequestField = 300,
110     /**
111     * The requestHandler does not have a valid requestData object.
112     *
113     * @enumIdentifier MissingRequestData
114     * @enumValue 301
115     * @enumType RequestStatus
116     * @rpcVersion -1
117     * @initialVersion 5.0.0
118     * @api enums
119     */
120     MissingRequestData = 301,
121
122     /**
123     * Generic invalid requestHandler field messageHandler.
124     *

```

```

125      * Note: A comment is required to be provided by obs-websocket.
126      *
127      * @enumIdentifier InvalidRequestField
128      * @enumValue 400
129      * @enumType RequestStatus
130      * @rpcVersion -1
131      * @initialVersion 5.0.0
132      * @api enums
133      */
134      InvalidRequestField = 400,
135      /**
136      * A requestHandler field has the wrong data type.
137      *
138      * @enumIdentifier InvalidRequestFieldType
139      * @enumValue 401
140      * @enumType RequestStatus
141      * @rpcVersion -1
142      * @initialVersion 5.0.0
143      * @api enums
144      */
145      InvalidRequestFieldType = 401,
146      /**
147      * A requestHandler field (number) is outside of the allowed range.
148      *
149      * @enumIdentifier RequestFieldOutOfRange
150      * @enumValue 402
151      * @enumType RequestStatus
152      * @rpcVersion -1
153      * @initialVersion 5.0.0
154      * @api enums
155      */
156      RequestFieldOutOfRange = 402,
157      /**
158      * A requestHandler field (string or array) is empty and cannot be.
159      *
160      * @enumIdentifier RequestFieldEmpty
161      * @enumValue 403
162      * @enumType RequestStatus
163      * @rpcVersion -1
164      * @initialVersion 5.0.0
165      * @api enums
166      */
167      RequestFieldEmpty = 403,
168      /**
169      * There are too many requestHandler fields (eg. a requestHandler takes
170      two optionals, where only one is allowed at a time).

```

```
171      * @enumIdentifier TooManyRequestFields
172      * @enumValue 404
173      * @enumType RequestStatus
174      * @rpcVersion -1
175      * @initialVersion 5.0.0
176      * @api enums
177      */
178      TooManyRequestFields = 404,
179
180      /**
181      * An output is running and cannot be in order to perform the
requestHandler.
182      *
183      * @enumIdentifier OutputRunning
184      * @enumValue 500
185      * @enumType RequestStatus
186      * @rpcVersion -1
187      * @initialVersion 5.0.0
188      * @api enums
189      */
190      OutputRunning = 500,
191      /**
192      * An output is not running and should be.
193      *
194      * @enumIdentifier OutputNotRunning
195      * @enumValue 501
196      * @enumType RequestStatus
197      * @rpcVersion -1
198      * @initialVersion 5.0.0
199      * @api enums
200      */
201      OutputNotRunning = 501,
202      /**
203      * An output is paused and should not be.
204      *
205      * @enumIdentifier OutputPaused
206      * @enumValue 502
207      * @enumType RequestStatus
208      * @rpcVersion -1
209      * @initialVersion 5.0.0
210      * @api enums
211      */
212      OutputPaused = 502,
213      /**
214      * An output is not paused and should be.
215      *
216      * @enumIdentifier OutputNotPaused
```

```

217      * @enumValue 503
218      * @enumType RequestStatus
219      * @rpcVersion -1
220      * @initialVersion 5.0.0
221      * @api enums
222      */
223      OutputNotPaused = 503,
224      /**
225       * An output is disabled and should not be.
226       *
227       * @enumIdentifier OutputDisabled
228       * @enumValue 504
229       * @enumType RequestStatus
230       * @rpcVersion -1
231       * @initialVersion 5.0.0
232       * @api enums
233       */
234      OutputDisabled = 504,
235      /**
236       * Studio mode is active and cannot be.
237       *
238       * @enumIdentifier StudioModeActive
239       * @enumValue 505
240       * @enumType RequestStatus
241       * @rpcVersion -1
242       * @initialVersion 5.0.0
243       * @api enums
244       */
245      StudioModeActive = 505,
246      /**
247       * Studio mode is not active and should be.
248       *
249       * @enumIdentifier StudioModeNotActive
250       * @enumValue 506
251       * @enumType RequestStatus
252       * @rpcVersion -1
253       * @initialVersion 5.0.0
254       * @api enums
255       */
256      StudioModeNotActive = 506,
257
258      /**
259       * The resource was not found.
260       *
261       * Note: Resources are any kind of object in obs-websocket, like
262       inputs, profiles, outputs, etc.
262       *

```



```

263      * @enumIdentifier ResourceNotFound
264      * @enumValue 600
265      * @enumType RequestStatus
266      * @rpcVersion -1
267      * @initialVersion 5.0.0
268      * @api enums
269      */
270      ResourceNotFound = 600,
271      /**
272       * The resource already exists.
273       *
274       * @enumIdentifier ResourceAlreadyExists
275       * @enumValue 601
276       * @enumType RequestStatus
277       * @rpcVersion -1
278       * @initialVersion 5.0.0
279       * @api enums
280       */
281      ResourceAlreadyExists = 601,
282      /**
283       * The type of resource found is invalid.
284       *
285       * @enumIdentifier InvalidResourceType
286       * @enumValue 602
287       * @enumType RequestStatus
288       * @rpcVersion -1
289       * @initialVersion 5.0.0
290       * @api enums
291       */
292      InvalidResourceType = 602,
293      /**
294       * There are not enough instances of the resource in order to perform
the requestHandler.
295       *
296       * @enumIdentifier NotEnoughResources
297       * @enumValue 603
298       * @enumType RequestStatus
299       * @rpcVersion -1
300       * @initialVersion 5.0.0
301       * @api enums
302       */
303      NotEnoughResources = 603,
304      /**
305       * The state of the resource is invalid. For example, if the resource
is blocked from being accessed.
306       *
307       * @enumIdentifier InvalidResourceState

```

```

308      * @enumValue 604
309      * @enumType RequestStatus
310      * @rpcVersion -1
311      * @initialVersion 5.0.0
312      * @api enums
313      */
314      InvalidResourceState = 604,
315      /**
316       * The specified input (obs_source_t-OBS_SOURCE_TYPE_INPUT) had the
wrong kind.
317       *
318       * @enumIdentifier InvalidInputKind
319       * @enumValue 605
320       * @enumType RequestStatus
321       * @rpcVersion -1
322       * @initialVersion 5.0.0
323       * @api enums
324       */
325      InvalidInputKind = 605,
326      /**
327       * The resource does not support being configured.
328       *
329       * This is particularly relevant to transitions, where they do not
always have changeable settings.
330       *
331       * @enumIdentifier ResourceNotConfigurable
332       * @enumValue 606
333       * @enumType RequestStatus
334       * @rpcVersion -1
335       * @initialVersion 5.0.0
336       * @api enums
337       */
338      ResourceNotConfigurable = 606,
339      /**
340       * The specified filter (obs_source_t-OBS_SOURCE_TYPE_FILTER) had the
wrong kind.
341       *
342       * @enumIdentifier InvalidFilterKind
343       * @enumValue 607
344       * @enumType RequestStatus
345       * @rpcVersion -1
346       * @initialVersion 5.0.0
347       * @api enums
348       */
349      InvalidFilterKind = 607,
350
351      /**

```

```

352      * Creating the resource failed.
353      *
354      * @enumIdentifier ResourceCreationFailed
355      * @enumValue 700
356      * @enumType RequestStatus
357      * @rpcVersion -1
358      * @initialVersion 5.0.0
359      * @api enums
360      */
361      ResourceCreationFailed = 700,
362      /**
363      * Performing an action on the resource failed.
364      *
365      * @enumIdentifier ResourceActionFailed
366      * @enumValue 701
367      * @enumType RequestStatus
368      * @rpcVersion -1
369      * @initialVersion 5.0.0
370      * @api enums
371      */
372      ResourceActionFailed = 701,
373      /**
374      * Processing the requestHandler failed unexpectedly.
375      *
376      * Note: A comment is required to be provided by obs-websocket.
377      *
378      * @enumIdentifier RequestProcessingFailed
379      * @enumValue 702
380      * @enumType RequestStatus
381      * @rpcVersion -1
382      * @initialVersion 5.0.0
383      * @api enums
384      */
385      RequestProcessingFailed = 702,
386      /**
387      * The combination of requestHandler fields cannot be used to perform
an action.
388      *
389      * @enumIdentifier CannotAct
390      * @enumValue 703
391      * @enumType RequestStatus
392      * @rpcVersion -1
393      * @initialVersion 5.0.0
394      * @api enums
395      */
396      CannotAct = 703,

```

设备连接握手创建会话

客户端发起握手协议，将版本信息/支持的方法/支持的事件告诉对端，对端创建会话，生成全局唯一的sid。

代码块

```
1  //请求握手连接
2  {
3      "d": {
4          "adxdpVersion": "5.2.3",
5          "rpcVersion": 1,
6          "supportedMethods": [
7              "GetVersion",
8              "StartAgentReboot",
9              "KeepAlive",
10             "StartDeviceReboot",
11             "StartAgentUpgrade",
12             "GetDeviceList"
13         ],
14         "supportedEvents": [
15             "EventUpdateDevice",
16             "EventUpgradeProgress"
17         ]
18     },
19     "op": 0
20 }
21
22
23 //握手响应
24 {
25     "d": {
26         "negotiatedRpcVersion": 1,
27         "expireIn": 300,
28         "supportedMethods": [
29             "GetVersion",
30             "StartAgentReboot",
31             "KeepAlive",
32             "StartDeviceReboot",
```

```
33         "StartAgentUpgrade",
34         "GetDeviceList"
35     ],
36     "supportedEvents": [
37         "EventUpdateDevice",
38         "EventUpgradeProgress"
39     ]
40 },
41 "op": 1,
42 "sid": "123456"    //后续所有请求消息都要携带sid
43 }
44
45
46
47
```

设备连接断开挥手销毁会话

代码块

```
1  //请求销毁会话
2  {
3      "d": {},
4      "op": 14,
5      "sid": "1234567"
6  }
7
8
9  //销毁会话响应
10 {
11     "d": {},
12     "op": 15,
13     "sid": "1234567"
14 }
15
```

会话协议保活-KeepAlive

代码块

```

1  //保活请求
2  {
3      "d": {
4          "id": "ab22-dddaa",      //请求id
5          "method": "KeepAlive"
6      },
7      "op": 7,
8      "sid": "123456"
9  }
10
11
12 //保活响应
13 {
14     "d": {
15         "id": "ab22-dddaa",
16         "method": "KeepAlive",
17         "status": {
18             "code": 100,
19             "result": true
20         }
21     },
22     "op": 8,
23     "sid": 123456
24 }
25

```

输入源管理

创建输入源-CreateInputSource

代码块

```

1  //输入源取流地址规则    rtsp://[ip]:554/input/[inputSourceId]
2  //创建输入源，外部只支持创建Network类型的输入源
3  {
4      "op": 7,
5      "sid": "123456",
6      "d": {
7          "id": "ab22-dddaa",
8          "method": "CreateInputSource",
9          "params": {
10             "name": "V520D-V1",
11             "type": "Network",
12             "streamContent": "rtsp://192.168.16.8/mainstream"
13         }
14     }
15 }

```

```
14     }
15 }
16
17
18 //正常响应
19 {
20     "op": 8,
21     "sid": "123456",
22     "d":{
23         "id": "ab22-dddaa",
24         "method":"CreateInputSource",
25         "status": {
26
27
28             "code": 100,
29             "result": true
30         },
31         "result":{
32             "inputSourceId": 6,
33             "name":"V520D-V1"
34         }
35     }
36 }
37
38
39 //异常响应
40 {
41     "op": 8,
42     "sid": "123456",
43     "d":{
44         "id": "ab22-dddaa",
45         "method":"CreateInputSource",
46         "status": {
47             "code": 205,
48             "result": false,
49             "comment":"the inputSource. has existed"
50         }
51     }
52 }
```

获取输入源列表-GetInputSource

代码块

```

1
2
3 //获取输入源 请求
4 {
5     "op": 7,
6     "sid": "123456",
7     "d":{
8         "id": "ab22-dddaa",
9         "method":"GetInputSource",
10        "params":{}
11    }
12 }
13
14
15 //响应
16 {
17     "op": 8,
18     "sid": "123456",
19     "d":{
20         "id": "ab22-dddaa",
21         "method":"GetInputSource",
22         "status": {
23             "code": 100,
24             "result": true
25         },
26         "result":{
27             "sourceList":[
28                 {
29                     "name":"USB-1",           //输入源名称
30                     "type":"USB-1",           //输入源接口类型  USB-
31                                     1/USB-2/HDMI-IN/LINE-IN 固定输入源类型
32                     "ability":"video/audio",   //输入源流能力集
33                                     video(只有视频数据), audio(只有音频数据), video/audio(音视频混合数据) 0x
34                     "streamContent":"",        //流描述信息
35                                     //输入源流描述
36                     "inputSourceId": 1,         //输入源唯一id, 后续使
37                                     用都用id来操作
38                     "status":true               //输入源接口是否正常连接设
39                                     备, 可拉流
40                 },
41                 {
42                     "name":"USB-2",
43                     "type":"USB-2",
44                     "ability":"video/audio",
45                     "streamContent":"",
46                     "inputSourceId": 2,
47                     "status":false

```



```

43         },
44         {
45             "name": "HDMI-IN",
46             "type": "HDMI-IN",
47             "ability": "video/audio",
48             "streamContent": "",
49             "inputSourceId": 3,
50             "status": true
51         },
52         {
53             "name": "LINE-IN",
54             "type": "LINE-IN",
55             "ability": "audio",
56             "streamContent": "",
57             "inputSourceId": 4,
58             "status": true
59         },
60         {
61             "name": "Network-1",
62             "type": "Network",
63             "ability": "video/audio",
64             "streamContent": "rtsp://192.168.16.12/live/mainstream",
65             "inputSourceId": 5,
66             "status": false //未开启场景，网络流该状态始终为false
67         }
68     ]
69 }
70 }
71 }

```

设置输入源信息-SetInputSource

代码块

```

1
2 //修改输入源，外部只支持修改Network类型的输入源
3 {
4     "op": 7,
5     "sid": "123456",
6     "d": {
7         "id": "ab22-dddaa",
8         "method": "SetInputSource"
9         "params": {
10             "inputSourceId": 6

```

```

11         "streamContent": "rtsp://192.168.16.12/live/mainstream" //支持设置
    输入源的content信息/name信息
12         "name": "Network-1",
13     }
14 }
15 }
16
17
18 //响应
19 {
20     "op": 8,
21     "sid": "123456",
22     "d": {
23         "id": "ab22-dddaa",
24         "method": "SetInputSource",
25         "status": {
26             "code": 100,
27             "result": true
28         }
29     }
30 }
31
32 //错误响应
33 {
34     "op": 8,
35     "sid": "123456",
36     "d": {
37         "id": "ab22-dddaa",
38         "method": "SetInputSource",
39         "status": {
40             "code": 205,
41             "result": false,
42             "comment": "the input source not exist"
43         }
44     }
45 }

```

删除输入源-DeleteInputSource

代码块

```

1
2 //删除输入源，外部只支持删除Network类型的输入源
3
4 {
5     "op": 7,

```

```

6      "sid": "123456",
7      "d":{
8          "id": "ab22-dddaa",
9          "method":"DeleteInputSource"
10         "params":{
11             "inputSourceId": 6
12         }
13     }
14 }
15
16
17 //响应
18 {
19     "op": 8,
20     "sid": "123456",
21     "d":{
22         "id": "ab22-dddaa",
23         "method":"DeleteInputSource",
24         "status": {
25             "code": 100,
26             "result": true
27         }
28     }
29 }
30
31 //错误响应
32 {
33     "op": 8,
34     "sid": "123456",
35     "d":{
36         "id": "ab22-dddaa",
37         "method":"DeleteInputSource",
38         "status": {
39             "code": 205,
40             "result": false,
41             "comment":"the inputSource not exist"
42         }
43     }
44 }

```

开启网络输入源拉流-OpenNetInputSource

代码块

```
1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"OpenNetInputSource"
8          "params":{
9              "inputSourceId": 6
10         }
11     }
12 }
13
14 //响应
15 {
16     "op": 8,
17     "sid": "123456",
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"OpenNetInputSource",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
27
28
29 //错误响应
30 {
31     "op": 8,
32     "sid": "123456",
33     "d":{
34         "id": "ab22-dddaa",
35         "method":"OpenNetInputSource",
36         "status": {
37             "code": 205,
38             "result": false,
39             "comment":"the inputSource not exist"
40         }
41     }
42 }
43
```

关闭网络输入源拉流-CloseNetInputSource

代码块

```
1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"CloseNetInputSource"
8          "params":{
9              "inputSourceId": 6
10         }
11     }
12 }
13
14 //响应
15 {
16     "op": 8,
17     "sid": "123456",
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"CloseNetInputSource",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
27
28
29 //错误响应
30 {
31     "op": 8,
32     "sid": "123456",
33     "d":{
34         "id": "ab22-dddaa",
35         "method":"CloseNetInputSource",
36         "status": {
37             "code": 205,
38             "result": false,
39             "comment":"the inputSource not exist"
40         }
41     }
42 }
```

输出源管理

获取输出源列表-GetOutputSource

代码块

```
1
2
3 //获取输出源 请求
4 {
5     "op": 7,
6     "sid": "123456",
7     "d":{
8         "id": "ab22-dddaa",
9         "method":"GetOutputSource",
10        "params":{
11
12        }
13    }
14 }
15
16
17 //响应
18 {
19     "op": 8,
20     "sid": 123456,
21     "d":{
22         "id": "ab22-dddaa",
23         "method":"GetOutputSource",
24         "status": {
25             "code": 100,
26             "result": true
27         },
28         "result":{
29             "sourceList":[
30                 {
31                     "name":"USB-1",
32                     "type":"USB-1", //输出源接口类型 USB-1/USB-
33                                     2/HDMI-OUT/USB-C/LINE-OUT 固定输出源类型
34                     "ability":"audio", //输出源流数据类型 video(只有视频数
35                                     据), audio(只有音频数据), video/audio(音视频混合数据)
```

```

34         "streamContent": "", //输出源流描述
35         "outputSourceId": 1, //输出源唯一标识id, 后续都用该字段操
    作输出源
36         "status": true //输出源接口是否正常连接设备, 可拉流
37     },
38     {
39         "name": "USB-2",
40         "type": "USB-2",
41         "ability": "audio",
42         "streamContent": "",
43         "outputSourceId": 2,
44         "status": false
45     },
46     {
47         "name": "USB-C",
48         "type": "USB-C",
49         "ability": "video/audio",
50         "streamContent": "",
51         "outputSourceId": 3,
52         "status": false
53     },
54     {
55         "name": "HDMI-OUT",
56         "type": "HDMI-OUT",
57         "ability": "video/audio",
58         "streamContent": "",
59         "outputSourceId": 4,
60         "status": true
61     },
62     {
63         "name": "LINE-OUT",
64         "type": "LINE-OUT",
65         "ability": "audio",
66         "streamContent": "",
67         "outputSourceId": 5,
68         "status": true
69     },
70     {
71         "name": "Network-1",
72         "type": "Network",
73         "ability": "video/audio",
74         "streamContent": "rtmp://192.168.16.100/live/mainstream",
75         "outputSourceId": 6,
76         "status": false //网络输出流固定为false
77     }
78 ]
79 }

```

```
80     }
81 }
```

创建输出源-CreateOutputSource

代码块

```
1
2 //创建输出源
3 {
4     "op": 7,
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"CreateOutputSource",
9         "params":{
10             "type":"Network", //目前只支持网络类型的输出源
11             "streamContent":"rtmp://192.168.16.12/live/mainstream",
12             "name":"Network-1"
13         }
14     }
15 }
16
17 //创建成功响应
18 {
19     "op": 8,
20     "sid":"123456",
21     "d":{
22         "id": "ab22-dddaa",
23         "method":"CreateOutputSource",
24         "status": {
25             "code": 100,
26             "result": true
27         },
28         "result":{
29             "outSourceId": 6,
30             "name":"Network-1"
31         }
32     }
33 }
34
35 //创建失败响应
36 {
37     "op": 8,
38     "sid": "123456",
39     "d":{
```



```
40         "id": "ab22-dddaa",
41         "method": "CreateOutputSource",
42         "status": {
43             "code": 205,
44             "result": false,
45             "comment": "the outSource has existed"
46         }
47     }
48 }
```

删除输出源-DeleteOutputSource

代码块

```
1
2 //删除输出源，外部只支持删除Network类型的输出源
3
4 {
5     "op": 7,
6     "sid": 123456,
7     "d": {
8         "id": "ab22-dddaa",
9         "method": "DeleteOutputSource",
10        "params": {
11            "outputSourceId": 6
12        }
13    }
14 }
15
16
17 //响应
18 {
19     "op": 8,
20     "sid": 123456,
21     "d": {
22         "id": "ab22-dddaa",
23         "method": "DeleteOutputSource",
24         "status": {
25             "code": 100,
26             "result": true
27         }
28     }
29 }
30
31 //错误响应
32 {
```

```

33     "op": 8,
34     "sid": 123456,
35     "d":{
36         "id": "ab22-dddaa",
37         "method":"DeleteOutputSource",
38         "status": {
39             "code": 205,
40             "result": false,
41             "comment":"the inputSource not exist"
42         }
43     }
44 }

```

设置输出源信息-SetOutputSource

代码块

```

1
2 //修改输入源，外部只支持修改Network类型的输出源
3 {
4     "op": 7,
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"SetOutputSource",
9         "params":{
10             "outputSourceId": 6,
11             "streamContent":"rtsp://192.168.16.12/live/mainstream", //支持设
置输入源的content信息/name信息
12             "name":"Network-1",
13         }
14     }
15 }
16
17
18 //响应
19 {
20     "op": 8,
21     "sid": "123456",
22     "d":{
23         "id": "ab22-dddaa",
24         "method":"SetOutputSource",
25         "status": {
26             "code": 100,
27             "result": true
28         }

```

```

29     }
30 }
31
32 //错误响应
33 {
34     "op": 8,
35     "sid": "123456",
36     "d":{
37         "id": "ab22-dddaa",
38         "method":"SetOutputSource",
39         "status": {
40             "code": 205,
41             "result": false,
42             "comment":"the input source not exist"
43         }
44     }
45 }

```

视频拼接器管理

创建视频拼接器-CreateVideoMixer

代码块

```

1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"CreateVideoMixer",
8          "params":{
9              "name":"recordMixer",
10             "videoMixer":{
11                 "detail":[
12                     {
13                         "position":{                //以8K分辨率为基准画布 7680×4320
14                             "width":1920,          //画面宽度
15                             "height":1080,         //画面高度
16                             "x":0,                  //画面左上角坐标[x,y]
17                             "y":0,
18                             "z":0                    //z标识画面层数
19                         },

```

```

20         "inputSourceId":1,           //通过GetInputSource获取，输入源
21     },
22     {
23         "position":{                 //以8K分辨率为基准画布 7680×4320
24             "width":1920,           //画面宽度
25             "height":1080,          //画面高度
26             "x":1920,               //画面左上角坐标[x,y]
27             "y":0,
28             "z":0
29         },
30         "inputSourceId":6,          //通过GetInputSource获取
31     }
32 ]
33 }
34 }
35 }
36 }
37
38 //响应
39 {
40     "op": 8,
41     "sid": "123456",
42     "d":{
43         "id": "ab22-dddaa",
44         "method":"CreateVideoMixer",
45         "status": {
46             "code": 100,
47             "result": true
48         },
49         "result":{
50             "videoMixerId": 6,
51             "name":"recordMixer"
52         }
53     }
54 }
55

```

设置视频拼接器-SetVideoMixer

代码块

```

1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{

```

```

6      "id": "ab22-dddaa",
7      "method": "SetVideoMixer",
8      "params": {
9          "videoMixerId": 6, //必填字段
10         "name": "recordMixer",
11         "videoMixer": {
12             "detail": [
13                 {
14                     "position": { //以8K分辨率为基准画布 7680×4320
15                         "width": 1920, //画面宽度
16                         "height": 1080, //画面高度
17                         "x": 0, //画面左上角坐标[x,y]
18                         "y": 0,
19                         "z": 0 //z标识画面层数
20                     },
21                     "inputSourceId": 1, //通过GetInputSource获取, 输入源
22                 },
23                 {
24                     "position": { //以8K分辨率为基准画布 7680×4320
25                         "width": 1920, //画面宽度
26                         "height": 1080, //画面高度
27                         "x": 1920, //画面左上角坐标[x,y]
28                         "y": 0,
29                         "z": 0
30                     },
31                     "inputSourceId": 6, //通过GetInputSource获取
32                 }
33             ]
34         }
35     }
36 }
37 }
38
39 //响应
40 {
41     "op": 8,
42     "sid": "123456",
43     "d": {
44         "id": "ab22-dddaa",
45         "method": "SetVideoMixer",
46         "status": {
47             "code": 100,
48             "result": true
49         }
50     }
51 }

```

删除视频拼接器-DeleteVideoMixer

代码块

```

1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"DeleteVideoMixer",
8          "params":{
9              "videoMixerId": 6, //必填字段
10         }
11     }
12 }
13
14 //响应
15 {
16     "op": 8,
17     "sid": "123456",
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"DeleteVideoMixer",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
27

```

获取视频拼接器信息-GetVideoMixer

代码块

```

1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"GetVideoMixer",

```

```

8      "params":{
9          // "videoMixerId": 6, //不填获取所有拼接器
10     }
11 }
12 }
13
14 //响应
15 {
16     "op": 8,
17     "sid": "123456",
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"CreateVideoMixer",
21         "status": {
22             "code": 100,
23             "result": true
24         },
25         "result":{
26             "videoMixerList":[
27                 {
28                     "videoMixerId": 6, //必填字段
29                     "name":"recordMixer",
30                     "videoMixer":{
31                         "detail":[
32                             {
33                                 "position":{ //以8K分辨率为基准画布
34                                     //画面宽度
35                                     "width":1920,
36                                     //画面高度
37                                     "height":1080,
38                                     //画面左上角坐标[x,y]
39                                     "x":0,
40                                     "y":0,
41                                     "z":0 //z标识画面层数
42                                 },
43                                 "inputSourceId":1, //通过GetInputSource获取
44                                 //取，输入源
45                             },
46                             {
47                                 "position":{ //以8K分辨率为基准画布
48                                     //画面宽度
49                                     "width":1920,
50                                     //画面高度
51                                     "height":1080,
52                                     //画面左上角坐标[x,y]
53                                     "x":1920,
54                                     "y":0,
55                                     "z":0
56                                 },
57                                 "inputSourceId":6, //通过GetInputSource获取
58                             }
59                         ]
60                     }
61                 }
62             ]
63         }
64     }
65 }

```

```

52         ]
53     }
54 },
55 {
56     "videoMixerId": 7, //必填字段
57     "name": "hdmiOutMixer",
58     "videoMixer": {
59         "detail": [
60             {
61                 "position": { //以8K分辨率为基准画布
62                     "width": 1920, //画面宽度
63                     "height": 1080, //画面高度
64                     "x": 0, //画面左上角坐标[x,y]
65                     "y": 0,
66                     "z": 0 //z标识画面层数
67                 },
68                 "inputSourceId": 1, //通过GetInputSource获取
69                 取, 输入源
70             },
71             {
72                 "position": { //以8K分辨率为基准画布
73                     "width": 1920, //画面宽度
74                     "height": 1080, //画面高度
75                     "x": 1920, //画面左上角坐标[x,y]
76                     "y": 0,
77                     "z": 0
78                 },
79                 "inputSourceId": 6, //通过GetInputSource获取
80             }
81         ]
82     }
83 ]
84 }
85 }
86 }

```

简单场景管理

创建场景-CreateScene


```

1 代码块 //场景取流地址 rtsp://[ip]:554/scene/[sceneId]
2  //创建场景
3  {
4      "op": 7,
5
6      "sid": "123456",
7      "d":{
8          "id": "ab22-dddaa",
9          "method":"CreateScene",
10         "params":{
11             "name":"classRoom-1",          //场景名称
12             "enable":true,                  //场景创建成功后，是否自动开启
13             "outputSourceList":[           //一个拼接/混音支持多个输出源输出
14                 {
15                     "enable":true,
16                     "outputSourceId": 4,     //通过GetOutputSource获取，输出源
17                     "videoInfo":{           //可选字段
18                         "resolution":"1080p", //支持1080p/720p/360p
19                         //可选字段
20                         "fps":30,             //输出帧率    25/30/60
21                         //可选
22                         "kbps":4096,          //输出码率
23                         //可选
24                         "format":"H264",      //视频编码    //  H264/H265
25                         //可选
26                     },
27                     "audioInfo":{             //可选字段
28                         "channelNum":2,        //输出音频通道个数
29                         "sampleRate":48000,    //输出音频采样率  8000/44100/48000
30                         "bitDepth":16,         //输出音频位深    8/16/24/32
31                         "format":"AAC",        //输出音频编码    PCM/AAC
32                         "gain":100
33                     }
34                 },
35                 {
36                     "enable":true,
37                     "outputSourceId": 6,
38                     "videoInfo":{             //可选字段
39                         "resolution":"1080p", //支持1080p/720p/360p
40                         //可选字段
41                         "fps":30,             //输出帧率    25/30/60    //
42                         //可选
43                         "kbps":4096,          //输出码率
44                         //可选
45                         "format":"H264",      //视频编码    //  H264/H265
46                         //可选
47                     },
48                 },
49             ]
50         }
51     }
52 }

```

```

40         "audioInfo":{                                //可选字段
41             "channelNum":2,                            //输出音频通道个数
42             "sampleRate":48000,                        //输出音频采样率 8000/44100/48000
43             "bitDepth":16,                            //输出音频位深 8/16/24/32
44             "format":"AAC",                            //输出音频编码 PCM/AAC
45             "gain":100
46         }
47     },
48     ],
49     "videoMixer":{
50         "detail":[
51             {
52                 "position":{                            //以8K分辨率为基准画布 7680×4320
53                     "width":1920,                      //画面宽度
54                     "height":1080,                    //画面高度
55                     "x":0,                             //画面左上角坐标[x,y]
56                     "y":0,
57                     "z":0                             //z标识画面层数
58                 },
59                 "inputSourceId":1,                    //通过GetInputSource获取, 输入源
60             },
61             {
62                 "position":{                            //以8K分辨率为基准画布 7680×4320
63                     "width":1920,                      //画面宽度
64                     "height":1080,                    //画面高度
65                     "x":1920,                          //画面左上角坐标[x,y]
66                     "y":0,
67                     "z":0
68                 },
69                 "inputSourceId":6,                    //通过GetInputSource获取
70             }
71         ]
72     },
73     },
74     "audioMixer":{
75         "detail":[
76             {
77                 "enable":true,
78                 "gain":30,                            //音频轨音量增益 0~100
79                 "inputSourceId":5,
80                 "delay" : 100
81             },
82             {
83                 "enable":true,
84                 "gain":80,                            //音频轨音量增益 0~100
85                 "inputSourceId":3,

```

```

86         "delay" : 0
87     }
88 ]
89 }
90 }
91 }
92 }
93
94 //创建成功响应
95 {
96     "op": 8,
97     "sid": "123456",
98     "d":{
99         "id": "ab22-dddaa",
100         "method":"CreateScene",
101         "status": {
102             "code": 100,
103             "result": true
104         },
105         "result":{
106             "sceneId":1
107         }
108     }
109 }
110
111 //创建失败响应
112 {
113     "op": 8,
114     "sid": "123456",
115     "d":{
116         "id": "ab22-dddaa",
117         "method":"CreateScene",
118         "status": {
119             "code": 205,
120             "result": false,
121             "comment":"the inputSourceId 2 not exist"
122         }
123     }
124 }
125

```

获取场景信息-GetScene

```

1
2 //获取场景布局配置
3 {
4     "op": 7,
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"GetScene"
9         "params":{
10             // "sceneId":1 //过滤场景ID, 不填则获取所有场景配置
11             // "enable":true //过滤当前处于开启状态的场景
12         }
13     }
14 }
15
16
17 //响应
18 {
19     "op": 8,
20     "sid": "123456",
21     "d":{
22         "id": "ab22-dddaa",
23         "method":"GetScene",
24         "status": {
25             "code": 100,
26             "result": true
27         },
28         "result":{
29             "sceneList":[
30                 {
31                     "sceneId":1
32                     "name":"classRoom-1", //场景名称
33                     "enable":true, //场景是否处于启动状态
34                     "outputSourceList":[ //一个拼接/混音支持多个输出源输出
35                         {
36                             "outputSourceId": 4, //通过GetOutputSource获
37                             取, 输出源
38                             "videoInfo":{ //
39                                 可选字段
40                                     "resolution":"1080p", //支持
41                                     1080p/720p/360p //可选字段
42                                     "fps":30, //输出帧率
43                                     25/30/60 //可选
44                                     "kbps":4096, //输出码率
45                                     //可选
46                                     "format":"H264" //视频编码 //
47                                     H264/H265 //可选

```

```

42         },
43         "audioInfo":{                                     //可选字段
44             "channelNum":2,                             //输出音频通道个数
45             "sampleRate":48000, //输出音频采样率
46                                     8000/44100/48000
47             "bitDepth":16,                             //输出音频位深
48                                     8/16/24/32
49             "format":"AAC",                             //输出音频编码
50                                     PCM/AAC
51             "gain":100
52         }
53     },
54     {
55         "outputSourceId": 6,
56         "videoInfo":{                                     //
57             "resolution":"1080p",                       //支持
58                                     1080p/720p/360p //可选字段
59             "fps":30,
60                                     //输出帧率 25/30/60 //可选
61             "kbps":4096,
62                                     //输出码率 //可选
63             "format":"H264"                             //视
64                                     频编码 // H264/H265 //可选
65         },
66         "audioInfo":{                                     //可选字段
67             "channelNum":2,                             //输出音频通道个数
68             "sampleRate":48000, //输出音频采样率
69                                     8000/44100/48000
70             "bitDepth":16,                             //输出音频位深
71                                     8/16/24/32
72             "format":"AAC",                             //输出音频编码
73                                     PCM/AAC
74             "gain":100
75         }
76     }
77 ],
78     //指定videoMixerId, 通过
79     CreateVideoMixer创建
80     "videoMixer":{
81         "detail":[
82             {
83                 "position":{                             //以8K分辨率为基准画布
84                                     7680×4320
85                 "width":1920,                             //画面宽度
86                 "height":1080,                             //画面高度

```

```

76         "x":0, //画面
    左上角坐标[x,y]
77         "y":0,
78         "z":0
79     },
80     "inputSourceId":1, //通过GetInputSource获
    取, 输入源
81 },
82 {
83     "position":{ //以8K分辨率为基准画布
    7680×4320
84         "width":1920, //画面宽度
85         "height":1080, //画面高度
86         "x":1920, //
    画面左上角坐标[x,y]
87         "y":0,
88         "z":0
89     },
90     "inputSourceId":6, //通过GetInputSource获取
91 }
92 ]
93
94 },
95 "audioMixer":{
96     "detail":[
97     {
98         "enable":true, //是否加入混音
99         "gain":30, //音频轨音量增益 0~100
100        "inputSourceId":5,
101        "delay" : 0 //单位ms
102    },
103    {
104        "enable":true, //是否加入混音
105        "gain":80, //音频轨音量增益 0~100
106        "inputSourceId":3,
107        "delay" : 0 //单位ms
108    }
109    ]
110 }
111 },
112
113 {
114     "sceneId":2
115     "name":"classRoom-2", //场景名称
116     "enable":false, //场景是否处于启动状态
117     "outputSourceList":[ //一个拼接/混音支持多个输出源输出

```

```

118         {
119             "outputSourceId": 7,          //通过GetOutputSource获取,
输出源
120             "videoInfo":{                //可选
字段
121                 "resolution":"1080p",    //支持
1080p/720p/360p //可选字段
122                 "fps":30,
//输出帧率 25/30/60 //可选
123                 "kbps":4096,              //
输出码率 //可选
124                 "format":"H264"          //视频编
码 // H264/H265 //可选
125             },
126             "audioInfo":{                //可选字段
127                 "channelNum":2,           //输出音频通道个数
128                 "sampleRate":48000, //输出音频采样率
8000/44100/48000
129                 "bitDepth":16,           //输出音频位深 8/16/24/32
130                 "format":"AAC",          //输出音频编码 PCM/AAC
131                 "gain":100
132             }
133         },
134         {
135             "outputSourceId":8,
136             "videoInfo":{                //可选
字段
137                 "resolution":"1080p",    //支持
1080p/720p/360p //可选字段
138                 "fps":30,
//输出帧率 25/30/60 //可选
139                 "kbps":4096,              //
输出码率 //可选
140                 "format":"H264",          //视频编
码 // H264/H265 //可选
141                 "gain":100
142             },
143             "audioInfo":{                //可选字段
144                 "channelNum":2,           //输出音频通道个数
145                 "sampleRate":48000, //输出音频采样率
8000/44100/48000
146                 "bitDepth":16,           //输出音频位深 8/16/24/32
147                 "format":"AAC",          //输出音频编码 PCM/AAC
148                 "gain":100
149             }
150         }
151     ],

```

```

152         "videoMixer":{
153             "detail":[
154                 {
155                     "position":{                //以8K分辨率为基准画布
156                         7680×4320
157                         "width":1920,          //画面宽度
158                         "height":1080,         //画面高度
159                         "x":0,                  //画面
160                         左上角坐标[x,y]
161                         "y":0,
162                         "z":0
163                     },
164                     "inputSourceId":1          //通过GetInputSource获取,
165                     输入源
166                 },
167                 {
168                     "position":{                //以8K分辨率为基准画布
169                         7680×4320
170                         "width":1920,          //画面宽度
171                         "height":1080,         //画面高度
172                         "x":1920,              //
173                         画面左上角坐标[x,y]
174                         "y":0,
175                         "z":0
176                     },
177                     "inputSourceId":6          //通过GetInputSource获取
178                 }
179             ]
180         },
181         "audioMixer":{
182             "detail":[
183                 {
184                     "enable":true,
185                     "gain":30,                //音频轨音量增益 0~100
186                     "inputSourceId":5,
187                     "delay" : 0              //单位ms
188                 },
189                 {
190                     "enable":true,
191                     "gain":80,                //音频轨音量增益 0~100
192                     "inputSourceId":3,
193                     "delay" : 0              //单位ms
194                 }
195             ]
196         }
197     }

```



```
193     ]
194   }
195 }
196 }
197
198
199
```

获取场景输出配置信息-GetSceneOutConfig

代码块

```
1  {
2    "op": 7,
3    "sid": 123456,
4    "d":{
5      "id": "ab22-dddaa",
6      "method":"GetSceneOutConfig",
7      "params":{
8        "sceneId":2,           //必填字段  场景id
9        "outputSourceId":3     //可选字段，  不填返回所有输出源信息
10     }
11   }
12 }
13
14 {
15   "op": 8,
16   "sid": "123456",
17   "d":{
18     "id": "ab22-dddaa",
19     "method":"GetSceneOutConfig",
20     "status": {
21       "code": 100,
22       "result": true
23     },
24     "result":{
25       "outputSourceList":[
26         {
27           "outputSourceId": 3,           //通过GetOutputSource获取， 输出
28           "name":"HDMI-OUT",
29           "videoInfo":{                  //可选字段
30             "resolution":"1080p",       //支持1080p/720p/360p
31           }
32         }
33       ]
34     }
35   }
36 }
```

```

31          "fps":30,                //输出帧率    25/30/60
//可选
32          "kbps":4096,            //输出码率
//可选
33          "format":"H264"        //视频编码    //    H264/H265    //
可选
34      },
35      "audioInfo":{                //可选字段
36          "channelNum":2,          //输出音频通道个数
37          "sampleRate":48000,      //输出音频采样率
8000/44100/48000
38          "bitDepth":16,          //输出音频位深    8/16/24/32
39          "format":"AAC",          //输出音频编码    PCM/AAC
40          "gain":100
41      }
42  }
43  ]
44  }
45  }
46  }
47
48
49

```

获取场景混音器信息-GetAudioMixerItem

代码块

```

1  {
2      "op": 7,
3      "sid": 123456,
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetAudioMixerItem",
7          "params":{
8              "sceneId":2,          //必填字段    场景id
9              "inputSourceId":3    //可选字段,    不填返回混音器所有信息
10         }
11     }
12 }
13
14 {
15     "op": 8,

```

```
16     "sid": "123456",
17     "d":{
18         "id": "ab22-dddaa",
19         "method":"GetAudioMixerItem",
20         "status": {
21             "code": 100,
22             "result": true
23         },
24         "result":{
25             "detail":[
26                 {
27                     "enable":true,    //是否加入混音
28                     "gain":30,        //音频轨音量增益 0~100
29                     "inputSourceId":3,
30                     "delay": 100,
31                     "name": "LINE-IN"
32                 }
33             ]
34         }
35     }
36 }
37
```

设备默认场景配置

音频路由场景配置

输入\输出	USB-1-OUT	USB-2-OUT	USB-C-OUT	HDMI-OUT	LINE-OUT	Rec/Stream
USB-1-IN		☒	☒	☒	☒	☒
USB-2-IN		☒	☒	☒	☒	☒
USB-C-IN	☒			☒	☒	☒
HDMI-IN		☒	☒	☒	☒	☒
Line-IN		☒	☒	☒	☒	☒

每一个音频输出都是单独的场景，可单独配置里面的混音器

配置场景混音器信息-SetAudioMixerItem

代码块

```
1  {
2      "op": 7,
3      "sid": 123456,
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetAudioMixerItem",
7          "params":{
8              "sceneId":2,          //必填字段  场景id
9              "action":"set",      // set (设置音频条目信息) /add (添加音频条目信
10             息) /remove (删除音频条目信息)
11              "audioMixerDetail":{
12                  "enable":true,  //是否加入混音
13                  "gain":30,      //音频轨音量增益 0~100
14                  "inputSourceId":5,
15                  "delay" : 0    //单位ms
16              }
17          }
18      }
19
20  {
21      "op": 8,
22      "sid": "123456",
23      "d":{
24          "id": "ab22-dddaa",
25          "method":"SetAudioMixerItem",
26          "status": {
27              "code": 100,
28              "result": true
29          },
30          "result":{
31
32          }
33      }
34  }
35
36
37  {
38      "op": 8,
39      "sid": "123456",
40      "d":{
```

```

41         "id": "ab22-dddaa",
42         "method": "SetAudioMixerItem",
43         "status": {
44             "code": 205,
45             "result": false,
46             "comment": "the sceneId not exist"
47         }
48     }
49 }
50

```

设置场景信息-SetScene

代码块

```

1
2 //设置场景信息
3 //修改设置场景名称
4 {
5     "op": 7,
6     "sid": 123456,
7     "d": {
8         "id": "ab22-dddaa",
9         "method": "SetScene",
10        "params": {
11            "sceneId": 2, //必填字段
12            "name": "room-3"
13        }
14    }
15 }
16
17 //修改场景子单元拼接信息，更新outputSourceList， 其他字段类比修改即可
18 {
19     "op": 7,
20     "sid": "123456",
21     "d": {
22         "id": "ab22-dddaa",
23         "method": "SetScene",
24         "params": {
25             "sceneId": 2, //必填字段
26             "outputSourceList": [ //一个拼接/混音支持多个输出源输出
27                 {
28                     "outputSourceId": 4, //通过GetOutputSource获取，输出源

```

```

29         "audioInfo":{                                //可选字段
30             "channelNum":2,                            //输出音频通道个数
31             "sampleRate":48000, //输出音频采样率 8000/44100/48000
32             "bitDepth":16, //输出音频位深 8/16/24/32
33             "format":"AAC", //输出音频编码 PCM/AAC
34             "gain":100
35         }
36     },
37     {
38         "outputSourceId" : 12,
39         "videoInfo" :
40         {
41             "format" : "H264",
42             "fps" : 30,
43             "kbps" : 4096,
44             "resolution" : "1080p"
45         }
46     }
47 ]
48 }
49 }
50 }
51
52
53 //修改场景混音信息，全量更新audioMixer，其他字段类比修改即可
54 {
55     "op": 7,
56     "sid": "123456",
57     "d":{
58         "id": "ab22-dddaa",
59         "method":"SetScene",
60         "params":{
61             "sceneId":2, //必填字段
62             "audioMixer":{
63
64                 "detail":[
65                     {
66                         "enable":true, //是否加入混音
67                         "gain":30, //音频轨音量增益 0~100
68                         "inputSourceId":5,
69                         "delay" : 0 //单位ms
70                     },
71                     {
72                         "enable":true, //是否加入混音
73                         "gain":80, //音频轨音量增益 0~100
74                         "inputSourceId":3,
75                         "delay" : 0 //单位ms

```

```

75         }
76     ]
77 }
78 }
79 }
80 }
81
82
83 //修改场景子单元拼接信息， 全量更新videoMixer， 其他字段类比修改即可
84 {
85     "op": 7,
86     "sid": "123456",
87     "d":{
88         "id": "ab22-dddaa",
89         "method":"SetScene",
90         "params":{
91             "name":"roomsPlus",
92             "sceneId":2, //必填字段
93             "videoMixer":{
94                 "detail":[
95                     {
96                         "position":{ //以8K分辨率为基准画布 7680×4320
97                             "width":1920, //画面宽度
98                             "height":1080, //画面高度
99                             "x":0, //画面左上角坐
100                             标[x,y]
101                             "y":0,
102                             "z":0
103                         },
104                         "inputSourceId":1 //通过GetInputSource获取， 输入源
105                     },
106                     {
107                         "position":{ //以8K分辨率为基准画布 7680×4320
108                             "width":1920, //画面宽度
109                             "height":1080, //画面高度
110                             "x":1920, //画面左上
111                             角坐标[x,y]
112                             "y":0,
113                             "z":0
114                         },
115                         "inputSourceId":6 //通过GetInputSource获取
116                     }
117                 ]
118             }
119         }

```

```
120
121
122
123
124 //设置成功响应
125 {
126     "op": 8,
127     "sid": "123456",
128     "d":{
129         "id": "ab22-dddaa",
130         "method":"SetScene",
131         "status": {
132             "code": 100,
133             "result": true
134         },
135         "result":{
136
137         }
138     }
139 }
140
141 //设置失败响应
142 {
143     "op": 8,
144     "sid": "123456",
145     "d":{
146         "id": "ab22-dddaa",
147         "method":"SetScene",
148         "status": {
149             "code": 205,
150             "result": false,
151             "comment":"the sceneId not exist"
152         }
153     }
154 }
```

删除场景-DeleteScene

代码块

```
1
2 //删除输出源，外部只支持删除Network类型的输出源
3 {
4     "op": 7,
```



```
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"DeleteScene"
9         "params":{
10             "sceneId": 2
11         }
12     }
13 }
14
15
16 //响应
17 {
18     "op": 8,
19     "sid": "123456",
20     "d":{
21         "id": "ab22-dddaa",
22         "method":"DeleteScene",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }
28 }
29
30 //错误响应
31 {
32     "op": 8,
33     "sid": "123456",
34     "d":{
35         "id": "ab22-dddaa",
36         "method":"DeleteScene",
37         "status": {
38             "code": 205,
39             "result": false,
40             "comment":"the sceneId not exist"
41         }
42     }
43 }
```

开启场景-StartScene

代码块

```
1
2 //开启场景
3 {
4     "op": 7,
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"StartScene",
9         "params":{
10             "sceneId":2 //必填字段
11         }
12     }
13 }
14
15
16 //开启场景成功响应
17 {
18     "op": 8,
19     "sid": 123456,
20     "d":{
21         "id": "ab22-dddaa",
22         "method":"StartScene",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }
28 }
29
30 //开启场景失败响应
31 {
32     "op": 8,
33     "sid": 123456,
34     "d":{
35         "id": "ab22-dddaa",
36         "method":"StartScene",
37         "status": {
38             "code": 205,
39             "result": false,
40             "comment":"the sceneId not exist"
41         }
42     }
43 }
```

停止场景-StopScene

代码块

```
1
2  //停止场景
3  {
4      "op": 7,
5      "sid": "123456",
6      "d":{
7          "id": "ab22-dddaa",
8          "method":"StopScene",
9          "params":{
10             "sceneId":2 //必填字段
11         }
12     }
13 }
14
15
16 //开启场景成功响应
17 {
18     "op": 8,
19     "sid": 123456,
20     "d":{
21         "id": "ab22-dddaa",
22         "method":"StopScene",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }
28 }
29
30 //开启场景失败响应
31 {
32     "op": 8,
33     "sid": 123456,
34     "d":{
35         "id": "ab22-dddaa",
36         "method":"StopScene",
37         "status": {
38             "code": 205,
39             "result": false,
40             "comment":"the sceneId not exist"
41         }
42     }
```

开启场景录制-StartSceneRecord

代码块

```
1
2 //开启场景录制
3 {
4     "op": 7,
5     "sid": "123456",
6     "d": {
7         "id": "ab22-dddaa",
8         "method": "StartSceneRecord",
9         "params": {
10             "sceneId": 2 //必填字段
11         }
12     }
13 }
14
15
16 //开启场景录制成功响应
17 {
18     "op": 8,
19     "sid": 123456,
20     "d": {
21         "id": "ab22-dddaa",
22         "method": "StartSceneRecord",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }
28 }
29
30 //开启场景录制失败响应
31 {
32     "op": 8,
33     "sid": 123456,
34     "d": {
35         "id": "ab22-dddaa",
36         "method": "StartSceneRecord",
37         "status": {
38             "code": 205,
```

```

39         "result": false,
40         "comment": "the sceneId not exist"
41     }
42 }
43 }
44
45
46 {
47     "op": 8,
48     "sid": 123456,
49     "d": {
50         "id": "ab22-dddaa",
51         "method": "StartSceneRecord",
52         "status": {
53             "code": 205,
54             "result": false,
55             "comment": "not found sd"
56         }
57     }
58 }

```

停止场景录制-StopSceneRecord

代码块

```

1
2 //停止场景录制
3 {
4     "op": 7,
5     "sid": "123456",
6     "d": {
7         "id": "ab22-dddaa",
8         "method": "StopSceneRecord",
9         "params": {
10             "sceneId": 2 //必填字段
11         }
12     }
13 }
14
15
16 //停止场景录制成功响应
17 {
18     "op": 8,
19     "sid": 123456,
20     "d": {
21         "id": "ab22-dddaa",

```

```
22         "method": "StopSceneRecord",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }
28 }
29
30 //开启场景录制失败响应
31 {
32     "op": 8,
33     "sid": 123456,
34     "d": {
35         "id": "ab22-dddaa",
36         "method": "StopSceneRecord",
37         "status": {
38             "code": 205,
39             "result": false,
40             "comment": "the sceneId not exist"
41         }
42     }
43 }
```

录像查询-SelectRecord

代码块

```
1 //录像查询
2 {
3     "op": 7,
4     "sid": "123456",
5     "d": {
6         "id": "ab22-dddaa",
7         "method": "SelectRecord",
8         "params": {
9             }
10    }
11 }
12
13
14 {
15     "op": 8,
16     "sid": "123456",
17     "d": {
```

```
18         "id": "ab22-dddaa",
19         "method": "SelectRecord",
20         "status": {
21             "code": 100,
22             "result": true
23         },
24         "result": {
25             "recordList": [
26                 {
27                     "url": "http://192.168.16.10/RecordFile/1/2024-11-08/10-
00-00.mp4"
28                 },
29                 {
30                     "url": "http://192.168.16.10/RecordFile/1/2024-11-07/11-
10-00.mp4"
31                 }
32             ]
33         }
34     }
35 }
```

录像删除-RemoveRecord

代码块

```
1  //录像删除请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d": {
6          "id": "ab22-dddaa",
7          "method": "RemoveRecord",
8          "params": {
9              "recordList": [
10                 {
11                     "url": "http://192.168.16.10/RecordFile/1/2024-11-08/10-
00-00.mp4"
12                 },
13                 {
14                     "url": "http://192.168.16.10/RecordFile/1/2024-11-07/11-
10-00.mp4"
15                 }
16             ]
17         }
18     }
19 }
```

```
20
21 //录像删除响应
22 {
23     "op": 8,
24     "sid": 123456,
25     "d":{
26         "id": "ab22-dddaa",
27         "method":"RemoveRecord",
28         "status": {
29             "code": 100,
30             "result": true
31         }
32     }
33 }
34
```

开启场景直播推流-StartLiveStream

代码块

```
1
2 //开启场景直播推流请求
3 {
4     "op": 7,
5     "sid": "123456",
6     "d":{
7         "id": "ab22-dddaa",
8         "method":"StartLiveStream",
9         "params":{
10             "sceneId":2, //必填字段
11             "url":"rtmp://192.168.11.1/live/stream" /////必填字段
12         }
13     }
14 }
15
16 //响应
17 {
18     "op": 8,
19     "sid": 123456,
20     "d":{
21         "id": "ab22-dddaa",
22         "method":"StartLiveStream",
23         "status": {
24             "code": 100,
```



```
25         "result": true
26     }
27 }
28 }
```

停止场景直播推流-StopLiveStream

代码块

```
1  //请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d": {
6          "id": "ab22-dddaa",
7          "method": "StopLiveStream",
8          "params": {
9              "sceneId": 1 //必填字段
10         }
11     }
12 }
13
14 //响应
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "StopLiveStream",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
```

视频拼接切换业务管理

设置工作场景（录制流）视频输出模式 SetWorkSceneOutPlayMode

代码块

```
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetWorkSceneOutPlayMode",
7          "params":{
8              // Presentation/Manual/AutoDirector
9              // [Presentation演讲者模式, 有分享流 (hdmi-in/tail投屏流) 进来, 分享流与
其他视频源自动布局] [Manual 自定义视频拼接]
10              // [AutoDirector] 需要配置波束映射, 根据波束位置自动切换画面
11              "mode":"Manual"
12          }
13      }
14  }
15
16  {
17      "op": 8,
18      "sid": 123456,
19      "d":{
20          "id": "ab22-dddaa",
21          "method":"SetWorkSceneOutPlayMode",
22          "status": {
23              "code": 100,
24              "result": true
25          }
26      }
27  }
```

获取工作场景（录制流）视频输出模式 GetWorkSceneOutPlayMode

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetWorkSceneOutPlayMode",
7          "params":{
8              }
9      }
10 }
11
```

```

12  {
13      "op": 8,
14      "sid": 123456,
15      "d":{
16          "id": "ab22-dddaa",
17          "method":"GetWorkSceneOutPlayMode",
18          "status": {
19              "code": 100,
20              "result": true
21          }
22          "result":{
23              // Presentation/Manual/AutoDirector
24              // [Presentation演讲者模式，有分享流（hdmi-in/tail投屏流）进来，分享流与
                其他视频源自动布局] [Manual 自定义视频拼接]
25              // [AutoDirector] 需要配置波束映射，根据波束位置自动切换画面
26              "mode":"Manual"
27          }
28      }
29  }
30

```

设置HDMI-OUT视频输出模式 SetHdmiOutPlayMode

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetHdmiOutPlayMode",
7          "params":{
8              // Share/Preview/Manual [Share模式，有分享流进来hdmiOut只显示分享流，无
                分享流显示向导页面]
9              // [Preview 模式跟随录制场景拼接信息] [Manual 模式自定义布局显示]
10             "mode":"Manual"
11         }
12     }
13 }
14
15 {
16     "op": 8,
17     "sid": 123456,

```

```

18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetHdmiOutPlayMode",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }

```

获取HDMI-OUT视频输出模式 GetHdmiOutPlayMode

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetHdmiOutPlayMode",
7          "params":{
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d":{
16         "id": "ab22-dddaa",
17         "method":"GetHdmiOutPlayMode",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22         "result":{
23             // Share/Preview/Manual [Share模式, 有分享流进来hdmiOut只显示分享流, 无
24             // [Preview 模式跟随录制场景拼接信息]    [Manual 模式自定义布局显示]
25             "mode":"Manual"
26         }
27     }
28 }

```

设置HDMI-OUT投屏share输出模式 SetHdmioutShareMode

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetHdmioutShareMode",
7          "params": {
8              // 0: tail和Hdmi in相互覆盖,
9              // 1: tail优先级最高, 拔掉tail后如果Hdmi in有画面, Hdmi in画
            面会显示在引导图片上,
10             // 2: Hdmi in不参与
11             "mode": 0
12         }
13     }
14 }
15
16 {
17     "d": {
18         "id": "ab22-dddaa",
19         "method": "SetHdmioutShareMode",
20         "status": {
21             "code": 100,
22             "result": true
23         }
24     },
25     "op": 8,
26     "sid": "18446744072144177456"
27 }
```

获取HDMI-OUT投屏share输出模式 GetHdmioutShareMode

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetHdmioutShareMode",
```

```

7      "params":{
8          }
9  }
10 }
11
12 {
13     "d": {
14         "id": "ab22-dddaa",
15         "method": "GetHdmioutShareMode",
16         "result": {
17             "mode": 2
18         },
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     },
24     "op": 8,
25     "sid": "18446744072144478824"
26 }

```

设置TYPEC-OUT视频输出模式 SetTypecOutPlayMode

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetTypecOutPlayMode",
7          "params":{
8              // Auto/Preview/Manual [Auto模式，使用除去HDMI投屏内容的自动布局画面]
              [Manual 模式自定义布局显示]
9              // [Preview 模式跟随录制场景拼接信息]    [custom 模式自定义布局显示]
10             "mode":"Manual"
11         }
12     }
13 }
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetTypecOutPlayMode",

```

```
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
```

获取TYPEC-OUT视频输出模式 GetTypecOutPlayMode

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetTypecOutPlayMode",
7          "params": {
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d": {
16         "id": "ab22-dddaa",
17         "method": "GetTypecOutPlayMode",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22         "result": {
23             // Auto/Preview/Manual [Auto模式, 使用除去HDMI投屏内容的自动布局画面]
24             [Manual 模式自定义布局显示]
25             // [Preview 模式跟随录制场景拼接信息]    [custom 模式自定义布局显示]
26             "mode": "Manual"
27         }
28     }
29 }
```

设置BYOM-OUT视频输出模式 SetByomOutPlayMode

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetByomOutPlayMode",
7          "params": {
8              // Auto/Preview/Manual [Auto模式, 使用除去Tail投屏内容的自动布局画面]
              [Manual 模式自定义布局显示]
9              // [Preview 模式跟随录制场景拼接信息]
10             "mode": "Manual"
11         }
12     }
13 }
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "SetByomOutPlayMode",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
```

获取BYOM-OUT视频输出模式 GetByomOutPlayMode

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetByomOutPlayMode",
7          "params": {
8              }
9      }
10 }
```



```

11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d":{
16         "id": "ab22-dddaa",
17         "method":"GetByomOutPlayMode",
18         "status": {
19             "code": 100,
20             "result": true
21         },
22         "result":{
23             // Auto/Preview/Manual [Auto模式，使用除去Tail投屏内容的自动布局画面]
24             [Manual 模式自定义布局显示]
25             // [Preview 模式跟随录制场景拼接信息]
26             "mode":"Manual"
27         }
28     }

```

AMX100+A50 波束联动方案配置

AMX100连接-AMX100Connect

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"AMX100Connect",
7          "params":{
8              "ipaddr":"xxx.xxx.xxx.xxx",
9              "port":5022
10         }
11     }
12 }
13
14
15 //正常连接成功响应
16 {
17     "op": 8,
18     "sid": 123456,
19     "d":{

```

```

20         "id": "ab22-dddaa",
21         "method": "AMX100Connect",
22         "status": {
23             "code": 100,
24             "result": true
25         }
26     }
27 }
28
29 //连接失败响应
30 {
31     "op": 8,
32     "sid": "123456",
33     "d": {
34         "id": "ab22-dddaa",
35         "method": "AMX100Connect",
36         "status": {
37             "code": 205,
38             "result": false,
39             "comment": "AMX100 connect failed"
40         }
41     }
42 }

```

AMX100断开连接-AMX100DisConnect

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "AMX100DisConnect",
7          "params": {
8              "ipaddr": "xxx.xxx.xxx.xxx",
9              "port": 5022
10         }
11     }
12 }
13
14
15 //正常连接成功响应
16 {
17     "op": 8,
18     "sid": 123456,

```

```

19     "d":{
20         "id": "ab22-dddaa",
21         "method":"AMX100DisConnect",
22         "status": {
23             "code": 100,
24             "result": true
25         }
26     }
27 }
28
29 //连接失败响应
30 {
31     "op": 8,
32     "sid": "123456",
33     "d":{
34         "id": "ab22-dddaa",
35         "method":"AMX100DisConnect",
36         "status": {
37             "code": 205,
38             "result": false,
39             "comment":"AMX100 DisConnect failed"
40         }
41     }
42 }

```

获取AMX100子设备及波束信息-GetAMX100DeviceInfo

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetAMX100DeviceInfo",
7          "params":{
8
9          }
10     }
11 }
12
13
14 {
15     "op": 7,
16     "sid": "123456",
17     "d":{

```

```

18         "id": "ab22-dddaa",
19         "method": "GetAMX100DeviceInfo",
20         "status": {
21             "code": 100,
22             "result": true
23         },
24         "result": {
25             "devices": [
26                 {
27                     "model": "A50",
28                     "sn": "AW31YCAB899A000560",
29                     "beams": 12
30                 },
31                 {
32                     "model": "A50",
33                     "sn": "AW31YCAB899A000491",
34                     "beams": 12
35                 }
36             ]
37         }
38     }
39 }
40
41

```

--

配置音频导播模式波束映射关系-SetAutoDirectorBeamMapConfig

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetAutoDirectorBeamMapConfig",
7          "params": {
8              "sn": "AW31YCAB899A000491",
9              "model": "a40", //string, amx100设备级联的设备类型
10             "am10p", "a30", "a40", "a50"
11             "devIndex": 0, //int ,amx100级联设备的索引号, 从0开始
12             "beamIndex": 1, //int, 波束索引号 从1开始
13             "name": "USB-1", //唯一标识videoMixer
14             "presetPosition": -1, //预置位,
15             "videoMixer": {

```

```

15         "detail": [
16             {
17                 "position": { //以8K分辨率为基准画布 7680×4320
18                     "width": 1920, //画面宽度
19                     "height": 1080, //画面高度
20                     "x": 0, //画面左上角坐标[x,y]
21                     "y": 0,
22                     "z": 0 //z标识画面层数
23                 },
24                 "inputSourceId": 1, //通过GetInputSource获取, 输入源
25             },
26             {
27                 "position": { //以8K分辨率为基准画布 7680×4320
28                     "width": 1920, //画面宽度
29                     "height": 1080, //画面高度
30                     "x": 1920, //画面左上角坐标[x,y]
31                     "y": 0,
32                     "z": 0
33                 },
34                 "inputSourceId": 6, //通过GetInputSource获取
35             }
36         ]
37     }
38 }
39 }
40 }
41
42
43
44 {
45     "op": 7,
46     "sid": "123456",
47     "d": {
48         "id": "ab22-dddaa",
49         "method": "SetBeamMapConfig",
50         "status": {
51             "code": 100,
52             "result": true
53         }
54     }
55 }

```

获取音频导播模式波束映射关系-GetAutoDirectorBeamMapConfig

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetAutoDirectorBeamMapConfig",
7          "params":{
8              }
9      }
10 }
11
12
13
14 {
15     "op": 7,
16     "sid": "123456",
17     "d":{
18         "id": "ab22-dddaa",
19         "method":"GetAutoDirectorBeamMapConfig",
20         "status": {
21             "code": 100,
22             "result": true
23         },
24         "result": {
25             "beamStatistics":10,           //波束统计缓存个数
26             "beamTriggerCount":5,         //触发视频拼接转换的最大波束个数
27             "autoDirectorBeamMaps": [
28                 {
29                     "sn": "AW31YCAB899A000491",
30                     "model": "a40", //string, amx100设备级联的设备类型
31                     "devIndex": 0, //int    ,amx100级联设备的索引号 从0开始
32                     "beams":12, //波束个数
33                     "maps":[
34                         {
35                             "name":"USB-1",
36                             "presetPosition": -1,
37                             "beamIndex": 2
38                         },
39                         {
40                             "name":"USB-2",
41                             "presetPosition": -1,
42                             "beamIndex": 1
43                         }
44                     ]
45                 },
46                 {

```

```

47         "sn": "AW31YCAB899A000491",
48         "model": "a40", //string, amx100设备级联的设备类型
        "am10P", "a30", "a40", "a50"
49         "devIndex": 1, //int ,amx100级联设备的索引号 从0开始
50         "beams": 12, //波束个数
51         "maps": [
52             {
53                 "name": "USB-1",
54                 "presetPosition": -1,
55                 "beamIndex": 2
56             },
57             {
58                 "name": "USB-2",
59                 "presetPosition": -1,
60                 "beamIndex": 1
61             },
62         ],
63     ],
64 },
65 ],
66 },
67 },
68 }

```

设置音频导播模式波束统计信息SetAutoDirectorBeamStatisticsInfo----- 调试使用

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetAutoDirectorBeamStatisticsInfo",
7          "params": { //字段定义暂时先这样做
8              "autoDirectorBeamStatistics": 10, //波束统计缓存个数
9              "autoDirectorBeamTriggerCount": 5 //触发视频拼接转换的最大波束个数
10         }
11     }
12 }
13
14
15 {
16     "op": 8,
17     "sid": 123456,

```

```

18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetAutoDirectorBeamStatisticsInfo",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }

```

--

配置讨论者高亮配置波束映射关系- SetSpeakerHighlightBeamMapConfig

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetSpeakerHighlightBeamMapConfig",
7          "params": {
8              "sn": "AW31YCAB899A000491",
9              "model": "a40", //string, amx100设备级联的设备类型
10             "am10p", "a30", "a40", "a50"
11             "devIndex": 0, //int ,amx100级联设备的索引号, 从0开始
12             "beamIndex": 1, //int, 波束索引号 从1开始
13             "inputSourceId": 1, //int, 所绑定的单源id
14         }
15     }
16 }
17
18
19
20 {
21     "op": 7,
22     "sid": "123456",
23     "d":{
24         "id": "ab22-dddaa",
25         "method":"SetSpeakerHighlightBeamMapConfig",
26         "status": {
27             "code": 100,

```



```

28         "result": true
29     }
30 }
31 }

```

获取讨论者高亮配置波束映射关系- GetSpeakerHighlightBeamMapConfig

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetSpeakerHighlightBeamMapConfig",
7          "params": {
8              }
9      }
10 }
11
12 {
13     "op": 7,
14     "sid": "123456",
15     "d": {
16         "id": "ab22-dddaa",
17         "method": "GetSpeakerHighlightBeamMapConfig",
18         "status": {
19             "code": 100,
20             "result": true
21         },
22         "result": {
23             "beamStatistics": 10,          //波束统计缓存个数
24             "beamTriggerCount": 5,        //触发视频拼接转换的最大波束个数
25             "speakerHighlightBeamMaps": [
26                 {
27                     "sn": "AW31YCAB899A000491",
28                     "model": "a40", //string, amx100设备级联的设备类型
29                     "devIndex": 0, //int ,amx100级联设备的索引号 从0开始
30                     "beams": 12, //波束个数
31                     "maps": [
32                         {
33                             "inputSourceId": 1,
34                             "beamIndex": 2
35                         },

```

```

36         {
37             "inputSourceId":4,
38             "beamIndex": 1
39         }
40     ]
41 },
42 {
43     "sn": "AW31YCAB899A000491",
44     "model": "a40", //string, amx100设备级联的设备类型
45     "devIndex": 1, //int ,amx100级联设备的索引号 从0开始
46     "beams":12, //波束个数
47     "maps":[
48         {
49             "inputSourceId":6,
50             "beamIndex": 2
51         },
52         {
53             "inputSourceId":3,
54             "beamIndex": 1
55         },
56     ]
57 }
58 ]
59 }
60 }
61 }

```

获取讨论者高亮配置开关-GetSpeakerHighlightConfig

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetSpeakerHighlightConfig",
7          "params":{
8              }
9      }
10 }
11
12 {
13     "op": 7,
14     "sid": "123456",

```

```
15     "d":{
16         "id": "ab22-dddaa",
17         "method":"GetSpeakerHighlightConfig",
18         "status": {
19             "code": 100,
20             "result": true
21         },
22         "result": {
23             "enable":true,          //配置是否开启
24         }
25     }
26 }
```

设置讨论者高亮配置开关-SetSpeakerHighlightConfig

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetSpeakerHighlightConfig",
7          "params": {
8              "enable" : true
9          }
10     }
11 }
12
13
14
15 {
16     "op": 7,
17     "sid": "123456",
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetSpeakerHighlightConfig",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
```

设置讨论者高亮波束统计信息SetSpeakerHighlightBeamStatisticsInfo- 调试使用

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetSpeakerHighlightBeamStatisticsInfo",
7          "params":{           //字段定义暂时先这样做
8              "speakerHighlightBeamStatistics":10,           //波束统计缓存个数
9              "speakerHighlightBeamTriggerCount":5           //触发视频拼接转换的最大波束个
10          }
11      }
12  }
13
14
15  {
16      "op": 8,
17      "sid": 123456,
18      "d":{
19          "id": "ab22-dddaa",
20          "method":"SetSpeakerHighlightBeamStatisticsInfo",
21          "status": {
22              "code": 100,
23              "result": true
24          }
25      }
26  }
```

子设备控制

子设备信息获取

代码块

```
1  待定
2
```

事件订阅

输入源/输出源状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"InputSourceChange"    //OutputSourceChange
7      }
8  }
9
10 //事件通知
11 {
12     "op":6,
13     "sid":"123456",
14     "d":{
15         "event":"InputSourceChange",    //OutputSourceChange
16         "data":{
17             "name":"USB-2",
18             "type":"USB-2",
19             "ability":"video/audio",
20             "streamContent":"",
21             "inputSourceId": 2,
22             "status":false,
23         }
24     }
25 }
26
27
```

推流直播状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"LiveStreamStatus"
7      }
8  }
9
10
```

```
11
12 //事件通知
13 {
14     "op":6,
15     "sid":"123456",
16     "d":{
17         "event":"LiveStreamStatus",
18         "data":{
19             "sceneId":1,
20             "url":"rtmp://192.168.11.3/live/stream",
21             //推流成功【streaming】， 推流失败【failed】， 正在重连【reconnecting】
22             //推流停止【stopped】
23             "liveStatus":"streaming",
24             "liveSeconds":100
25         }
26     }
27 }
28
29
```

SD卡存储状态订阅

代码块

```
1 //订阅请求
2 {
3     "op": 5,
4     "sid": "123456",
5     "d":{
6         "subscribe":"SDStatus"
7     }
8 }
9
10
11 //事件通知
12 {
13     "op":6,
14     "sid":"123456",
15     "d":{
16         "event":"SDStatus",
17         "data":{
18             //sdAddUnformatted sd卡插入未格式化
19             //sdAddFormatted sd卡插入已格式化
20             //sdRemove sd卡拔掉
21             //sdFull sd卡空间已满
22             //sdFormatSuccess
```

```
23         //sdFormatFail
24         "status":"sdAddUnformatted",
25         //sd卡总空间
26         "totalSize":2344444,
27         //sd卡可用空间
28         "availableSize":100000
29     }
30 }
31 }
32
33
```

录制流状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"RecordStatus"
7      }
8  }
9
10 //事件通知
11 {
12     "op":6,
13     "sid":"123456",
14     "d":{
15         "event":"RecordStatus",
16         "data":{
17             //recording    正在录制
18             //recordStopped 录制停止
19             "status":"recording",
20             "recordSeconds":100
21         }
22     }
23 }
24
25
```

USB-C 连接状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"UsbcConnectEvent"
7      }
8  }
9
10 //事件通知
11 {
12     "op":6,
13     "sid":"123456",
14     "d":{
15         "event":"UsbcConnectEvent",
16         "data":{
17             //usbcConnect usb-c已连接
18             //usbcDisConnect usb-c断开连接
19             "status":"usbcConnect"
20         }
21     }
22 }
```

USB-C 视频拉流状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"UsbcStreamEvent"
7      }
8  }
9
10 //事件通知
11 {
12     "op":6,
13     "sid":"123456",
14     "d":{
15         "event":"UsbcStreamEvent",
```



```
16         "data":{
17             //usbcStartVideoStream    usb-c视频拉流
18             //usbcStopVideoStream     usb-c停止视频拉流
19             "status":"usbcStopVideoStream"
20         }
21     }
22 }
```

AMX100连接状态订阅

代码块

```
1  //订阅请求
2  {
3      "op": 5,
4      "sid": "123456",
5      "d":{
6          "subscribe":"AMX100ConnectStatusEvent"
7      }
8  }
9
10
11 //事件通知
12 {
13     "op":6,
14     "sid":"123456",
15     "d":{
16         "event":"AMX100ConnectStatusEvent",
17         "data":{
18             //AMX100Connected    已连接状态
19             //AMX100DisConnected 断开连接状态
20             "status":"AMX100Connected"
21         }
22     }
23 }
```

设置系统时间-SetSysTime

代码块

```
1  //设置系统时间请求
2  {
```

```

3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",
7          "method":"SetSysTime",
8          "params":{
9              //时区  America/New_York  America/Los_Angeles  Europe/Berlin Europe/Moscow
              Asia/Kolkata Asia/Shanghai Asia/Tokyo Australia/Sydney  Pacific/Auckland
10             "timezone": "Asia/Shanghai",
11             "year": 2024,
12             "month": 11,
13             "day": 12,
14             "hour": 14,
15             "minute": 30,
16             "second": 45
17         }
18     }
19 }
20
21 //设置系统时间响应
22 {
23     "op": 8,
24     "sid": 123456,
25     "d":{
26         "id": "ab22-dddaa",
27         "method":"SetSysTime",
28         "status": {
29             "code": 100,
30             "result": true
31         }
32     }
33 }
34

```

格式化SD卡-FormatSd

代码块

```

1  //格式化sd卡 请求
2  {
3      "op": 7,
4      "sid": "123456",
5      "d":{
6          "id": "ab22-dddaa",

```

```

7         "method": "FormatSd",
8         "params": {
9             }
10    }
11 }
12
13 //格式化一般比较耗时，这里设备端基本都是返回成功，通过订阅事件通知格式化结果
14 //格式化sd卡 响应
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "FormatSd",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
27
28 //格式化失败响应
29 {
30     "op": 8,
31     "sid": 123456,
32     "d": {
33         "id": "ab22-dddaa",
34         "method": "FormatSd",
35         "status": {
36             "code": 205,
37             "result": false,
38             "comment": "device may be busy, please stop record"
39         }
40     }
41 }

```

获取SD卡存储信息-GetSDInfo

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {

```

```

5      "id": "ab22-dddaa",
6      "method": "GetSDInfo",
7      "params": {
8      }
9  }
10 }
11
12
13 {
14     "op": 8,
15     "sid": "123456",
16     "d": {
17         "id": "ab22-dddaa",
18         "method": "GetSDInfo",
19         "status": {
20             "code": 100,
21             "result": true
22         },
23         "result": {
24             //sdAddUnformatted sd卡插入未格式化
25             //sdAddFormatted sd卡插入已格式化
26             //sdRemove sd卡拔掉
27             "status": "sdAddUnformatted",
28             //sd卡总空间
29             "totalSize": 2344444,
30             //sd卡可用空间
31             "availableSize": 100000
32         }
33     }
34 }
35
36
37

```

重置配置-ResetConfig

代码块

```

1  //重置配置后，设备会自动重启
2
3  {
4      "op": 7,
5      "sid": "123456",
6      "d": {
7          "id": "ab22-dddaa",
8          "method": "ResetConfig",

```

```
9      "params":{
10      }
11  }
12 }
13
14
15
16 {
17     "op": 8,
18     "sid": 123456,
19     "d":{
20         "id": "ab22-dddaa",
21         "method":"ResetConfig",
22         "status": {
23             "code": 100,
24             "result": true
25         }
26     }
27 }
```

获取设备基本信息-GetDeviceInfo

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetDeviceInfo",
7          "params":{
8              }
9      }
10 }
11
12
13 {
14     "op": 8,
15     "sid": 123456,
16     "d":{
17         "id": "ab22-dddaa",
18         "method":"GetDeviceInfo",
19         "status": {
20             "code": 100,
```

```
21         "result": true
22     },
23     "result":{
24         "model":"ROOMS",          //设备型号
25         "devName":"classRooms-201",      //设备名称
26         "cpuUsage":60,          //已使用CPU百分比
27         "memoryUsage":20,      //已使用内存百分比
28         "ip":"192.168.19.165",    //设备有线网卡地址
29         "version":"V1.0.0.0.R.250120",    //设备固件版本
30         "mac":"98:6E:E8:50:03:A1"    //设备mac地址
31     }
32 }
33 }
34
```

设置设备名称-SetDeviceName

代码块

```
1  {
2    "op": 7,
3    "sid": "123456",
4    "d":{
5      "id": "ab22-dddaa",
6      "method":"SetDeviceName",
7      "params":{
8        "devName":"c\classRooms-201"
9      }
10   }
11 }
12
13 {
14   "op": 8,
15   "sid": 123456,
16   "d":{
17     "id": "ab22-dddaa",
18     "method":"SetDeviceName",
19     "status": {
20       "code": 100,
21       "result": true
22     }
23   }
24 }
```

KVM 数据传输

代码块

```
1  {
2    "op": 7,
3    "sid": "123456",
4    "d":{
5      "id": "ab22-dddaa",
6      "method":"SetKvm",
7      "params":{
8        "kvmData":"1267abdc"
9      }
10   }
11 }
12
13 {
14   "op": 8,
15   "sid": 123456,
```

```
16     "d":{
17         "id": "ab22-dddaa",
18         "method":"SetKvm",
19         "status": {
20             "code": 100,
21             "result": true
22         },
23         "result":{
24             "kvmData":"1267abdc"
25         }
26     }
27 }
```

远程升级

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"RemoteUpgrade",
7          "params":{
8
9              "url":"http://fgsy.uuc.com/file/General_MB_[Nearhub_ROOMS]_V1.0.0.0.R.250304.bin"
10          }
11      }
12
13
14  {
15      "op": 8,
16      "sid": 123456,
17      "d":{
18          "id": "ab22-dddaa",
19          "method":"RemoteUpgrade",
20          "status": {
21              "code": 100,
22              "result": true
23          }
24      }
25  }
26
```


远程升级进度查询

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "UpgradeProgress",
7          "params": {
8
9              "url": "http://fgsy.uuc.com/file/General_MB_[Nearhub_ROOMS]_V1.0.0.0.R.250304.bin"
10         }
11     }
12
13
14 {
15     "op": 8,
16     "sid": 123456,
17     "d": {
18         "id": "ab22-dddaa",
19         "method": "UpgradeProgress",
20         "status": {
21             "code": 100,
22             "result": true
23         },
24         "result": {
25             "progress": 20    //0~100
26         }
27     }
28 }
```

设置Line-in预增益

代码块

```

1  {
```

```

2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetLineInPreGain",
7          "params":{
8              "preGain":10    //1~10
9          }
10     }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetLineInPreGain",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }

```

获取Line-in预增益

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetLineInPreGain",
7          "params":{
8
9          }
10     }
11 }
12
13
14

```

```
15  {
16      "op": 8,
17      "sid": 123456,
18      "d":{
19          "id": "ab22-dddaa",
20          "method":"GetLineInPreGain",
21          "status": {
22              "code": 100,
23              "result": true
24          },
25          "result":{
26              "preGain":1 //1~10
27          }
28      }
29  }
```

设置音频播放模式

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetAudioPlaybackMode",
7          "params":{
8              "mode":"priority" //or manual
9          }
10     }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"SetAudioPlaybackMode",
21         "status": {
22             "code": 100,
23             "result": true
24         }
```

```
25     }
26 }
```

获取音频播放模式

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetAudioPlaybackMode",
7          "params": {
8
9          }
10     }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "GetAudioPlaybackMode",
21         "status": {
22             "code": 100,
23             "result": true
24         },
25         "result": {
26             "mode": "priority"    //or manual
27         }
28     }
29 }
```

获取USB-C连接状态

代码块

```
1  {
```

```

2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetUsbcConnectStatus",
7          "params":{
8
9          }
10     }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d":{
19         "id": "ab22-dddaa",
20         "method":"GetUsbcConnectStatus",
21         "status": {
22             "code": 100,
23             "result": true
24         },
25         "result":{
26             //usbcConnect usb-c已连接
27             //usbcDisConnect usb-c断开连接
28             "status":"usbcConnect"
29         }
30     }
31 }
32

```

V520D/V540D支持协议

设置智能模式

代码块

```

1  {
2      "op": 7,

```

```

3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetAlgMode",
7          "params":{
8              "mode":"Manual"    //Manual AutoFraming SmartTracking
//SpeakerTacking
9          }
10     }
11 }
12
13 {
14     "op": 8,
15     "sid": 123456,
16     "d":{
17         "id": "ab22-dddaa",
18         "method":"SetAlgMode",
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     }
24 }

```

获取智能模式

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetAlgMode",
7          "params":{
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d":{
16         "id": "ab22-dddaa",
17         "method":"GetAlgMode",
18         "status": {

```

```

19         "code": 100,
20         "result": true
21     }
22     "result":{
23         "mode":"Manual"    //Manual AutoFraming SmartTracking
    SpeakerTacking
24     }
25 }
26 }

```

设置DOA Mic源

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetDoaMic",
7          "params":{
8              "mic":"IntMic"    //IntMic ExtMic
9          }
10     }
11 }
12
13 {
14     "op": 8,
15     "sid": 123456,
16     "d":{
17         "id": "ab22-dddaa",
18         "method":"SetDoaMic",
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     }
24 }

```

获取DOA Mic源

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetDoaMic",
7          "params":{
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d":{
16         "id": "ab22-dddaa",
17         "method":"GetDoaMic",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22         "result":{
23             "mic":"IntMic"    //IntMic ExtMic
24         }
25     }
26 }

```

简化版本

由于目前520d/540d的相关基础库版本很老，没法直接更新到最新，故没法使用ws，故添加一个基于tcp的连接，camera端为server，b10端为client，端口号：50362,报文格式为json

获取设备信息

代码块

```

1  {
2      "op": 7,
3      "method":"GetDevInfo",
4      "params":{
5          }
6  }
7
8  {

```



```

9      "op": 8,
10     "method": "GetDevInfo",
11     "status": {
12         "code": 100,
13         "result": true
14     }
15     "result": {
16         "devType": "V520D",      //V403 V410 V415 V520D V540D
17         "algCapacity": 1111      //分别对应Manual AutoFraming SmartTracking
                                   SpeakerTracking, 比如支持Manual AutoFraming, 则值为1100
18     }
19 }

```

设置智能模式

代码块

```

1  {
2      "op": 7,
3      "method": "SetAlgMode",
4      "params": {
5          "mode": "Manual"      //Manual AutoFraming SmartTracking SpeakerTracking
6      }
7  }
8
9  //正常响应
10 {
11     "op": 8,
12     "method": "SetAlgMode",
13     "status": {
14         "code": 100,
15         "result": true
16     }
17 }
18
19 //异常响应
20 {
21     "op": 8,
22     "method": "SetAlgMode",
23     "status": {
24         "code": 205,
25         "result": false,
26         "comment": "Fail to SetAlgMode"
27     }

```

获取智能模式

代码块

```
1  {
2      "op": 7,
3      "method": "GetAlgMode",
4      "params": {
5      }
6  }
7
8  {
9      "op": 8,
10     "method": "GetAlgMode",
11     "status": {
12         "code": 100,
13         "result": true
14     }
15     "result": {
16         "mode": "Manual"    //Manual AutoFraming SmartTracking SpeakerTracking
17     }
18 }
```

设置DOA Mic源

代码块

```
1  {
2      "op": 7,
3      "method": "SetDoaMic",
4      "params": {
5          "mic": "IntMic"    //IntMic ExtMic
6      }
7  }
8
9  //正常响应
10 {
11     "op": 8,
12     "method": "SetDoaMic",
13     "status": {
14         "code": 100,
```

```

15         "result": true
16     }
17 }
18
19 //异常响应
20 {
21     "op": 8,
22     "method": "SetDoaMic",
23     "status": {
24         "code": 205,
25         "result": false,
26         "comment": "Fail to SetDoaMic"
27     }
28 }

```

获取DOA Mic源

代码块

```

1  {
2      "op": 7,
3      "method": "GetDoaMic",
4      "params": {
5      }
6  }
7
8  {
9      "op": 8,
10     "method": "GetDoaMic",
11     "status": {
12         "code": 100,
13         "result": true
14     }
15     "result": {
16         "mic": "IntMic" //IntMic ExtMic
17     }
18 }

```

设置跟AMX100联动参数

代码块

```

1  {
2      "op": 7,
3      "method": "SetAMX100Param",

```

```

4      "params":{
5          "amx100Dev":[{
6              "devType": "a40", //string, amx100设备级联的设备类型
              "am10p","a30","a40","a50"
7              "index": 0, //int ,amx100级联设备的索引号
8              "snid": "88888888", //string,amx100级联设备的sn码
9              "beam":[-1,-1,3,-1,-1,-1,-1,-1] //array, 数组大小根据设备不同会改变,
              a50:12,a40:8,amp10:1,amx100级联设备的波束对应的预置位信息(-1表示无预置位, 可支持的预置
              位为0~255)
10             },
11             {
12                 "devType": "a40", //string, amx100设备级联的设备类型
                  "am10p","a30","a40","a50"
13                 "index": 1, //int ,amx100级联设备的索引号
14                 "snid": "88888888", //string,amx100级联设备的sn码
15                 "beam":[-1,-1,3,-1,-1,-1,-1,-1] //array, 数组大小根据设备不同会改变,
                  a50:12,a40:8,amp10:1,amx100级联设备的波束对应的预置位信息(-1表示无预置位, 可支持的预置
                  位为0~255)
16             }]
17         }
18     }
19
20     {
21         "op": 8,
22         "method":"SetAMX100Param",
23         "status": {
24             "code": 100,
25             "result": true
26         }
27     }

```

获取跟AMX100联动参数

代码块

```

1  {
2      "op": 7,
3      "method":"GetAMX100Param",
4      "params":{
5          }
6  }
7
8  {
9      "op": 8,
10     "method":"GetAMX100Param",
11     "status": {

```

```

12         "code": 100,
13         "result": true
14     }
15     "result":{
16         "amx100Dev":[{
17             "devType": "a40", //string, amx100设备级联的设备类型
18             "index": 0, //int ,amx100级联设备的索引号
19             "snid": "88888888", //string,amx100级联设备的sn码
20             "beam":[-1,-1,3,-1,-1,-1,-1,-1] //array, 数组大小根据设备不同会改变,
21             a50:12,a40:8,amp10:1,amx100级联设备的波束对应的预置位信息(-1表示无预置位, 可支持的预置
22             位为0~255)
23         },
24         {
25             "devType": "a40", //string, amx100设备级联的设备类型
26             "index": 1, //int ,amx100级联设备的索引号
27             "snid": "88888888", //string,amx100级联设备的sn码
28             "beam":[-1,-1,3,-1,-1,-1,-1,-1] //array, 数组大小根据设备不同会改变,
29             a50:12,a40:8,amp10:1,amx100级联设备的波束对应的预置位信息(-1表示无预置位, 可支持的预置
30             位为0~255)
31         }
32     ]
33 }

```

设置AMX100的ip地址

代码块

```

1  {
2      "op": 7,
3      "method":"SetAMX100Ip",
4      "params":{
5          "ipaddr":"xxx.xxx.xxx.xxx"
6      }
7  }
8
9  //正常响应
10 {
11     "op": 8,
12     "method":"SetAMX100Ip",
13     "status": {
14         "code": 100,
15         "result": true
16     }
17 }

```

```
18
19 //异常响应
20 {
21     "op": 8,
22     "method": "SetAMX100Ip",
23     "status": {
24         "code": 205,
25         "result": false,
26         "comment": "Fail to SetAMX100Ip"
27     }
28 }
```

获取AMX100的ip地址

代码块

```
1  {
2      "op": 7,
3      "method": "GetAMX100Ip",
4      "params": {
5      }
6  }
7
8  //正常响应
9  {
10     "op": 8,
11     "method": "GetAMX100Ip",
12     "status": {
13         "code": 100,
14         "result": true
15     }
16     "result": {
17         "ipaddr": "xxx.xxx.xxx.xxx"
18     }
19 }
20
21 //异常响应
22 {
23     "op": 8,
24     "method": "GetAMX100Ip",
25     "status": {
26         "code": 205,
27         "result": false,
28         "comment": "Fail to GetAMX100Ip"
29 }
```

```
30 }
```

设置Line Out音量

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetLineOutVolume",
7          "params": {
8              "volume": 10 //0~16, 0:mute
9          }
10     }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "SetLineOutVolume",
21         "status": {
22             "code": 100,
23             "result": true
24         }
25     }
26 }
```

获取Line Out音量

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
```

```
6         "method": "GetLineOutVolume",
7         "params": {
8
9         }
10    }
11 }
12
13
14
15 {
16     "op": 8,
17     "sid": 123456,
18     "d": {
19         "id": "ab22-dddaa",
20         "method": "GetLineOutVolume",
21         "status": {
22             "code": 100,
23             "result": true
24         },
25         "result": {
26             "volume": 10 //0~16, 0:mute
27         }
28     }
29 }
```

Decode产测协议

连接wifi

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "WifiConnect",
7          "params": {
8              "ssid": "wifi name",
9              "key": "wifi key"
10         }
11     }
12 }
13
14 //正常响应
```



```

15  {
16      "op": 8,
17      "sid": 123456,
18      "d":{
19          "id": "ab22-dddaa",
20          "method":"WifiConnect",
21          "status": {
22              "code": 100,
23              "result": true
24          }
25      }
26  }
27
28  //异常响应
29  {
30      "op": 8,
31      "sid": 123456,
32      "d":{
33          "id": "ab22-dddaa",
34          "method":"WifiConnect",
35          "status": {
36              "code": 205,
37              "result": false
38          }
39      }
40  }

```

获取已连接wifi的信号强度

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"GetWifiSignalStrength",
7          "params":{
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d":{

```

```
16         "id": "ab22-dddaa",
17         "method": "GetWifiSignalStrength",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22         "result": {
23             "signalStrength": 50          //0--100
24         }
25     }
26 }
```

视频播放

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "VideoPlay",
7          "params": {
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d": {
16         "id": "ab22-dddaa",
17         "method": "VideoPlay",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22     }
23 }
```

音频播放

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "AudioPlay",
7          "params": {
8              }
9      }
10 }
11
12 {
13     "op": 8,
14     "sid": 123456,
15     "d": {
16         "id": "ab22-dddaa",
17         "method": "AudioPlay",
18         "status": {
19             "code": 100,
20             "result": true
21         }
22     }
23 }

```

检测line port状态

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "CheckLineStatus",
7          "params": {
8              }
9      }
10 }
11
12 //正常响应
13 {
14     "op": 8,
15     "sid": 123456,
16     "d": {
17         "id": "ab22-dddaa",
18         "method": "CheckLineStatus",

```

```
19         "status": {
20             "code": 100,
21             "result": true
22         }
23         "result":{
24             "lineInStatus":1,
25             "lineOutStatus":1
26         }
27     }
28 }
29
30 //异常响应
31 {
32     "op": 8,
33     "sid": 123456,
34     "d":{
35         "id": "ab22-dddaa",
36         "method":"CheckLineStatus",
37         "status": {
38             "code": 205,
39             "result": false
40         }
41         "result":{
42             "lineInStatus":1,
43             "lineOutStatus":1
44         }
45     }
46 }
```

kvm测试

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"TestKvm",
7          "params":{
8              }
9      }
10 }
11
12 //正常响应
13 {
```

```
14     "op": 8,
15     "sid": 123456,
16     "d":{
17         "id": "ab22-dddaa",
18         "method":"TestKvm",
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     }
24 }
25
26 //异常响应
27 {
28     "op": 8,
29     "sid": 123456,
30     "d":{
31         "id": "ab22-dddaa",
32         "method":"TestKvm",
33         "status": {
34             "code": 205,
35             "result": false
36         }
37     }
38 }
```

USB口测试

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"TestUsb",
7          "params":{
8              }
9      }
10 }
11
12 //正常响应
13 {
14     "op": 8,
15     "sid": 123456,
16     "d":{
```

```
17         "id": "ab22-dddaa",
18         "method": "TestUsb",
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     }
24 }
25
26 //异常响应
27 {
28     "op": 8,
29     "sid": 123456,
30     "d": {
31         "id": "ab22-dddaa",
32         "method": "TestUsb",
33         "status": {
34             "code": 205,
35             "result": false
36         }
37     }
38 }
```

设置sn码

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetSn",
7          "params": {
8              "snSerial": "xxxxxx"
9          }
10     }
11 }
12
13 //正常响应
14 {
15     "op": 8,
16     "sid": 123456,
17     "d": {
```

```
18         "id": "ab22-dddaa",
19         "method": "SetSn",
20         "status": {
21             "code": 100,
22             "result": true
23         }
24     }
25 }
26
27 //异常响应
28 {
29     "op": 8,
30     "sid": 123456,
31     "d": {
32         "id": "ab22-dddaa",
33         "method": "SetSn",
34         "status": {
35             "code": 205,
36             "result": false
37         }
38     }
39 }
```

获取sn码

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetSn",
7          "params": {
8              }
9      }
10 }
11
12 //正常响应
13 {
14     "op": 8,
15     "sid": 123456,
16     "d": {
17         "id": "ab22-dddaa",
18         "method": "GetSn",
19         "status": {
```

```

20         "code": 100,
21         "result": true
22     }
23     "result":{
24         "snSerial":"xxxxxx"
25     }
26 }
27 }
28
29 //异常响应
30 {
31     "op": 8,
32     "sid": 123456,
33     "d":{
34         "id": "ab22-dddaa",
35         "method":"GetSn",
36         "status": {
37             "code": 205,
38             "result": false
39         }
40     }
41 }

```

设置mac地址

代码块

```

1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"SetMacAddr",
7          "params":{
8              "mac":"xx:xx:xx:xx:xx:xx"
9          }
10     }
11 }
12
13 //正常响应
14 {
15     "op": 8,
16     "sid": 123456,
17     "d":{

```



```
18         "id": "ab22-dddaa",
19         "method": "SetMacAddr",
20         "status": {
21             "code": 100,
22             "result": true
23         }
24     }
25 }
26
27 //异常响应
28 {
29     "op": 8,
30     "sid": 123456,
31     "d": {
32         "id": "ab22-dddaa",
33         "method": "SetMacAddr",
34         "status": {
35             "code": 205,
36             "result": false
37         }
38     }
39 }
```

获取mac地址

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "GetMacAddr",
7          "params": {
8              }
9      }
10 }
11
12 //正常响应
13 {
14     "op": 8,
15     "sid": 123456,
16     "d": {
17         "id": "ab22-dddaa",
18         "method": "GetMacAddr",
19         "status": {
```

```
20         "code": 100,
21         "result": true
22     }
23     "result":{
24         "mac":"xx:xx:xx:xx:xx:xx"
25     }
26 }
27 }
28
29 //异常响应
30 {
31     "op": 8,
32     "sid": 123456,
33     "d":{
34         "id": "ab22-dddaa",
35         "method":"GetMacAddr",
36         "status": {
37             "code": 205,
38             "result": false
39         }
40     }
41 }
```

检测复位按键

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d":{
5          "id": "ab22-dddaa",
6          "method":"ResetButton",
7          "params":{
8              }
9      }
10 }
11
12 //正常响应
13 {
14     "op": 8,
15     "sid": 123456,
16     "d":{
17         "id": "ab22-dddaa",
```

```
18         "method": "ResetButton",
19         "status": {
20             "code": 100,
21             "result": true
22         }
23     }
24 }
25
26 //异常响应
27 {
28     "op": 8,
29     "sid": 123456,
30     "d": {
31         "id": "ab22-dddaa",
32         "method": "ResetButton",
33         "status": {
34             "code": 205,
35             "result": false
36         }
37     }
38 }
```

设置hwid

代码块

```
1  {
2      "op": 7,
3      "sid": "123456",
4      "d": {
5          "id": "ab22-dddaa",
6          "method": "SetHwid",
7          "params": {
8              "hwid": "xxxxxx"
9          }
10     }
11 }
12
13 //正常响应
14 {
15     "op": 8,
16     "sid": 123456,
17     "d": {
18         "id": "ab22-dddaa",
19         "method": "SetHwid",
20         "status": {
```

```
21         "code": 100,
22         "result": true
23     }
24 }
25 }
26
27 //异常响应
28 {
29     "op": 8,
30     "sid": 123456,
31     "d":{
32         "id": "ab22-dddaa",
33         "method":"SetHwid",
34         "status": {
35             "code": 205,
36             "result": false
37         }
38     }
39 }
```