## Wednesday, July 17, 2019 20:15 #1 FILE - NEW - CCS Project TARGET: TMS320F28335 CONNECTION: Texas Insuruments XDS100v2 USB Debug Probe TOOL- CHAIN; - LINKER COMMAND FILE: X - RUNTIME support library: rts 2800\_fp32. lib PROJECT TEMPLATE: EMPTY PROJECT #2 RIGHT CLICK on Project -> Properties: BUILD >C200 Compiler > OPTIMIZATION - OPTIMIZATION LEVEL: 4 -SPEED VS. SIZE TRADE-OFFS: 5 - FLOATING POINT MODE ! PELAXED > INCLUDE OPTIONS (ADD): ti/C2000/device\_support/f2833x/headers/include ti/C2000/device\_support/f2833x/ common/include ti (C2000) libraries \ math \ FPU fase RTS \ c28 \ in clude ti/c2000/libraries/mach/lQmath/c28/include >C2000 Liuker >BASIC OPTIONS - SET C system stack size: $0 \times 400$ > FILE SEARCH PATH -include library file... (add) ti/C2000 libraries/math/FPUfaseRTS/C28/lib/rtsl800\_fpu32\_fast\_supplement MOVE UP SO IT'S ON TOP - ADD <DIR> TO LIBRARY SEARCH PATH ti/C2000/libraries/math/FPUfaseRTS/c28/lib #3 files to the new PROJECT #4 RIGHT OUCK on PROJECT NAME > Add Files! HEADERS / CMd: DSPRB33 x\_ Headers\_mouBIOS From \SouRce: DSP2833x\_GlobalVariable Defs COMMON SOURCE: DSP2833x\_ ADC\_cal - Code Start Branch \_DefaultISR - Pie Ctrl - Pie Vect - SysCtrl \_us Delay

#5 EXCLUPE EXISTING LINKER FILE F28335. cmd or F28335\_RAM\_lnx.cmd AOP PLES > til c2000/ device\_support 1 f2833x1 common and 1 F28335.cmd