Manualslib.com - Easy to Read Manuals

# Audi Q5 2012 Manual

# Contents


1. Introduction
2. Cockpit
3. Convenience key
4. Starting the engine
5. Automatic transmission
6. Adjusting the seats
7. Climate control
8. Panoramic sliding sunroof
9. Electromechanical parking brake
10. Adaptive cruise control
11. Technology
12. Multi Media Interface/ Sound system
13. Storing radio station
14. Starting navigation
15. Driver assistance systems
16. Documents / Resources
    - 16.1. In Other Languages
    - 16.2. Other ManualsLib Projects

## Introduction

This Quick Reference Guide provides you w th a brief overview of selected procedures and functions in your vehicle. It does not rep lace the Owner's Manual with its important explanations and warnings.

## Cockpit

1. Hood release
2. Release button for luggage compartment
3. Data Link Connector for On Board Diagnostics (OBD ||)
4. Power windows

   **WARNING**

   Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

5. Adjusting the exterior mirrors

Adjust the knob:
Left exterior mirror
Heating the exterior mirror
Right exterior mirror
Folding the exterior mirror
The mirror glass moves in t he direct ion that the knob is pressed.

6. Memory seat buttons

7. Door handle and central locking switch
   locked
   unlocked

8. Audi side assist

9. Light switch and instrument lighting

10. Cruise control or adaptive cruise control

11. Turn signal and high beam lever

12. Multifunction steering wheel controls

13. tiptronic shift buttons

14. Instruments and indicator lights

15. Windshield wiper controls and trip computer buttons

16. Ignition lock

17. Sound system/MM! display

18. Emergency flashers
    PASSENGER AIR BAG OFF indicator light

19. Sound system/ Audi multimedia

20. Audi drive select

21. Parking system
    Electronic Stabilization
    Program
    Hill descent assist On vehicles equipped with a sound system, but tons 20 and 21 are located on the shift gate.

22. Climate control system

23. Shift lever for automatic transmission

24. MMI control console

25. START ENGINE STOP button

26. Electromechanical parking brake
27. Steering wheel position adjuster

**WARNING**

The column should only be adjusted when the vehicle is at a complete standstill.

## Convenience key

### Opening and closing the vehicle

With the convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

**Unlocking the vehicle:**

Grasp one of the door handles or the handle recess on the luggage compartment lid.

**Locking the vehicle:**

Place the selector lever in the P position. Touch the sensor ❶ on one of the door handles.

**Closing the luggage compartment lid automatically:**

Press the button in the open luggage compartment lid.

**WARNING**

When you lock your vehicle from the outside, do not leave anyone· especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

**WARNING**

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

**WARNING**

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

## Starting the engine

**Switching the ignition on and off:**
Insert the key into the ignition lock. Do not depress the brake pedal. Press on the key. The key can only be removed when the ignition is switched off.

**Starting the engine:**
Insert the key into the ignition lock. Depress the brake pedal and move the selector lever into P or N
Briefly press on the key.

**Stopping the engine when the vehicle is standing:**
Move the selector lever into P or N. Briefly press on the key.

**Convenience key:**
You can switch on the ignition and start/stop the engine using the START ENGINE STOP button without having t he key inserted in the ignition lock.

## Automatic transmission

**Selector Lever positions**

P Park
R Reverse
N Neut ral (Idle)
D Drive
S Sport
Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever. Place the selector lever in the D or S position to drive forward.
tiptronic: To shift manually, move the selector lever to the right out of the D position. The

driver information system displays the gears.

**Shifting up/ down:**
Press the selector lever forward/back.

## Adjusting the seats

1. **Adjusting the lumbar support:**
   Press on the respective area of the switch.

2. **Adjusting seat height and forward/ back position:**
   Front of the seat cushion up/down
   Back of the seat cushion up/down
   Seat up/down
   Seat forward/back

3. Adjusting the backrest:
   Backrest forward/ back

**Adjusting the headrests**
Adjust the head restraint so the upper edge is as even as possible with the top of your head.

**WARNING**

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

**WARNING**

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

**⚠ WARNING ⚠**

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

**⚠ WARNING ⚠**

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

**⚠ WARNING ⚠**

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

## Climate control

Left switch - driver's side
Right switch - passenger's side
Rota ry switch: Temperature selection

AUTO **Automatic mode**: Set t he desired temperature and press the button.

**Recirculation mode**

**Fan speed**

**Air distribution**

**Defrost the windshield / side windows**

**Rear window defroster**

**Heated seats**

**Ventilated seats**

AC **Switch the air conditioning system on/off**

OFF **Switching on/off**

## Panoramic sliding sunroof



**Comfort position:**
Rotate the switch to ❶.
**Opening**: Rotate the switch in t he direction ❷ until the desired posit ion is reached.
**Closing**: Rotate the switch to ⓪.
**Tilting/closing:** Briefly press/pull the switch in the ⓪ position. Press/pull longer to adjust the tilt height individually
**Sun shade, opening and closing:** Push the switch in the direction of arrow.
Intermediate position: Push the switch again in direction of the arrow.

⚠ **WARNING** ⚠

Be careful when closing the panoramic sliding sunroof. Check to see that no one is in the way, or serious personal injury could result.

## Electromechanical parking brake

**Stopping and engaging the parking brake**: Pull the (P) butt on. Releasing the parking brake: Pres s the brake pe da l and press the (P) button.
**Releasing automatically**: The par king brake re leases its elf automatically wh en t he safety belt is fasten e d an d you be gin d riving.

## Adaptive cruise control

The adaptive cruise control is a combined cruise control and distance regulation system.
**Switching on/off:** Pull/ press the lever ❸.
**Storing the speed:** Press t he button ❶.
**Changing the stored speed**:
Press the lever ❸ up (fast er) or down (slower)
**Increasing/decreasing the distance:**
Press the switch ❷ to th e right/ left.

⚠ **WARNING** ⚠

Improper use of the adaptive cruise control can cause collision s, other accidents and serious personal injury. Always read and heed the Warning s in the Owner's Manual.

## Technology




## Multi Media Interface/ Sound system

### Components

1. **Driver information system**
2. **Multifunction steering wheel**

Roll the left menu thumbwheel to mark a menu item in the driver information system.
Press the thumbwheel to confirm the menu item.
Press the MODE button to switch between the active radio source, nav igat ion system and telephone.
Press the button briefly to switch voice commands on.
For example, after the <Beep>, say <Help> to call up the system announcement with the possible speech commands. Hold the Talk button down to switch voice commands off.
Roll the right menu thumbwheel to control the volume. Press the right thumbwheel to repeat the last navigation announcement.

3. **Sound system/MMI display**

4. **On/Off knob**
   **Switching on**: Press briefly.
   **Adjusting the volume:** Rotate.
   **Muting:** Tap.
   **Switching off** : Press and hold.

5. **Function buttons**
   Press the desired button (such as MEDIA ) to activate that mode.

6. **Control knob**
   **Marking a menu item in the display** 3 : Rotate the control knob.
   **Confirming the selection:** Press the control knob.

7. **Control buttons**
   To call up one of the functions shown in the four corners of the disp lay, press the corresponding control button that is assigned to that corner of the display.

8. **Joystick**
   To move the crosshairs in a map view (navigation) or to control the DVD menu.

## ⚠ WARNING ⚠

**Distraction causes accidents:**

- Never enter data while driving!
- Obey traffic laws & road signs!

- Refer to the Owner's Manual!

**Operating concept**
All functions are controlled using the same operating concept.




A. **Calling up menus in the display corners:** Press the corresponding button.

B. **Marking**: Rotate the knob.

C. **Confirming**: Press the knob.

## Storing radio station

1. Press the RADIO function button.

2. Rotate the control knob and mark the desired station.

3. Press the control knob to confirm.

4. Press the "Presets" control button.

5. Rotate the control knob and mark "Store <station name>".

6. Press the control knob. The next free memory preset is marked.

7. Rotate the control knob and mark the desired preset.
8. Press the control knob to confirm.

## Starting navigation

1. Press the NAV function button.

2. Rotate the control knob and mark "City/ZIP".
3. Press the control knob to confirm.

4. Rotate the control knob to mark the first letter of the destination.
5. Press the control knob to confirm.

6. Continue entering the remaining letters of the destination name using the same procedure until the desired location name is displayed.

7. Press and hold the control knob longer when the city appears in the list.
8. Rotate and press to select the city and enter detailed destination information if necessary.

9. Mark the menu item "Start route guidance".
10. Press the control knob to confirm. The route is calculated.

## Driver assistance systems

Use the CAR button to adjust or operate many driver assistance systems in your Audi. For detailed information on this, please see your vehicle Owner's Manual.

### Establishing a Bluetooth ™ cell phone connection

You can quickly connect your Bluetooth - compatible cell phone with the sound system or MMI.

### Connecting with the sound system:

- Switch the ignition, sound system and cell phone on.
- Select the menu in the cell phone that searches for Bluetooth-compatible devices (such as the cell phone prep or handsfree system).
- Connect the cell phone with the cell phone prep.
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

**Connecting to the MMI :**

- Switch the ignition, MMI and cell phone on.
- Activate "Bluetooth" and "Access to SIM card" on the cell phone.
- Press the TEL function button.
- Mark the menu item "Search for new cell phones".
- Press the SETUP function button.
- Press the "Bluetooth" control button.
- Highlight the menu item "Search for Bluetooth devices" and confirm.
- Mark and confirm your cell phone in the display.
- Mark "Handsfree" and confirm.
- Confirm the PIN number with "Yes".
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

**For additional information on indicator lights , refer to your vehicle Owner's Manual.**

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | Dynamic steering | | Tire pressure low (check immediately) | | Cruise control activated (USA) | | Ant i-lock brake system (CAN) | | Cooling system malfunction |
| | Electron ic power control | | Turn signals/Emergency flasher | | Cruise control activated (CAN) | | Parking brake (USA) | | Engine oil pressure too low |
| | Electronic Stabilization Program (ESP) | | Trailer turn sign al assembly | | Open road (adaptive cruise control) | | Parking brake (CAN) | | Refill engine oil now |
| | Electronic Stabilization Program (ESP) | | Safety belt | | Driving in traffic (adaptive cruise control) | | Alternator malfunction | | Steering defective |
| | Safety systems (USA) | | Malfunction indicator Lamp | | Request for driver to assume control (adaptive cruise control) | | Brake malfunction (USA) | | Ignition switch defective |

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| | Safety systems (CAN) | | High beam | | Anti-lock brake system (USA) | | Brake malfunction (CAN) |

## Documents / Resources

### Available languages

Deutsch Français Español Mexicano Dutch Italiano Dansk Norsk Polski Suomi Português Español (Latinoamérica) Русский Български Čeština ε λ λ η ν ι κ ά English (UK) Eesti Hrvatski Magyar Bahasa indonesia Қазақша Lietuvių Português (Brasil) Română Română (Moldova) Slovenčina Slovenščina Shqip Kiswahili Türkçe O‘zbekcha

### Other ManualsLib Projects

www.manualslib.com
www.manualslib.de
www.manualslib.es
www.manualslib.fr
www.manualslib.nl
www.manualslib.mx
www.manualslib.tech 30+ languages