Arduino Adafruit RFID Shield Library Install Directions

- Go to https://www.arduino.cc/en/Main/Software to download the IDE
- Install and open the app
- Go to: Tools > Manage Library
- In the search bar enter "Adafruit PN532"
- Install the library

