


Release Notes

v1.0	February 27, 2015	Tiffanie Shakespeare	New spec
v1.1	March 1, 2015	Tiffanie Shakespeare	Volume key use in preview will adjust media volume which affects video playback.
v1.2	April 10, 2015	Tiffanie Shakespeare	Volume key is able to start/stop self-timer.


Hardware Volume Key`

Photo Mode




When in viewfinder, interacting with the volume keyshould snap a single photo.

Video Mode



When in viewfinder, interacting with the volume key should start/stop recording.

Preview



When in preview, interacting with the volume key should change the media volume in order to adjust for video playback.

Notes

Volume Key

Is the physical hardware button that controls the volume setting.

In video and photo mode, the volume key will behave as the capture button. This includes the ability to start/stop the self-timer when enabled.

In preview, the key will adjust the media volume setting.

Optional Feature

This feature may be disabled by the manufacturer. Since this is hardware dependent, we need to provide an option to disable this feature for those devices where it doesn't make sense (e.g volume rocker is on the back).

Thanks!

From your friends in Firefox OS UX