


Release Notes

v1.0 February 27, 2015 Tiffanie Shakespeare New spec

Sound Picker


Hardware Volume Key`

Photo Mode




When in viewfinder, interacting with the volume keyshould snap a single photo.

Video Mode



When in viewfinder, interacting with the volume keyshould start/stop recording.

Preview



When in preview, interacting with the volume keyshould dismiss preview and return to the viewfinder.

Notes

Volume Key

Is the physical hardware button that controls the volume setting. Wihtin the camera application, the volume keywill NOT control volume settings.

In video and photo mode, the rocker will behave as the capture button. In preview, the keywill dismiss preview.

Optional Feature

This feature may be disabled by the manufacturer. Since this is hardware dependent, we need to provide an option to disable this feature for those devices where it doesn't make sense (e.g volume rocker is on the back).

Volume Key in Preview


1. Preview



2. Viewfinder



3. Start Recording



Hit either volume up or down.

Preview is dismissed and user is returned to the viewfinder. Mode is retained.

Tapping volume key again begins recording.

Thanks!

From your friends in Firefox OS UX