Alienware Tri-Mode Wireless Gaming Mouse - AW720M User Manual 1\. Safety and Handling

General Safety:

Avoid exposing the mouse to extreme temperatures, moisture, or direct sunlight.

Do not disassemble the mouse; it contains sensitive electronic components.

Ergonomics:

Ensure your hand is positioned comfortably on the mouse to prevent strain during extended use.

Take regular breaks to avoid repetitive strain injuries.

Battery Safety:

Use only the recommended USB-C cable for charging.

Do not attempt to replace the battery; contact customer support for battery issues.

2\. Startup and Shutdown

Startup

1. Power On:

Switch the power button located on the underside of the mouse to the "ON" position.

The LED indicator will light up, confirming the mouse is powered on.

2. Connection Mode:

Choose your preferred connection mode (2.4GHz, Bluetooth, or USB-C) using the mode switch button.

Shutdown

1. Power Off:

Switch the power button to the "OFF" position to conserve battery life when not in use.

3\. Controller or Operation Instructions

Basic Functions:

Left Click: Primary button for selecting and executing commands.

Right Click: Secondary button for context menus and additional options.

Scroll Wheel: Scroll through documents or web pages; click for additional functions.

DPI Adjustment:

Use the DPI button located on the top of the mouse to cycle through preset DPI settings (up to 26,000 DPI).

Mode Switching:

Press the mode switch button to toggle between 2.4GHz wir was erspace user was connectivity.

4\. Advanced Programming / Connectivity

Software Installation:

- 1. Download the Alienware Command Center software from the official Alienware website.
 - 2. Install the software and follow the on-screen instructions.

Customizing Buttons:

Open the Alienware Command Center.

Select the mouse from the device list.

Assign functions to buttons as desired.

Connecting via Bluetooth:

- 1. Enable Bluetooth on your device.
 - 2. Press the mode switch button to select Bluetooth mode.
 - 3. Hold the pairing button until the LED blinks rapidly.
 - 4. Select "Alienware AW720M" from your device's Bluetooth settings.

5\. AI Features and Sensing

Smart DPI Adjustment:

The mouse features an Al-driven DPI adjustment that adapts to your usage patterns for optimal performance.

Surface Calibration:

The mouse automatically calibrates to different surfaces for improved tracking accuracy.

6\. Maintenance and Troubleshooting

Cleaning:

Use a soft, lint-free cloth to clean the mouse surface.

Avoid using harsh chemicals or abrasive materials.

Troubleshooting Common Issues:

Mouse Not Responding:

Ensure the mouse is powered on and charged.

Check the connection mode and reconnect if necessary.

Connectivity Issues:

Restart the device you are connecting to and try reconnecting.

Ensure that no other devices are interfering with the connection.

7\. Additional Notes

Battery Life:

Makerspace User Manual

The AW720M offers up to 400 hours of battery life in Bluetooth mode and up to 200 hours in 2.4GHz mode.

Warranty Information:

The mouse comes with a one-year limited warranty. For warranty claims, contact Alienware support.

Customer Support:

For further assistance, visit the Alienware support website or contact customer service.

Thank you for choosing the Alienware Tri-Mode Wireless Gaming Mouse - AW720M. Enjoy your enhanced gaming and design experience!

Resources:

- Manual Pdf:

/manuals/alienware_mouse_manual.pdf

- Tutorial Video:

https://www.youtube.com/watch?v=FJcILQ6 YBs

- Qr Link:

https://www.dell.com/en-us/shop/alienware-tri-mode-wireless-gaming-mouse-aw720m/apd/570-bcqh/pc-accessories