## **Skycube Big Boy Spool Holder**

The print orientation of the files is the best for printing. This requires no supports and no raft/brim.

## **Recommended Print Settings:**

Material	Layer Height	Infill	Top/Bottom Layers	Shells	Supports?
PLA	0.2mm	30-50%	4-6(0.8mm-1.2mm)	3 (1.2mm)	no

<sup>\*</sup>The above settings are assuming you have a printer with a 0.4mm nozzle, if yours doesn't adjust accordingly

## Installation

## Tools Needed: Phillips screw driver, maybe super glue

- 1. Remove the two screws that attach the original spool holder to the printer, and set them aside.
- 2. Put the longer screw in the bottom hole of the spool holder and screw it into the bottom hole on the printer. Do not fully tighten it.
- 3. Insert the smaller screw into the top hole of the spool holder and line it up with the printer and tighten it fully.
- 4. Fully tighten the bottom screw
- 5. Insert the spool rod into the holder and attach with a bit of glue if the fit isn't tight enough.
- 6. Load a full sized spool on it and start printing!

