



OpenTheremin V4

<https://www.gaudi.ch/OpenTheremin/>




Pitch Bend Range



How to save configuration during calibration:

- 1- Turn Volume full left
- 2- Turn Pitch full right
- 3- Long press Function
- * Wait end of calibration *
- 4- Re-center Pitch & Volume


Keep Pitch and Volume centered to perform calibration without saving configuration



Play ●
Mute ●

Register knob becomes Parameter
Timbre knob becomes Value

Step 1: Select a Parameter
Step 2: Adjust its Value



MIDI Configuration

https://github.com/MrDham/OpenTheremin_V4_with_MIDI