



# OpenTheremin V4

<https://www.gaudi.ch/OpenTheremin/>




## Pitch Bend Range



How to save configuration during calibration:

- 1- Turn Volume full left
- 2- Turn Pitch full right
- 3- Long press Function
- \* Wait for end of calibration \*
- 4- Re-center Pitch & Volume


Ignore step 1 and 2 and keep Pitch and Volume centered to perform calibration without saving configuration.



Play ●  
Mute ●

Register knob becomes Parameter  
Timbre knob becomes Value

Step 1: Select a Parameter  
Step 2: Adjust its Value



## MIDI Configuration

[https://github.com/MrDham/OpenTheremin\\_V4\\_with\\_MIDI](https://github.com/MrDham/OpenTheremin_V4_with_MIDI)