


Viper Lite User Manual




1.Overall Layout

This watchface provides comprehensive data monitoring:



The top section displays the current time and solar trail (including sunrise and sunset times, as well as the current position).



The center section displays the date, battery status, step count, heart rate, and other metrics.

- **Top-left area:** Displays real-time heart rate and blood oxygen levels.
- **Top-right area:** Displays today's step count.
- **Bottom-left area:** Day of the week and date.
- **Center position:** Current seconds (this information is not displayed on models with physical hands).
- **Bottom-right area:** Battery level and estimated battery life (in days).




Bottom section: Displays barometric pressure and the status bar.

- **Top-left area:** Barometric pressure trend graph for the past four hours (includes upper and lower bounds of the chart).
- **Bottom-left area:** Current barometric pressure (unit in hPa).
- **Right Status Panel (Upper part):** Notification count, Bluetooth connection status, and alarm status etc.
- **Right Status Panel (Lower part):** Do Not Disturb status and Body Battery.

Refer to the following section for a detailed description of the displayed information.


2. Time



Time is displayed at the very top of the watch face and updates every minute. You can switch between 12-hour and 24-hour formats in the Garmin system settings, and the watch face will automatically adjust its display format accordingly.



Certain models, such as the Instinct Crossover AMOLED, feature physical hands. When an analog hand moves into a position that overlaps with the time display, the digital time will automatically shift its position to ensure optimal readability.



3. Solar Trail


The solar trail displays sunrise and sunset times, as well as your current relative position in the day, as illustrated below:



The 09:22 mark on the left represents **sunrise**, and the central yellow bar shows the **duration of daylight throughout the day**. The 19:26 mark on the right indicates **sunset**. The red-and-white indicator (positioned at

approximately 11:45) marks your **current time's position along the solar trail progress bar**.

The solar trail updates every 15 minutes within the watch face application and relies on a smartphone connection to retrieve data. If your device remains disconnected from your phone for an extended period, the accuracy of the solar trail information may be affected. Upon initial startup, a connection to your phone is required to fetch this information; otherwise, the sun path will not be displayed, as shown in the figure below:



Note: Once your watch reconnects with your smartphone, the sun path will automatically recalibrate during its next scheduled update cycle within 15 minutes.

4. Data Fields

The data fields display your heart rate, blood oxygen levels, and today's step count, as illustrated below:



The left side displays your **heart rate and blood oxygen (SpO2)** levels. Heart rate is measured in beats per minute (BPM), while blood oxygen level is shown as a percentage. While the watch face is active, this information is updated every three seconds. For reference: A healthy person's resting blood oxygen saturation typically ranges from 95% to 100%.

The right side displays **today's step count**, which resets at midnight. If you have not yet met your daily step goal, the number will be displayed in

gray; once the goal is reached or exceeded, it will change to the theme color of the watch face. This information updates every 15 minutes. If it falls below 20%, the color will change to red. The built-in 'Red Mode' on the watch face does not affect its color.

5. Date and Battery

The date and battery information are displayed in the center section. The **date** on the left is shown in a fixed format: the top half displays the **day of the week**, while the bottom half shows the **month and day**. On the right side, the battery status also follows a fixed layout: the upper portion shows your **current battery percentage** as a number, and the lower portion provides an **estimate of remaining battery life (in days)**. A progress bar on the far right offers an intuitive view of your overall battery level, as shown in the figure below:




The central gray "30" indicates where the **seconds** are displayed. To conserve battery life, the seconds will not update continuously while the watch face is active. For the first three seconds after waking the screen, the numbers will update in real-time and match the theme color; thereafter, they will turn gray and stop updating until the next time the watch face is activated.

The battery icon on the far right provides an intuitive visual overview of your current charge level. If your watch's battery drops below 50%, the segment representing the remaining power will turn gray. If it falls below 20%, the color will change to red. The built-in 'Red Mode' on the watch face does not affect its color.

6. Barometric Pressure

Barometric pressure information is displayed on the left side of the bottom section, as illustrated in the figure below:



The two numbers on the left represent the **upper and lower bounds** of the barometric pressure history trend chart, measured in hPa. You can use these values to gauge the intensity of atmospheric pressure changes; the minimum range for these bounds is +2 and -2. The gray-shaded area within the rectangular frame displays the **pressure trend** over the past four hours. Due to linear interpolation, you may see data fluctuations below 1.0. This history updates approximately every 20 minutes. The "225hPa" at the bottom indicates your **current atmospheric pressure** in hPa; as this value is updated every 15 minutes, the displayed reading may be up to 14 minutes old.

Note: The barometric pressure information shown in the screenshot is randomly generated by a simulator and may differ from real-world values.

7. Status Panel

The status panel is located on the right side of the bottom section, as shown in the figure below:



The status panel icons are organized into two rows: the top row displays the notification count, Bluetooth connection status, and alarm status from left to right; the bottom row features the Do Not Disturb mode status and the Body Battery progress bar.

- The **notification** icon displays the current number of unread notifications on your phone. When there are zero notifications, the icon appears as shown below: . Due to system limitations, a maximum of 20 notifications can be displayed; when this limit is reached, the icon will appear like this: .
- The **connection status** icon indicates whether your watch is currently connected to your smartphone. When connected, the icon appears as shown below: ; when disconnected, it appears like this: .
- The **alarm status** icon indicates whether there are any active alarms currently set on your watch. If an alarm is active, the icon appears as shown below: ; if no alarms are active, it appears like this: .
- The **Do Not Disturb (DND)** status icon indicates whether DND mode is active on your watch. When DND is enabled (typically during your scheduled sleep time), the icon appears as shown below: . In this state, you will not receive alerts for new incoming notifications. Conversely, if DND is inactive, the icon looks like this: , and the watch will provide normal notification alerts for any incoming messages.
- The **Body Battery** icon represents your current energy levels, a value calculated by the watch system based on sleep quality and stress levels. This is shown as a progress bar: when your Body Battery is high, the icon appears as follows ; as you expend energy throughout the day, the level decreases, potentially reaching a state represented by this icon . You can use this information to help plan your daily fitness and rest cycles.

Note: Status panel icons are updated once per minute; therefore, a displayed icon may reflect a state that is up to one minute old.

8. Settings

Viper Lite features a total of three setting options, as shown in the following interface:



- **Red Mode** is designed for low-light environments, providing a low-brightness and high-visibility display to optimize visual clarity in the dark. At the same time, it helps preserve your eyes' natural ability to adapt to darkness (dark adaptation).
- **Zulu Time (ZULU Time)** mode provides a standard time reference based on Coordinated Universal Time (UTC). This mode ignores any local timezone offsets from your device's current location, maintaining its time base strictly at UTC+0 for display.
- **Military Format** utilizes the standard 24-hour clock but omits separators between hours and minutes (such as colons ':') in accordance with specific communication protocols. By presenting time as a continuous four-digit sequence, this format enhances readability and eliminates ambiguity.

Note: Enabling Military Format will force the time format to a 24-hour display, overriding your current system settings.

9. FAQ

Question: Why is the solar trail not displaying?

Answer: Please check the connection between your watch and your smartphone. To conserve battery life, your phone may terminate background communication with the Garmin application; if this occurs, you will need to manually open the Connect IQ app to re-activate it.

Question: Why is the information shown on the watch face inconsistent with my current status?

Answer: To conserve battery and extend usage time, the watch face does not update data continuously. Please wait up to 20 minutes for a complete refresh of all information. If you do not wish to wait, you can access the "Watch Face" setting menu on your device to force a restart/refresh of the watch face.

Question: How can I contact the author to report a bug/issue or provide feedback?

Answer: Please contact me via email ark_spark_studio@outlook.com