BTG4 Testing Specification

Purpose: Test the Banyan Bluetooth Gateway using options to run in client mode.

Requires:

See btg2.test_spec.pdf

Procedure:

- 1. This test requires that a second RPi be setup as a Bluetooth server using rfcomm_server.py using sudo.
 - 2. Start the server.
 - 2. Run btg4.csv in Banyan launcher.
 - 3. Check coverage report to confirm that all expected lines of code were executed.