INI A350

PRE FLIGHT

VATSIM Flightplan filed? Volanta/VA Tracking Started? Simbreif Flightplan Imported?

Preliminary Cockpit Preparation

ENGINE MASTER SWITCHES	OFF
PARKING BRAKE(OR CHOCKS)	ON
SPEED BRAKE LEVER	RETRACTED
FLAPS LEVER	RETRACTED
WEATHER RADAR	OFF
ENGINE MODE SELECTOR	NORM
THRUST LEVERS	IDLE
GEAR LEVER	DOWN
WIPERS(BOTH)	OFF

POWER UP

BATTERY VOLTAGE	WITHIN LIMITS
ALL BATTERIES	ON
ALL EXTERNAL POWER	ON
COCKPIT LIGHTING	AS REQ

OIS & MFD

FLT OPS	Simbrief Import
LOADSHEET	Simbrief Import
TERML CHARTS	PIN
GSX	SET
NAVIGATION DATABASE	CONFIRM

Overhead Panel Left (bottom to top)

CREW SUPPLY	ON
EVAC CAPT/CAPT & PURS	CAPT
ADIRS	NAV

Overhead Panel Center (bottom to top)

STROBE	AUTO
BEACON	OFF
REMAINING EXTERIOR LIGHTS	AS REQ
CONSIDER REFUELING IN-PROGRESS	
SEATBELTS	ON
NO SMOKING	AUTO
NO MOBILE	AUTO
EMERGENCY EXIT LIGHTS	ARM
APU	START
APU BLEED	ON
XBLEED	AUTO
AIRFLOW	NORM
CKPT	AS REQ
CABIN	PURS SEL
TRIM TK FEED	AUTO
FUEL PUMPS	ALL ON

Overhead Panel Right (bottom to top)

CARGO AIR COND	AS REQ
NO LIGHTS	Check

Centre Instrument Panel

AIR DATA SWITCH	AUTO
FMS SWITCH	NORM
ISIS	ON, ALIGNED, QNH
GEAR	DOWN
ANTI SKID (A/SKID)	ON
N/W STRG	ON

Pedestal

RADIOS (RMP)	SET
SPOILER	RET
PARK BRAKE	ON
BODY ACCUMULATOR PRESSURE	CHECK
THRUST LEVERS	IDLE
THRUST REVERSE	STOWED
ENGINE MASTERS	OFF
COCKPIT DOOR	NORM
OBTAIN AN IFR CLEARANCE	
FLAPS	POSITION CROSS CHECK

Initialise FMS

At this point, the Flight Management System (FMS) should be initialised.

Glareshield & Lateral Consoles

INTEGRAL LIGHTS	AS REQ
BAROMETRIC REFERENCE	SET
ND MODE AND RANGE	AS REQ
WX RADAR	OFF
OTHER EFIS OPTIONS	AS REQ
SPD, HDG	MANAGED
FD	ON
ALT	INITIAL CLIMB (STOP ALT)
NORTH REF	MAG
PFD/ND MODES CHECK	CONFIRM
OXYGEN MASKS	TEST
DOOR SD PAGE REGUL PR LO	CHECK NOT DISPLAYED
TAKEOFF BREIFING	PERFORM

Before Push & Start

IFR clearance obtained
The aircraft is secure
APU is available

EXT POWER	DISCONNECT and CHECK AVAIL
EXTERNAL POWER DISCONNECTION	REQUEST
OBTAIN PUSH & START CLEARANCE	
DOORS	CLOSED
SLIDES	ARMED
BEACON	ON
THRUST LEVERS	IDLE
PARKING BRAKE & CHOCKS	OFF & REMOVED
KCCU SURV	DEFAULT
BEFORE START CHKL	COMPLETE
	COMMENCE PUSH

Engine Start

ENGINE START selector	IGN START
START ENGINES 1	ANNOUNCE
ENGINE MASTER 1	ON
WHEN AVAIL: ENGINE IDLE PARAMETERS	CHECK NORMAL
START ENGINES2	ANNOUNCE
ENGINE MASTER 2	ON
WHEN AVAIL: ENGINE IDLE PARAMETERS	CHECK NORMAL

After Engine Start

ENGINE START selector ..... NORM
APU BLEED ..... OFF
APU ..... OFF
ANTI ICE ..... AS REQ
GROUND SPOILERS ..... ARM
RUDDER TRIM ..... ZERO
TRIM ..... CHECK
TO FLAPS ..... SET
ECAM STATUS ..... CHECK

DISCONNECT GROUND CREW, HAND SIGNALS RECIEVED

TUG ..... CLEAR
FLIGHT CONTROLS ..... CHECK
A/BRK ..... ON
AFTER START CHKL ..... COMPLETE

Taxi

ND RANGE ..... AS REQ
WX RADAR ..... ON
TO CONFIG ..... HOLD
TAXI CLEARANCE ..... OBTAIN
NOSE LIGHTS ..... TAXI
PARK BRAKE ..... OFF
BRAKES ..... CHECKED
NW Steering ..... AS REQ
ATC CLEARANCE ..... CONFIRM

Before takeoff

SELECTED RUNWAY AND INPUT DATA ..... CHECK
F-PLN (SID, TRANS) ..... REVISE OR CHECK
INITIAL CLIMB SPEED AND SPEED LIMIT ..... MODIFY OR CHECK
CLEARED ALTITUDE ON FCU ..... SET
HDG ON FCU ..... IF REQUIRED, PRESET
FLIGHT DIRECTOR ..... CHECK SELECTED ON
PFD/ND ..... CHECK
MFD ..... CHECK
V1/VR/V2/THR RATING ..... CHECK (BOTH)
TAKEOFF BRIEFING ..... CONFIRM
FLIGHT INSTRUMENTS ..... CONFIRM
SPLRS ..... ARM
FLAPS ..... T.O
AUTOBRAKE RTO ..... ARM
SIGNS ..... AS NEEDED
T.O MEMO ..... NO BLUE LINE
CABIN ..... READY
BEFORE TAKEOFF CHECKLIST (TAXI - down to the line) ..... COMPLETE

Lineup

OBTAIN TAKEOFF OR LINEUP CLEARANCE

CABIN CREW ..... ADVISE
PACKS 1 and 2 ..... AS REQ
EXTERIOR LIGHTS ..... SET
ND RANGE ..... SET
EFIS ..... SET
APPROACH PATH ..... CLEAR
STROBES ..... ON
TAKEOFF RWY ..... CONFIRM (RAAS)
SLIDING TABLE ..... STOWED
TCAS ..... TA/RA
BEFORE TAKEOFF CHECKLIST (Line-Up - below the line ..... COMPLETE

Takeoff

TAKEOFF CLEARANCE RECIEVED

PARK BRAKE ..... OFF
BRAKES ..... PRESS & HOLD
TAKEOFF ..... ANNOUNCE
THRUST 25%
BRAKES ..... RELEASE
THRUST LEVERS ..... FLX/MCT or TOGA

After Takeoff

THRUST LEVERS ..... CLIMB
A/THR ..... CHECK ACTIVE
PACKS ..... ON
AP ..... AS REQ
AT F SPEED ..... FLAPS 1
AT S SPEED ..... FLAPS 0
EXTERIOR LIGHTS ..... OFF
GROUND SPOILERS ..... DISARM
APU ..... CONFIRM OFF
TCAS ..... CONFIRM TA/RA
ANTI ICE ..... AS REQ

Climb

Aircraft is Climbing to or is at Initially CLRD FL
Complete After Takeoff Checklist

ATC has cleared further climb ..... action
Cruise FL ..... AS REQ
ANTI ICE ..... AS REQ

ON PASSING 10,000ft

Landing Lights ..... OFF
SEATBELTS ..... CONSIDER OFF
EFIS ..... AS REQ
ECAM MEMO ..... REVIEW

consider optimal/max altitude

BARO ..... STD

Cruise

ALT CRZ ..... CONFIRM
ECAM MEMO ..... REVEIW
SD PAGES ..... REVIEW

Monitor flight progress, fuel etc

Before TOD

WEATHER AND LANDING INFORMATION ..... OBTAIN
LANDING ELEVATION ..... CHECK
BARO ..... PRE SET
LANDING PERFORMANCE ..... CHECK

IN FMS

FMS ACTIVE/F-PLN/ARRIVAL PAGE ..... INSERT/CHECK
DES PANEL OF THE FMS ACTIVE/PERF PAGE ..... INSERT/CHECK
APPR PANEL OF THE FMS ACTIVE/PERF PAGE ..... INSERT/CHECK
GA PANEL OF THE FMS ACTIVE/PERF PAGE ..... CHECK
FMS POSITIONAL/NAVAIDS PAGE ..... CHECK
LANDING BRIEF ..... PERFROM

OANS and BTV if AVAIL

RUNWAY SHIFT ..... AS REQUIRED
ND MODE ..... PLAN
ND RANGE ..... ZOOM
RUNWAY ..... SELECT
RUNWAY EXIT ..... SELECT
AUTO BRAKE/BTV ..... SELECT, AS REQUIRED
OANS RWY LENGTH/CHARTS RWY LENGTH ..... CROSSCHECK
LANDING BRIEF ..... PERFORM

Descent

DESCENT CLEARANCE	OBTAIN
CLEARED ALTITUDE/FL	SET
ANTI-ICE	AS REQ
DESCENT	INITIATE
CREW	ADVISE
20,000ft	
CABIN CREW	ADVISE
TER & WX RADAR	AS REQ
10,000ft	
LANDING LIGHTS	ON
LANDING DATA	SET
SEATBELTS	ON
CSTR & LS BUTTON	PUSH
NAVAIDS	AS REQ
APPROACH CHECKLIST	COMPLETE

Before Intercepting ILS

ALTIMETER	SET
APPROACH PHASE	CHECK/ACTIVATE
MANAGED SPEED	CHECK
SPEEDBRAKES	AS REQ

ILS Approach

ILS FREQUENCY	VERIFY
LS	CHECK ON
ALTITUDE	VERIFY
ATC APPROACH CLEARANCE	
SPEED MODE	MANAGED
APPR MODE	PRESS
AUTOPILOT 1+2	ON
FLIGHT MODE ANNUNCIATOR	CHECK
FLAPS 1 (at V~FE~ -15)	SET
TCAS MODE	TA/RA
LOC CAPTURE	MONITOR
ATC CONTACT	TOWER
GO AROUND ALTITUDE	SET
FLAPS 2 (~2.500ft and below V~FE~)	SET

Landing

Below 2,000ft	
LANDING GEAR	DOWN
AUTO BRAKE	CONFIRM
GROUND SPOILERS	ARM
FLAPS 3 (after L/G down and below V~FE~)	SET
WHEEL SYSTEM DISPLAY PAGE	CHECK
FLAPS (below V~FE~)	FULL
AUTOTHRUST	CHECK IN SPEED MODE OR OFF
LANDING MEMO	NO BLUE LINE
CABIN	READY
LANDING CHECKLIST	COMPLETE

After Landing

REVERSE LEVERS	STOW
AUTOBRAKE	DISARM
SPOILER	DISARM
FLAPS	RETRACT
APU MASTER	ON
APU START	ON
ENGINE START SELECTOR	CHECK NORM
ANTI-ICE	AS REQ
LANDING LIGHTS	OFF
STROBE	AUTO
OTHER EXTERIOR LIGHTS	AS REQ
NOSE LIGHT	TAXI

Taxi In

AIRPORT NAVIGATION DISPLAY	ZOOM, AS APPROPRIATE
EFIS TAXI	AS REQ
WX RADAR	CHECK OFF
WX Radar left on will cause ground crew serious health side effects	
BRAKE TEMP	MONITOR
After sufficient time ENG 1 can be shutdown before arriving at the gate	

Turning Into Gate & Engine Shut Down

NOSE LIGHTS	OFF
ANTI-ICE	OFF
APU BLEED	ON
PARKING BRAKE	ON
ENGINE MASTERS	OFF
SEATBELTS	OFF
SLIDES	DISARM
After engine N1 <5%	
BEACON	OFF
GROUND CONTACT	ESTABLISH
	call GSX
FUEL PUMPS	OFF
FUEL QUANTITY	CHECK
PARKING CHECKLIST	COMPLETE

Securing the Aircraft

PARKING BRAKE & CHOCKS	ON, SET
OXYGEN CREW SUPPLY	OFF
ADIRS	OFF
EXTERIOR LIGHTS	OFF
APU BLEED	OFF
EXTERNAL POWER	OFF
APU MASTER	OFF
EMERGENCY LIGHTS	OFF
NO SMOKING/MOBILE	OFF
SECURING THE AIRCRAFT CHECKLIST	COMPLETE
ALL BATT	OFF